

System MICRO

CPU | M13-CCF0001 | Manual

HB400 | CPU | M13-CCF0001 | en | 24-04 SPEED7 CPU M13C



YASKAWA Europe GmbH Philipp-Reis-Str. 6 65795 Hattersheim Germany

Tel.: +49 6196 569-300 Fax: +49 6196 569-398 Email: info@yaskawa.eu Internet: www.yaskawa.eu.com

Table of contents

1	Gener	al	10
	1.1	Copyright © YASKAWA Europe GmbH	10
	1.2	About this manual	11
	1.3	Safety information	11
2	Basics	s and mounting	13
	2.1	Safety notes for the user	13
	2.2	System conception	14
	2.3	Dimensions	15
	2.4	Mounting	17
	2.4.1	Mounting CPU	17
	2.4.2	Mounting the extension module	20
	2.4.3	Mounting periphery module	21
	2.5	Wiring	22
	2.5.1	Wiring CPU	22
	2.5.2	Wiring periphery module	25
	2.6	Demounting	27
	2.6.1	Demounting CPU	27
	2.6.2	Demounting the extension module	30
	2.6.3	Demounting periphery module	31
	2.7	Industrial security and installation guidelines	35
	2.7.1	Industrial security in information technology	35
	2.7.2	Installation guidelines	37
	2.8	General data for the System MICRO	40
	2.8.1	Use in difficult operating conditions	41
3	Hardw	are description	42
	3.1	Properties	42
	3.2	Structure	43
	3.2.1	System MICRO CPU M13C	43
	3.2.2	Interfaces	44
	3.2.3	LEDs	49
	3.2.4	Memory management	52
	3.2.5	Slot for storage media	52
	3.2.6	Buffering mechanisms	53
	3.2.7	Operating mode switch	53
	3.3	Option: Extension module EM M09 2x serial interface	53
	3.4	Technical data	56
	3.4.1	Technical data CPU	56
	3.4.2	Technical data EM M09	68

4	Deploy	ment CPU M13-CCF0001	69
	4.1	Please note!	69
	4.2	Assembly	69
	4.3	Start-up behavior	69
	4.4	Addressing	70
	4.4.1	Overview	70
	4.4.2	Default address assignment of the I/O part	70
	4.4.3	Option: Addressing periphery modules	71
	4.5	Hardware configuration - CPU	72
	4.6	Hardware configuration - System MICRO modules	74
	4.7	Hardware configuration - Ethernet PG/OP channel	74
	4.7.1	Take IP address parameters in project	76
	4.8	Setting standard CPU parameters	79
	4.8.1	Parameterization via Siemens CPU	79
	4.8.2	Parameter CPU	79
	4.9	Setting product specific CPU parameters	82
	4.9.1	Free Module Mapping (FMM)	85
	4.9.2	Access settings	89
	4.10	Project transfer	90
	4.10.1	Transfer via Ethernet	90
	4.10.2	Transfer via memory card	91
	4.10.3	Option: Transfer via MPI	91
	4.11	Accessing the web server	93
	4.11.1	Device web page CPU	93
	4.12	Operating modes	100
	4.12.1	Overview	100
	4.12.2	Function security	102
	4.13	Overall reset	103
	4.14	Firmware update	104
	4.14.1	Firmware update online	105
	4.14.2	Firmware update via memory card	106
	4.15	Reset to factory settings	107
	4.16	Deployment storage media - VSD, VSC	108
	4.17	Extended know-how protection	109
	4.18	CMD - auto commands	110
	4.19	Control and monitoring of variables with test functions	112
	4.20	Diagnostic entries	114
5		/ment I/O periphery	115
	5.1	Overview	115
	5.2	Address assignment	116

5.3	Analog input	117
5.3.1	Properties	117
5.3.2	Analog value representation	117
5.3.3	Wiring	118
5.3.4	Parametrization	119
5.4	Digital input	. 122
5.4.1	Properties	122
5.4.2	Wiring	122
5.4.3	Parametrization	123
5.4.4	Status indication	124
5.5	Digital output	126
5.5.1	Properties	126
5.5.2	Wiring	126
5.5.3	Parametrization	126
5.5.4	Status indication	127
5.6	Counting	128
5.6.1	Properties	128
5.6.2	Wiring	128
5.6.3	Proceeding	130
5.6.4	Parametrization	131
5.6.5	Counter operating modes	135
5.6.6	Counter - Additional functions	143
5.6.7	Diagnostics and interrupt	149
5.7	Frequency measurement	150
5.7.1	Properties	150
5.7.2	Wiring	151
5.7.3	Proceeding	152
5.7.4	Parametrization	152
5.7.5	Status indication	154
5.8	Pulse width modulation - PWM	155
5.8.1	Properties	155
5.8.2	Wiring	156
5.8.3	Proceeding	156
5.8.4	Parametrization	
5.8.5	Status indication	158
5.9	Pulse train	159
5.9.1	Properties	159
5.9.2	Wiring	
5.9.3	Proceeding	
5.9.4	Parametrization	
5.9.5	Status indication	

	5.10	Diagnostic and interrupt	164
	5.10.1	Overview	164
	5.10.2	Process interrupt	164
	5.10.3	Diagnostic interrupt	166
6	Deploy	rment OPC UA	172
	6.1	General	. 172
	6.2	Basics OPC UA	173
	6.2.1	OPC UA	173
	6.2.2	Information modeling	. 174
	6.2.3	OPC UA data types and their conversion	177
	6.2.4	Integrated security concept	178
	6.3	Activate OPC UA functionality	181
	6.4	Usage in SPEED7 Studio	181
	6.5	Usage in Siemens SIMATIC Manager	181
	6.5.1	Precondition	181
	6.5.2	Installation OPC UA Configurator	182
	6.5.3	Steps of the OPC UA configuration	183
	6.6	Usage in Siemens TIA Portal	184
	6.6.1	Precondition	184
	6.6.2	Installation OPC UA Configurator	185
	6.6.3	Steps of the OPC UA configuration	. 186
	6.7	Usage OPC UA Configurator	188
	6.7.1	OPC UA Configurator	188
	6.7.2	Project tree 🔲	189
	6.7.3	Device properties 🐚	190
	6.7.4	Server settings - Connection 😹	192
	6.7.5	Server settings - Certificate 🐻	194
	6.7.6	Data access 📻	195
	6.7.7	User management 🌲	196
	6.7.8	Role management 🖺	196
	6.7.9	Output 🗎	197
7	Deploy	ment <i>WebVisu</i> - Web visualization	198
	7.1	WebVisu editor	198
	7.1.1	Working environment	199
	7.1.2	Creating a <i>WebVisu</i> project	. 199
	7.2	Activate WebVisu functionality	201
	7.3	Start-up of the <i>WebVisu</i> project	201
	7.4	Access to the WebVisu	202
	7.4.1	Status of the WebVisu	202
8	Deploy	ment PG/OP communication - productive	203
	8.1	Basics - Industrial Ethernet in automation	203
	8.2	Basics - ISO/OSI reference model	204

	8.3	Basics - Terms.	205
	8.4	Basics - Protocols	206
	8.5	Basics - IP address and subnet	207
	8.6	Fast introduction	209
	8.7	Hardware configuration	209
	8.8	Configure Siemens S7 connections	210
	8.9	Configure Open Communication	214
9	Deploy	ment PG/OP communication - PROFINET	217
	9.1	Basics PROFINET	217
	9.2	PROFINET installation guidelines	219
	9.3	Deployment as PROFINET IO controller	220
	9.3.1	Steps of configuration	220
	9.3.2	Commissioning and initialization	221
	9.3.3	Configuration PROFINET IO controller	221
	9.3.4	Configuration PROFINET IO device	223
	9.4	Deployment as PROFINET I-Device.	224
	9.4.1	Steps of configuration	224
	9.4.2	Installing the GSDML file	226
	9.4.3	Configuration as I-Device	226
	9.4.4	Configuration in the higher-level IO controller	227
	9.4.5	Error behavior and interrupts	229
	9.5	MRP	231
	9.6	Topology	232
	9.7	Device replacement without exchangeable medium/PG	233
	9.8	Commissioning and start-up behavior	233
	9.9	PROFINET diagnostics	235
	9.9.1	Overview	235
	9.9.2	Diagnostics with the configuration and engineering tool	235
	9.9.3	Diagnostics during runtime in the user program	235
	9.9.4	Diagnostics via OB start information	237
	9.9.5	Diagnostics status indication via SSLs	237
	9.10	PROFINET system limits	239
10	Option	: PtP communication	240
	10.1	Fast introduction	240
	10.2	Principle of the data transfer	241
	10.3	PtP communication via extension module EM M09	242
	10.4	Parametrization	245
	10.4.1	FC/SFC 216 - SER_CFG - Parametrization PtP	245
	10.5	Communication	246
	10.5.1	FC/SFC 217 - SER_SND - Send to PtP	246
	10.5.2	FC/SFC 218 - SER_RCV - Receive from PtP	246

	10.6	Protocols and procedures	246
	10.7	Modbus - Function codes	250
11	Option	: Deployment PROFIBUS communication	254
	11.1	Fast introduction	254
	11.2	PROFIBUS communication	254
	11.3	PROFIBUS communication via extension module EM M09	255
	11.4	Deployment as PROFIBUS DP slave	256
	11.4.1	Diagnostic functions	258
	11.5	PROFIBUS installation guidelines.	261
12	Config	uration with SPEED7 Studio	264
	12.1	SPEED7 Studio - Overview	264
	12.2	SPEED7 Studio - Work environment	265
	12.2.1	Project tree	266
	12.2.2	Catalog	267
	12.3	SPEED7 Studio - Hardware configuration - CPU	269
	12.4	SPEED7 Studio - Hardware configuration - Ethernet PG/OP channel	269
	12.5	SPEED7 Studio - Hardware configuration - I/O modules	273
	12.6	Deployment I/O periphery	273
	12.6.1	Overview	273
	12.6.2	Analog input	274
	12.6.3	Digital input	275
	12.6.4	Digital output	275
	12.6.5	Counter	276
	12.6.6	Frequency measurement	279
	12.6.7	Pulse width modulation - PWM	281
	12.6.8	Pulse train	283
	12.7	Deployment OPC UA	285
	12.8	Deployment WebVisu - Web visualization	285
	12.9	SPEED7 Studio - Project transfer	285
	12.9.1	Transfer via MPI	285
	12.9.2	Transfer via Ethernet	287
	12.9.3	Transfer via memory card	288
13	Config	uration with TIA Portal	289
	13.1	TIA Portal - Work environment	289
	13.1.1	General	289
	13.1.2	Work environment of the TIA Portal	289
	13.2	TIA Portal - Functional limitations	. 290
	13.3	TIA Portal - Hardware configuration - CPU	291
	13.4	TIA Portal - Hardware configuration - Ethernet PG/OP channel	293
	13.4.1	Take IP address parameters in project	294
	13.5	TIA Portal - Hardware configuration - I/O modules	297

	13.6	TIA Portal - Deployment PG/OP communication - PROFINET	298
	13.6.1	Deployment as PROFINET IO controller	299
	13.6.2	Deployment as PROFINET I-Device	304
	13.7	TIA Portal - Option: Deployment PROFIBUS communication	309
	13.7.1	Fast introduction	309
	13.7.2	PROFIBUS communication via extension module EM M09	310
	13.7.3	Hardware configuration - CPU	312
	13.7.4	Deployment as PROFIBUS DP slave	312
	13.8	Deployment OPC UA	313
	13.9	TIA Portal - Include Controls Library	313
	13.10	TIA Portal - Project transfer	314
	13.10.	1 Transfer via Ethernet	314
	13.10.2	2 Transfer via memory card	315
	13.10.3	Option: Transfer via MPI	315
14	Appen	dix	317
		Content	319
	Α	System specific event IDs	321
	В	Integrated blocks	374
	С	SSL partial list	377

General System MICRO

Copyright © YASKAWA Europe GmbH

1 General

1.1 Copyright © YASKAWA Europe GmbH

All Rights Reserved

This document contains proprietary information of Yaskawa and is not to be disclosed or used except in accordance with applicable agreements.

This material is protected by copyright laws. It may not be reproduced, distributed, or altered in any fashion by any entity (either internal or external to Yaskawa) except in accordance with applicable agreements, contracts or licensing, without the express written consent of Yaskawa and the business management owner of the material.

For permission to reproduce or distribute, please contact: YASKAWA Europe GmbH, European Headquarters, Philipp-Reis-Str. 6, 65795 Hattersheim, Germany

Tel.: +49 6196 569 300 Fax.: +49 6196 569 398 Email: info@yaskawa.eu Internet: www.yaskawa.eu.com

EC conformity declaration

Hereby, YASKAWA Europe GmbH declares that the products and systems are in compliance with the essential requirements and other relevant provisions. Conformity is indicated by the CE marking affixed to the product.

Conformity Information

For more information regarding CE marking and Declaration of Conformity (DoC), please contact your local representative of YASKAWA Europe GmbH.

Trademarks

MICRO and SPEED7 are registered trademarks of YASKAWA Europe GmbH.

SIMATIC, STEP, TIA Portal, S7-300 und S7-400 are registered trademarks of Siemens AG.

All Microsoft Windows, Office and Server products mentioned are registered trademarks of Microsoft Inc., USA.

All other trademarks, logos and service or product marks specified herein are owned by their respective companies.

General terms of use

Every effort has been made to ensure that the information contained in this document was complete and accurate at the time of publishing. We cannot guarantee that the information is free of errors, and we reserve the right to change the information at any time. There is no obligation to inform the customer about any changes. The customer is requested to actively keep his documents up to date. The customer is always responsible for the deployment of the products with the associated documentation, taking into account the applicable directives and standards.

This documentation describes all hardware and software units and functions known today. It is possible that units are described that do not exist at the customer. The exact scope of delivery is described in the respective purchase contract.

Document support

Contact your local representative of YASKAWA Europe GmbH if you have errors or questions regarding the content of this document. You can reach YASKAWA Europe GmbH via the following contact:

Email: Documentation.HER@yaskawa.eu

System MICRO General

Safety information

Technical support

Contact your local representative of YASKAWA Europe GmbH if you encounter problems or have questions regarding the product. If such a location is not available, you can reach the Yaskawa customer service via the following contact:

YASKAWA Europe GmbH,

European Headquarters, Philipp-Reis-Str. 6, 65795 Hattersheim, Germany

Tel.: +49 6196 569 500 (hotline) Email: support@yaskawa.eu

1.2 About this manual

Objective and contents

This manual describes the CPU M13-CCF0001 of the System MICRO.

- It describes the structure, configuration and application.
- The manual is written for users with basic knowledge of automation technology.
- The manual consists of chapters. Each chapter describes a completed topic.
- The following guides are available in the manual:
 - An overall table of contents at the beginning of the manual.
 - References with pages numbers.

Validity of the documentation

Product	Order number	as of version:	
CPU M13C	M13-CCF0001	CPU-HW: 01	CPU-FW: V3.0.13

Icons and headings

Important passages in the text are highlighted by following icons and headings:



DANGER

Immediate or likely danger. Personal injury is possible.



CAUTION

Damages to property is likely if these warnings are not heeded.



Supplementary information and useful tips.

1.3 Safety information

Applications conforming with specifications

The system is constructed and produced for:

- communication and process control
- general control and automation tasks
- industrial applications
- operation within the environmental conditions specified in the technical data
- installation into a cubicle



DANGER

This device is not certified for applications in

in explosive environments (EX-zone)

General System MICRO

Safety information

Disposal

National rules and regulations apply to the disposal of the unit!

Documentation

The manual must be available to all personnel in the:

- project design department
- installation department
- commissioning
- operation



CAUTION

The following conditions must be met before using or commissioning the components described in this manual:

- Hardware modifications to the process control system should only be carried out when the system has been disconnected from power!
- Installation and hardware modifications only by properly trained personnel.
- The national rules and regulations of the respective country must be satisfied (installation, safety, EMC ...)

Safety notes for the user

2 Basics and mounting

2.1 Safety notes for the user



DANGER

Protection against dangerous voltages

- When using System MICRO modules, the user must be protected from touching hazardous voltage.
- You must therefore create an insulation concept for your system that includes safe separation of the potential areas of ELV and hazardous voltage.
- Here, observe the insulation voltages between the potential areas specified for the System MICRO modules and take suitable measures, such as using PELV/SELV power supplies for System MICRO modules.

Handling of electrostatic sensitive modules

The modules are equipped with highly integrated components in MOS technology. These components are highly sensitive to over-voltages that occur, e.g. with electrostatic discharge. The following symbol is used to identify these hazardous modules:



The symbol is located on modules, module racks or on packaging and thus indicates electrostatic sensitive modules. Electrostatic sensitive modules can be destroyed by energies and voltages that are far below the limits of human perception. If a person who is not electrically discharged handles electrostatic sensitive modules, voltages can occur and damage components and thus impair the functionality of the modules or render the modules unusable. Modules damaged in this way are in most cases not immediately recognized as faulty. The error can only appear after a long period of operation. Components damaged by static discharge can show temporary faults when exposed to temperature changes, vibrations or load changes. Only the consistent use of protective devices and responsible observance of the handling rules can effectively prevent malfunctions and failures on electrostatic sensitive modules.

Shipping of modules

Please always use the original packaging for shipping.

Measurement and modification of electrostatic sensitive modules

For measurements on electrostatic sensitive modules the following must be observed:

- Floating measuring instruments must be discharged before use.
- Measuring instruments used must be grounded.

When modifying electrostatic sensitive modules, ensure that a grounded soldering iron is used.




CAUTION

When working with and on electrostatic sensitive modules, make sure that personnel and equipment are adequately grounded.

System conception

2.2 System conception

Overview



The System MICRO is a modular automation system for assembly on a 35mm mounting rail. By means of periphery modules this system may be adapted matching to your automation tasks. In addition, it is possible to expand your CPU by appropriate interfaces. The wiring complexity is low, because the DC 24V electronic section supply is integrated to the backplane bus and this allows replacement with standing wire.

Components

- CPU
- Extension module
- Power supply
- Periphery module

CPU



With the CPU electronic, input/output components and power supply are integrated to one casing. In addition, up to 8 periphery modules of the System MICRO can be connected to the backplane bus. As head module via the integrated power module for power supply CPU electronic and the I/O components are supplied as well as the electronic of the periphery modules, which are connected via backplane bus. To connect the power supply of the I/O components and for DC 24V electronic power supply of the periphery modules, which are connected via backplane bus, the CPU has removable connectors. By installing of up to 8 periphery modules at the backplane bus of the CPU, these are electrically connected, this means these are assigned to the backplane bus and connected to the DC 24V electronic power supply.

Extension module



By using extension modules you can extend the interfaces of the CPU. The attachment to the CPU is made by plugging on the left side of the CPU. You can only connect one extension module to the CPU at a time.

Dimensions

Power supply



The power supply can be mounted together with System MICRO components at the mounting rail. It serves for electronics and power supply.


Periphery module



By means of up to 8 periphery modules, you can extend the internal I/O areas. The attachment to the CPU is made by plugging them on the right side of the CPU.


2.3 Dimensions

Dimensions CPU M13C




Dimensions

Dimensions extension module EM M09




Dimensions in mm

Dimensions power supply



Mounting > Mounting CPU

Dimensions periphery module



Dimensions in mm

2.4 Mounting



CAUTION

Requirements for UL compliance use

Use for power supply exclusively SELV/PELV power supplies.

2.4.1 Mounting CPU

2.4.1.1 Mounting CPU without mounting rail




CAUTION

Mounting without mounting rail is only permitted, if you only want to use the CPU without extension and periphery modules. Otherwise, a mounting rail must always be used for EMC technical reasons.

Proceeding

You can screw the CPU to the back wall by means of screws via the locking levers. This happens with the following proceeding:

Mounting > Mounting CPU




Dimensions in mm

- 1. The CPU has a locking lever on the upper and lower side. Pull these levers outwards as shown in the figure, until these engage 2x audible.
 - ⇒ By this openings on the locking levers get visible.
- 2. Use the appropriate screws to fix your CPU to your back wall. Consider the installation clearances for the CPU.
 - ➡ The CPU is now mounted and can be wired.


2.4.1.2 Mounting with mounting rail

Proceeding



Dimensions in mm

- 1. Mount the mounting rail. Please consider that a clearance from the middle of the mounting rail of at least 44mm respectively 55mm above and below exists.
- 2. The CPU has a locking lever on the upper and lower side. Pull these levers outwards as shown in the figure, until these engage audible.






CAUTION

It is not allowed to mount the module sideways on the mounting rail, as otherwise the module may be damaged.


Mounting > Mounting CPU



3. Plug the CPU from the top onto the mounting rail and turn the CPU downward until it rests on the mounting rail.



 $\underline{\textbf{4.}}$ Move the CPU on the mounting rail at its position.



- 5. To fix the CPU at the mounting rail, move the locking levers back to the initial position.
 - → The CPU is now mounted and can be wired.


Mounting > Mounting the extension module

2.4.2 Mounting the extension module

Proceeding

You have the possibility to extend the interfaces of the CPU by plugging an extension module. For this the extension module is plugged at the left side of the CPU. The mountings happens with the following proceeding:

1. Remove the bus cover with a screwdriver on the left side of the CPU.




2. The extension module has a locking lever on the upper and lower side. Pull these levers outwards as shown in the figure, until these engage audible.



CAUTION

It is not allowed to mount the module sideways on the mounting rail, as otherwise the module may be damaged.



To mount plug the extension module from the top onto the mounting rail and turn the extension module downward until it rests on the mounting rail.



4. Attach the extension module to the CPU by sliding the extension module on the mounting rail to the right until the interface connector slightly locks into the CPU.



5. To fix the extension module at the mounting rail, move the locking levers back to the initial position.


Mounting > Mounting periphery module

2.4.3 Mounting periphery module

Proceeding

You have the possibility to extend the periphery area of the CPU by plugging up to 8 periphery modules. For this the periphery modules are plugged at the right side of the CPU. The mountings happens with the following proceeding:

1. Remove the bus cover with a screwdriver on the right side of the CPU.




2. Each periphery module has a locking lever on its upper and lower side. Pull these levers outwards as shown in the figure, until these engage audible.




CAUTION


It is not allowed to mount the module sideways on the mounting rail, as otherwise the module may be damaged.



To mount plug the periphery module from the top onto the mounting rail and turn the periphery module downward until it rests on the mounting rail.



4. Attach the periphery module to the CPU by sliding the periphery module on the mounting rail to the left until the interface connector slightly locks into the CPU.



- 5. To fix the periphery module at the mounting rail, move the locking levers back to the initial position.
- **6.** Proceed in this way with additional periphery modules.

Wiring > Wiring CPU

2.5 Wiring



DANGER

Consider strain relief of the supply lines!

Since the plug for the supply lines of the input voltage has no (double) insulation, not permanently fixed supply lines must be relieved from push and pull!



CAUTION

Consider temperature for external cables!

Cables may experience temperature increase due to system heat dissipation. Thus the cabling specification must be chosen 25°C above ambient temperature!



CAUTION

Separate insulation areas!


The system is specified for SELV/PELV environment. Devices, which are attached to the system must meet theses specifications. Installation and cable routing other than SELV/PELV specification must be separated from the system's equipment!

2.5.1 Wiring CPU

CPU connector

For wiring the CPU has removable connectors. With the wiring of the connectors a "push-in" spring-clip technique is used. This allows a quick and easy connection of your signal and supply lines. The clamping off takes place by means of a screwdriver.

Data




U_{max} 30V DC I_{max} 10A

Cross section 0.2 ... 1.5mm² (AWG 24 ... 16)

Stripping length 10mm

Use for wiring rigid wires respectively use wire sleeves. When using stranded wires you have to press the release button with a screwdriver during the wiring.

Wiring procedure




- 1 Labeling on the casing
- 2 Status LED
- 3 Release area
- 4 Connection hole for wire
- 5 Pin 1 of the connector is labelled by a white line

Insert wire


The wiring happens without a tool.

Wiring > Wiring CPU



- Determine according to the casing labelling the connection position and insert through the round connection hole of the according contact your prepared wire until it stops, so that it is fixed.
 - ⇒ By pushing the contact spring opens, thus ensuring the necessary contact pressure


Remove wire





The wire is to be removed by means of a screwdriver with 2.5mm blade width.


- 1. Press with your screwdriver vertically at the release button.
 - → The contact spring releases the wire.
- 2. Pull the wire from the round hole.


Standard wiring












6

DO Byte 1



Wiring > Wiring CPU



- (1) X2: 4L+: DC 24V power section supply for integrated outputs X1: 3L+: DC 24V power section supply for integrated inputs
- (2) X6: 1L+ DC 24V for electronic power supply



The electronic power section supply is internally protected against higher voltage by fuse. The fuse is located inside the CPU and can not be changed by the user.

Fusing



CAUTION

 The power section supply of the internal DOs is to be externally protected with a 8A fuse (fast) respectively by a line circuit breaker 8A characteristics Z.

Remove connector




By means of a screwdriver there is the possibility to remove the connectors e.g. for module exchange with a fix wiring. For this each connector has indentations for unlocking at the top. Unlocking takes place by the following proceeding:

1. Remove connector:

Insert your screwdriver from above into one of the indentations.

Wiring > Wiring periphery module



- 2. Push the screwdriver backwards:
 - → The connector is unlocked and can be removed.

\triangle

CAUTION

Via wrong operation such as pressing the screwdriver downward, the release lever may be damaged.

3. Plug connector:

The connector is plugged by plugging it directly into the release lever.

2.5.2 Wiring periphery module

Periphery module connector

For wiring the periphery module has removable connectors. With the wiring of the connectors a "push-in" spring-clip technique is used. This allows a quick and easy connection of your signal and supply lines. The clamping off takes place by means of a screwdriver.

Data



U_{max} 240V AC / 30V DC


I_{max} 10A

Cross section 0.2 ... 1.5mm² (AWG 24 ... 16)

Stripping length 10mm


Use for wiring rigid wires respectively use wire sleeves. When using stranded wires you have to press the release button with a screwdriver during the wiring.

Wiring procedure



- 1 Labeling on the casing
- 2 Status LED
- 3 Release area
- 4 Connection hole for wire
- 5 Pin 1 of the connector is labelled by a white line


Insert wire



The wiring happens without a tool.

- Determine according to the casing labelling the connection position and insert through the round connection hole of the according contact your prepared wire until it stops, so that it is fixed.
 - ⇒ By pushing the contact spring opens, thus ensuring the necessary contact pressure.

Remove wire



The wire is to be removed by means of a screwdriver with 2.5mm blade width.

- 1. Press with your screwdriver vertically at the release button.
 - The contact spring releases the wire.
- 2. Pull the wire from the round hole.

Wiring > Wiring periphery module

Fusing



CAUTION

- The power section supply of the output modules DO16 is to be externally protected with a 10A fuse (fast) respectively by a line circuit breaker 10A characteristics Z.
- The power section supply of the output part of the DIO8 is to be externally protected with a 5A fuse (fast) respectively by a line circuit breaker 5A characteristics Z.

Remove connector



By means of a screwdriver there is the possibility to remove the connectors e.g. for module exchange with a fix wiring. For this each connector has indentations for unlocking at the top. Unlocking takes place by the following proceeding:

1. Remove connector:

Insert your screwdriver from above into one of the indentations.



- 2. Push the screwdriver backwards:
 - → The connector is unlocked and can be removed.



CAUTION

Via wrong operation such as pressing the screwdriver downward, the release lever may be damaged.

3. Plug connector:

The connector is plugged by plugging it directly into the release lever.

Demounting > Demounting CPU

2.6 Demounting

2.6.1 Demounting CPU

Remove connector

By means of a screwdriver there is the possibility to remove the connectors e.g. for module exchange with a fix wiring. For this each connector has indentations for unlocking at the top. Unlocking takes place by the following proceeding:

- 1. Power-off your system.
- 2. Remove connector:

Insert your screwdriver from above into one of the indentations.




- **3.** ▶ Push the screwdriver backwards:
 - → The connector is unlocked and can be removed.



CAUTION


Via wrong operation such as pressing the screwdriver downward, the connector may be damaged!

4. In this way, remove all plugged connectors on the CPU.




If more modules are connected to the CPU — 'Option: CPU replacement in a system'...page 29. If no other modules are connected to the CPU, the CPU is replaced according to the following proceeding:


1. Use a screwdriver to pull the locking levers of the CPU outwards until these engage audible.



2. Remove the CPU with a rotation upwards from the mounting rail.



Demounting > Demounting CPU



3. Pull the locking levers of the CPU outwards until these engage audible.




CAUTION


It is not allowed to mount the module sideways on the mounting rail, as otherwise the module may be damaged!



Plug the CPU from the top onto the mounting rail and turn the CPU downward until it rests on the mounting rail.



5. Move the CPU on the mounting rail at its position.



6. To fix the CPU at the mounting rail, move the locking levers back to the initial position.




7. Remove the connectors, which are not necessary at the CPU.

Demounting > Demounting CPU



- **8.** Plug again the wired connectors.
 - Now you can bring your system back into operation.


Option: CPU replacement in a system



 \mathbf{m}

In the following the replacement of a CPU in a system is shown:

- 1. If there is an extension module connected to the CPU, you have to remove it from the CPU. For this use a screwdriver to pull the locking levers of the extension module and CPU outwards until these engage audible.
- <u>2.</u> Disconnect all the modules, which are connected to the CPU by moving the CPU along with the extension module on the mounting rail.
- 3. ▶ Remove the CPU with a rotation upwards from the mounting rail.




4. Pull the locking levers of the CPU outwards until these engage audible.



CAUTION

It is not allowed to mount the module sideways on the mounting rail, as otherwise the module may be damaged!



5. For mounting pull the locking levers of the CPU outwards until these engage audible. Plug the CPU from the top onto the mounting rail and turn the CPU downward until it rests on the mounting rail.



6. Rebind your modules by moving the CPU along with the extension module on the mounting rail.

Demounting > Demounting the extension module



7. To fix the CPU at the mounting rail, move the locking levers back to the initial position.



8. Remove the connectors, which are not necessary at the CPU.





- **9.** Plug again the wired connectors.
 - Now you can bring your system back into operation.

2.6.2 Demounting the extension module

Proceeding

- 1. Power-off your system.
- **2.** Remove the corresponding bus connectors.







4. Remove the extension module from the CPU by sliding it on the mounting rail.



5. Remove the extension module with a rotation upwards from the mounting rail.



Demounting > Demounting periphery module




6. Pull the locking levers of the extension module outwards until these engage audible.




CAUTION

It is not allowed to mount the module sideways on the mounting rail, as otherwise the module may be damaged!

Plug the extension module from the top onto the mounting rail and turn the extension module downward until it rests on the mounting rail.



Reattach the extension module to the CPU by sliding the extension module on the mounting rail to the right until the interface connector slightly locks into the CPU.



- **9.** Move the locking levers back to the initial position.
- **10.** ▶ Plug the corresponding bus connectors.
 - ▶ Now you can bring your system back into operation.

2.6.3 Demounting periphery module

Remove connector


By means of a screwdriver there is the possibility to remove the connectors e.g. for module exchange with a fix wiring. For this each connector has indentations for unlocking at the top. Unlocking takes place by the following proceeding:

1. Power-off your system.



CAUTION

Make sure that the working contacts from the relay module are disconnected from the power supply!



Insert your screwdriver from above into one of the indentations.



Demounting > Demounting periphery module



- **3.** ▶ Push the screwdriver backwards:
 - → The connector is unlocked and can be removed.



CAUTION

Via wrong operation such as pressing the screwdriver downward, the connector may be damaged!

4. ▶ In this way, remove all plugged connectors on the periphery module.


Replace the periphery module




1. Remove the modules that are connected to the module to be replaced by pulling their release levers outwards until these engage audible ...



2. ... and move the modules accordingly.



3. Remove the periphery module with a rotation upwards from the mounting rail.




4. ▶ Pull the locking levers outwards until these engage audible.




CAUTION

It is not allowed to mount the module sideways on the mounting rail, as otherwise the module may be damaged!



5. Plug the periphery module from the top onto the mounting rail and turn the periphery module downward until it rests on the mounting rail.



6. Reconnect all modules by pushing them together again on the mounting rail.

Demounting > Demounting periphery module



7. Move the locking levers back to the initial position.



 $\underline{\textbf{8.}}$ Remove the connectors, which are not necessary.



- **9.** Plug again the wired connectors.
 - → Now you can bring your system back into operation.

Demounting > Demounting periphery module

2.6.3.1 Easy Maintenance

Overview

Easy Maintenance means the support for adding and removing modules during operation without having to restart the system. There are the following behaviors:

- Periphery module is removed
 - The CPU detects a module failure on the backplane bus.
 - Diagnostic message 'System MICRO bus failure' (0x39D0) is triggered.
 - OB 86 is called. If this is not available, the CPU switches to STOP otherwise it remains in RUN.
 - The red LED of the status bar of the CPU lights up.
 - The I/O data of all modules become invalid.
- Identical periphery module is plugged
 - The CPU detects the module return on the backplane bus.
 - The red LED of the status bar of the CPU gets off.
 - All green LEDs of the status bars of the peripheral modules get on and all the red LEDs of the status bars of the peripheral modules get off.
 - Diagnostic message 'System MICRO bus recovery' (0x38D0) is triggered.
 - OB 86 is called. If this is not available, the CPU switches to STOP otherwise it remains in RUN.
 - The I/O data of all modules become valid again.
- Wrong periphery module is plugged
 - The CPU detects the wrong module.
 - Diagnostic message 'System MICRO bus recovery, but expected configuration does not match actual configuration' (0x38D1) is triggered.
 - The red LED of the status bar of the CPU remains on.
 - The red LED of the status bar of the wrong I/O module flashes.
 - OB 86 is called. If this is not available, the CPU switches to STOP otherwise it remains in RUN.
 - With the exception of the wrong module, the I/O data of all modules become valid again.



Please note that the CPU switches to STOP, if there is no OB 86 configured when adding or removing System MICRO modules!

Industrial security and installation guidelines > Industrial security in information technology

2.7 Industrial security and installation guidelines

2.7.1 Industrial security in information technology

Latest version

This chapter can also be found as a guide 'Industrial IT Security' in the 'Download Center' of www.yaskawa.eu.com

Hazards

The topic of data security and access protection has become increasingly important in the industrial environment. The increased networking of entire industrial systems to the network levels within the company together with the functions of remote maintenance have all served to increase vulnerability. Hazards can arise from:

- Internal manipulation such as technical errors, operating and program errors and deliberate program or data manipulation.
- External manipulation such as software viruses, worms and trojans.
- Human carelessness such as password phishing.

Precautions

The most important precautions to prevent manipulation and loss of data security in the industrial environment are:

- Encrypting the data traffic by means of certificates.
- Filtering and inspection of the traffic by means of VPN "Virtual Private Networks".
- Identification of the user by "Authentication" via save channels.
- Segmenting in protected automation cells, so that only devices in the same group can exchange data.
- Deactivation of unnecessary hardware and software.

Further Information

You can find more information about the measures on the following websites:

- Federal Office for Information Technology → www.bsi.bund.de
- Cybersecurity & Infrastructure Security Agency → us-cert.cisa.gov
- VDI / VDE Society for Measurement and Automation Technology www.vdi.de

Industrial security and installation guidelines > Industrial security in information technology

2.7.1.1 Protection of hardware and applications

Precautions

- Do not integrate any components or systems into public networks.
 - Use VPN "Virtual Private Networks" for use in public networks. This allows you to control and filter the data traffic accordingly.
- Always keep your system up-to-date.
 - Always use the latest firmware version for all devices.
 - Update your user software regularly.
- Protect your systems with a firewall.
 - The firewall protects your infrastructure internally and externally.
 - This allows you to segment your network and isolate entire areas.
- Secure access to your plants via user accounts.
 - If possible, use a central user management system.
 - Create a user account for each user for whom authorization is essential.
 - Always keep user accounts up-to-date and deactivate unused user accounts.
- Secure access to your plants via secure passwords.
 - Change the password of a standard login after the first start.
 - Use strong passwords consisting of upper/lower case, numbers and special characters. The use of a password generator or manager is recommended.
 - Change the passwords according to the rules and guidelines that apply to your application.
- Deactivate inactive communication ports respectively protocols.
 - Only the communication ports that are used for communication should be activated.
 - Only the communication protocols that are used for communication should be activated.
- Consider possible defence strategies when planning and securing the system.
 - The isolation of components alone is not sufficient for comprehensive protection.
 An overall concept is to be drawn up here, which also provides defensive measures in the event of a cyber attack.
 - Periodically carry out threat assessments. Among others, a comparison is made here between the protective measures taken and those required.
- Limit the use of external storage media.
 - Via external storage media such as USB memory sticks or SD memory cards, malware can get directly into a system while bypassing a firewall.
 - External storage media or their slots must be protected against unauthorized physical access, e.g. by using a lockable control cabinet.
 - Make sure that only authorized persons have access.
 - When disposing of storage media, make sure that they are safely destroyed.
- Use secure access paths such as HTTPS or VPN for remote access to your plant.
- Enable security-related event logging in accordance with the applicable security policy and legal requirements for data protection.

System MICRO Basics and mounting

Industrial security and installation guidelines > Installation guidelines

2.7.1.2 Protection of PC-based software

Precautions

Since PC-based software is used for programming, configuration and monitoring, it can also be used to manipulate entire systems or individual components. Particular caution is required here!

- Use user accounts on your PC systems.
 - If possible, use a central user management system.
 - Create a user account for each user for whom authorization is essential.
 - Always keep user accounts up-to-date and deactivate unused user accounts.
- Protect your PC systems with secure passwords.
 - Change the password of a standard login after the first start.
 - Use strong passwords consisting of upper/lower case, numbers and special characters. The use of a password generator or manager is recommended.
 - Change the passwords according to the rules and guidelines that apply to your application.
- Enable security-related event logging in accordance with the applicable security policy and legal requirements for data protection.
- Protect your PC systems by security software.
 - Install virus scanners on your PC systems to identify viruses, trojans and other malware.
 - Install software that can detect phishing attacks and actively prevent them.
- Always keep your software up-to-date.
 - Update your operating system regularly.
 - Update your software regularly.
- Make regular backups and store the media at a safe place.
- Regularly restart your PC systems. Only boot from storage media that are protected against manipulation.
- Use encryption systems on your storage media.
- Perform security assessments regularly to reduce the risk of manipulation.
- Use only data and software from approved sources.
- Uninstall software which is not used.
- Disable unused services.
- Activate a password-protected screen lock on your PC systems.
- Always lock your PC systems as soon as you leave your PC workstation.
- Do not click any links that come from unknown sources. If necessary ask, e.g. on e-mails.
- Use secure access paths such as HTTPS or VPN for remote access to your PC system.

2.7.2 Installation guidelines

General

The installation guidelines contain information about the interference free deployment of a PLC system. There is the description of the ways, interference may occur in your PLC, how you can make sure the electromagnetic compatibility (EMC), and how you manage the isolation.

What does EMC mean?

Electromagnetic compatibility (EMC) means the ability of an electrical device, to function error free in an electromagnetic environment without being interfered respectively without interfering the environment.

The components are developed for the deployment in industrial environments and meets high demands on the EMC. Nevertheless you should project an EMC planning before installing the components and take conceivable interference causes into account.

Basics and mounting System MICRO

Industrial security and installation guidelines > Installation guidelines

Possible interference causes

Electromagnetic interferences may interfere your control via different ways:

- Electromagnetic fields (RF coupling)
- Magnetic fields with power frequency
- Bus system
- Power supply
- Protected earth conductor

Depending on the spreading medium (lead bound or lead free) and the distance to the interference cause, interferences to your control occur by means of different coupling mechanisms.

There are:

- galvanic coupling
- capacitive coupling
- inductive coupling
- radiant coupling

Basic rules for EMC

In the most times it is enough to take care of some elementary rules to guarantee the EMC. Please regard the following basic rules when installing your PLC.

- Take care of a correct area-wide grounding of the inactive metal parts when installing your components.
 - Install a central connection between the ground and the protected earth conductor system.
 - Connect all inactive metal extensive and impedance-low.
 - Please try not to use aluminium parts. Aluminium is easily oxidizing and is therefore less suitable for grounding.
- When cabling, take care of the correct line routing.
 - Organize your cabling in line groups (high voltage, current supply, signal and data lines).
 - Always lay your high voltage lines and signal respectively data lines in separate channels or bundles.
 - Route the signal and data lines as near as possible beside ground areas (e.g. suspension bars, metal rails, tin cabinet).
- Proof the correct fixing of the lead isolation.
 - Data lines must be shielded.
 - Analog lines must be shielded. When transmitting signals with small amplitudes the one sided laying of the isolation may be favourable.
 - Cables for frequency inverters, servo and stepper motors must be shielded.
 - Lay the line isolation extensively on an isolation/protected earth conductor rail directly after the cabinet entry and fix the isolation with cable clamps.
 - Make sure that the isolation/protected earth conductor rail is connected impedance-low with the cabinet.
 - Use metallic or metallised plug cases for isolated data lines.
- In special use cases you should appoint special EMC actions.
 - Consider to wire all inductivities with erase links.
 - Please consider luminescent lamps can influence signal lines.

System MICRO Basics and mounting

Industrial security and installation guidelines > Installation guidelines

 Create a homogeneous reference potential and ground all electrical operating supplies when possible.

- Please take care for the targeted employment of the grounding actions. The grounding of the PLC serves for protection and functionality activity.
- Connect installation parts and cabinets with your PLC in star topology with the isolation/protected earth conductor system. So you avoid ground loops.
- If there are potential differences between installation parts and cabinets, lay sufficiently dimensioned potential compensation lines.

Isolation of conductors

Electrical, magnetically and electromagnetic interference fields are weakened by means of an isolation, one talks of absorption. Via the isolation rail, that is connected conductive with the rack, interference currents are shunt via cable isolation to the ground. Here you have to make sure, that the connection to the protected earth conductor is impedancelow, because otherwise the interference currents may appear as interference cause.

When isolating cables you have to regard the following:

- If possible, use only cables with isolation tangle.
- The hiding power of the isolation should be higher than 80%.
- Normally you should always lay the isolation of cables on both sides. Only by means of the both-sided connection of the isolation you achieve high quality interference suppression in the higher frequency area. Only as exception you may also lay the isolation one-sided. Then you only achieve the absorption of the lower frequencies. A one-sided isolation connection may be convenient, if:
 - the conduction of a potential compensating line is not possible.
 - analog signals (some mV respectively µA) are transferred.
 - foil isolations (static isolations) are used.
- With data lines always use metallic or metallised plugs for serial couplings. Fix the isolation of the data line at the plug rack. Do not lay the isolation on the PIN 1 of the plug bar!
- At stationary operation it is convenient to strip the insulated cable interruption free and lay it on the isolation/protected earth conductor line.
- To fix the isolation tangles use cable clamps out of metal. The clamps must clasp the isolation extensively and have well contact.
- Lay the isolation on an isolation rail directly after the entry of the cable in the cabinet.



CAUTION

Please regard at installation!

At potential differences between the grounding points, there may be a compensation current via the isolation connected at both sides.

Remedy: Potential compensation line

Basics and mounting System MICRO

General data for the System MICRO

2.8 General data for the System MICRO

Conformity and approval		
Conformity		
CE	2014/35/EU	Low-voltage directive
	2014/30/EU	EMC directive
Approval		
UL	-	Refer to Technical data
others		
RoHS	2011/65/EU	Restriction of the use of certain hazardous substances in electrical and electronic equipment

Protection of persons and device protection			
Type of protection	-	IP20	
Electrical isolation			
to the field bus	-	electrically isolated	
to the process level	-	electrically isolated	
Insulation resistance	-	-	
Insulation voltage to reference earth			
Inputs / outputs	-	AC / DC 50V, test voltage AC 500V	
Protective measures	-	against short circuit	

Environmental conditions to EN 61131-2						
Climatic						
Storage / transport	EN 60068-2-14	-25+70°C				
Operation						
Horizontal installation hanging	EN 61131-2	0+60°C				
Horizontal installation lying	EN 61131-2	0+60°C				
Vertical installation	EN 61131-2	0+60°C				
Air humidity	EN 60068-2-30	RH1 (without condensation, rel. humidity 1095%)				
Pollution	EN 61131-2	Degree of pollution 2				
Installation altitude max.	-	2000m				
Mechanical						
Oscillation	EN 60068-2-6	1g, 9Hz 150Hz				
Shock	EN 60068-2-27	15g, 11ms				

Mounting conditions		
Mounting place	-	In the control cabinet
Mounting position	-	Horizontal and vertical

System MICRO Basics and mounting

General data for the System MICRO > Use in difficult operating conditions

EMC	Standard		Comment
Emitted interference	EN 61000-6-4		Class A (Industrial area)
Noise immunity	EN 61000-6-2		Industrial area
zone B		EN 61000-4-2	ESD
			8kV at air discharge (degree of severity 3),
			4kV at contact discharge (degree of severity 2)
		EN 61000-4-3	HF field immunity (casing)
			80MHz 1000MHz, 10V/m, 80% AM (1kHz)
			1.4GHz 2.0GHz, 3V/m, 80% AM (1kHz)
			2GHz 2.7GHz, 1V/m, 80% AM (1kHz)
		EN 61000-4-6	HF conducted
			150kHz 80MHz, 10V, 80% AM (1kHz)
		EN 61000-4-4	Burst
		EN 61000-4-5	Surge ¹

¹⁾ Due to the high-energetic single pulses with Surge an appropriate external protective circuit with lightning protection elements like conductors for lightning and overvoltage is necessary.

2.8.1 Use in difficult operating conditions



Without additional protective measures, the products must not be used in locations with difficult operating conditions; e.g. due to:

- dust generation
- chemically active substances (corrosive vapors or gases)
- strong electric or magnetic fields


Properties

3 Hardware description

3.1 Properties

M13-CCF0001

- SPEED7 technology integrated
- Programmable via SPEED7 Studio, Siemens SIMATIC Manager or Siemens TIA Portal
- 128kbyte work memory integrated (64kbyte code, 64kbyte data)
- 128kbyte load memory integrated
- Slot for external storage media (lockable)
- Status LEDs for operating state and diagnostics
- X1/X5: DI 16xDC24V with status indication integrated
- X2/X6: DO 12xDC24V 0.5A with status indication integrated
- X3/X4: Ethernet PG/OP channel for active and passive Communication integrated
- X6: Al 2x12Bit U, I (single ended) integrated
- Technological functions: 4 channels for counter, frequency measurement and 2 channels for pulse width modulation
- Pulse Train via SFB 49 (PULSE)
- PROFINET IO controller and I-Device via Ethernet PG/OP channel
- OPC UA project via Ethernet PG/OP channel
- WebVisu project via Ethernet PG/OP channel
- Option: Extension module 2xRS485
- Option: max. 8 periphery modules
- I/O address area digital/analog 2048byte
- 512 timer/counter, 8192 flag byte



Differences to the M13-CCF0000

- Existing projects of the M13-CCF0000 can be used without modification.
- Since the M13-CCF0001 has a maximum memory expansion, an inserted VSC to activate a memory expansion is ignored.
- For configuration please use the SPEED7 Studio V1.9.2 and up for the configuration, respectively in the Siemens SIMATIC Manager and TIA Portal the GSDML V107 and up.


Ordering data

Туре	Order number	Description
CPU M13C	M13-CCF0001	System MICRO CPU M13C with 128kbyte work memory, DI 16xDC24V, DO 12xDC24 0.5A, AI 2x12bit and 4 channels technological functions
EM M09	M09-0CB00	System MICRO extension: Serial interface 2x (RS485/RS422, MPI, option PROFIBUS DP slave)

3.2 Structure

3.2.1 System MICRO CPU M13C

CPU M13-CCF0001




- Slot for external storage media (lockable)
- Operating mode switch CPU
- 3
- X3: Ethernet PG/OP channel 1 X4: Ethernet PG/OP channel 2
- X2: Connector DO +0.0 ... DO +0.7
- X1: Connector DI +0.0 ... DI +0.7
- 7 Status bar CPU
- X5: Connector DI +1.0 ... DI +1.7
- X6: Connector electronic section supply, AI, DO +1.0 ... DO +1.3
- 10 X2 4L+: LED DC 24V power section supply for on-board DO
- 11 X2 4M: LED on error, overload respectively short circuit at the outputs
- 12 X2 DO +0.x: LEDs DO +0.0 ... DO +0.7
- 13 X1 3L+: LED DC 24V power section supply for on-board DI
- 14 X1 DI +0.x: LEDs DI +0.0 ... DI +0.7
- 15 X5 DI +1.x: LEDs DI +1.0 ... DI +1.7
- 16 X6 1L+: LED DC 24V for electronic section supply
- 17 X6 AI x: LEDs AI 0, AI 1
- 18 X6 DO +1.x: LEDs DO +1.0 ... DO +1.3
- 19 X3 Ethernet PG/OP channel: LEDs Link/Activity
- 20 X4 Ethernet PG/OP channel: LEDs Link/Activity


Structure > Interfaces

3.2.2 **Interfaces**















- 1 Transmit +
- 1 Transmit +
 2 Transmit 3 Receive +
 4 5 6 Receive 7 8 -Receive +



X4 PG/OP 2




- Transmit + 1 2 3 4 5 6 7
- Transmit -
- Receive +
- Receive -
- 8



System MICRO Hardware description


Structure > Interfaces

X1: DI byte 0



X1	Function	Туре	LED	Description
			green	
1	DI 0.7	I		Digital input DI 7 / Counter 2 (B) / Frequency 21
2	DI 0.6	I		Digital input DI 6 / Counter 2 (A) ¹
3	DI 0.5	1		Digital input DI 5
4	DI 0.4	1		Digital input DI 4 / Counter 1 (B) / Frequency 1 ¹
5	DI 0.3	1		Digital input DI 3 / Counter 1 (A) ¹
6	DI 0.2	1		Digital input DI 2
7	DI 0.1	1		Digital input DI 1 / Counter 0 (B) / Frequency 01
8	DI 0.0	1		Digital input DI 0 / Counter 0 (A) ¹
9	0 V	1		3M: GND for onboard DI power section supply
10	DC 24V	1		3L+: DC 24V for onboard DI power section supply
1) Max. input fre	quency 100kHz ot	herwise 1kHz.		

X2: DO byte 0



Structure > Interfaces

X2	Function	Туре	LED	Description
			green	
1	DO 0.7	0		Digital output DO 7
2	DO 0.6	0		Digital output DO 6
3	DO 0.5	0		Digital output DO 5
4	DO 0.4	0		Digital output DO 4
5	DO 0.3	0		Digital output DO 3 / Output channel counter 3
6	DO 0.2	0		Digital output DO 2 / Output channel counter 2
7	DO 0.1	0		Digital output DO 1 / PWM 1 / Output channel counter 1
8	DO 0.0	0		Digital output DO 0 / PWM 0 / Output channel counter 0
9	0 V	1	red	4M: GND for onboard DO power section supply / GND PWM
				LED (red) is on at short circuit respectively overload
10	DC 24V	I		4L+: DC 24V for onboard DO power section supply


X3/X4: Ethernet PG/OP channel

8pin RJ45 jack:

- The RJ45 jack serves as interface to the Ethernet PG/OP channel.
- This interface allows you to program respectively remote control your CPU and to access the internal web server.
- The Ethernet PG/OP channel (X3/X4) is designed as switch. This enables PG/OP communication via the connections X3 and X4.
- Configurable connections are possible.
- DHCP respectively the assignment of the network configuration with a DHCP server is supported.
- Default diagnostics addresses: 2025 ... 2040
- At the first commissioning respectively after a factory reset the Ethernet PG/OP channel has no IP address. For online access to the CPU via the Ethernet PG/OP channel, valid IP address parameters have to be assigned to this by means of your configuration tool. This is called "initialization".
- Via the Ethernet PG/OP channel, you have access to:
 - Device web page, where you can find information on firmware status, connected peripherals, current cycle times, etc.
 - OPC UA project, which is to be created in the OPC UA Configurator.
 - WebVisu project, which is to be created in the SPEED7 Studio.
 - PROFINET IO controller or the PROFINET I-Device.
- → 'Hardware configuration Ethernet PG/OP channel'...page 74
- → 'Deployment PG/OP communication productive'...page 203


Structure > Interfaces

X5: DI byte 1



X5	Function	Туре	LED	Description
			green	
1	-	-		reserved
2	-	-		reserved
3	DI 1.0	I		Digital input DI 8
4	DI 1.1	I		Digital input DI 9 / Counter 3 (A) ¹
5	DI 1.2	I		Digital input DI 10 / Counter 3 (B) / Frequency 31
6	DI 1.3	I		Digital input DI 11 / Gate 3 ¹
7	DI 1.4	I		Digital input DI 12
8	DI 1.5	I		Digital input DI 13
9	DI 1.6	I		Digital input DI 14
10	DI 1.7	I		Digital input DI 15 / Latch 3 ¹
1) Max. input fre	quency 100kHz ot	herwise 1kHz.		

X6: DC 24V, AI, DO byte 1



Structure > Interfaces

X6	Function	Туре	LED	Description	
			green		
1	1L+	I		1L+: DC 24V for electronic	section supply
2	1M	I		1M: DC 0V for electronic se	ection supply
3	Ţ	1		Shield	
4	2M	I		2M: Ground for analog inpu	uts
5	AI 0	I	red	Al0: Analog input Al 0	Error LED is on at:
6	Al 1	I	red	Al1: Analog input Al 1	■ Error in the parametrization
7	DO 1.0	0		Digital output DO 8	
8	DO 1.1	0		Digital output DO 9	
9	DO 1.2	0		Digital output DO 10	
10	DO 1.3	0		Digital output DO 11	




Temporarily not used analog inputs must be connected to the concerning ground.



If a 2wire measuring transducer is used, you have to connect in line an external power supply.

X6: Electronic power supply




The CPU has an integrated power supply. The power supply has to be provided with DC 24V. Via the power supply not only the internal electronic of the CPU is provided with voltage, but also the electronic from the integrated IO components. The power supply is protected against polarity inversion and over current.


Structure > LEDs

3.2.3 LEDs





- 1 Status bar CPU
- 2 X3 Ethernet PG/OP channel: LEDs Link/Activity
- 3 X4 Ethernet PG/OP channel: LEDs Link/Activity
- 4 X1 DI +0.x: LEDs DI +0.0 ... DI +0.7
- 5 X1 3L+: LED DC 24V power section supply for on-board DI
- 6 X2 DO +0.x: LEDs DO +0.0 ... DO +0.7
- 7 X2 4L+: LED DC 24V power section supply for on-board DO
- 8 X2 4M: LED on error, overload respectively short circuit at the outputs
- 9 X5 DI +1.x: LEDs DI +1.0 ... DI +1.7
- 10 X6 AI x: LEDs AI 0, AI 1
- 11 X6 DO +1.x: LEDs DO +1.0 ... DO +1.3
- 12 X6 1L+: LED DC 24V for electronic section supply



Status bar CPU

Status bar	Function
green	CPU - RUN: CPU is in state RUN without error. → 51
yellow	CPU - STOP: CPU is in STOP state. → 51
red	CPU - system fault: System error occurred. → 51

Ethernet PG/OP channel

X3/X4	Function
green	Ethernet PG/OP channel X3/X4: Link/Activity → 52
yellow	Ethernet PG/OP channel X3/X4: Speed → 52

X1 DI +0.x

Digital input	LED	Description
	green	
DI +0.0 DI +0.7		Digital input I+0.0 0.7 has "1" signal
		Digital input I+0.0 0.7 has "0" signal

X1 3L+

Power supply	LED	Description
	green	
3L+		DC 24V power section supply inputs OK
		DC 24V power section supply inputs not available

X2 DO +0.x

Digital output	LED green	Description
DO +0.0 DO +0.7		Digital output Q+0.0 0.7 has "1" signal

Structure > LEDs

Digital output	LED	Description
	green	
		Digital output Q+0.0 0.7 has "0" signal

X2 4L+

Power supply	LED	Description
	green	
4L+		DC 24V power section supply outputs OK
		DC 24V power section supply outputs not available

X2 4M

Error	LED	Description
	red	
4M		Error, overload respectively short circuit on the outputs
		no error

X5 DI +1.x

Digital input	LED	Description
	green	
DI +1.0 DI +1.7		Digital input I+1.0 1.7 has "1" signal
		Digital input I+1.0 1.7 has "0" signal

X6 AI 0, AI 1

Error	LED	Description
	red	
AI 0, AI 1		Error, signal outside of the measuring range
		no error

X6 DO +1.x

Digital output	LED	Description
	green	
DO +1.0 DO +1.3		Digital output Q+1.0 1.3 has "1" signal
		Digital output Q+1.0 1.3 has "0" signal

X6 1L+

Power supply	LED	Description
	green	
1L+		DC 24V electronic section supply OK
		DC 24V electronic section supply not available

Structure > LEDs

3.2.3.1 Status bar CPU

LED	Description
Start-up	
	LED yellow blinks with 1Hz: State of the CPU after PowerON
	LEDs green are blinking with 2Hz: During the start-up (OB 100) the status bar blinks for at least 3s.
Operation	
	LED yellow on: CPU is in STOP state.
	LED red on: CPU is in error state.
	LEDs green on: CPU is in RUN state without error.
	LED red blinks with 1Hz and LED green is on: CPU is in RUN state with error/warning.
	LED red on and LED green blinks with 1Hz: CPU is in STOP state, configured holding point reached.
	LED red blinks with 1Hz and LED green blinks with 2Hz: Diagnostic messages detected during start-up.
	LED red on and LED yellow on: CPU is in error state. There is a system error or an internal error has occurred.
	Here a write access is made to the memory card. As long as the LEDs red and yellow are on, do not remove the memory card.
	LED yellow blinks with 2Hz: Hardware configuration is loaded.
	LEDs green are blinking with 1Hz: Blinking test (started via configuration tool)
	LED green on and LED green flickers: Access to the memory card in the RUN state.
	LED red blinks with 1Hz and LED green flickers: Access to the memory card with CPU is in RUN state with error/warning.
	LED yellow flickers: Access to the memory card in STOP state.
Overall reset	
	LED yellow blinks with 1Hz: Overall reset is requested
	LED yellow blinks with 2Hz: Overall reset is executed.
	LED yellow on: Overall reset was successfully finished.
Factory reset	
	LED yellow blinks with 2Hz: Reset to factory setting is executed.
	LED red blinks with 1Hz and LED yellow blinks with 1Hz: Reset to factory settings was finished without errors. Please perform a power cycle!
Firmware update	e e e e e e e e e e e e e e e e e e e
	LED red and LED yellow are alternately blinking with 1Hz: A new firmware is available on the memory card.
	LED yellow blinks with 2Hz: A firmware update is in progress.
	LED yellow flickers: Access the memory card during the firmware update.
	LED red and LED yellow are blinking with 1Hz: Firmware update finished without error. Please perform a power cycle!
	LED red blinks with 1Hz: Error during Firmware update.

Structure > Slot for storage media

3.2.3.2 LEDs Ethernet PG/OP channel

X3/X4: LEDs

L/A	S	Description
Link/Activity	Speed	
green	yellow	
	X	The Ethernet PG/OP channel is physically connected to the Ethernet interface.
	X	There is no physical connection.
	X	Blinking: Shows Ethernet activity.
		The Ethernet interface of the Ethernet PG/OP channel has a transfer rate of 100Mbit.
		The Ethernet interface of the Ethernet PG/OP channel has a transfer rate of 10Mbit.
not relevant: X		

3.2.4 Memory management

General

The CPU has an integrated memory. Information about the capacity of the memory may be found at the front of the CPU. The memory is divided into the following parts:

- Load memory 128kbyte
- Code memory (50% of the work memory)
- Data memory (50% of the work memory)
- Work memory 128kbyte

3.2.5 Slot for storage media

Overview

In this slot you can insert the following storage media:

- VSD VIPA SD-Card
 - External memory card for programs and firmware.
- VSC VIPASetCard
 - External memory card (VSD) for programs and firmware with the possibility to unlock optional functions like field bus interfaces.
 - These functions can be purchased separately. → 'Deployment storage media -VSD, VSC'...page 108
 - To activate the corresponding card is to be installed and a Overall reset is to be established. "Overall reset"...page 103



To avoid malfunctions, you should use Yaskawa memory cards. These correspond to the industrial standard. A list of the currently available VSD respectively VSC can be found at www.yaskawa.eu.com

System MICRO Hardware description

Option: Extension module EM M09 2x serial interface

3.2.6 Buffering mechanisms

The CPU has a capacitor-based mechanism to buffer the internal clock in case of power failure for max. 30 days. With PowerOFF the content of the RAM is automatically stored in the Flash (NVRAM).



CAUTION

Please connect the CPU for approximately 1 hour to the power supply, so that the internal buffering mechanism is loaded accordingly.

In case of failure of the buffer mechanism Date and Time 01.09.2009 00:00:00 set. Additionally, you receive a diagnostics message. → 'Diagnostic entries'...page 114

3.2.7 Operating mode switch

General




- With the operating mode switch you may switch the CPU between STOP and RUN.
- During the transition from STOP to RUN the operating mode START-UP is driven by the CPU.
- Placing the switch to MR (Memory Reset), you request an overall reset with following load from memory card, if a project there exists.

3.3 Option: Extension module EM M09 2x serial interface

EM M09




X1 PtP



- ① n. c.
- ② TxD-P (line B) RS422
- ③ RxD-P (line B) RS422 RxD/TxD-P (line B) - RS485
- 4 RTS
- ⑤ M5V
- 6 P5V
- 7 TxD-N (line A) RS422
- 8 RxD-N (line A) RS422 RxD/TxD-N (line A) - RS485
- 9 n.c.

X2 MPI(PB)



- ① n. c.
- ② n. c.
- ③ RxD/TxD-P (line B)
- 4 RTS
- 5 M5V
- 6 P5V
- (7) n. c.
- 8 RxD/TxD-N (line A)
- (9) n.c.



Please note that the interface X2 MPI(PB) does not provide DC 24V, which is necessary for some programming adapters!

Option: Extension module EM M09 2x serial interface

X1 PtP (RS422/485)

9pin SubD jack (isolated):

Using the *PtP* functionality the RS485 interface is allowed to connect via serial **p**oint **t**o **p**oint connection to different source res. target systems.

- Protocols:
 - ASCII
 - STX/ETX
 - 3964R
 - USS
 - Modbus master (ASCII, RTU)
- Serial bus connection
 - Full-duplex Four-wire operation (RS422)
 - Half-duplex Two-wire operation (RS485)
 - Data transfer rate: max. 115 kBaud
- → 'Option: PtP communication'...page 240

X2 MPI(PB)

9pin SubD jack (isolated):

The interface supports the following functions, which are switch able:

- MPI (default / after overall reset)
 - The MPI interface serves for the connection between programming unit and CPU. By means of this the project engineering and programming happens. In addition MPI serves for communication between several CPUs or between HMIs and CPU. Standard setting is MPI address 2.
- PROFIBUS DP slave (optional)

The PROFIBUS slave functionality of this interface can be activated by configuring the sub module 'MPI/DP' of the CPU in the hardware configuration. → 'Option: Deployment PROFIBUS communication'...page 254



Enable bus functionality via VSC

To switch the interface X2 MPI(PB) to PROFIBUS functionality you have to activate the according bus functionality by means of a Yaskawa VSC storage media. By plugging the VSC storage card and then an overall reset the according functionality is activated. → 'Deployment storage media - VSD, VSC'...page 108

System MICRO Hardware description

Option: Extension module EM M09 2x serial interface

LEDs



X1 PtP	Description
TxD	
green flickers	Send activity
	No send activity
X2 MPI(PB) DE	Description
green	 Power supply Expansion module EM M09 available Slave is in DE (data exchange) Slave exchanges data with the master Slave is in RUN state
green flashes	■ LED flashes at PowerON of EM M09
	No power supply EM M09 availableSlave has no configuration

Technical data > Technical data CPU

3.4 Technical data

3.4.1 Technical data CPU

Order no.	M13-CCF0001
Туре	CPU M13C
Module ID	-
Technical data power supply	
Power supply (rated value)	DC 24 V
Power supply (permitted range)	DC 20.428.8 V
Reverse polarity protection	✓
Current consumption (no-load operation)	120 mA
Current consumption (rated value)	360 mA
Inrush current	3 A
l²t	0.1 A ² s
Max. current drain at backplane bus	1 A
Max. current drain load supply	
Power loss	7 W
Technical data digital inputs	
Number of inputs	16
Cable length, shielded	1000 m
Cable length, unshielded	600 m
Rated load voltage	DC 24 V
Reverse polarity protection of rated load voltage	✓
Current consumption from load voltage L+ (without load)	25 mA
Rated value	DC 24 V
Input voltage for signal "0"	DC 05 V
Input voltage for signal "1"	DC 1528.8 V
Input voltage hysteresis	-
Signal logic input	Sinking input
Frequency range	-
Input resistance	-
Input current for signal "1"	3 mA
Connection of Two-Wire-BEROs possible	✓
Max. permissible BERO quiescent current	0.5 mA
Input delay of "0" to "1"	$3 \mu s - 15 ms / 0.5 ms - 15 ms$
Input delay of "1" to "0"	$3 \mu s - 15 ms / 0.5 ms - 15 ms$
Number of simultaneously utilizable inputs horizontal configuration	16
Number of simultaneously utilizable inputs vertical configuration	16

Order no.	M13-CCF0001
Input characteristic curve	IEC 61131-2, type 1
Initial data size	16 Bit
Technical data digital outputs	
Number of outputs	12
Cable length, shielded	1000 m
Cable length, unshielded	600 m
Rated load voltage	DC 24 V
Reverse polarity protection of rated load voltage	✓
Current consumption from load voltage L+ (without load)	20 mA
Total current per group, horizontal configuration, 40°C	6 A
Total current per group, horizontal configuration, 60°C	6 A
Total current per group, vertical configuration	6 A
Output voltage signal "1" at min. current	L+ (-0.8 V)
Output voltage signal "1" at max. current	L+ (-0.8 V)
Output current at signal "1", rated value	0.5 A
Signal logic output	Sourcing output
Output current, permitted range to 40°C	5 mA to 0.6 A
Output current, permitted range to 60°C	5 mA to 0.6 A
Output current at signal "0" max. (residual current)	0.5 mA
Output delay of "0" to "1"	2 µs / 30 µs
Output delay of "1" to "0"	3 µs / 175 µs
Minimum load current	-
Lamp load	10 W
Parallel switching of outputs for redundant control of a load	not possible
Parallel switching of outputs for increased power	not possible
Actuation of digital input	✓
Switching frequency with resistive load	max. 1000 Hz
Switching frequency with inductive load	max. 0.5 Hz
Switching frequency on lamp load	max. 10 Hz
Internal limitation of inductive shut-off voltage	L+ (-45 V)
Short-circuit protection of output	yes, electronic
Trigger level	1 A
Number of operating cycle of relay outputs	-
Switching capacity of contacts	-
Output data size	12 Bit
Technical data analog inputs	
Number of inputs	2
Cable length, shielded	200 m

Order no.	M13-CCF0001
Rated load voltage	-
Reverse polarity protection of rated load voltage	-
Current consumption from load voltage L+ (without load)	-
Voltage inputs	✓
Min. input resistance (voltage range)	100 kΩ
Input voltage ranges	0 V +10 V
Operational limit of voltage ranges	+/-3.5%
Operational limit of voltage ranges with SFU	-
Basic error limit voltage ranges	+/-3.0%
Basic error limit voltage ranges with SFU	-
Destruction limit voltage	max. 30V
Current inputs	✓
Max. input resistance (current range)	145 Ω
Input current ranges	+4 mA +20 mA
Operational limit of current ranges	+/-3.5%
Operational limit of current ranges with SFU	-
Basic error limit current ranges	+/-3.0%
Radical error limit current ranges with SFU	-
Destruction limit current inputs (electrical current)	-
Destruction limit current inputs (voltage)	max. 30V
Resistance inputs	-
Resistance ranges	-
Operational limit of resistor ranges	-
Operational limit of resistor ranges with SFU	-
Basic error limit	-
Basic error limit with SFU	-
Destruction limit resistance inputs	-
Resistance thermometer inputs	-
Resistance thermometer ranges	-
Operational limit of resistance thermometer ranges	-
Operational limit of resistance thermometer ranges with SFU	-
Basic error limit thermoresistor ranges	-
Basic error limit thermoresistor ranges with SFU	-
Destruction limit resistance thermometer inputs	-
Thermocouple inputs	-
Thermocouple ranges	-

Order no.	M13-CCF0001
Operational limit of thermocouple ranges with SFU	-
Basic error limit thermocouple ranges	-
Basic error limit thermocouple ranges with SFU	-
Destruction limit thermocouple inputs	-
Programmable temperature compensation	-
External temperature compensation	-
Internal temperature compensation	-
Technical unit of temperature measurement	-
Resolution in bit	12
Measurement principle	successive approximation
Basic conversion time	2 ms
Noise suppression for frequency	40 dB
Initial data size	4 Byte
Technical data analog outputs	
Number of outputs	-
Cable length, shielded	-
Rated load voltage	-
Reverse polarity protection of rated load voltage	-
Current consumption from load voltage L+ (without load)	-
Voltage output short-circuit protection	-
Voltage outputs	-
Min. load resistance (voltage range)	-
Max. capacitive load (current range)	-
Max. inductive load (current range)	-
Output voltage ranges	-
Operational limit of voltage ranges	-
Basic error limit voltage ranges with SFU	-
Destruction limit against external applied voltage	-
Current outputs	-
Max. in load resistance (current range)	-
Max. inductive load (current range)	-
Typ. open circuit voltage current output	-
Output current ranges	-
Operational limit of current ranges	-
Radical error limit current ranges with SFU	-
Destruction limit against external applied voltage	-
Settling time for ohmic load	-
Settling time for capacitive load	-

Order no.	M13-CCF0001
Settling time for inductive load	-
Resolution in bit	-
Conversion time	-
Substitute value can be applied	-
Output data size	-
Technical data counters	
Number of counters	4
Counter width	32 Bit
Maximum input frequency	100 kHz
Maximum count frequency	400 kHz
Mode incremental encoder	✓
Mode pulse / direction	✓
Mode pulse	✓
Mode frequency counter	✓
Mode period measurement	✓
Gate input available	✓
Latch input available	✓
Reset input available	-
Counter output available	✓
Load and working memory	
Load memory, integrated	128 KB
Load memory, maximum	128 KB
Work memory, integrated	128 KB
Work memory, maximal	128 KB
Memory divided in 50% program / 50% data	✓
Memory card slot	SD/MMC-Card with max. 2 GB
Hardware configuration	
Racks, max.	1
Modules per rack, max.	8
Number of integrated DP master	-
Number of DP master via CP	-
Operable function modules	-
Operable communication modules PtP	-
Operable communication modules LAN	-
Status information, alarms, diagnostics	
Status display	yes
Interrupts	yes, parameterizable
Process alarm	yes, parameterizable

Order no.	M13-CCF0001
Diagnostic interrupt	yes, parameterizable
Diagnostic functions	yes, parameterizable
Diagnostics information read-out	possible
Supply voltage display	green LED
Group error display	red LED
Channel error display	red LED per group
Isolation	
Between channels	✓
Between channels of groups to	16
Between channels and backplane bus	✓
Between channels and power supply	-
Max. potential difference between circuits	DC 75 V/ AC 50 V
Max. potential difference between inputs (Ucm)	-
Max. potential difference between Mana and Mintern (Uiso)	-
Max. potential difference between inputs and Mana (Ucm)	-
Max. potential difference between inputs and Mintern (Uiso)	-
Max. potential difference between Mintern and outputs	-
Insulation tested with	DC 500 V
Command processing times	
Bit instructions, min.	0.02 μs
Word instruction, min.	0.02 μs
Double integer arithmetic, min.	0.02 μs
Floating-point arithmetic, min.	0.12 μs
Timers/Counters and their retentive characteristics	
Number of S7 counters	512
S7 counter remanence	adjustable 0 up to 256
S7 counter remanence adjustable	C0 C7
Number of S7 times	512
S7 times remanence	adjustable 0 up to 256
S7 times remanence adjustable	not retentive
Data range and retentive characteristic	
Number of flags	8192 Byte
Bit memories retentive characteristic adjustable	adjustable 0 up to 256
Bit memories retentive characteristic preset	MB0 MB15
Number of data blocks	1024
Max. data blocks size	64 KB

Order no.	M13-CCF0001
Max. local data size per execution level	4096 Byte
Blocks	
Number of OBs	22
Number of FBs	1024
Number of FCs	1024
Maximum nesting depth per priority class	16
Maximum nesting depth additional within an error OB	4
Time	
Real-time clock buffered	✓
Clock buffered period (min.)	30 d
Accuracy (max. deviation per day)	10 s
Number of operating hours counter	8
Clock synchronization	✓
Synchronization via MPI	Master/Slave
Synchronization via Ethernet (NTP)	no
Address areas (I/O)	
Input I/O address area	2048 Byte
Output I/O address area	2048 Byte
Input process image maximal	2048 Byte
Output process image maximal	2048 Byte
Digital inputs	144
Digital outputs	140
Digital inputs central	144
Digital outputs central	140
Integrated digital inputs	16
Integrated digital outputs	12
Analog inputs	2
Analog outputs	0
Analog inputs, central	2
Analog outputs, central	0
Integrated analog inputs	2
Integrated analog outputs	0
Communication functions	
PG/OP channel	✓
Global data communication	✓
Number of GD circuits, max.	8
Size of GD packets, max.	54 Byte
S7 basic communication	✓

Order no.	M13-CCF0001
S7 basic communication, user data per job	76 Byte
S7 communication	✓
S7 communication as server	✓
S7 communication as client	-
S7 communication, user data per job	160 Byte
Number of connections, max.	32
PWM data	
PWM channels	2
PWM time basis	1 µs / 0.1 ms / 1 ms
Period length	-
Minimum pulse width	00.5 * Period duration
Type of output	Highside
Functionality Sub-D interfaces	
Туре	X1
Type of interface	RS422/485 isolated
Connector	Sub-D, 9-pin, female
Electrically isolated	✓
MPI	-
MP ² I (MPI/RS232)	-
DP master	-
DP slave	-
Point-to-point interface	✓
5V DC Power supply	max. 90mA, isolated
24V DC Power supply	-
Туре	X2
Type of interface	RS485 isolated
Connector	Sub-D, 9-pin, female
Electrically isolated	✓
MPI	✓
MP ² I (MPI/RS232)	-
DP master	-
DP slave	optional
Point-to-point interface	-
5V DC Power supply	max. 90mA, isolated
24V DC Power supply	-
Functionality MPI	
i difficulty will i	

Order no.	M13-CCF0001
PG/OP channel	✓
Routing	✓
Global data communication	✓
S7 basic communication	✓
S7 communication	✓
S7 communication as server	✓
S7 communication as client	-
Transmission speed, min.	19.2 kbit/s
Transmission speed, max.	12 Mbit/s
Functionality PROFIBUS slave	
Number of connections, max.	32
PG/OP channel	✓
Routing	✓
S7 communication	✓
S7 communication as server	✓
S7 communication as client	-
Direct data exchange (slave-to-slave communication)	
DPV1	✓
Transmission speed, min.	9.6 kbit/s
Transmission speed, max.	12 Mbit/s
Automatic detection of transmission speed	✓
Transfer memory inputs, max.	244 Byte
Transfer memory outputs, max.	244 Byte
Address areas, max.	32
User data per address area, max.	32 Byte
Functionality RJ45 interfaces	
Туре	X3/X4
Type of interface	Ethernet 10/100 MBit Switch
Connector	2 x RJ45
Electrically isolated	✓
PG/OP channel	✓
Number of connections, max.	4
Productive connections	✓
Fieldbus	-
Туре	-
Type of interface	-
Connector	-

Order no.	M13-CCF0001
Electrically isolated	-
PG/OP channel	-
Number of connections, max.	-
Productive connections	-
Fieldbus	-
Point-to-point communication	
PtP communication	✓
Interface isolated	✓
RS232 interface	-
RS422 interface	✓
RS485 interface	✓
Connector	Sub-D, 9-pin, female
Transmission speed, min.	1200 bit/s
Transmission speed, max.	115.2 kbit/s
Cable length, max.	500 m
Point-to-point protocol	
ASCII protocol	✓
STX/ETX protocol	✓
3964(R) protocol	✓
RK512 protocol	-
USS master protocol	✓
Modbus master protocol	✓
Modbus slave protocol	✓
Special protocols	-
Properties PROFINET I/O-Controller via PG/OP	
Realtime Class	-
Conformance Class	PROFINET IO
Number of PN IO devices	8
IRT support	-
Shared Device supported	✓
MRP Client supported	✓
Prioritized start-up	-
Number of PN IO lines	1
Address range inputs, max.	2 KB
Address range outputs, max.	2 KB
Transmitting clock	1 ms
Update time	1 ms 512 ms
Isochronous mode	-

Order no.	M13-CCF0001
Parallel operation as controller and I-Device	✓
Properties PROFINET I/O controller	
Realtime Class	-
Conformance Class	-
Number of PN IO devices	-
IRT support	-
Prioritized start-up	
Number of PN IO lines	-
Address range inputs, max.	-
Address range outputs, max.	-
Transmitting clock	-
Update time	-
Isochronous mode	-
Properties PROFINET I-Device via PG/OP	
I/O Data range, max.	768 Byte
Update time	1 ms 512 ms
Mode as Shared I-Device	-
Management & diagnosis via PG/OP	
Protocols	ICMP DCP LLDP / SNMP NTP
Web based diagnosis	✓
NCM diagnosis	
Ethernet communication via PG/OP	
Number of productive connections via PG/OP, max.	2
Number of productive connections by Siemens NetPro, max.	2
S7 connections	BSEND, BRCV, GET, PUT, Connection of active and passive data handling
User data per S7 connection, max.	64 KB
TCP-connections	FETCH PASSIV, WRITE PASSIV, Connection of passive data handling
User data per TCP connection, max.	8 KB
ISO on TCP connections (RFC 1006)	FETCH PASSIV, WRITE PASSIV, Connection of passive data handling
User data per ISO connection, max.	8 KB
Ethernet open communication via PG/OP	
Number of configurable connections, max.	2

User data per ISO on TCP connection, max. TSEND, TRCV, TCON, TDISCON User data per native TCP connection, max. User data per ad hoc TCP connection, max. 1460 Byte TUSEND, TURCV UDP-connections TUSEND, TURCV UDP-connections TUSEND, TURCV USER data per UDP connection, max. 1472 Byte WebVisu via PG/OP WebVisu via PG/OP WebVisu is supported Max. number of connections WebVisu WebVisu supports HTTP VebVisu supports HTTP VOPC UA server via PG/OP OPC UA server is supported Max. number of connections per interface 4 Services Data Access (Read, Write, Subscribe) Security policies Anonymous, username and password Housing Material PPE / PPE GF10 Mounting Mechanical data Dimensions (WxHxD) T2 mm x 88 mm x 71 mm Mechanical data Dimensions (WxHxD) T2 mm x 88 mm x 71 mm Net weight 230 g Weight including accessories Gross weight 250 g Environmental conditions Operating temperature 0 °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification yes	Order no.	M13-CCF0001
TCP-Connections native TSEND, TRCV, TCON, TDISCON User data per native TCP connection, max. 32 KB User data per ad hoc TCP connection, max. 1460 Byte UDP-connections TUSEND, TURCV User data per UDP connection, max. 1472 Byte WebVisu via PG/OP WebVisu is supported Max. number of connections WebVisu 4 WebVisu supports HTTP OPC UA server via PG/OP OPC UA server is supported Max. number of connections per interface 4 Services Data Access (Read, Write, Subscribe) Security policies None, Basic128Rsa15, Basic256, Basic256Sha256 Authentication Anonymous, username and password Housing Material PPE / PPE GF10 Mounting Profile rail 35 mm Mechanical data Dimensions (WxHxD) 72 mm x 88 mm x 71 mm Net weight Mechanical data Dimensions (WxHxD) 72 mm x 88 mm x 71 mm Net weight 1230 g Gross weight 250 g Environmental conditions Operating temperature 0 °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification yes	ISO on TCP connections (RFC 1006)	TSEND, TRCV, TCON, TDISCON
User data per native TCP connection, max. User data per ad hoc TCP connection, max. 1460 Byte UDP-connections TUSEND, TURCV User data per UDP connection, max. 1472 Byte WebVisu via PG/OP WebVisu is supported Max. number of connections WebVisu WebVisu supports HTTP VebVisu supports HTTPS OPC UA server via PG/OP OPC UA server is supported As. number of connections per interface Services Data Access (Read, Write, Subscribe) None, Basic128Rsa15, Basic256, Basic256Sha256 Authentication Anonymous, username and password Housing Material PPE / PPE GF10 Mounting Profile rail 35 mm Mechanical data Dimensions (WXHXD) Nat weight 230 g Gross weight 250 g Environmental conditions Operating temperature 0 °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification yes	User data per ISO on TCP connection, max.	32 KB
User data per ad hoc TCP connection, max. UDP-connections TUSEND, TURCV User data per UDP connection, max. WebVisu via PG/OP WebVisu is supported Max. number of connections WebVisu WebVisu supports HTTP WebVisu supports HTTPS OPC UA server via PG/OP OPC UA server is supported Max. number of connections per interface Services Data Access (Read, Write, Subscribe) None, Basic128Rsa15, Basic256, Basic256Sha256 Authentication Anonymous, username and password Housing Material PPE / PPE GF10 Mounting Profile rail 35 mm Mechanical data Dimensions (WXHXD) 72 mm x 88 mm x 71 mm Mechanical including accessories 230 g Gross weight 250 g Environmental conditions Operating temperature O °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification yes	TCP-Connections native	TSEND, TRCV, TCON, TDISCON
UDP-connections User data per UDP connection, max. WebVisu via PG/OP WebVisu is supported Max. number of connections WebVisu WebVisu supports HTTP WebVisu supports HTTPS OPC UA server via PG/OP OPC UA server is supported Max. number of connections per interface Aservices Data Access (Read, Write, Subscribe) None, Basic128Rsa15, Basic256, Basic256Sha256 Authentication Anonymous, username and password Housing Material PPE / PPE GF10 Mounting Profile rail 35 mm Mechanical data Dimensions (WxHxD) Net weight 230 g Weight including accessories Gross weight 250 g Environmental conditions Operating temperature O °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification yes	User data per native TCP connection, max.	32 KB
User data per UDP connection, max. WebVisu via PG/OP WebVisu is supported Max. number of connections WebVisu WebVisu supports HTTP WebVisu supports HTTPS OPC UA server via PG/OP OPC UA server is supported Max. number of connections per interface Max. number of connections per interface Services Data Access (Read, Write, Subscribe) None, Basic128Rsa15, Basic256, Basic256Sha256 Authentication Anonymous, username and password Housing Material PPE / PPE GF10 Mounting Profile rail 35 mm Mechanical data Dimensions (WxHxD) 72 mm x 88 mm x 71 mm Net weight 230 g Weight including accessories Gross weight 250 g Environmental conditions Operating temperature 0 °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification yes	User data per ad hoc TCP connection, max.	1460 Byte
WebVisu via PG/OP WebVisu is supported Max. number of connections WebVisu WebVisu supports HTTP WebVisu supports HTTPS OPC UA server via PG/OP OPC UA server via PG/OP OPC UA server is supported Max. number of connections per interface Services Data Access (Read, Write, Subscribe) None, Basic128Rsa15, Basic256, Basic256Sha256 Authentication Anonymous, username and password Housing Material PPE / PPE GF10 Mounting Profile rail 35 mm Mechanical data Dimensions (WxHxD) 72 mm x 88 mm x 71 mm Net weight 230 g Gross weight 230 g Gross weight Environmental conditions Operating temperature 0 °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification yes	UDP-connections	TUSEND, TURCV
WebVisu is supported Max. number of connections WebVisu WebVisu supports HTTP WebVisu supports HTTPS OPC UA server via PG/OP OPC UA server is supported Max. number of connections per interface Max. number of connections per interface Services Data Access (Read, Write, Subscribe) None, Basic128Rsa15, Basic256, Basic256Sha256 Authentication Anonymous, username and password Housing Material PPE / PPE GF10 Mounting Profile rail 35 mm Mechanical data Dimensions (WxHxD) 72 mm x 88 mm x 71 mm Net weight 230 g Weight including accessories 230 g Gross weight 250 g Environmental conditions Operating temperature 0 °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification	User data per UDP connection, max.	1472 Byte
Max. number of connections WebVisu WebVisu supports HTTP WebVisu supports HTTPS OPC UA server via PG/OP OPC UA server is supported Max. number of connections per interface Services Data Access (Read, Write, Subscribe) Security policies None, Basic128Rsa15, Basic256, Basic256Sha256 Authentication Housing Material PPE / PPE GF10 Mounting Profile rail 35 mm Mechanical data Dimensions (WxHxD) 72 mm x 88 mm x 71 mm Net weight 230 g Gross weight 250 g Environmental conditions Operating temperature 0 °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification yes	WebVisu via PG/OP	
WebVisu supports HTTP WebVisu supports HTTPS OPC UA server via PG/OP OPC UA server is supported Max. number of connections per interface Services Data Access (Read, Write, Subscribe) None, Basic128Rsa15, Basic256, Basic256Sha256 Authentication Anonymous, username and password Housing Material PPE / PPE GF10 Mounting Profile rail 35 mm Mechanical data Dimensions (WxHxD) 72 mm x 88 mm x 71 mm Net weight 230 g Weight including accessories 230 g Gross weight Environmental conditions Operating temperature 0 °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification yes	WebVisu is supported	✓
WebVisu supports HTTPS OPC UA server via PG/OP OPC UA server is supported Max. number of connections per interface Services Data Access (Read, Write, Subscribe) Security policies None, Basic128Rsa15, Basic256, Basic256Sha256 Authentication Housing Material PPE / PPE GF10 Mounting Profile rail 35 mm Mechanical data Dimensions (WxHxD) 72 mm x 88 mm x 71 mm Net weight 230 g Gross weight Environmental conditions Operating temperature 0 °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification yes	Max. number of connections WebVisu	4
OPC UA server via PG/OP OPC UA server is supported Max. number of connections per interface Services Data Access (Read, Write, Subscribe) Security policies None, Basic128Rsa15, Basic256, Basic256Sha256 Authentication Anonymous, username and password Housing Material PPE / PPE GF10 Mounting Profile rail 35 mm Mechanical data Dimensions (WxHxD) 72 mm x 88 mm x 71 mm Net weight 230 g Weight including accessories 230 g Gross weight 250 g Environmental conditions Operating temperature O °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification yes	WebVisu supports HTTP	✓
OPC UA server is supported Max. number of connections per interface Services Data Access (Read, Write, Subscribe) Security policies None, Basic128Rsa15, Basic256, Basic256Sha256 Authentication Anonymous, username and password Housing Material PPE / PPE GF10 Mounting Mechanical data Dimensions (WxHxD) 72 mm x 88 mm x 71 mm Net weight 230 g Weight including accessories Gross weight Environmental conditions Operating temperature 0 °C to 60 °C Storage temperature Certifications UL certification yes	WebVisu supports HTTPS	✓
Max. number of connections per interface Services Data Access (Read, Write, Subscribe) Security policies None, Basic128Rsa15, Basic256, Basic256Sha256 Authentication Anonymous, username and password Housing Material PPE / PPE GF10 Mounting Profile rail 35 mm Mechanical data Dimensions (WxHxD) 72 mm x 88 mm x 71 mm Net weight 230 g Weight including accessories 230 g Gross weight 250 g Environmental conditions Operating temperature 0 °C to 60 °C Storage temperature Certifications UL certification yes	OPC UA server via PG/OP	
Services Data Access (Read, Write, Subscribe) Security policies None, Basic128Rsa15, Basic256, Basic256Sha256 Authentication Anonymous, username and password Housing Material PPE / PPE GF10 Mounting Profile rail 35 mm Mechanical data Dimensions (WxHxD) 72 mm x 88 mm x 71 mm Net weight 230 g Weight including accessories 230 g Gross weight 250 g Environmental conditions Operating temperature 0 °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification yes	OPC UA server is supported	✓
Security policies Authentication Anonymous, username and password Housing Material PPE / PPE GF10 Mounting Profile rail 35 mm Mechanical data Dimensions (WxHxD) 72 mm x 88 mm x 71 mm Net weight 230 g Weight including accessories Gross weight 250 g Environmental conditions Operating temperature 0 °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification yes	Max. number of connections per interface	4
Authentication Housing Material PPE / PPE GF10 Mounting Mechanical data Dimensions (WxHxD) Net weight Veright including accessories Gross weight Environmental conditions Operating temperature O °C to 60 °C Storage temperature O Certifications UL certification Anonymous, username and password PPE / PPE GF10 Profile rail 35 mm 72 mm x 88 mm x 71 mm 230 g We so 9 We so 9 Comparison of the password of the	Services	Data Access (Read, Write, Subscribe)
Housing Material PPE / PPE GF10 Mounting Profile rail 35 mm Mechanical data Dimensions (WxHxD) 72 mm x 88 mm x 71 mm Net weight 230 g Weight including accessories 230 g Gross weight 250 g Environmental conditions Operating temperature 0 °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification yes	Security policies	None, Basic128Rsa15, Basic256, Basic256Sha256
Material PPE / PPE GF10 Mounting Profile rail 35 mm Mechanical data Dimensions (WxHxD) 72 mm x 88 mm x 71 mm Net weight 230 g Weight including accessories 230 g Gross weight 250 g Environmental conditions Operating temperature 0 °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification yes	Authentication	Anonymous, username and password
Mounting Mechanical data Dimensions (WxHxD) 72 mm x 88 mm x 71 mm Net weight 230 g Weight including accessories 230 g Gross weight Environmental conditions Operating temperature 0 °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification Profile rail 35 mm 72 mm x 88 mm x 71 mm 230 g 230 g 250 g	Housing	
Mechanical data Dimensions (WxHxD) 72 mm x 88 mm x 71 mm Net weight 230 g Weight including accessories 230 g Gross weight 250 g Environmental conditions Operating temperature 0 °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification yes	Material	PPE / PPE GF10
Dimensions (WxHxD) 72 mm x 88 mm x 71 mm 230 g Weight including accessories 230 g Gross weight 250 g Environmental conditions Operating temperature 0 °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification yes	Mounting	Profile rail 35 mm
Net weight 230 g Weight including accessories 230 g Gross weight 250 g Environmental conditions Operating temperature 0 °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification yes	Mechanical data	
Weight including accessories 230 g Gross weight 250 g Environmental conditions Operating temperature 0 °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification yes	Dimensions (WxHxD)	72 mm x 88 mm x 71 mm
Gross weight Environmental conditions Operating temperature O °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification yes	Net weight	230 g
Environmental conditions Operating temperature O °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification yes	Weight including accessories	230 g
Operating temperature 0 °C to 60 °C Storage temperature -25 °C to 70 °C Certifications UL certification yes	Gross weight	250 g
Storage temperature -25 °C to 70 °C Certifications UL certification yes	Environmental conditions	
Certifications UL certification yes	Operating temperature	0 °C to 60 °C
UL certification yes	Storage temperature	-25 °C to 70 °C
	Certifications	
KC certification in preparation	UL certification	yes
	KC certification	in preparation

Technical data > Technical data EM M09

3.4.2 Technical data EM M09

Order no.	M09-0CB00
Туре	Micro Extension 2xRS485
Module ID	-
Status information, alarms, diagnostics	
Status display	green LED
Interrupts	no
Process alarm	no
Diagnostic interrupt	no
Diagnostic functions	no
Diagnostics information read-out	-
Supply voltage display	none
Group error display	-
Channel error display	-
Housing	
Material	PPE / PPE GF10
Mounting	Profile rail 35 mm
Mechanical data	
Dimensions (WxHxD)	35 mm x 88 mm x 26 mm
Net weight	56 g
Weight including accessories	56 g
Gross weight	66 g
Environmental conditions	
Operating temperature	0 °C to 60 °C
Storage temperature	-25 °C to 70 °C
Certifications	
UL certification	yes
KC certification	yes

Start-up behavior

4 Deployment CPU M13-CCF0001

4.1 Please note!

Differences to the M13-CCF0000

- Existing projects of the M13-CCF0000 can be used without modification.
- Since the M13-CCF0001 has a maximum memory expansion, an inserted VSC to activate a memory expansion is ignored.
- For configuration please use the SPEED7 Studio V1.9.2 and up for the configuration, respectively in the Siemens SIMATIC Manager and TIA Portal the GSDML V107 and up.



The following descriptions always refer to the usage in the Siemens SIMATIC Manager. Information on usage in the SPEED7 Studio or Siemens TIA Portal can be found here:

- → 'Configuration with SPEED7 Studio'...page 264
- → 'Configuration with TIA Portal'...page 289

4.2 Assembly



Information about assembly and cabling → 'Basics and mounting'...page 13.

4.3 Start-up behavior

Turn on power supply

- The CPU checks whether a project AUTOLOAD.WLD exists on the memory card. If so, an overall reset is executed and the project is automatically loaded from the memory card.
- The CPU checks whether a command file with the name VIPA_CMD.MMC exists on the memory card. If so the command file is loaded from the memory card and the commands are executed.
- After PowerON and CPU STOP the CPU checks if there is a *.pkb file (firmware file) on the memory card. If so, this is shown by the status bar of the CPU and the firmware may be installed by an update request. → 'Firmware update'...page 104
- The CPU checks if a previously activated VSC is inserted. If not, this is shown by the status bar of the CPU and a diagnostics entry is released. The CPU switches to STOP after 72 hours. With a just installed VSC activated functionalities remain activated.

 → 'Diagnostic entries'...page 114

After this the CPU switches to the operating mode, which is set on the operating mode switch.

Delivery state

In the delivery state the CPU is overall reset. After a STOP→RUN transition the CPU switches to RUN without program.

Addressing > Default address assignment of the I/O part

4.4 Addressing

4.4.1 Overview

To provide specific addressing of the installed peripheral modules, certain addresses must be allocated in the CPU. This address mapping is in the CPU as hardware configuration. If there is no hardware configuration, depending on the slot, the CPU assigns automatically peripheral addresses for digital in-/output modules starting with 0 and analog modules are assigned to even addresses starting with 256.

4.4.2 Default address assignment of the I/O part

Sub module	Input address	Access	Assignment
AI5/AO2	800	WORD	Analog input channel 0 (X6)
	802	WORD	Analog input channel 1 (X6)

Sub module	Input address	Access	Description
DI24/DO16 136 137	136	BYTE	Digital input I+0.0 I+0.7 (X1)
	137	BYTE	Digital input I+1.0 I+1.7 (X5)

Sub module	Input address	Access	Description
Counter	816	DINT	Channel 0: Counter value / Frequency value
	820	DINT	Channel 1: Counter value / Frequency value
	824	DINT	Channel 2: Counter value / Frequency value
	828	DINT	Channel 3: Counter value / Frequency value

Sub module	Output address	Access	Description
DI24/DO16	136	BYTE	Digital output Q+0.0 Q+0.7 (X2)
	137	BYTE	Digital output Q+1.0 Q+1.3 (X6)

Sub module	Output address	Access	Description
Counter	816	DWORD	reserved
	820	DWORD	reserved
	824	DWORD	reserved
	828	DWORD	reserved


Addressing > Option: Addressing periphery modules

4.4.3 Option: Addressing periphery modules

The CPU M13-CCF0001 provides an I/O area (address 0 ... 2047) and a process image of the in- and outputs (each address default 0 ... 127). The size of the process image can be preset via the parameterization. → 'Setting standard CPU parameters'...page 79

The process image is updated automatically when a cycle has been completed. The process image is divided into two parts:

- process image to the inputs (PII)
- process image to the outputs (PIQ)



- 1 I/O area: 0 ... 127 (default)
- 2 I/O area: 0 ... 2047
- 3 Process image of the inputs (PII): 0 ... 127
- 4 Process image of the inputs (PII) max.: 2047
- 5 Process image of the outputs (PIQ): 0 ... 127
- 6 Process image of the outputs (PIQ) max.: 2047

Max. number of pluggable modules

Up to 8 periphery modules can be connected to the CPU.

Define addresses by hardware configuration

You may access the modules with read res. write accesses to the peripheral bytes or the process image. To define addresses a hardware configuration may be used. For this, click on the properties of the according module and set the wanted address.

Automatic addressing

If you do not like to use a hardware configuration, an automatic addressing is established. Here the address assignment follows the following specifications:

- Starting with slot 1, the central plugged modules are assigned with ascending logical addresses.
- The length of the memory area corresponds to the size of the process data of the according module. Information about the sizes of the process data can be found in the according manual of the module.
- The memory areas of the modules are assigned without gaps separately for input and output area.
- Digital modules are mapped starting at address 0 and all other modules are mapped starting from address 256.
- As soon as the mapping of digital modules exceeds the address 256, by regarding the order, these are mapped starting from address 256.

Hardware configuration - CPU

4.5 Hardware configuration - CPU

Precondition

- The configuration of the CPU takes place at the 'hardware configurator' of the Siemens SIMATIC Manager V 5.5 SP2 and up.
- The configuration of the System MICRO CPU happens by means of a virtual PROFINET IO device '... MICRO PLC'. The '... MICRO PLC' is to be installed in the hardware catalog by means of the GSDML.



For project engineering a thorough knowledge of the Siemens SIMATIC Manager and the Siemens hardware configurator is required!

Installing the IO device ... MICRO PLC

The installation of the PROFINET IO devices '... MICRO PLC' happens in the hardware catalog with the following approach:

- 1. Go to the 'Download Center' of www.yaskawa.eu.com.
- **2.** Load from the download area under 'GSDML MICRO' the GSDML file V107 and up for your System MICRO.
- **3.** Extract the file into your working directory.
- **4.** Start the Siemens hardware configurator.
- 5. Close all the projects.
- **6.** Select 'Options → Install new GSD file'
- 7. Navigate to your working directory and install the according GSDML file.
 - **→** After the installation according PROFINET IO device can be found at 'PROFINET IO → Additional field devices → I/O → ... Micro System'

Proceeding


In the Siemens SIMATIC Manager the following steps should be executed:

- 1. Start the Siemens hardware configurator with a new project.
- 2. Insert a profile rail from the hardware catalog.
- 3. Place at 'Slot' number 2 the CPU 314C-2 PN/DP (314-6EH04-0AB0 V3.3).

Slot	Module
1	
2	CPU 314C-2PN/DP
X1	MPI/DP
X2	PN-IO
X2	Port 1
X2	Port 2
3	

- 4. Click at the sub module 'PN-IO' of the CPU.
- **5.** Select 'Context menu → Insert PROFINET IO System'.

Hardware configuration - CPU



6. Use [New] to create a new subnet and assign valid IP address data for your PROFINET system.




With firmware version V2.4.0 and up, you can access the Ethernet PG/OP channel via this IP address data. The configuration via an additional CP is no longer required, but still possible. → 'Hardware configuration - Ethernet PG/OP channel'...page 74

- 7. Click at the sub module 'PN-IO' of the CPU and open with 'Context menu → Properties' the properties dialog.
- **8.** Enter at 'General' a 'Device name'. The device name must be unique at the Ethernet subnet.



Please leave 'Send clock' in Tab 'PROFINET' at 1ms, otherwise this leads to a configuration error!



0	MICRO CPU	M13-CCF0000	
X2	M13-CCF0000		
1			
2			
3			

- 9. Navigate in the hardware catalog to the directory 'PROFINET IO → Additional field devices → I/O → ... Micro System' and connect the IO device M13-CCF0001 to your PROFINET system.
 - ▶ In the slot overview of the PROFINET IO device '... MICRO PLC' the CPU is already placed at slot 0.

Hardware configuration - Ethernet PG/OP channel


4.6 Hardware configuration - System MICRO modules

System MICRO backplane bus

Proceeding

To connect System MICRO modules, the CPU has a backplane bus, which is supplied by the CPU. Here up to 8 System MICRO modules can be connected.

- 1. ▶ Perform, if not already done, a hardware configuration for the CPU. → 'Hardware configuration CPU'...page 72
- 2. Starting with slot 1 place in the slot overview of the PROFINET IO device '... MICRO PLC' your System MICRO modules in the plugged sequence.
- **3.** Parameterize if necessary the modules and assign valid addresses, so that they can directly be addressed.



4.7 Hardware configuration - Ethernet PG/OP channel

Overview



Please note!

- At the first commissioning respectively after a reset to factory setting the Ethernet interface has no IP address.
- For online access, you have to assign valid IP address data to it by means of "Initialization".
- After initialization, you can transfer the IP address data to your project.

The CPU has an integrated Ethernet PG/OP channel. This channel allows you to program and remote control your CPU.

- The Ethernet PG/OP channel (X3/X4) is designed as switch. This enables PG/OP communication via the connections X3 and X4.
- Configurable connections are possible.
- DHCP respectively the assignment of the network configuration with a DHCP server is supported.
- Default diagnostics addresses: 2025 ... 2040
- Via the Ethernet PG/OP channel, you have access to:
 - Device website, where you can find information on firmware status, connected peripherals, current cycle times, etc.
 - OPC UA project, which is to be created in the OPC UA Configurator.

Hardware configuration - Ethernet PG/OP channel

- WebVisu project, which is to be created in the SPEED7 Studio.
- PROFINET IO controller or the PROFINET I-Device.

Assembly and commissioning

- 1. Install your System MICRO with your CPU.
- 2. Wire the system by connecting cables for voltage supply and signals.
- 3. Connect the one of the Ethernet jacks (X3, X4) of the Ethernet PG/OP channel to Ethernet.
- **4.** Switch on the power supply.
 - → After a short boot time the CP is ready for communication. It possibly has no IP address data and requires an initialization.

"Initialization" via PLC functions

The initialization via PLC functions takes place with the following proceeding:

Determine the current Ethernet (MAC) address of your Ethernet PG/OP channel. This can be found at the front of your CPU with the name "MAC PG/OP: ...".

X3 PG/OP





X4 PG/OP





MAC PG/OP: 00-20-D5-77-05-10

Assign IP address parameters

You get valid IP address parameters from your system administrator. The assignment of the IP address data happens online in the Siemens SIMATIC Manager starting with version V 5.5 & SP2 with the following proceeding:

- Start the Siemens SIMATIC Manager and set via 'Options → Set PG/PC interface'the access path to 'TCP/IP -> Network card'.
- 2. ▶ Open with 'PLC → Edit Ethernet Node n' the dialog window with the same name.
- 3. To get the stations and their MAC address, use the [Browse] button or type in the MAC Address. The Mac address may be found at the 1. label beneath the front flap of the CPU.
- **4.** Choose if necessary the known MAC address of the list of found stations.
- 5. Either type in the IP configuration like IP address, subnet mask and gateway.
- **6.** ▶ Confirm with [Assign IP configuration].
 - ➡ Direct after the assignment the Ethernet PG/OP channel may be reached online by these address data. The value remains as long as it is reassigned, it is overwritten by a hardware configuration or an factory reset is executed.

Hardware configuration - Ethernet PG/OP channel > Take IP address parameters in project

4.7.1 Take IP address parameters in project

2 variants for configuration

From firmware version V2.4.0 and up, you have the following options for configuring the Ethernet PG/OP channel:

- Configuration via integrated CPU interface (firmware version V2.4.0 and up only).
- Configuration via additional CP (all firmware versions).

4.7.1.1 Configuration via integrated CPU interface


Proceeding

From firmware version V2.4.0 this variant for configuration is recommended. The following advantages result:


- The configuration becomes clearer, because the periphery modules and the PROFINET IO devices are configured on the PROFINET line of the CPU and no additional CP is to be configured.
- There are no address collisions, because the S7 addresses for all components are assigned from the address area of the CPU.

Unless during the hardware configuration of the CPU → 72 there was no IP address data assigned yet or these are to be changed, the configuration happens to the following proceeding, otherwise the Ethernet PG/OP channel is configured.

- 1. Open the Siemens hardware configurator and, if not already done, configure the Siemens CPU 314C-2 PN/DP (314-6EH04-0AB0 V3.3).
- 2. Open the PROFINET Properties dialog box of the CPU by double-clicking 'PN-IO'.



- 3. Click at 'General'.
- 4. At 'Properties', enter the previously assigned IP address data and a subnet. The IP address data are not accepted without subnet assignment!
- 5. Transfer your project.




1 Ethernet PG/OP channel

Hardware configuration - Ethernet PG/OP channel > Take IP address parameters in project

4.7.1.1.1 Time-of-day synchronization

NTP method

In the NTP mode (Network Time Protocol) the module sends as client time-of-day queries at regular intervals to all configured NTP servers within the sub net. You can define up to 4 NTP server. Based on the response from the servers, the most reliable and most exact time-of-day is determined. Here the time with the lowest *stratum* is used. *Stratum 0* is the time standard (atomic clock). *Stratum 1* are directly linked to this NTP server. Using the NTP method, clocks can be synchronized over subnet boundaries. The configuration of the NTP servers is carried out in the Siemens SIMATIC Manager via the CP, which is already configured.



- 1. Den the Properties dialog by double-clicking 'PN-IO'.
- 2. Select the tab 'Time-of-day synchronization'.
- 3. Activate the NTP method by enabling 'Activate NTP time-of-day synchronization'.
- 4. Click at [Add] and add the corresponding NTP server.
- **5.** Set the *'Update interval'* you want. Within this interval, the time of the module is synchronized once.
- 6. ▶ Close the dialog with [OK].
- 7. Save and transfer your project to the CPU.
 - → After transmission, the NTP time is requested by each configured time server and the best response for the time synchronization is used.



Please note that although the time zone is evaluated, an automatic changeover from winter to summer time is not supported. Industrial systems with time-of-day synchronization should always be set in accordance to the winter time.

With the FC 61 you can determine the local time in the CPU. More information about the usage of this block may be found in the manual "SPEED7 Operation List".

4.7.1.2 Configuration via additional CP

Proceeding

This is the conventional variant for configuration and is supported by all firmware versions. If possible, always use the configuration via the internal interface, otherwise the following disadvantages result:

- Address overlaps are not recognized in the Siemens SIMATIC Manager.
- For PROFINET devices only the address range 0 ... 1023 is available.
- The addresses of the PROFINET devices are not checked with the address range of the CPU by the Siemens SIMATIC Manager for address overlaps.

The configuration happens according to the following procedure:

1. Open the Siemens hardware configurator and, if not already done, configure the Siemens CPU 314C-2 PN/DP (314-6EH04-0AB0 V3.3).

Hardware configuration - Ethernet PG/OP channel > Take IP address parameters in project


Place for the Ethernet PG/OP channel at slot 4 the Siemens CP 343-1 (SIMATIC 300 \ CP 300 \ Industrial Ethernet \ CP 343-1 \ 6GK7 343-1EX30 0XE0 V3.0).



CAUTION

Please configure the diagnostic addresses of the CP343-1EX30 for 'PN-IO', 'Port1' and 'Port2' so that no overlaps occur in the periphery input area. Otherwise your CPU can not start-up and you receive the diagnostic entry 0xE904. These addresses overlaps are not recognized by the Siemens SIMATIC Manager.

- 3. Open the Properties dialog by double-clicking on 'PN-IO' of the CP 343-1EX30 and enter the previously assigned IP address data and a subnet for the CP at 'Properties'. The IP address data are not accepted without subnet assignment!
- 4. Transfer your project.




1 Ethernet PG/OP channel

4.7.1.2.1 Time-of-day synchronization

NTP method

In the NTP mode (Network Time Protocol) the module sends as client time-of-day queries at regular intervals to all configured NTP servers within the sub net. You can define up to 4 NTP server. Based on the response from the servers, the most reliable and most exact time-of-day is determined. Here the time with the lowest *stratum* is used. *Stratum 0* is the time standard (atomic clock). *Stratum 1* are directly linked to this NTP server. Using the NTP method, clocks can be synchronized over subnet boundaries. The configuration of the NTP servers is carried out in the Siemens SIMATIC Manager via the CP, which is already configured.



- 1. Dopen the properties dialog via double-click on the CP 343-1EX30.
- 2. Select the tab 'Time-of-day synchronization'.
- 3. Activate the NTP method by enabling 'Activate NTP time-of-day synchronization'.
- 4. Click at [Add] and add the corresponding NTP server.
- 5. Select your 'Time zone'. In the NTP method, UTC (Universal Time Coordinated) is generally transmitted; this corresponds to GMT (Greenwich Mean Time). By configuring the local time zone, you can set a time offset to UTC.
- **6.** Set the *'Update interval'* you want. Within this interval, the time of the module is synchronized once.
- 7. Close the dialog with [OK].
- **8.** Save and transfer your project to the CPU.
 - → After transmission, the NTP time is requested by each configured time server and the best response for the time synchronization is used.

Setting standard CPU parameters > Parameter CPU

Ŋ

Please note that although the time zone is evaluated, an automatic changeover from winter to summer time is not supported. Industrial systems with time-of-day synchronization should always be set in accordance to the winter time.


With the FC 61 you can determine the local time in the CPU. More information about the usage of this block may be found in the manual "SPEED7 Operation List" from Yaskawa.

4.8 Setting standard CPU parameters

4.8.1 Parameterization via Siemens CPU

Parametrization via Siemens CPU 314-6EH04

Since the CPU is to be configured as Siemens CPU 314C-2 PN/DP (314-6EH04-0AB0 V3.3) in the Siemens hardware configurator, the standard parameters of the CPU may be set with "Object properties" of the CPU 314C-2 PN/DP during hardware configuration. Via a double-click on the CPU 314C-2 PN/DP the parameter window of the CPU may be accessed. Using the registers you get access to every standard parameter of the CPU.



4.8.2 Parameter CPU

Supported parameters

The CPU does not evaluate each parameter, which may be set at the hardware configuration. The parameters of the following registers are not supported: Synchronous cycle interrupts, communication and web. The following parameters are currently supported:

General

- Short description
 - The short description of the Siemens CPU is CPU 314C-2 PN/DP (314-6EH04-0AB0 V3.3).
- Order No. / Firmware
 - Order number and firmware are identical to the details in the "hardware catalog" window.
- Name
 - The Name field provides the short description of the CPU.
 - If you change the name the new name appears in the Siemens SIMATIC Manager.
- Plant designation
 - Here is the possibility to specify a plant designation for the CPU.
 - This plant designation identifies parts of the plant according to their function.
 - Its structure is hierarchic according to IEC 81346-1.
- Location designation
 - The location designation is part of the resource designation.
 - Here the exact location of your module within a plant may be specified.
- Comment
 - In this field information about the module may be entered.

Setting standard CPU parameters > Parameter CPU

Startup

- Startup when expected/actual configuration differs
 - If the checkbox for 'Startup when expected/actual configuration differ' is deselected and at least one module is not located at its configured slot or if another type of module is inserted there instead, then the CPU does not switch to RUN mode and remains in STOP mode.
 - If the checkbox for 'Startup when expected/actual configuration differ' is selected, then the CPU starts even if there are modules not located in their configured slots of if another type of module is inserted there instead, such as during an initial system start-up.
- Monitoring time for ready message by modules [100ms]
 - This operation specifies the maximum time for the ready message of every configured module after PowerON.
 - Here connected PROFIBUS DP slaves are also considered until they are parameterized.
 - If the modules do not send a ready message to the CPU by the time the monitoring time has expired, the actual configuration becomes unequal to the preset configuration.
- Monitoring time for transfer of parameters to modules [100ms]
 - The maximum time for the transfer of parameters to parameterizable modules.
 - Here connected PROFINET IO devices also considered until they are parameterized.
 - If not every module has been assigned parameters by the time this monitoring time has expired; the actual configuration becomes unequal to the preset configuration.

Cycle / Clock memory

- Update OB1 process image cyclically
 - This parameter is not relevant.
- Scan cycle monitoring time
 - Here the scan cycle monitoring time in milliseconds may be set.
 - If the scan cycle time exceeds the scan cycle monitoring time, the CPU enters the STOP mode.
 - Possible reasons for exceeding the time are:
 - Communication processes
 - a series of interrupt events
 - an error in the CPU program
- Minimum scan cycle time
 - This parameter is not relevant.
- Scan cycle load from Communication
 - Using this parameter you can control the duration of communication processes, which always extend the scan cycle time so it does not exceed a specified length.
 - If the cycle load from communication is set to 50%, the scan cycle time of OB 1 can be doubled. At the same time, the scan cycle time of OB 1 is still being influenced by asynchronous events (e.g. hardware interrupts) as well.
- Size of the process image input/output area
 - Here the size of the process image max. 2048 for the input/output periphery may be fixed (default: 256).
- OB85 call up at I/O access error
 - The preset reaction of the CPU may be changed to an I/O access error that occurs during the update of the process image by the system.
 - The CPU is preset such that OB 85 is not called if an I/O access error occurs and no entry is made in the diagnostic buffer either.
- Clock memory
 - Activate the check box if you want to use clock memory and enter the number of the memory byte.

Setting standard CPU parameters > Parameter CPU

 \int_{1}^{∞}

The selected memory byte cannot be used for temporary data storage.

Retentive Memory

- Number of Memory bytes from MB0
 - Enter the number of retentive memory bytes from memory byte 0 onwards.
- Number of S7 Timers from T0
 - Enter the number of retentive S7 timers from T0 onwards. Each S7 timer occupies 2bytes.
- Number of S7 Counters from C0
 - Enter the number of retentive S7 counter from C0 onwards.
- Areas
 - This parameter is not supported.

Interrupts

Priority

 Here the priorities are displayed, according to which the hardware interrupt OBs are processed (hardware interrupt, time-delay interrupt, async. error interrupts).

Time-of-day interrupts

- Priority
 - This value is fixed to 2.
- Active
 - By enabling 'Active' the time-of-day interrupt function is enabled.
- Execution
 - Select how often the interrupts are to be triggered.
 - Intervals ranging from every minute to yearly are available. The intervals apply to the settings made for start date and time.
- Start date/time
 - Enter date and time of the first execution of the time-of-day interrupt.
- Process image partition
 - This parameter is not supported.

Cyclic interrupts

Priority

 Here the priorities may be specified according to which the corresponding cyclic interrupt is processed.

Execution

- Enter the time intervals in ms, in which the watchdog interrupt OBs should be processed.
- The start time for the clock is when the operating mode switch is moved from STOP to RUN.

Phase offset

- Enter the delay time in ms for current execution for the watch dog interrupt. This should be performed if several watchdog interrupts are enabled.
- Phase offset allows to distribute processing time for watchdog interrupts across the cycle.
- Process image partition
 - This parameter is not supported.

Setting product specific CPU parameters

Diagnostics/Clock

Report cause of STOP

- Activate this parameter, if the CPU should report the cause of STOP to PG respectively OP on transition to STOP.
- Number of messages in the diagnostics buffer
 - This parameter is ignored. The CPU always has a diagnostics buffer (circular buffer) for 100 diagnostics messages.
- Synchronization type
 - Here you specify whether clock should synchronize other clocks or not.
 - as slave: The clock is synchronized by another clock.
 - as master: The clock synchronizes other clocks as master.
 - none: There is no synchronization
- Time interval
 - Time intervals within which the synchronization is to be carried out.
- Correction factor
 - Lose or gain in the clock time may be compensated within a 24 hour period by means of the correction factor in ms.
 - If the clock is 1s slow after 24 hours, you have to specify a correction factor of "+1000" ms.

Protection

Level of protection

- Here 1 of 3 protection levels may be set to protect the CPU from unauthorized access.
- Protection level 1 (default setting):
 - No password adjustable, no restrictions
- Protection level 2 with password:

Authorized users: read and write access Unauthorized user: read access only

Protection level 3:


Authorized users: read and write access
Unauthorized user: no read and write access

4.9 Setting product specific CPU parameters

Overview

Except of the product specific CPU parameters the CPU parametrization takes place in the parameter dialog of the CPU 314C-2 PN/DP (314-6EH04-0AB0 V3.3) from Siemens. After the hardware configuration of the CPU you can set the parameters of the CPU in the virtual IO device '... MICRO PLC'. Via double-click at '... MICRO PLC M13-CCF0001' the properties dialog is opened.

Setting product specific CPU parameters



Here the following parameters may be accessed:

- Diagnostics
 - Diagnostics interrupt DI power section supply
 - Diagnostics interrupt DO power section supply
 - Diagnostics interrupt DO short circuit/overload
- Retentive data
 - Additional retentive memory, timer respectively counter
- OB
 - Call OB 80 on cyclic interrupt
- Miscellaneous
 - PN MultipleWrite
 - Free Module Mapping → 85
 - Reduced PDU size
- Access settings → 89 CPU
 - Activation of interfaces and ports
 - Activation of protocols

Setting product specific CPU parameters

Parameter

The following parameters may be accessed by means of the properties dialog of the CPU.

- Diagnostics interrupt (default: deactivated)
 - Diagnostic interrupt DI power section supply
 Error: 3L+ (Dc 24v power section supply) missing respectively < 19 V
 - Diagnostic interrupt DO power section supply
 Error: 4L+ (DC 24V DO power section supply) missing respectively < 19 V
 - Diagnostics interrupt DO short circuit/overload
 Error: Short circuit or overload of a digital output respectively current exceeds 0.5A

Retentive data

- Additional retentive memory
 - Here enter the number of memory bytes. With 0 the value 'Retentive memory
 → Number of memory bytes starting with MB0' is set, which is pre-set at the
 parameters of the Siemens CPU.
 - Range of values: 0 (default) ... 8192
- Additional retentive timer
 - Enter the number of S7 timers. With 0 the value 'Retentive memory → Number S7 timers starting with T0' is set, which is pre-set at the parameters of the Siemens CPU.
 - Range of values: 0 (default) ... 512
- Additional retentive counter
 - Enter the number of S7 counter. With 0 the value 'Retentive memory → Number S7 counters starting with C0' is set, which is pre-set at the parameters of the Siemens CPU.
 - Range of values: 0 (default) ... 512

OB

- OB 80 for cyclic interrupt error
 - Here you can set for which cyclic interrupt OB 80 (time error) should be called.
 - Range of values: Deactivated (default), selection of the corresponding OB

Miscellaneous

- PN MultipleWrite
 - In the activated state, parameter record sets are combined at PROFINET to one or more Ethernet frames during the connection setup. This speeds up the connection setup, since a separate Ethernet frame is not used for each parameter record set.
- Free Module Mapping → 85
 - When activated, you can use your CPU in different hardware variants.
 - You specify the mapping at runtime with record set 0x7F.
- Reduced PDU size
 - When activated, the PDU size is reduced accordingly.
 - For some protocols, some configuration tools require a reduced PDU size. For example, in the Siemens TIA Portal for variable forcing, the PDU size must be reduced. For the processing of single steps at several breakpoints, the PDU size must also be reduced.

Access settings → 89

- When activated, you have access to the interface or the corresponding communication protocol.
- By default, there is no access restriction.

4.9.1 Free Module Mapping (FMM)

4.9.1.1 Overview

- With *FMM* you can use your CPU in different hardware variants without adapting your user program. You only have to adapt the FMM configuration in the CPU when configuring the hardware variants. Here you have the following possibilities:
 - Modules from the target configuration can be divided in any order to the slots of the actual configuration.
 - Modules from the target configuration may be missing in the actual configuration.
 - Individual slots of the target configuration can be deactivated, on which modules are located in the actual configuration.
- FMM is a functionality of Yaskawa and is only supported by Yaskawa modules.
- By default, FMM is disabled. To use FMM mapping, you must enable the CPU parameter 'Free Module Mapping'.
- For the FMM the mapping of the slots is to be specified via the record set 0x7F.
- For commissioning, you have to enable the parameter 'Startup when expected/actual configuration differs' in your CPU.
- If FMM is activated and configured correctly, the system reacts as follows:
 - During start-up, no target/actual difference of the hardware is diagnosed.
 - Output data of missing modules are ignored and not output.
 - Input data of missing modules are set to 0.

4.9.1.2 FMM configuration

Configuration

- The mapping of the modules is defined as configuration by the 64byte record set 0x7F.
- The data record is retentively stored in the CPU.
- The record set must be transferred to the CPU by the user program by means of a write command.
- With the record set read command parts of the active configuration can be read. You have always to write the complete record set.
- Each written and valid configuration is only saved if a difference to the existing configuration exists.

Record set 0x7F

Record set 0x7F						
Byte	0	1	2	3		63
Mapping						

- The record 0x7F has a length of 64Byte, where Byte 0 ... 63 corresponds to the slot 1 ... 64 of the target configuration.
- For the FMM configuration, you must specify for each used slot of the target configuration at 'Mapping' the corresponding value that corresponds to the actual configuration.

The following values can be entered at Mapping:

- 0 (0x00) module is ignored
 - If modules of the target configuration are to be ignored, the value 0x00 must be used. In this way, gaps can be projected.
- 1 ... 64 (0x01 ... 0x40) position of the module in the actual configuration
 - 'Mapping' corresponds to the value of Slot_{actual} i.e. the slot of the actual configuration on which the module of the target configuration is located.
- 255 (0xFF) virtual module
 - If a module from the target configuration is missing, for Mapping the value 255 for "virtual module" is to be used.
 - Behaviour of a virtual module:

- The input area always has the value 0, regardless of its size.
- The writing to the output area has no effect.

Commissioning

The target configuration serves as template for the configuration of hardware variants.

- 1. Configure your system with a hardware configuration as target configuration and create your user program. The target configuration represents a superset of all available hardware variants.
- 2. Activate the parameter 'Free Module Mapping' in your CPU.
- 3. Activate the parameter 'Startup when expected/actual configuration differs' in your CPU.
- **4.** Create the configuration by defining the deviation of the actual and target configuration for the current hardware configuration in record set 0x7F.
- <u>5.</u>

Transfer this record set via write command to your CPU.

- For this use SFB 53 or SFB 58.
- The address to be used is the diagnostic address of the CPU in the virtual IO device '... MICRO CPU'.
- → The configuration is permanently stored in the CPU and immediately active.

4.9.1.3 Examples



Slot_{target} The mapping always refers to the slot of the target configuration.

Based on the target configuration, the following examples show how to determine the mapping values for the hardware variants.

4.9.1.3.1 Examples of hardware variants

Variant 1: Same type and number of modules but reversed slots

Record set 0x7F	

Determination of *Mapping* values of record set 0x7F:

- Byte 0: The module of $Slot_{target} = 1$ is in the actual configuration at $Slot_{actual} = 2 \rightarrow Mapping = 0x02$
- Byte 1: The module of $Slot_{target} = 2$ is in the actual configuration at $Slot_{actual} = 1 \rightarrow Mapping = 0x01$
- Byte 2: The module of $Slot_{target} = 3$ is in the actual configuration at $Slot_{actual} = 3 \rightarrow Mapping = 0x03$
- Byte 3: The module of $Slot_{target} = 4$ is in the actual configuration at $Slot_{actual} = 5 \rightarrow Mapping = 0x05$
- Byte 4: The module of Slot_{target} = 5 is in the actual configuration at Slot_{actual} = 6 → Mapping = 0x06
- Byte 5: The module of $Slot_{target} = 6$ is in the actual configuration at $Slot_{actual} = 4 \rightarrow Mapping = 0x04$

Slot_{target} The mapping always refers to the slot of the target configuration.

Slot_{actual} Slot of the actual configuration on which the module of the target configuration

is located.

Mapping For variant 1, *Mapping* corresponds to *Slot_{actual}*, i.e. slot of the actual configu-

ration on which the module of the target configuration is located.

Variant 2: Reversed slots and modules are missing

(1): Tar	(1): Target configuration						Slot _{target} Slot _{actual}		Record s	et 0x7F
(2): Actual configuration									Byte	Mapping
Slot	1	2	3	4	5	6	1	1	0	0x01
							2	-	1	0xFF
(1)	DI	DO X	DIO	Al	AO	DI X	3	2	2	0x02
-					4	3	3	0x03		
_	\	K			ı		5	4	4	0x04
2	DI	DIO	Al	АО			6	-	5	0xFF

Determination of *Mapping* values of record set 0x7F:

- Byte 0: The module of $Slot_{target} = 1$ is in the actual configuration at $Slot_{actual} = 1 \rightarrow Mapping = 0x01$
- Byte 1: The module of $Slot_{target}$ = 2 is not available in the actual configuration \rightarrow Mapping = 0xFF
- Byte 2: The module of $Slot_{target} = 3$ is in the actual configuration at $Slot_{actual} = 2 \rightarrow Mapping = 0x02$
- Byte 3: The module of $Slot_{target} = 4$ is in the actual configuration at $Slot_{actual} = 3 \rightarrow Mapping = 0x03$
- Byte 4: The module of $Slot_{target} = 5$ is in the actual configuration at $Slot_{actual} = 4 \rightarrow Mapping = 0x04$
- Byte 5: The module of $Slot_{target}$ = 6 is not available in the actual configuration \rightarrow Mapping = 0xFF

Slot_{target} The mapping always refers to the slot of the target configuration.

Slot of the actual configuration on which the module of the target configuration

is located.

Mapping For variant 2, *Mapping* corresponds to the value of *Slot_{actual}*, i.e. slot of the actual configuration on which the module of the target configuration is located. If a module from the target configuration is missing, for *Mapping* the value

0xFF for "virtual module" is to be used.

Setting product specific CPU parameters > Access settings

Variant 3: Modules are ignored

(1): Tar	(1): Target configuration						Slot _{target}	Slot _{actual}	Record s	Record set 0x7F	
(2): Actual configuration								Byte	Mapping		
Slot	: 1	2	3	4	5	6	1	empty	0	0x00	
							2	empty	1	0x00	
(1)	DI	DO	DIO	Al	AO	DI	3	3	2	0x03	
	!	!		1			4	4	3	0x04	
	, , ,	, - -	+	+	+	\	5	5	4	0x05	
							6	6	5	0x06	
2	DI	DO	DIO	ΑI	AO	DI					
	DI	ВО	DIO	AI	AU	וט					

Determination of *Mapping* values of record set 0x7F:

- Byte 0: The module of $Slot_{target} = 1$ is ignored in the actual configuration \rightarrow Mapping = 0x00
- Byte 1: The module of Slot_{target} = 2 is ignored in the actual configuration → Mapping = 0x00
- Byte 2: The module of $Slot_{target} = 3$ is in the actual configuration at $Slot_{actual} = 3 \rightarrow Mapping = 0x03$
- Byte 3: The module of Slot_{larget} = 4 is in the actual configuration at Slot_{actual} = 4 → Mapping = 0x04
- Byte 4: The module of $Slot_{target} = 5$ is in the actual configuration at $Slot_{actual} = 5 \rightarrow Mapping = 0x05$
- Byte 5: The module of $Slot_{target} = 6$ is in the actual configuration at $Slot_{actual} = 6 \rightarrow Mapping = 0x06$

Slot_{target} The mapping always refers to the slot of the target configuration.

Slot actual Slot of the actual configuration on which the module of the target configuration

is located.

Mapping For variant 3, *Mapping* corresponds to the value of *Slot_{actual}*, i.e. slot of the actual configuration on which the module of the target configuration is located. If modules of the target configuration are to be ignored, for *Mapping* the value

0x00 is to be used.

 $\hat{\mathbb{I}}$

The presence of gaps in the System MICRO is not allowed! But you can place modules and define them via the configuration as empty slot for the target hardware configuration.

4.9.2 Access settings

Overview

- The 'Access setting' allows you to disable access to ports or protocols.
- The CPU has an integrated *Device web page* that shows information about the access ways via 'Access Ways'. → 'Device web page CPU'...page 93

Ethernet Port

Here you can disable individual Ethernet interfaces.

ĭ

Please note that by disabling e.g. the Ethernet PG/OP channel after transferring the hardware configuration, the CPU can no longer be configured via this Ethernet PG/OP channel. The access setting can be reset by an overall reset.

Project transfer > Transfer via Ethernet

Ethernet protocol

Here you can disable Ethernet protocols. If a protocol is disabled, requests via the disabled protocol will be rejected.

- TCP/UDP/IP services
 - NTP protocol protocol for time synchronization between the stations.
 - OPC UA protocol for access to an OPC UA project in the CPU.
 - Open communication protocol for communication via the user program when using handling blocks.
 - Device WebSite protocol for access to the integrated web server.
 - Web Visu protocol for access to the Web visualization in the CPU, which can be configured accordingly.
- S7 connections
 - PG/OP protocol protocol for PG/OP communication via Siemens S7 connections.
 - PG/OP Routing routing requests via Siemens S7 connections.
 - NetPro connections protocol for communication between PLC systems based on Siemens STEP®7 by means of configured communication connections.
- Other services
 - DCP frame for determining accessible nodes on PROFINET
 - LLDP frame for determining the topology on PROFINET
 - Field bus PN communication via PROFINET frames

 \int_{1}^{0}

Please regard that with the deactivation of the communication via PROFINET telegrams the DCP protocol is also deactivated!

MPI/PB protocol via X3

Here you can deactivate protocols for the MPI(PB) interface X3. If a protocol is disabled, requests via the disabled protocol will be rejected.

- MPI(PB) PG/OP protocol protocol for PG/OP communication via the MPI(PB) interface X3.
- MPI(PB) Routing routing requests via the MPI(PB) interface X3.
- Field bus PB communication via PROFIBUS.
- Global data communication Global data communication protocol for cyclic data exchange between CPUs via the MPI interface.

4.10 Project transfer

Overview

There is the following possibility for project transfer into the CPU:

- Transfer via Ethernet
- Transfer via memory card
- Option: Transfer via MPI → 'Option: Transfer via MPI'...page 91

4.10.1 Transfer via Ethernet

Initialization

So that you may access the according Ethernet interface you have to assign IP address parameters by means of the "initialization".

- X3/X4: Ethernet PG/OP channel
 - → 'Hardware configuration Ethernet PG/OP channel'...page 74

Project transfer > Option: Transfer via MPI

Transfer

- 1. For the transfer, connect, if not already done, the appropriate Ethernet port to your Ethernet.
- 2. Open your project with the Siemens SIMATIC Manager.
- 3. Set via 'Options \rightarrow Set PG/PC Interface' the access path to "TCP/IP \rightarrow Network card".
- Click to 'PLC → Download' Download → the dialog "Select target module" is opened. Select your target module and enter the IP address parameters of the Ethernet PG/OP channel for connection. Provided that no new hardware configuration is transferred to the CPU, the entered Ethernet connection is permanently stored in the project as transfer channel.
- **5.** ▶ With [OK] the transfer is started.
 - Ŋ

System dependent you get a message that the projected system differs from target system. This message may be accepted by [OK].

→ Your project is transferred and may be executed in the CPU after transfer.

4.10.2 Transfer via memory card

Proceeding transfer via memory card

The memory card serves as external storage medium. There may be stored several projects and sub-directories on a memory card. Please regard that your current project is stored in the root directory and has one of the following file names:

- S7PROG.WLD
- AUTOLOAD.WLD
- 1. Start the Siemens SIMATIC Manager with your project
- 2. ▶ Create with 'File → Memory Card File → New' a new wld file.
- 3. ▶ Copy the blocks from the project blocks folder and the *System data* into the wld file.
- **4.** ▶ Copy the wld file at a suited memory card. Plug this into your CPU and start it again.
 - ➡ The transfer of the application program from the memory card into the CPU takes place depending on the file name after an overall reset or PowerON.

S7PROG.WLD is read from the memory card after overall reset.

AUTOLOAD.WLD is read from the memory card after PowerON.

The flickering of the yellow LED ______ of the status bar of the CPU marks the active transfer. Please regard that your user memory serves for enough space for your user program, otherwise your user program is not completely loaded and the red LED ______ of the status bar lights up.

4.10.3 Option: Transfer via MPI

General

For the transfer via MPI the use of the optionally available extension module EM M09 is required. The extension module provides the interface X2: MPI(PB) with fixed pin assignment.

'Mounting'...page 17

Net structure

The structure of a MPI net is electrically identical with the structure of a PROFIBUS net. This means the same rules are valid and you use the same components for the build-up. The single participants are connected with each other via bus interface plugs and PROFIBUS cables. Per default the MPI net runs with 187.5kbaud. The CPUs are delivered with MPI address 2.


Project transfer > Option: Transfer via MPI

MPI programming cable

The MPI programming cables are available at Yaskawa in different variants. The cables provide a RS232 res. USB plug for the PC and a bus enabled RS485 plug for the CPU. Due to the RS485 connection you may plug the MPI programming cables directly to an already plugged plug on the RS485 jack. Every bus participant identifies itself at the bus with an unique address, in the course of the address 0 is reserved for programming devices.

Terminating resistor


A cable has to be terminated with its surge impedance. For this you switch on the terminating resistor at the first and the last participant of a network or a segment. Please make sure that the participants with the activated terminating resistors are always power supplied. Otherwise it may cause interferences on the bus.





- 1 MPI programming cable
- 2 Activate the terminating resistor via switch
- 3 MPI network

Proceeding enabling the interface









2. Mount the extension module. → 'Mounting'...page 17



- **3.** Switch on the power supply.
 - → After a short boot time the interface X2 MPI(PB) is ready for MPI communication with the MPI address 2.

Approach transfer via MPI interface

- 1. Connect your PC to the MPI jack of your CPU via a MPI programming cable.
- 2. Load your project in the SIMATIC Manager from Siemens.
- 3. ▶ Choose in the menu 'Options → Set PG/PC interface'.
- Select in the according list the "PC Adapter (MPI)"; if appropriate you have to add it first, then click on [Properties].
- 5. Set in the register MPI the transfer parameters of your MPI net and type a valid address.
- **6.** ▶ Switch to the register *Local connection*.
- **7.** Set the COM port of the PCs and the transfer rate 38400baud for the MPI programming cable.

8. Transfer your project via 'PLC → Load to module' via MPI to the CPU and save it with 'PLC → Copy RAM to ROM' on a memory card if one is plugged.

4.11 Accessing the web server

Overview

The CPU has a web server integrated. This provides access via the Ethernet PG/OP channel to:

- Device web page
- CPU OPC UA project → 'Tab: 'OPC UA''...page 96→ 'Deployment OPC UA'...page 172
- CPU WebVisu project → 'Tab: 'WebVisu''...page 97→ 'Deployment WebVisu Web visualization'...page 198

4.11.1 Device web page CPU

Overview


- Dynamic web page, which exclusively outputs information.
- On the device web page you will find information about your CPU, the connected modules and your WebVisu project.
 - CPU
 - the connected modules
 - OPC UA project
 - WebVisu project
- The shown values cannot be changed.
- Access is via the IP address of the Ethernet PG/OP channel.
 - → 'Hardware configuration Ethernet PG/OP channel'...page 74
- You can access the IP address with a web browser.



It is assumed that there is a connection between PC and CPU with web browser via the Ethernet PG/OP channel. This may be tested by Ping to the IP address of the Ethernet PG/OP channel.

4.11.1.1 Web page with selected CPU

Tab: 'Info'



Name	Value	
Ordering Info	M13-CCF0001	Order number of the CPU
Serial		Serial number of the CPU
Version	01V	Version number of the CPU
HW Revision	01	CPU hardware revision
Software	3.0.13	CPU firmware version
Package	Pb000351.pkb	File name for the firmware update

[Expert View] takes you to the advanced "Expert View".

Runtime Information		CPU	
Operation Mode	RUN	Mode	
Mode Switch	RUNP		
System Time	18.01.21 08:34:14:486	Date, time	
Up Time	0 days 02 hrs 07 min 08 sec	Time to change the operating mode	
Last Change to RUN	n/a		
Last Change to STOP	18.01.21 16:09:03:494		
OB1-Cycle Time	cur = 0us, min = 0us, max = 0us,	Cyclic time:	
	avg = 0us	min = minimum	
		cur = current	
		max = maximum	
		avg = average	

Interface Information			Interface
X1/X5	DI 16	Address 136137	Digital input
	Counter	Address 816831	Counter
X2/X6	DO 12	Address 136137	Digital output
	AI 2	Address 800803	Analog input

Interface Informati						
Interface Information						Interface
		Counter		Addre	ess 816831	Counter
X3		PG/OP Eth	ernet Port 1	Addre	ess 2025 2040	Ethernet PG/OP channel
X4 PG/OP Ethe		ernet Port 2 Ad		ess 2025 2040		
Serial X1		PTP				PtP: Point to point operation (RS422/485)
Serial X2		MPI		Addre	ess 2047	Operating mode RS485
						MPI: MPI operation
						or
						PROFIBUS DP slave mode
Card Information						
No card inserted						Information about the memory card
Active Feature Set	· lafa	ation.				
No feature activate		lauon				Information about enabled functions
no leature activate	∌u					mormation about enabled functions
Memory Usage						CPU
	free		used		total	Information on the memory expansion
LoadMem	125.8	kbyte	2,2 kbyte		128.0 kbyte	Load memory, working memory (code/data)
WorkMemCode	62.0 k	byte	2,0 kbyte		64.0 kbyte	
WorkMemData	60.2 k	byte	3,8 kbyte		64.0 kbyte	
PG/OP Network In	format	ion				Ethernet PG/OP channel
Device Name			Onboard PG/OP			Name
IP Address		172.20.139.76				
IP Address			172.20.139	.76		Address information
Subnet Mask			172.20.139 255.255.25			Address information
				5.0		Address information
Subnet Mask			255.255.25	5.0 .76	7	Address information
Subnet Mask Gateway Address			255.255.25 172.20.139	5.0 .76 2:6C:2		Address information Link Mode and speed
Subnet Mask Gateway Address MAC Address			255.255.25 172.20.139 00:20:D5:02	5.0 .76 2:6C:2 Full D		
Subnet Mask Gateway Address MAC Address Link Mode X3	ormatio	n	255.255.25 172.20.139 00:20:D5:02 100 Mbps -	5.0 .76 2:6C:2 Full D		
Subnet Mask Gateway Address MAC Address Link Mode X3 Link Mode X4	ormatio	on	255.255.25 172.20.139 00:20:D5:02 100 Mbps -	5.0 .76 2:6C:2 Full D		Link Mode and speed
Subnet Mask Gateway Address MAC Address Link Mode X3 Link Mode X4 CPU Firmware Info	ormatio	on	255.255.25 172.20.139 00:20:D5:02 100 Mbps - Not Availab	5.0 .76 2:6C:2 Full Du		Link Mode and speed
Subnet Mask Gateway Address MAC Address Link Mode X3 Link Mode X4 CPU Firmware Info	ormatio	o n	255.255.25 172.20.139 00:20:D5:02 100 Mbps - Not Availab	5.0 .76 2:6C:2 Full Du		Link Mode and speed
Subnet Mask Gateway Address MAC Address Link Mode X3 Link Mode X4 CPU Firmware Info	ormatio	on	255.255.25 172.20.139 00:20:D5:02 100 Mbps - Not Availab V1.0.2 M13-CCF	5.0 .76 .2:6C:2 Full Di le		Link Mode and speed
Subnet Mask Gateway Address MAC Address Link Mode X3 Link Mode X4 CPU Firmware Info	ormatio	on	255.255.25 172.20.139 00:20:D5:02 100 Mbps - Not Availab V1.0.2 M13-CCF V3.0.13.0	5.0 .76 .2:6C:2 Full Di le		Link Mode and speed
Subnet Mask Gateway Address MAC Address Link Mode X3 Link Mode X4 CPU Firmware Info File System PRODUCT	ormatio	on	255.255.25 172.20.139 00:20:D5:02 100 Mbps - Not Availab V1.0.2 M13-CCF V3.0.13.0 Px000351.p	5.0 .76 .2:6C:2 Full Di le		Link Mode and speed CPU Name, firmware version, package
Subnet Mask Gateway Address MAC Address Link Mode X3 Link Mode X4 CPU Firmware Info File System PRODUCT	ormatio	o n	255.255.25 172.20.139 00:20:D5:02 100 Mbps - Not Availab V1.0.2 M13-CCF V3.0.13.0 Px000351.p	5.0 .76 2:6C:27 Full Di le		Link Mode and speed CPU Name, firmware version, package
Subnet Mask Gateway Address MAC Address Link Mode X3 Link Mode X4 CPU Firmware Info File System PRODUCT	ormatio	o n	255.255.25 172.20.139 00:20:D5:02 100 Mbps - Not Availab V1.0.2 M13-CCF V3.0.13.0 Px000351.p V0.1.0.0 5852A-V11	5.0 .76 2:6C:27 Full Di le F0001		Link Mode and speed CPU Name, firmware version, package
Subnet Mask Gateway Address MAC Address Link Mode X3 Link Mode X4 CPU Firmware Info File System PRODUCT HARDWARE	ormatio	on.	255.255.25 172.20.139 00:20:D5:02 100 Mbps - Not Availab V1.0.2 M13-CCF V3.0.13.0 Px000351.p V0.1.0.0 5852A-V11 MX000445.	5.0 .76 2:6C:27 Full Di le F0001		Link Mode and speed CPU Name, firmware version, package

CPU Firmware Information		CPU
fx000018.wld	V1.0.2.0	
syslibex.wld	n/a	
Protect.wld	n/a	
ARM Processor Load		CPU
Measurement Cycle Time	100 ms	Information for the support
Last Value	9%	
Average Of Last 10 Values	9%	
Minimum Load	9%	

Tab: 'IP' Here the IP address data of your Ethernet PG/OP channel are shown.

As of CPU firmware version V3.0.0, you can transfer the firmware file online to the CPU via the *'Firmware'* tab. The firmware update in the CPU is triggered by means of the

operating mode switch. → 'Firmware update'...page 104

Tab: 'Access Ways'


As of CPU firmware version V3.0.0, information about access settings is shown here. In the delivery state, there are no restrictions. You can specify access to interfaces, ports and protocols via the parametrization. → 'Setting product specific CPU parame-

ters'...page 82

4.11.1.1.1 Tab: 'OPC UA'

Tab: 'Firmware'

As of CPU firmware version V3.0.0, information about the *OPC UA* project is shown here. Deployment *OPC UA*...page 172



ì

For your CPU can process a OPC UA project, you have to activate the OPC UA functionality. → 'Activate OPC UA functionality'...page 181

Start Conditions

Here the start conditions for the OPC UA server are listed:

Conflicting projects

- Simultaneous use of an OPC UA and WebVisu project via the same interface is not permitted and results in the message 'conflicting project on card'.
- The status 'no conflicting project on card' indicates that there is no conflict with a WebVisu project on the same interface.

Feature Set activated

- yes: The OPC UA functionality is activated.
- no: The OPC UA functionality is not activated.
- → 'Activate OPC UA functionality'...page 181

Allowed by User

- yes: The OPC UA server is activated and access to it is allowed. As soon as an OPC UA project is found on the memory card, it is automatically started and enabled for access.
- no: You can disable and stop the OPC UA server by means of the CMD auto command 'OPCUA_PGOP_DISABLE'. With 'OPCUA_PGOP_ENABLE' you can enable to restart the OPC UA server.
- → 'CMD auto commands'...page 110

Allowed by Access Ways

- yes: By default, the OPC UA protocol is enabled.
- no: The OPC UA protocol is disabled. You can deactivate or activate the OPC UA protocol by means of the parameter 'OPC UA' in the 'Access settings'.

Hardware configured

- yes: A hardware configuration as a precondition for the OPC UA communication is loaded. The hardware configuration is checked for validity elsewhere.
- no: A hardware configuration is not loaded e.g. after an overall reset.
- → 'Hardware configuration CPU'...page 72

OPC UA project

- loaded: An OPC UAOPC UA project is loaded.
- not loaded: An OPC UAOPC UA project is not loaded.
- → 'Deployment OPC UA'...page 172

Server

State

- Running: The start conditions are fulfilled and the OPC UA server is started.
- Stopped: The OPC UA server is stopped.
- Startup failure: The OPC UA server can not be started.
- Starting: The OPC UA server currently starts up.
- Stopping: The OPC UA server currently stopps.

Endpoint URL

 As soon as the OPC UA server is started, the endpoint URL of the OPC UA server is listed here.

4.11.1.1.2 Tab: 'WebVisu'

Information about the web visualization ('WebVisu') are shown here. The creation of a 'WebVisu' project is only possible with the SPEED7 Studio V1.7.0 and up. → 'Deployment WebVisu - Web visualization'...page 198

Ŋ

For your CPU can process a WebVisu project, you have to activate the WebVisu functionality. → 'Activate WebVisu functionality'...page 201



General Information

- Feature
 - activated: The WebVisu functionality is activated.
 - not activated: The WebVisu functionality is not activated.
- Status
 - The status of your WebVisu project is shown here. → 'Status of the Web-Visu'...page 99
- User authentication
 - activated: User authentication is activated. Access to the WebVisu happens via a login by user name and password.
 - not activated: User authentication is de-activated. Access to the WebVisu is unsecured.

Statistics

Statistical information about your WebVisu project are shown here.

- Sessions: Number of sessions, i.e. online connections to this WebVisu project. A session corresponds to an open window or tab in a web browser.
 - free: Number of sessions still possible.
 - used: Number of active sessions. For the number of active sessions, it is not relevant whether the sessions were started by the same or different users.
 - max.: Number of sessions still possible. The maximum number of sessions is device specific and specified in the technical data.
- Subscribed items: Number of variables.
 - free: Here nothing is shown.
 - used: Number of variables used.
 - max.: Here nothing is shown.
- WebVisu Project: Information on the memory allocation for the *WebVisu* project.
 - free: Still free space for the WebVisu project.
 - used: Size of the current WebVisu project.
 - max.: Maximum available space for a WebVisu project.

Link

In Status 'running' the links to access your WebVisu are listed here.

Status of the WebVisu

On the device web page at the tab 'WebVisu' via 'Status' you get the status of your WebVisu project.

Status	Meaning
running	WebVisu is active / has started-up and can be opened
loading webvisu project	Loading WebVisu project
shutting down	WebVisu server shuts down
stop requested	WebVisu STOP requested
stopped	WebVisu server is down
webvisu feature not activated	WebVisu not activated, memory card is not inserted
webvisu is disabled by the user	WebVisu was disabled by the user
no webvisu project file found	No WebVisu project found
no hardware configuration loaded	No hardware configuration is loaded
invalid configuration	Invalid WebVisu configuration
internal error: filesystem	Error initializing the file system
webvisu project file too large	Error loading WebVisu project, project file too large
loading webvisu project file	Error loading WebVisu project, project file may be damaged
deleting webvisu project	Failed to delete the WebVisu project
internal error: file system - delete	WebVisu project to be deleted was not found in the memory
CRC mismatch	CRC of the WebVisu project file is not correct
webvisu stopped	WebVisu server has terminated unexpectedly
internal error 1	Internal error - initialization failed step 1
internal error 2	Internal error - initialization failed step 2
internal error 3	Unexpected internal error
unknown error	General error

4.11.1.1.3 Tab: *'Port Mirroring'*

Overview

- Port Mirroring offers the possibility to diagnose the communication without additional hardware effort.
- The Ethernet PG/OP interface is designed as switch.
- When Port Mirroring of the PG/OP2: X4 (Mirror Port) interface is activated, all telegrams received and sent via the PG/OP1: X3 interface are mirrored to the PG/OP2: X4 interface and vice versa.
- When Port Mirroring is activated, for diagnostics with diagnostics software such as Wireshark, you can connect your PC directly to the 2. interface.
- The next power-cycle will automatically disable Port Mirroring.

Enable Port Mirroring

When enabled, you can set the parameters for *Port Mirroring*.

PG/OP1: X3

When enabled the frames of PG/OP2: X4 are mirrored to PG/OP1: X3.

Operating modes > Overview

PG/OP2: X4

When enabled the frames of PG/OP1: X3 are mirrored to PG/OP2: X4.


Disable communication on the Mirror Port

When enabled additional communication via the mirrored interface (Mirror Port) is prevented.

Save

With *Save*, the setting are taken and activated. The next power-cycle will automatically disable *Port Mirroring*.

4.11.1.2 Web page with selected module



Tab: 'Info'

Here product name, order number, serial number, firmware version and hardware state number of the according module are listed.

Tab: 'Data'

Here the address and the state of the inputs respectively outputs are listed. Please note with the outputs that here exclusively the states of outputs can be shown, which are within the OB 1 process image.

Tab: 'Parameter'

With parameterizable modules e.g. analog modules the parameter setting is shown here. These come from the hardware configuration.

4.12 Operating modes

4.12.1 Overview

The CPU has 4 operating modes:

- Operating mode STOP
- Operating mode START-UP (OB 100 - restart / OB 102 - cold start *)
- Operating mode RUN
- Operating mode HOLD

Certain conditions in the operating modes START-UP and RUN require a specific reaction from the system program. In this case the application interface is often provided by a call to an organization block that was included specifically for this event.

Operating modes > Overview

Operating mode STOP

- The application program is not processed.
- If there has been a processing before, the values of counters, timers, flags and the process image are retained during the transition to the STOP mode.
- Command output disable (BASP) is activated this means the all digital outputs are disabled.
- The yellow LED of the status bar lights up in the STOP state.

Operating mode START-UP

- After PowerON the yellow LED of the status bar blinks in the STOP state.
- After a short time the flashing changes to a steady light.
- During the transition from STOP to RUN a call is issued to the start-up organization block OB 100.
 - The processing time for this OB is not monitored.
 - The START-UP OB may issue calls to other blocks.
 - All digital outputs are disabled during the START-UP, this means BASP is activated.
 - ETHE GREEN LEDS blinks as soon as the OB 100 is operated and for at least 3s, even if the start-up time is shorter or the CPU gets to STOP due to an error
 - Example : The green LEDs of the status bar lights up when the START-UP is completed and the CPU is in the RUN state.

5

* OB 102 (Cold start)

If there is a "Watchdog" error the CPU still remains in STOP state. With such an error the CPU must be manually started again. For this the OB 102 (cold start) must exist. The CPU will not go to RUN without the OB 102. Alternatively you can bring your CPU in RUN state again by an overall reset respectively by reloading your project.

Please consider that the OB 102 (cold start) may exclusively be used for treatment of a watchdog error.

Operating mode RUN

- The green LED lights up when the CPU is in the RUN state.
- The application program in OB 1 is processed in a cycle. Under the control of alarms other program sections can be included in the cycle.
- All timers and counters being started by the program are active and the process image is updated with every cycle.
- BASP is deactivated, i.e. all outputs are enabled.

Operating mode HOLD

The CPU offers up to 3 breakpoints to be defined for program diagnosis. Setting and deletion of breakpoints happens in your programming environment. As soon as a breakpoint is reached, you may process your program step by step.

Precondition

For the usage of breakpoints, the following preconditions have to be fulfilled:

- Testing in single step mode is possible with STL. If necessary switch the view via 'View → STL' to STL.
- The block must be opened online and must not be protected.

Operating modes > Function security

Approach for working with breakpoints

- 1. ▶ Activate 'View → Breakpoint Bar'.
- **2.** Set the cursor to the command line where you want to insert a breakpoint.
- 3. Set the breakpoint with 'Debug → Set Breakpoint'.
 - ➡ The according command line is marked with a circle.
- **4.** ▶ To activate the breakpoint click on 'Debug → Breakpoints Active'.
 - → The circle is changed to a filled circle.
- **5.** Bring your CPU into RUN.
 - When the program reaches the breakpoint, your CPU switches to the state HOLD, the breakpoint is marked with an arrow and the register contents are monitored.
- 6. Now you may execute the program code step by step via 'Debug → Execute Next Statement' or run the program until the next breakpoint via 'Debug → Resume'.
- 7. Delete (all) breakpoints with the option 'Debug → Delete All Breakpoints'.

Behavior in operating state HOLD

- Red LED is on and green LED blinks with 1Hz: CPU is in STOP state, configured holding point reached.
- The execution of the code is stopped. No level is further executed.
- All times are frozen.
- The real-time clock runs is just running.
- The outputs were disabled (BASP is activated).
- Configured CP connections remain exist.



The usage of breakpoints is always possible. Switching to the operating mode test operation is not necessary.

With more than 2 breakpoints, a single step execution is not possible.

4.12.2 Function security

The CPUs include security mechanisms like a Watchdog (100ms) and a parameterizable cycle time surveillance (parameterizable min. 1ms) that stop res. execute a RESET at the CPU in case of an error and set it into a defined STOP state. The CPUs are developed function secure and have the following system properties:

Event	concerns	Effect
RUN → STOP	general	BASP (Befehls-Ausgabe-Sperre, i.e. command output lock) is set.
	central digital outputs	The outputs are disabled.
	central analog outputs	The outputs are disabled.
		■ Voltage outputs issue 0V
		■ Current outputs 020mA issue 0mA
		Current outputs 420mA issue 4mA
		If configured also substitute values may be issued.
	decentral outputs	Same behaviour as the central digital/analog outputs.
	decentral inputs	The inputs are cyclically be read by the decentralized station and the recent values are put at disposal.

Overall reset

Event	concerns	Effect		
$\mbox{STOP} \rightarrow \mbox{RUN res. PowerON}$	general	First the PII is deleted, then OB 100 is called. After the execution of the OB, the BASP is reset and the cycle starts with:		
		Delete PIO \rightarrow Read PII \rightarrow OB 1.		
	decentral inputs	The inputs are be read by the decentralized station and the recent values are put at disposal.		
RUN	general	The program is cyclically executed:		
		Read PII \rightarrow OB 1 \rightarrow Write PIO.		
PII = Process image inputs				
PIO = Process image outputs				

4.13 Overall reset

Overview


During the overall reset the entire user memory is erased. Data located in the memory card is not affected. You have 2 options to initiate an overall reset:

- Overall reset by means of the operating mode switch
- Overall reset by means of a configuration tool like e.g. the Siemens SIMATIC Manager



You should always establish an overall reset to your CPU before loading an application program into your CPU to ensure that all blocks have been cleared from the CPU.

Overall reset by means of the operating mode switch



- 1. Your CPU must be in STOP mode. For this switch the operating mode switch of the CPU to STOP.
 - → Status bar:
- 2. Switch the operating mode switch to MR position for about 3 seconds.
 - → The yellow LED blinks with 1Hz and changes from repeated blinking to permanently on.
- **3.** Place the operating mode switch in the position STOP and switch it to MR and quickly back to STOP within a period of less than 3 seconds.
 - → The overall reset is carried out. Here the yellow LED blinks with 2Hz
- The overall reset has been completed when the yellow LED is on permanently

Overall reset by means of the Siemens SIMATIC Manager

For the following proceeding you must be online connected to your CPU.

- **1.** For an overall reset the CPU must be switched to STOP state. You may place the CPU in STOP by the menu command 'PLC → Operating mode'.
- 2. You may request the overall reset by means of the menu command 'PLC → Clean/ Reset'.
 - → A dialog window opens. Here you can bring your CPU in STOP state, if not already done, and start the overall reset. During the overall reset the yellow LED of the status bar blinks with 2Hz ______. The overall reset has been completed when the yellow LED is on permanently ______.

Firmware update

Activating functionality by means of a VSC

If there is a Yaskawa VSC plugged, after an overall reset the according functionality is automatically activated.

'Deployment storage media - VSD, VSC'...page 108

Automatic reload

If there is a project S7PROG.WLD on the memory card, after an overall reset the CPU attempts to reload this project from the memory card. Here the yellow LED of the status line flickers ______. The operating mode of the CPU will be STOP respectively RUN, depending on the position of the operating mode switch.

Reset to factory setting

The Reset to factory setting deletes completely the internal RAM of the CPU and resets this to delivery state. Please regard that the MPI address is also set back to default 2!

*Reset to factory settings'...page 107

4.14 Firmware update

Overview


You can find current firmware versions at www.yaskawa.eu.com in the 'Download Center' under 'Firmware M13-CCF0001'. There are the following possibilities for the firmware update:

- Firmware update online from FW V3.0.0 → 'Firmware update online'...page 105
 - Transfer of the firmware file to the CPU via the CPU web page.
 - Triggering the firmware update by means of the operating mode switch.
- Firmware update via memory card → 'Firmware update via memory card'...page 106
 - Transfer of the firmware file to a memory card.
 - The identification of a firmware file on the memory card takes place by means of a defined naming convention.
 - After PowerON and operating mode switch in the STOP position, the firmware update can be triggered by means of operating mode switch.

Show the firmware version via web page

The CPU has an integrated *Device web page* that also shows information about the firmware version via '*Info*'. Here you will also find information about the required firmware '*Package*'. With **[Expert View]** you can access the extended "Expert" overview. → '*Device web page CPU'...page 93*

Tab: 'Info'



Name	Value	
Ordering Info	M13-CCF0001	Order number of the CPU
Serial		Serial number of the CPU

Firmware update > Firmware update online

Name	Value	
Version	01V	Version number of the CPU
HW Revision	01	CPU hardware revision
Software	3.0.13	CPU firmware version
Package	Pb000351.pkb	File name for the firmware update

Current firmware at www.yaskawa.eu.com

The latest firmware versions can be found in the 'Download Center' at www.yaskawa.eu.com under 'Firmware M13-CCF00001'. For example the following file is necessary for the firmware update of the CPU M13-CCF0001 and its components with hardware release 01:

CPU M13C, Hardware release 01: Pb000351.pkb



CAUTION

When installing a new firmware you have to be extremely careful. Under certain circumstances you may destroy the CPU, for example if the voltage supply is interrupted during transfer or if the firmware file is defective. In this case, please call our hotline!

Please regard that the version of the update firmware has to be different from the existing firmware otherwise no update is executed.

4.14.1 Firmware update online

Precondition

- Access is via the IP address of the Ethernet PG/OP channel.
 - → 'Hardware configuration Ethernet PG/OP channel'...page 74
- You can access the IP address with a web browser.



It is assumed that there is a connection via the Ethernet PG/OP channel between the PC with web browser and the CPU. This may be tested by Ping to the IP address of the Ethernet PG/OP channel.

Load firmware and store it in working directory

- **1.** Go to the 'Download Ceneter' of www.yaskawa.eu.com.
- 2. Download under 'Firmware M13-CCF0001' the zip file for your CPU to your PC.
- 3. Extract the zip file into your working directory.



CAUTION

With a firmware update an overall reset is automatically executed. If your program is only available in the load memory of the CPU it is deleted! Save your program before executing a firmware update!


Perform firmware update



- 1. Switch the operating mode switch of your CPU in position STOP.
- 2. ▶ Execute an overall reset. → 'Overall reset'...page 103
- 3. Dopen the CPU web page and select the 'Firmware' tab.
- **4.** Click at 'Browse ...' and navigate to the firmware file in your working directory.

Firmware update > Firmware update via memory card

5. Click at 'Upload'.





- You start the firmware update by tipping the operating mode switch downwards to MR and then leaving the switch in STOP position.
 - → During the update process, the yellow LED of the status bar flashes or flickers
 _______. This may last several minutes.
- The update is completed without errors when the red and yellow LEDs of the status bar are flashing (1Hz) . If only the red LED of the status bar is flashing, an error has occurred.



- 8. Turn power OFF and ON.
 - → After the start-up, the CPU is ready for operation with the new firmware. The current firmware version can be determined via the web page of the CPU.

4.14.2 Firmware update via memory card

Overview

- For the firmware update via memory card an accordingly prepared memory card must be in the CPU during the start-up.
- So a firmware files can be recognized and assigned with start-up, a pkb file name is reserved for each hardware revision, which begins with "pb" and differs in a number with 6 digits.
- In the System MICRO CPU, the pkb file name can be shown via the web page.
- After PowerON and operating mode switch of the CPU in STOP, the CPU checks if there is a pkb file at the memory card. If this firmware version is different to the existing firmware version, this is indicated by blinking of the LEDs and the firmware may be installed by an update request.



The procedure here describes the update <u>from</u> the CPU firmware version V2.4.0. The update of an older version to the firmware version V2.4.0 has to be done via pkg files. For this refer to the corresponding manual for your CPU version.

Load firmware and transfer it to memory card

- 1. Go to the 'Download Center' of www.yaskawa.eu.com
- **2.** Download under *'Firmware M13-CCF0001'* the corresponding zip file for your CPU to your PC.
- 3. Unzip the zip file and copy the pgb file to the root directory of your memory card.



CAUTION

With a firmware update an overall reset is automatically executed. If your program is only available in the load memory of the CPU it is deleted! Save your program before executing a firmware update! After a firmware update you should execute a "Reset to factory setting". → 'Reset to factory settings'...page 107

Transfer firmware from memory card into CPU



1. Switch the operating mode switch of your CPU in position STOP.

Reset to factory settings



2. Turn off the power supply.




3. Plug the memory card with the firmware file into the CPU. Please take care of the correct plug-in direction of the memory card.





4. Switch on the power supply.



After a short boot-up time, the alternate blinking of the red and yellow LED of the status bar shows that at least a more current firmware file was found at the memory card.










8. Turn power OFF and ON.


→ After the start-up, the CPU is ready for operation with the new firmware. The current firmware version can be determined via the web page of the CPU.

4.15 Reset to factory settings

Proceeding


- With the following proceeding the internal RAM of the CPU is completely deleted and the CPU is reset to delivery state.
- Please regard that the MPI address is also reset to default 2 and the IP address of the Ethernet PG/OP channel is reset to 0.0.0.0!
- A factory reset may also be executed by the command FACTORY_RESET. → 'CMD auto commands'...page 110





- **3.** After the 6. static light release the operating mode switch and tip it downwards to MR.
 - → To confirm the reset process the yellow LED of the status bar blinks (2Hz)

 ______. This means that the RAM was deleted completely.



4. The reset process is completed when the red and yellow LEDs of the status bar are blinking (1Hz)

Deployment storage media - VSD, VSC



5. Turn power OFF and ON.

4.16 Deployment storage media - VSD, VSC

Overview

At the front of the CPU there is a slot for storage media. Here the following storage media can be plugged:

- VSD VIPA SD-Card
 - External memory card for programs and firmware.
- VSC VIPASetCard
 - External memory card (VSD) for programs and firmware with the possibility to unlock optional functions like field bus interfaces.
 - These functions (FSC: Feature Set Code) can be purchased separately.
 - To activate a FSC the corresponding card is to be installed and a Overall reset is to be established. → 'Overall reset'...page 103




To avoid malfunctions, you should use Yaskawa memory cards. These correspond to the industrial standard. A list of the currently available VSD respectively VSC can be found at www.yaskawa.eu.com

You can cause the CPU to load a project automatically respectively to execute a command file by means of pre-defined file names.

VSD

VSDs are external storage media based on SD memory cards. VSDs are pre-formatted with the PC format FAT 16 (max. 2GB) and can be accessed via a card reader. After PowerON respectively an overall reset the CPU checks, if there is a VSD with data valid for the CPU.

Push the VSD into the slot until it snaps in leaded by a spring mechanism. This ensures contacting. By sliding down the sliding mechanism, a just installed VSD card can be protected against drop out.



To remove, slide the sliding mechanism up again and push the storage media against the spring pressure until it is unlocked with a click.



CAUTION

If the media was already unlocked by the spring mechanism, with shifting the sliding mechanism, a just installed memory card can jump out of the slot!

VSC

The VSC is a VSD with the possibility to enable optional functions. Here you have the opportunity to enable field bus functionalities. Information about the enabled functions can be shown via the web page. → 'Accessing the web server'...page 93

Extended know-how protection



CAUTION

Please regard that the VSC must remain plugged when you've enabled optional functions at your CPU. Otherwise the red LED of the status bar blinks in RUN with 1Hz and the CPU goes into STOP after 72 hours. As long as an activated VSC is not plugged in, the LED blinks and the "TrialTime" timer counts from 72 hours down to 0. The CPU then goes into STOP mode. By inserting the VSC, the LED goes out and the CPU runs again without restrictions.

The VSC cannot be exchanged with a VSC of the same optional functions. The activation code is fixed to the VSD by means of an unique serial number. Here the functionality as an external memory card is not affected.

Accessing the storage medium

To the following times an access takes place on a storage medium:

After overall reset

- The CPU checks if a VSC is inserted. If so, the corresponding optional functions are enabled.
- The CPU checks whether a project S7PROG.WLD exists. If so, it is automatically loaded.

After PowerON

- The CPU checks whether a project AUTOLOAD.WLD exists. If so, an overall reset is executed and the project is automatically loaded.
- The CPU checks whether a command file with the name VIPA_CMD.MMC exists. If so the command file is loaded and the commands are executed.
- After PowerON and CPU STOP the CPU checks if there is a *.pkb file (firmware file). If so, this is shown by the CPU by blinking LEDs and the firmware may be installed by an update request. → 'Firmware update'...page 104

In STOP state when inserting a memory card

If a memory card is plugged in STOP state, which contains a command file VIPA_CMD.MMC, the command file is loaded and the containing instructions are executed.



The FC/SFC 208 ... FC/SFC 215 and FC/SFC 195 allow you to include the memory card access into your user application. More information about this may be found in the manual "SPEED7 Operation List".

4.17 Extended know-how protection

Overview



Please note that this functionality is not supported by the Siemens TIA Portal!

Besides the "standard" Know-how protection the CPUs provide an "extended" know-how protection that serves a secure block protection for accesses of 3. persons.

- Standard protection
 - The standard protection from Siemens transfers also protected blocks to the PG but their content is not displayed.
 - But with according manipulation the know-how protection is not guaranteed.

CMD - auto commands

Extended protection

- The "extended" know-how protection offers the opportunity to store blocks permanently in the CPU.
- With the "extended" protection you transfer the protected blocks to a memory card into a WLD-file named protect.wld.
- By plugging the memory card and then an overall reset the blocks in the protect.wld are permanently stored in the CPU.
- You may protect OBs, FBs and FCs.
- When back-reading the protected blocks into the PG, exclusively the block header are loaded. The block code that is to be protected remains in the CPU and cannot be read.

Protect blocks with protect.wld

- $\underline{\mathbf{1.}}$ Create a new wld file in the Siemens SIMATIC Manager with 'File \rightarrow Memory Card file \rightarrow New'.
- 2. Rename the wld file to "protect.wld".
- **3.** Transfer the according blocks into the file by dragging them with the mouse from the project to the file window of protect.wld.
- **4.** Transfer the file protect.wld to a memory card.
- 5. Plug the memory card into the CPU and execute an overall reset. → 'Overall reset'...page 103
 - → The overall reset stores the blocks in protect.wld permanently in the CPU protected from accesses of 3. persons.

Protection behaviour

Protected blocks are overwritten by a new protect.wld. Using a PG 3. persons may access protected blocks but only the block header is transferred to the PG. The block code that is to be protected remains in the CPU and cannot be read.

Change respectively delete protected blocks

Protected blocks in the RAM of the CPU may be substituted at any time by blocks with the same name. This change remains up to next overall reset. Protected blocks may permanently be overwritten only if these are deleted at the protect.wld before. A factory reset does not affect the protected blocks. By transferring an empty protect.wld from the memory card with an overall reset, you may delete all protected blocks in the CPU.

Usage of protected blocks

Due to the fact that reading of a "protected" block from the CPU monitors no symbol labels it is convenient to provide the "block covers" for the end user. For this, create a project of all protected blocks. Delete all networks in the blocks so that these only contain the variable definitions in the according symbolism.

4.18 CMD - auto commands

Overview

A Command file at a memory card is automatically executed under the following conditions:

- CPU is in STOP and memory card is plugged
- After each PowerON

Command file

- The *Command* file is a text file, which consists of a command sequence to be stored as **VIPA_cmd.mmc** in the root directory of the memory card.
- The file has to be started by CMD_START as 1. command, followed by the desired commands (no other text) and must be finished by CMD_END as last command.
- Text after the last command CMD_END e.g. comments is permissible, because this is ignored.

CMD - auto commands

- As soon as the command file is recognized and executed each action is stored at the memory card in the log file logfile.txt.
- For each executed command a diagnostics entry may be found in the diagnostics buffer.

Commands

Please regard the command sequence is to be started with *CMD_START* and ended with *CMD_END*.

Command	Description	Diagnostics entry
CMD_START	In the first line CMD_START is to be located.	0xE801
	There is a diagnostics entry if CMD_START is missing.	0xE8FE
WAIT1SECOND	Waits about 1 second.	0xE803
LOAD_PROJECT	The function "Overall reset and reload from memory card" is executed. The wld file located after the command is loaded else "s7prog.wld" is loaded.	0xE805
SAVE_PROJECT	The recent project (blocks and hardware configuration) is stored as "s7prog.wld" at the memory card. If the file just exists it is renamed to "s7prog.old". If your CPU is password protected so you have to add this as parameter. Otherwise there is no project written.	0xE806
FACTORY DECET	Example: SAVE_PROJECT password	0. 5007
FACTORY_RESET	Executes "factory reset".	0xE807
DIAGBUF	The current diagnostics buffer of the CPU is stored as "diagbuff.txt" at the memory card.	0xE80B
SET_NETWORK	IP parameters for Ethernet PG/OP channel may be set by means of this command. The IP parameters are to be given in the order IP address, subnet mask and gateway in the format x.x.x.x each separated by a comma. Enter the IP address if there is no gateway used.	0xE80E
CMD_END	In the last line CMD_END is to be located.	0xE802
WEBPAGE	Saves all information on the device web page (Expert-View) as webpage.txt on the memory card → 'Accessing the web server'page 93	0xE804
WEBVISU_PGOP_ENABLE	Enable WebVisu project via Ethernet PG/OP channel	0xE82C
WEBVISU_PGOP_DISABLE1	Disable WebVisu project via Ethernet PG/OP channel	0xE82D
OPCUA_PGOP_ENABLE	Enable OPC UA project via Ethernet PG/OP channel	0xE830
OPCUA_PGOP_DISABLE	Disable OPC UA project via Ethernet PG/OP channel	0xE831
1) After a power cycle or loading a hardware configuration, project is set to the default value "enabled".		

Control and monitoring of variables with test functions

Examples

The structure of a command file is shown in the following. The corresponding diagnostics entry is put in parenthesizes.

Example 1

CN	ID_START	Marks the start of the command sequence (0xE801)
LC	DAD_PROJECT proj.wld	Execute an overall reset and load "proj.wld" (0xE805)
WZ	AIT1SECOND	Wait ca. 1s (0xE803)
DI	AGBUF	Store diagnostics buffer of the CPU as "diagbuff.txt" (0xE80B)
CN	d_end	Marks the end of the command sequence (0xE802)
	. arbitrary text	Text after the command CMD_END is not evaluated.

Example 2

CMD_START	Marks the start of the command sequence (0xE801)
LOAD_PROJECT proj2.wld	Execute an overall reset and load "proj2.wld" (0xE805)
WAIT1SECOND	Wait ca. 1s (0xE803)
WAIT1SECOND	Wait ca. 1s (0xE803)
	IP parameter (0xE80E)
SET_NETWORK 172.16.129.210,255.255.2	24.0,172.16.129.210
WAIT1SECOND	Wait ca. 1s (0xE803)
WAIT1SECOND	Wait ca. 1s (0xE803)
DIAGBUF	Store diagnostics buffer of the CPU as "diagbuff.txt" (0xE80B)
CMD_END	Marks the end of the command sequence (0xE802)
arbitrary text	Text after the command CMD_END is not evaluated.



The parameters IP address, subnet mask and gateway may be received from the system administrator. Enter the IP address if there is no gateway used.

4.19 Control and monitoring of variables with test functions

Overview

- For troubleshooting purposes and to display the status of certain variables you can access certain test functions via the menu item **Debug** of the Siemens SIMATIC Manager.
- The status of the operands and the RLO can be displayed by means of the test function 'Debug → Monitor'.
- The status of the operands and the RLO can be displayed by means of the test function 'PLC → Monitor/Modify Variables'.

'Debug → Monitor'

- This test function displays the current status and the RLO of the different operands while the program is being executed.
- It is also possible to enter corrections to the program.
- The processing of the states may be interrupted by means of jump commands or by timer and process-related interrupts.
- At the breakpoint the CPU stops collecting data for the status display and instead of the required data it only provides the PG with data containing the value 0.
- The interruption of the processing of statuses does not change the execution of the program. It only shows that the data displayed is no longer valid.

Control and monitoring of variables with test functions

 \int_{1}^{∞}

When using the test function "Monitor" the PLC must be in RUN mode!

For this reason, jumps or time and process alarms can result in the value displayed during program execution remaining at 0 for the items below:

- the result of the logical operation RLO
- Status / AKKU 1
- AKKU 2
- Condition byte
- absolute memory address SAZ. In this case SAZ is followed by a "?".

'PLC → Monitor/Modify Variables' This test function returns the condition of a selected operand (inputs, outputs, flags, data word, counters or timers) at the end of program execution. This information is obtained from the corresponding area of the selected operands. During the controlling of variables respectively in operating mode STOP the input area is directly read. Otherwise only the process image of the selected operands is displayed.

Control of outputs

- Serves to check the wiring and proper operation of output modules.
- If the CPU is in RUN mode, so only outputs can be controlled, which are not controlled by the user program. Otherwise values would be instantly overwritten.
- If the CPU is in STOP even without user program, so you need to disable the command output lock BASP ('Enable PO'). Then you can control the outputs arbitrarily

Controlling variables

- The following variables may be modified: I, Q, M, T, C and D.
- The process image of binary and digital operands is modified independently of the operating mode of the CPU.
- When the operating mode is RUN the program is executed with the modified process variable. When the program continues they may, however, be modified again without notification.

Forcing variables

- You can pre-set individual variables of a user program with fixed values so that they can not be changed or overwritten by the user program of the CPU.
- By pre-setting of variables with fixed values, you can set certain situations for your user program and thus test the programmed functions.



CAUTION

- Please consider that controlling of output values represents a potentially dangerous condition.
- Even after a power cycle forced variables remain forced with its value, until the force function is disabled.
- These functions should only be used for test purposes respectively for troubleshooting. More information about the usage of these functions may be found in the manual of your configuration tool.

Diagnostic entries

4.20 Diagnostic entries

Accessing diagnostic data

- → 'System specific event IDs'...page 321
- You may read the diagnostics buffer of the CPU via the Siemens SIMATIC Manager. Besides of the standard entries in the diagnostics buffer, the CPUs support some additional specific entries as Event-IDs.
- To monitor the diagnostics entries you choose in the Siemens SIMATIC Manager 'PLC → Module information'. Via the register "Diagnostics Buffer" you reach the diagnostics window.
- The current content of the diagnostic buffer is stored at the memory card by means of the CMD DIAGBUF. → 'CMD - auto commands'...page 110
- The diagnostic is independent from the operating mode of the CPU. You may store a max. of 100 diagnostic entries in the CPU.

Overview

5 Deployment I/O periphery

5.1 Overview

Project engineering and parametrization

- On this CPU the connectors for digital respectively analog signal and *Technological* functions are combined in a one casing.
- The project engineering happens in the Siemens SIMATIC Manager as Siemens CPU 314C-2 PN/DP (314-6EH04-0AB0 V3.3). Here the CPU M13-CCF0001 is parameterized via the *'Properties'* dialog of the Siemens CPU 314C-2 PN/DP (314-6EH04-0AB0 V3.3).
- For parametrization of the digital I/O periphery and the *technological functions* the corresponding sub modules of the CPU 314C-2 PN/DP (314-6EH04-0AB0 V3.3) is to be used.
- The controlling of the operating modes of the technological functions happens by means of handling blocks of the user program.

I/O periphery

- The integrated I/Os of the CPU may be used for technological functions or as standard periphery.
- Technological functions and standard periphery may be used simultaneously with appropriate hardware.
- Read access to inputs used by technological functions is possible.
- Write access to used outputs is not possible.
- - AI 2x12Bit U, I
 - Voltage measurement for encoders with 0 ... 10V
 - Current measurement for encoders with 4 ... 20mA
 - The analog channels of the module are not isolated to the electronic power supply.
 - Status indication via LEDs
- → 'Digital input'...page 122
 - DI 16xDC 24V
 - Interrupt functions parameterizable
 - Status indication via LEDs
- → 'Digital output'...page 126
 - DO 12xDC 24V, 0.5A
 - Status indication via LEDs

Technological functions

- → 'Counting'...page 128
 - 4 channels
 - Count once
 - Count continuously
 - Count Periodically
 - Control by the user program (SFB 47)
- → 'Frequency measurement'...page 150
 - 4 channels
 - Control by the user program (SFB 48)
- Pulse width modulation PWM'...page 155
 - 2 channels
 - Control by the user program (SFB 49)
- → 'Pulse train'...page 159
 - 2 channels
 - Control by the user program (SFB 49)

Address assignment

5.2 Address assignment

Sub module	Input address	Access	Assignment
AI5/AO2	800	WORD	Analog input channel 0 (X6)
	802	WORD	Analog input channel 1 (X6)

Sub module	Input address	Access	Description
DI24/DO16	136	BYTE	Digital input I+0.0 I+0.7 (X1)
	137	BYTE	Digital input I+1.0 I+1.7 (X5)

Sub module	Input address	Access	Description
Counter	816	DINT	Channel 0: Counter value / Frequency value
	820	DINT	Channel 1: Counter value / Frequency value
	824	DINT	Channel 2: Counter value / Frequency value
	828	DINT	Channel 3: Counter value / Frequency value

Sub module	Output address	Access	Description
Counter	816	DWORD	reserved
	820	DWORD	reserved
	824	DWORD	reserved
	828	DWORD	reserved

Sub module	Output address	Access	Description
DI24/DO16	136	BYTE	Digital output Q+0.0 Q+0.7 (X2)
	137	BYTE	Digital output Q+1.0 Q+1.3 (X6)

Analog input > Analog value representation

5.3 Analog input

5.3.1 Properties

- AI 2x12Bit U, I
- Voltage measurement for encoders with 0 ... 10V
- Current measurement for encoders with 4 ... 20mA
- The analog channels of the module are not isolated to the electronic power supply.
- Status indication via LEDs

5.3.2 Analog value representation

Number representation

Resolution	Analog value - twos complement															
	High byte (byte 0)							Low byte (byte 1)								
Bit number	15	15 14 13 12 11 10 9 8 7							6	5	4	3	2	1	0	
Value	SG	214	213	212	211	210	2 ⁹	28	27	26	2 ⁵	24	23	22	21	20
11Bit+sign	n SG Measuring value X1 X1 X1 X1									X ¹						
1) The lowest valu	e irrelevan	t bits of th	e output v	alue (0) ar	e marked	with "X".										

Sign bit (SG)

Here it is essential:

- Bit 15 = "0": → positive value
- Bit 15 = "1": → negative value

Error behavior

- As soon as a measured value leaves the measuring range, the associated red LED gets on.
- As soon as a measuring value exceeds overrange respectively underrange, the following value is returned:
 - Measured value > overrange: 32767 (7FFFh)
 - Measured value < underrange: -32768 (8000h)
- On parametrization error the measuring value 32767 (7FFFh) is returned.

Voltage measuring range

0 ... 10V

Measuring range	Voltage	Decimal	Hex	Range	Formulas
(Fct.No.)	(U)	(D)			
0 10V	> 11.759V	32767	7FFFh	overflow	D 27649 U
(CHxFN: 00h)	11.759V	32511	7EFFh	overdrive range	$D = 27648 \cdot \frac{U}{10}$
(CHxFN: 18h)	10V	27648	6C00h	nominal range	
	5V	13824	3600h		$U = D \cdot \frac{10}{27648}$
	0V	0	0000h		
	-0.8V	-2212	F75Ch	underdrive range	D: decimal value
	<-0.8V	-32768	8000h	underflow	U: voltage value

Analog input > Wiring


Current measuring range

4 ... 20mA

Measuring range (Fct.No.)	Current (I)	Decimal (D)	Hex	Range	Conversion	
4 20mA	> 22.81mA	32767	7FFFh	overflow	$D = 27648 \cdot \frac{I-4}{16}$	
(CHxFN: 33h)	22.81mA	32511	7EFFh	overrange	16	
	20mA	27648	6C00h	nominal range	16	
	12mA	13824	3600h		$I = D \cdot \frac{16}{27648} + 4$	
	4mA	0	0000h		D: Decimal value	
	1.19mA	-4864	ED00h	underrange	I: Current value	
	< 1.19mA	-32768	8000h	underflow		

5.3.3 Wiring

X6: DC 24V, AI, DO byte 1



X6	Function	Туре	LED	LED	Description			
			green	red				
1	1L+	I			1L+: DC 24V for electronic section supply			
2	1M	1			1M: DC 0V for electronic section supply			
3	Ţ	I			Shield			
4	2M	1			2M: GND for analog inputs			
5	AI 0	I			Al0: Analog input Al 0	Error LED is on at:		
6	Al 1	I			Al1: Analog input Al 1	Signal leaves measuring range		

Cables for analog signals

For the analog signals you have to use isolated cables. With this the interferences can be reduced. The shield of the analog cables should be grounded at both ends. If there are potential differences between the cables, a potential compensation current can flow, which could disturb the analog signals. In this case, you should only ground the shield at one end of the cable.

Analog input > Parametrization

Temporarily not used analog inputs must be connected to the concerning ground.



If a 2wire measuring transducer is used, you have to connect in line an external power supply.

5.3.4 Parametrization

5.3.4.1 Address assignment

Sub module	Input address	Access	Assignment
AI5/AO2	800	WORD	Analog input channel 0 (X6)
	802	WORD	Analog input channel 1 (X6)

5.3.4.2 Parameter data

DS Record set for Access via CPU, PROFIBUS and PROFINET

Name	Bytes	Function	Default	DS
RES0	1	reserved	00h	00h
FILT	1	Filter analog input channel 0/1	0Ah	01h
CH0FN	1	Function number analog input channel 0	00h	01h
CH1FN	1	Function number analog input channel 1	00h	01h
RES1	9	reserved	00h	01h

FILT Filter

Byte	Bit 7 0
0	Filter
	■ Bit 1, 0: Filter analog input channel 0
	■ Bit 3, 2: Filter analog input channel 1
	■ Bit 7 4: reserved

Analog input > Parametrization

The analog input part has a filter integrated. The filter uses the "moving averaging method". By specifying a time, you can determine here how many samples the mean value has to be calculated over. In during continuous measurement, the most recent sampled values are always used in "sliding" averaging. Since a sample value is recorded every 2ms, the mean value is calculated from the 50 most current sample values, e.g. with a filter time of 100ms. The default value of the filter is 1000ms. The following values can be entered:

- 00b: 2ms no filter
- 01b: 100ms small filter, mean value from the 50 most recent samples
- 10b: 1000ms medium filter, mean value from the 500 most recent samples
- 11b: 10000ms large filter, mean value from the 5000 most recent samples. This setting is only available in the SPEED7 Studio from V1.9.2 or when parametrizing during runtime.

CHxFN Function number channel x



You cannot deactivate the channels. By specifying 00h, the corresponding channel is set to voltage measurement 0 ... 10V.

By default, both channels are set to voltage measurement 0 ... 10V. All measuring ranges with the associated function number that are supported by analog input channel 0 or 1 are listed below. The here listed formulas allow you to transform an evaluated measuring value (digital value) to a value (analog value), which is assigned to a measuring range and vice versa.

Voltage measuring range

0 ... 10V

Measuring range (Fct.No.)	Voltage	Decimal	Hex	Range	Formulas
	(U)	(D)			
0 10V	> 11.759V	32767	7FFFh	overflow	$D = 27648 \cdot \frac{U}{}$
(CHxFN: 00h)	11.759V	32511	7EFFh	overdrive range	$D = 27048 \cdot \frac{10}{10}$
(CHxFN: 18h)	10V	27648	6C00h	nominal range	
	5V	13824	3600h		$U = D \cdot \frac{10}{27648}$
	0V	0	0000h		
	-0.8V	-2212	F75Ch	underdrive range	D: decimal value
	<-0.8V	-32768	8000h	underflow	U: voltage value

Analog input > Parametrization

Current measuring range

4 ... 20mA

Measuring range (Fct.No.)	Current (I)	Decimal (D)	Hex	Range	Conversion
4 20mA	> 22.81mA	32767	7FFFh	overflow	$D = 27648 \cdot \frac{I-4}{16}$
(CHxFN: 33h)	22.81mA	32511	7EFFh	overrange	16
	20mA	27648	6C00h	nominal range	16
	12mA	13824	3600h		$I = D \cdot \frac{16}{27648} + 4$
	4mA	0	0000h		D: Decimal value
	1.19mA	-4864	ED00h	underrange	I: Current value
	< 1.19mA	-32768	8000h	underflow	

Parametrization during runtime

By using the record set 1 of the SFC 55 "WR_PARM" you may alter the parametrization in the module during runtime.



The duration needed until the new parametrization is valid can last up to 2ms. During this time, the measuring value output is 7FFFFh.

Parametrization in the Siemens SIMATIC Manager

The parametrization in the Siemens SIMATIC Manager takes place via the sub module 'AI5/AO2' of the Siemens CPU 314C-2 PN/DP. Click at the sub module 'AI5/AO2' and open the 'Properties' dialog. Here you can specify your parameters at the 'Inputs' tab. Please note that you cannot specify the parameters directly. An assignment of the parameters to the corresponding setting in the Siemens SIMATIC Manager can be found in the following table:

Parameter	corresponds to the setting in the SIMATIC Manager
Analog input channel x	'Input x'
FILT = 00b: 2ms - no filter	'Integration time 2.5ms'
FILT = 01b: 100ms - small filter	'Integration time 16.6ms'
FILT = 10b: 1000ms - medium filter	'Integration time 20ms'
FILT = 11b: 10000ms - large filter	This setting is only available in the <i>SPEED7 Studio</i> from V1.9.2 or when parametrizing during runtime.
CHxFN = 18h: Measuring range 0 10V	'Measurement type': U
	'Measuring range': 010V
CHxFN = 33h: Measuring range 420mA	'Measurement type': I
	'Measuring range': 420mA



You cannot deactivate the channels. By setting the 'Measurement type: deactivated' or by accepting the preset default values in the Siemens SIMATIC Manager, the corresponding channel is set to voltage measurement 0 ... 10V.

Digital input > Wiring


5.4 Digital input

5.4.1 Properties

- 16xDC 24V
- Maximum input frequency
 - 10 inputs: 100kHz
 - 6 inputs: 1kHz
- Interrupt functions parameterizable
- Status indication via LEDs

5.4.2 Wiring


X1: DI byte 0



X1	Function	Туре	LED	Description
			green	
1	DI 0.7	I		Digital input DI 7 / Counter 2 (B) / Frequency 2 ¹
2	DI 0.6	1		Digital input DI 6 / Counter 2 (A) ¹
3	DI 0.5	1		Digital input DI 5
4	DI 0.4	I		Digital input DI 4 / Counter 1 (B) / Frequency 1 ¹
5	DI 0.3	1		Digital input DI 3 / Counter 1 (A) ¹
6	DI 0.2	I		Digital input DI 2
7	DI 0.1	1		Digital input DI 1 / Counter 0 (B) / Frequency 01
8	DI 0.0	I		Digital input DI 0 / Counter 0 (A) ¹
9	0 V	I		3M: GND for onboard DI power section supply
10	DC 24V	I		3L+: DC 24V for onboard DI power section supply
1) Max. input frequency 100kHz otherwise 1kHz.				

Digital input > Parametrization

X5: DI byte 1



X5	Function	Туре	LED	Description	
			green		
1	-	-		reserved	
2	-	-		reserved	
3	DI 1.0	I		Digital input DI 8	
4	DI 1.1	I		Digital input DI 9 / Counter 3 (A) ¹	
5	DI 1.2	1		Digital input DI 10 / Counter 3 (B) / Frequency 31	
6	DI 1.3	I		Digital input DI 11 / Gate 31	
7	DI 1.4	1		Digital input DI 12	
8	DI 1.5	1		Digital input DI 13	
9	DI 1.6	I		Digital input DI 14	
10	DI 1.7	1		Digital input DI 15 / Latch 3 ¹	
1) Max. input frequency 100kHz otherwise 1kHz.					

5.4.3 Parametrization

5.4.3.1 Adress assignment

Sub module	Input address	Access	Description
DI24/DO16	136	BYTE	Digital input I+0.0 I+0.7 (X1)
	137	BYTE	Digital input I+1.0 I+1.7 (X5)

5.4.3.2 Hardware interrupt

Parameter hardware configuration

With the parameter 'Hardware interrupt at ...' you can specify a hardware interrupt for each input for the corresponding edge. The hardware interrupt is disabled, if nothing is selected (default setting). A diagnostics interrupt is only supported with Hardware interrupt lost. Select with the arrow keys the input and enable the according hardware interrupts.

Here is valid:

Rising edge: Edge 0-1Falling edge: Edge 1-0

Digital input > Status indication

5.4.3.3 Input delay

Parameter hardware configuration

- The input delay can be configured per channel in groups of 4.
- An input delay of 0.1ms is only possible with "fast" inputs, which have a max. input frequency of 100kHz → 'Digital input'...page 122. Within a group, the input delay for slow inputs is limited to 0.5ms.
- Range of values: 0.1ms / 0.5ms / 3ms / 15ms

5.4.4 Status indication

X1	Function	Туре	LED	Description	
			green		
1	DI 0.7	I		Digital input DI 7 / Counter 2 (B) / Frequency 2 ¹	
2	DI 0.6	I		Digital input DI 6 / Counter 2 (A) ¹	
3	DI 0.5	I		Digital input DI 5	
4	DI 0.4	I		Digital input DI 4 / Counter 1 (B) / Frequency 1 ¹	
5	DI 0.3	I		Digital input DI 3 / Counter 1 (A) ¹	
6	DI 0.2	I		Digital input DI 2	
7	DI 0.1	I		Digital input DI 1 / Counter 0 (B) / Frequency 01	
8	DI 0.0	I		Digital input DI 0 / Counter 0 (A) ¹	
9	0 V	I		3M: GND for onboard DI power section supply	
10	DC 24V	I		3L+: DC 24V for onboard DI power section supply	
1) Max. input frequency 100kHz otherwise 1kHz.					

X5 Function LED Description **Type** green 1 reserved 2 reserved 3 DI 1.0 Digital input DI 8 4 DI 1.1 Digital input DI 9 / Counter 3 (A)1 DI 1.2 5 Digital input DI 10 / Counter 3 (B) / Frequency 31 6 DI 1.3 Digital input DI 11 / Gate 31 7 DI 1.4 Digital input DI 12 8 DI 1.5 Digital input DI 13 9 DI 1.6 Digital input DI 14 10 DI 1.7 Digital input DI 15 / Latch 31 1) Max. input frequency 100kHz otherwise 1kHz.

Digital input > Status indication

DI +x

Digital input	LED	Description
	green	
DI +0.0 DI +0.7		Digital I+0.0 0.7 has "1" signal
		Digital I+0.0 0.7 has "0" signal
DI +1.0 DI +1.7		Digital input I+1.0 1.7 has "1" signal
		Digital input I+1.0 1.7 has "0" signal

xL+

Power supply	LED	Description
	green	
1L+		DC 24V electronic section supply
		DC 24V electronic section supply not available
3L+		DC 24V power section supply inputs OK
		DC 24V power section supply inputs not available
4L+		DC 24V power section supply outputs OK
		DC 24V power section supply outputs not available

хF

Error	LED	Description
	green / red	
4M		Error, overload respectively short circuit on the outputs
		no error

Digital output > Parametrization


5.5 Digital output

5.5.1 Properties

- 12xDC 24V, 0.5A
- Status indication via LEDs

5.5.2 Wiring

X2: DO byte 0



X2	Function	Туре	LED	Description
			green	
1	DO 0.7	0		Digital output DO 7
2	DO 0.6	0		Digital output DO 6
3	DO 0.5	0		Digital output DO 5
4	DO 0.4	0		Digital output DO 4
5	DO 0.3	0		Digital output DO 3 / Output channel counter 3
6	DO 0.2	0		Digital output DO 2 / Output channel counter 2
7	DO 0.1	0		Digital output DO 1 / PWM 1 / Output channel counter 1
8	DO 0.0	0		Digital output DO 0 / PWM 0 / Output channel counter 0
9	0 V	1	red	4M: GND for onboard DO power section supply / GND PWM
				LED (red) is on at short circuit respectively overload
10	DC 24V	1		4L+: DC 24V for onboard DO power section supply

5.5.3 Parametrization

5.5.3.1 Address assignment

Sub module	Output address	Access	Description
DI24/DO16	6 136	BYTE Digital outp	Digital output Q+0.0 Q+0.7 (X2)
	137	BYTE	Digital output Q+1.0 Q+1.3 (X6)

Digital output > Status indication

5.5.4 Status indication

X2	Function	Туре	LED	Description
			green	
1	DO 0.7	0		Digital output DO 7
2	DO 0.6	0		Digital output DO 6
3	DO 0.5	0		Digital output DO 5
4	DO 0.4	0		Digital output DO 4
5	DO 0.3	0		Digital output DO 3 / Output channel counter 3
6	DO 0.2	0		Digital output DO 2 / Output channel counter 2
7	DO 0.1	0		Digital output DO 1 / PWM 1 / Output channel counter 1
8	DO 0.0	0		Digital output DO 0 / PWM 0 / Output channel counter 0
9	0 V	I	red	4M: GND for onboard DO power section supply / GND PWM
				LED (red) is on at short circuit respectively overload
10	DC 24V	I		4L+: DC 24V for onboard DO power section supply

DO +x

Digital output	LED	Description
	green	
DO +0.0 DO +0.7		Digital output Q+0.0 0.7 has "1" signal
		Digital output Q+0.0 0.7 has "0" signal
DO +1.0 DO +1.3		Digital output Q+1.0 1.3 has "1" signal
		Digital output Q+1.0 1.3 has "0" signal

xL+

Power supply	LED	Description
	green	
1L+		DC 24V electronic section supply
		DC 24V electronic section supply not available
3L+		DC 24V power section supply inputs OK
		DC 24V power section supply inputs not available
4L+		DC 24V power section supply outputs OK
		DC 24V power section supply outputs not available

хF

Error	LED	Description
	green / red	
4M		Error, overload respectively short circuit on the outputs
		no error

Counting > Wiring

5.6 Counting


5.6.1 Properties

- 4 channels
- Various counting modes
 - once
 - continuously
 - periodically
- Control by the user program via blocks

5.6.2 Wiring


5.6.2.1 Counter inputs

X1: DI byte 0



X1	Function	Туре	LED	Description
			green	
1	DI 0.7	I		Counter 2 (B) ¹
2	DI 0.6	I		Counter 2 (A) ¹
4	DI 0.4	I		Counter 1 (B) ¹
5	DI 0.3	I		Counter 1 (A) ¹
7	DI 0.1	1		Counter 0 (B) ¹
8	DI 0.0	1		Counter 0 (A) ¹
9	0 V	I		3M: GND for counter
10	DC 24V	I		3L+: DC 24V power section supply for counter
1) Max. input frequency 100kHz otherwise 1kHz.				

X5: DI byte 1



Counting > Wiring

X5	Function	Туре	LED	Description	
			green		
4	DI 1.1	I		Counter 3 (A) ¹	
5	DI 1.2	I		Counter 3 (B) ¹	
6	DI 1.3	I		Gate 3 ¹	
10	DI 1.7	I		Latch 3 ¹	
1) Max. input frequency 100kHz otherwise 1kHz.					

Input signals

The following sensors can be connected


- 24V incremental encoders with two phase-shifted by 90° tracks
- 24V pulse encoder with direction signal
- 24V initiator as BERO or beam sensor

For not all inputs are available at the same time, for every counter you may define the input assignment via the parameterization for the following input signals:

- Counter_x (A)
 - Pulse input for counter signal respectively track A of an encoder for 1-, 2- or 4-fold evaluation.
- Counter_x (B)
 - Direction signal respectively track B of the encoder. Via the parameterization you
 may invert the direction signal.
- Gate 3
 - Via this input you can if parameterized open the HW gate of Counter 3 with edge 0-1 and start counting.
- Latch 3
 - Via this input via edge 0-1 the current counter value of Counter 3 is stored in a memory that you may read if needed.

5.6.2.2 Counter outputs

X2: DO byte 0



Counting > Proceeding

X2	Function	Туре	LED green / red	Description
5	DO 0.3	0		Output channel counter 3
6	DO 0.2	0		Output channel counter 2
7	DO 0.1	0		Output channel counter 1
8	DO 0.0	0		Output channel counter 0
9	0 V	I		4M: GND for output channel counter
				LED (red) is on at short circuit respectively overload
10	DC 24V	1		4L+: DC 24V power section supply for output channel counter

Output channel Counterx

Every counter has an assigned output channel. For each counter you can specify the behavior of the counter output via the parametrization with *'Characteristics of the output'* and *'Pulse duration'*.

— *'Counter'*...page 131

5.6.3 Proceeding

Hardware configuration

In the Siemens SIMATIC Manager the following steps should be executed:

- Perform a hardware configuration for the CPU. → 'Hardware configuration CPU'...page 72
- 2. Double-click the counter sub module of the CPU 314C-2 PN/DP (314-6EH04-0AB0 V3.3).
 - → The dialog 'Properties' is opened.
- 3. As soon as you select the operating mode for the corresponding channel, a dialog box with default values for this counter mode is created and shown.
- 4. Perform the required parameter settings.
- **5.** ▶ Safe your project with 'Station → Safe and compile'.
- 6. ▶ Transfer your project to your CPU.

User program

- The SFB 47 should cyclically be called (e.g. OB 1) for controlling the counter functions.
- The SFB is to be called with the corresponding instance DB. Here the parameters of the SFB are stored.
- Among others the SFB 47 contains a request interface. Hereby you get read and write access to the registers of the appropriate counter.
- So that a new job may be executed, the previous job must have be finished with JOB DONE = TRUE.
- Per channel you may call the SFB in each case with the same instance DB, since the data necessary for the internal operational are stored here.
- Writing accesses to outputs of the instance DB is not permissible.
- Starting, stopping and interrupting a count function of Counter 0 to Counter 2 exclusively happens via the SW gate by setting the SW gate of the SFB 47.
 You can also activate input 'Gate 3' via the parametrization for Counter 3.



More information about the usage of this block may be found in the manual "SPEED7 Operation List".

5.6.4 Parametrization

5.6.4.1 Address assignment

Sub module	Input address	Access	Description
Counter	816	DINT	Channel 0: Counter value
	820	DINT	Channel 1: Counter value
	824	DINT	Channel 2: Counter value
	828	DINT	Channel 3: Counter value

Sub module	Output address	Access	Description
Counter	816	DWORD	reserved
	820	DWORD	reserved
	824	DWORD	reserved
	828	DWORD	reserved

5.6.4.2 Interrupt selection

Via 'Basic parameters' you can reach 'Select interrupt'. Here you can define the interrupts the CPU will trigger. The following parameters are supported:

- None: The interrupt function is disabled.
- Process: The following events of the counter can trigger a hardware interrupt (selectable via 'Count'):
 - Hardware gate opening
 - Hardware gate closing
 - On reaching the comparator
 - on Counting pulse
 - on overflow
 - on underflow
- Diagnostics+process: A diagnostics interrupt is only triggered when a hardware interrupt was lost.

5.6.4.3 Counter

Parameter hardware configuration

Default values and structure of this dialog box depend on the selected 'Operating mode'.



Please consider that the range of values could be limited due to the used projecting tool. With the SPEED7 Studio there are no limitations.

→ 'Configuration with SPEED7 Studio'...page 264

Parameter overview

Description	Assignment
 None No restriction of the counting range Up: Restricts the up-counting range. The counter starts from 0 or load value, counts in positive direction up to the declaration end value -1 and then jumps back to load value at the next positive transducer pulse. Down: Restricts the down-counting range. The counter starts from the declared start value or load value in negative direction, counts to 1 and then jumps to start value at the next negative encoder pulse. Function is disable with count continuously. 	None
 Cancel count: The count starts when the gate opens and resumes at the load value when the gate opens again. Stop count: The count is interrupted when the gate closes and resumed at the last actual counter value when the gate opens again. Gate function'page 143 	Abort count process
Start value with counting direction backward. End value with main counting direction forward.	2147483647 (2 ³¹ -1)
Range of values: 22147483647 (2 ³¹ -1)	
The count value is compared with the <i>comparison value</i> . See also the parameter "Characteristics of the output": No main counting direction Range of values: -2) ³¹ to +2) ³¹ -1 Main counting direction forward Range of values: -2 ³¹ to end value-1 Main counting direction backward Range of values: 1 to +2 ³¹ -1	0
The <i>hysteresis</i> serves the avoidance of many toggle processes of the output, if the counter value is in the range of the <i>comparison value</i> . 0, 1: <i>Hysteresis</i> disabled	0
Range of values. 0 to 255	
Description	Assignment
 Specify the signal of the connected encoder: Pulse/direction At the input count and direction signal are connected At the input there is an encoder connected with the following evaluation: Rotary encoder single Rotary encoder double Rotary encoder quadruple 	Pulse/direction
	■ None No restriction of the counting range ■ Up: Restricts the up-counting range. The counter starts from 0 or load value, counts in positive direction up to the declaration end value -1 and then jumps back to load value at the next positive transducer pulse. ■ Down: Restricts the down-counting range. The counter starts from the declared start value or load value in negative direction, counts to 1 and then jumps to start value at the next negative encoder pulse. Function is disable with count continuously. ■ Cancel count: The count starts when the gate opens and resumes at the load value when the gate opens again. ■ Stop count: The count is interrupted when the gate closes and resumed at the last actual counter value when the gate opens again. ■ 'Gate function'page 143 Start value with counting direction backward. End value with main counting direction forward. Range of values: 22147483647 (2³¹-1) The count value is compared with the comparison value. See also the parameter "Characteristics of the output": ■ No main counting direction - Range of values: -2³¹ to +2)³¹-1 ■ Main counting direction forward - Range of values: 1 to +2³¹-1 The hysteresis serves the avoidance of many toggle processes of the output, if the counter value is in the range of the comparison value. 0, 1: Hysteresis disabled Range of values: 0 to 255 Description Specify the signal of the connected encoder: ■ Pulse/direction At the input count and direction signal are connected At the input there is an encoder connected with the following evaluation: - Rotary encoder single - Rotary encoder double

Input	Description	Assignment
Hardware gate	Gate control exclusively via channel 3:	disabled
	enabled: The gate control for channel 3 happens via SW and HW gate	
	disabled: The gate control for channel 3 exclusively happens via SW gate	
	→ 'Gate function'page 143	
Count direction inverted	Invert the input signal 'Direction':	disabled
	■ enabled: The input signal is inverted	
	disabled: The input signal is not inverted	
Output	Description	Assignment
Characteristics of the output	The output and the "Comparator" (STS_CMP) status bit are set, dependent on this parameter.	No comparison
	No comparison: The output is used as normal output and STS_CMP remains reset.	
	■ Comparator	
	 Counter value ≥ Comparison value 	
	 Counter value ≤ Comparison value 	
	Pulse at comparison value	
	 To adapt the used actuators you can specify a pulse duration. The output is set for the specified pulse duration when the counter value reaches the comparison value. When you've set a main counting direction the output is only set at reaching the comparison value from the main counting direction. 	
Pulse duration	Here you can specify the <i>pulse duration</i> for the output signal.	0
	The pulse duration starts with the setting of the according digital output.	
	■ The inaccuracy of the <i>pulse duration</i> is less than 1ms.	
	There is no past triggering of the pulse duration when the comparison value has been left and reached again during pulse output.	
	If the pulse duration is changed during operation, it will take effect with the next pulse.	
	■ If the <i>pulse duration</i> = 0, the output is set until the comparison condition is not longer fulfilled.	
	Range of values: 0510ms in steps of 2ms	
Hardware interrupt	Description	Assignment
Hardware gate opening	Hardware interrupt by edge 0-1 exclusively at HW gate channel 3	disabled
	 enabled: Process interrupt by edge 0-1 exclusively at HW gate channel 3 with open SW gate 	
	disabled: no hardware interrupt	

Hardware interrupt	Description	Assignment
Hardware gate closing	Hardware interrupt by edge 1-0 exclusively at HW gate channel 3	disabled
	 enabled: Process interrupt by edge 1-0 exclusively at HW gate channel 3 with open SW gate disabled: no hardware interrupt 	
On reaching comparator	Hardware interrupt on reaching comparator	disabled
	 enabled: Hardware interrupt when comparator is triggered, can be configured via 'Characteristics of the output' disabled: no hardware interrupt 	
Overflow	Hardware interrupt overflow	disabled
Overnow	 enabled: Hardware interrupt on overflow the upper counter limit 	uisabieu
	disabled: no hardware interrupt	
Underflow	Hardware interrupt on underrun	disabled
	enabled: Hardware interrupt on underflow the lower counter limit	
	disabled: no hardware interrupt	

Max. frequency	Description		Assignment
Counting signals/HW gate	Specify the max. frequency for track A/pulse, track B/direction and HW gate		60kHz
	Frequency	shortest permissible count pulse	
	1kHz	400µs	
	2kHz	200µs	
	5kHz	80µs	
	10kHz	40µs	
	30kHz	13µs	
	60kHz	6.7µs	
Latch	Specify the max. frequency for the latch signal		10kHz
	Frequency	shortest permissible Latch pulse	
	1kHz	400µs	
	2kHz	200µs	
	5kHz	80µs	
	10kHz	40µs	
	30kHz	13µs	
	60kHz	6.7µs	

5.6.5 Counter operating modes

5.6.5.1 Count continuously

- In this operating mode the counter counts starting with the load value.
- When the counter counts forward and reaches the upper count limit and another counting pulse in positive direction arrives, it jumps to the lower count limit and counts from there on.
- When the counter counts backwards and reaches the lower count limit and another counting pulse in negative direction arrives, it jumps to the upper count limit and counts from there on.
- The counter limits are fix set to maximum range.
- With overflow or underflow the status bits STS_OFLW respectively STS_UFLW in the SFB 47 are set. These bits remain set until these are reset with RES_STS. If enabled additionally a hardware interrupt is triggered.

Limits	Valid range of values
Lower count limit	-2 147 483 648 (-2 ³¹)
Upper count limit	+2 147 483 647 (231 -1)



5.6.5.2 Count once

5.6.5.2.1 No main counting direction


- The counter counts once starting with load value.
- It is counted forward or backward.
- The counter limits are fix set to maximum range.
- At over- or underflow at the count limits, the counter jumps to the according other count limit and the gate is automatically closed.
- To restart the count process, you have to generate an edge 0-1 at the gate → 'Gate function'...page 143.
- With the configured 'Gate function' 'Interrupt count' the counting is continued with current Counter value.
- With configured 'Gate function' 'Cancel count' the counter starts with the Load value.

Limits	Valid range of values
Lower count limit	-2 147 483 648 (-2 ³¹)
Upper count limit	+2 147 483 647 (2 ³¹ -1)

Interrupting gate control



Aborting gate control



5.6.5.2.2 Main counting direction forward

- The counter counts forward starting with the load value.
- When the counter reaches the *End value* -1 in positive direction, it jumps to the *load value* at the next count pulse and the gate is automatically closed.
- To restart the count process, you have to generate an edge 0-1 at the gate → 'Gate function'...page 143. The counter counts starting with the load value.
- You may exceed the lower count limit.


Limits	Valid range of values
End value	-2 147 483 647 (-2 ³¹ +1)
	up to +2 147 483 647 (231 -1)
Lower count limit	-2 147 483 648 (-2 ³¹)



5.6.5.2.3 Main counting direction backward

- The counter counts backward starting with the load value.
- When the counter reaches the *End value* +1 in positive direction, it jumps to the *load value* at the next count pulse and the gate is automatically closed.
- To restart the count process, you have to generate an edge 0-1 at the gate → 'Gate function'...page 143. The counter counts starting with the load value.
- You may exceed the upper count limit.

Limits	Valid range of values
End value	-2 147 483 648 (-2 ³¹)
	up to +2 147 483 646 (231 -2)
Upper count limit	+2 147 483 647 (2 ³¹ -1)



5.6.5.3 Count periodically

5.6.5.3.1 No main counting direction

- The counter counts forward or backwards starting with the load value.
- At over- or underrun at the count limits, the counter jumps to the *load value* and continues counting. If enabled additionally a hardware interrupt is triggered.
- The counter limits are fix set to maximum range.

Limits	Valid range of values
Lower count limit	-2 147 483 648 (-2 ³¹)
Upper count limit	+2 147 483 647 (2 ³¹ -1)



5.6.5.3.2 Main counting direction forward

- The counter counts forward starting with the load value.
- When the counter reaches the end value -1 in positive direction, it jumps to the load value at the next positive count pulse and continues counting. If enabled additionally a hardware interrupt is triggered.
- You may exceed the lower count limit.


Limits	Valid range of values
End value	-2 147 483 647 (-2 ³¹ +1)
	up to +2 147 483 647 (231 -1)
Lower count limit	-2 147 483 648 (-2 ³¹)



5.6.5.3.3 Main counting direction backward

- The counter counts backward starting with the load value.
- When the counter reaches the end value +1 in negative direction, it jumps to the load value at the next negative count pulse and continues counting. If enabled additionally a hardware interrupt is triggered.
- You may exceed the upper count limit.

Limits	Valid range of values
End value	-2 147 483 648 (-2 ³¹)
	up to +2 147 483 646 (231 -2)
Upper count limit	+2 147 483 647 (2 ³¹ -1)




Counting > Counter - Additional functions

5.6.6 Counter - Additional functions

5.6.6.1 Overview

Schematic structure

The illustration shows how the additional functions influence the counting behavior. The following pages describe these additional functions in detail:



5.6.6.2 Gate function

Function


- Starting, stopping and interrupting a count function of counter 0 to counter 2 exclusively happens via the SW gate by setting the SW gate of SFB 47.
- Starting, stopping and interrupting a count function of counter 3 happens via the internal gate (I gate). The i gate is the result of logic operation of HW gate and SW gate. The HW gate evaluation of the connection 'Gate 3' may be deactivated by the parametrization. With a de-activated HW gate evaluation the triggering exclusively happens by setting the SW gate of SFB 47.

Gate function abort and interrupt

The parametrization defines if the gate interrupts or aborts the counter process.

At abort function the counter starts counting with the load value after gate restart.

Counting > Counter - Additional functions



At interrupt function, the counter starts counting with the last recent counter value after gate restart.



Counter 0 ... 2

SW gate	Gate function	Reaction counter 0 2
Edge 0-1	Abort count process	Restart with load value
Edge 0-1	Interrupt count process	Continue

5.6.6.3 Comparator

Function

In the CPU a *comparison value* may be stored. During the counting procedure the counter value is compared with the *comparative value*. Depending on the result of the comparison the output channel of the counter and the status bit of STS_CMP of SFB 47 can be set. In addition, you can configure a hardware interrupt. A *comparison value* can be specified via the parametrization respectively the job interface of SFB 47.

5.6.6.4 Additional functions counter 3

Exclusively counter 3 has the following additional functions:

- HW gate via Gate 3
- Latch function

5.6.6.4.1 HW gate via *Gate 3*

Starting, stopping and interrupting a count function of counter 3 happens via the internal gate (I gate). The i gate is the result of logic operation of HW gate and SW gate. The HW gate evaluation of the connection 'Gate 3' may be deactivated by the parametrization. With a de-activated HW gate evaluation the triggering exclusively happens by setting the SW gate of the SFB 47.

Counter 3:

SW gate	HW gate	Gate function	Reaction counter 3:
Edge 0-1	de-activated	Abort count process	Restart with load value
Edge 0-1	de-activated	Interrupt count process	Continue
Edge 0-1	1	Abort count process	Continue
1	Edge 0-1	Abort count process	Restart with load value
Edge 0-1	1	Interrupt count process	Continue
1	Edge 0-1	Interrupt count process	Continue

Counter 3 - count once

If the internal gate has been closed automatically it may only be opened again under the following conditions:						
SW gate	HW gate	I gate				
1	Edge 0-1	1				
Edge 0-1 (after edge 0-1 at HW gate)	Edge 0-1	1				

5.6.6.4.2 Latch function

Function

- As soon as during a count process an edge 0-1 is recognized at the "Latch" input of counter 3, the current counter value is stored in the according latch register.
- You may access the latch value via the parameter LATCHVAL of the SFB 47.
- A just in LATCHVAL loaded value remains after a STOP-RUN transition.

5.6.6.5 Counter output channel

Characteristics of the output

Each counter has an output channel. You pre-define the behavior of the counter output via the parametrization:

- no comparison:
 - The output is used as normal output.
 - SFB 47:

The input parameter CTRL DO is effect less.

The status bits STS_DO and STS_CMP (status comparator in the instance DB) remain reset.

- Counter value ≥ comparison value respectively counter value ≤ comparison value
 - The output remains set as long as the counter value is higher or equal *comparison* value respectively lower or equal *comparison* value.
 - SFB 47:

Control bit CTRL DO must be set.

The comparison result is shown by the status bit STS_CMP. This status bit may only be reset if the comparison condition is no longer fulfilled.

- Pulse at comparison value
 - When the counter reaches the *comparison value* the output is set for the parametrized *pulse duration*. When you've set a main counting direction the output is only set at reaching the *comparison value* from the main counting direction.

If the *pulse duration* = 0, the output is set until the comparison condition is not longer fulfilled.

SFB 47:

Control bit CTRL DO must be set.

The status of the digital output may be shown by the status bit ST_DO.

The comparison result is shown by the status bit STS_CMP. The bit may only be reset if the *pulse duration* has expired.

- Pulse duration
 - The pulse duration starts with the setting of the according digital output.
 - The inaccuracy of the pulse duration is less than 1ms.
 - There is no past triggering of the pulse duration when the comparison value has been left and reached again during pulse output.
 - If the *pulse duration* is changed during operation, it will take effect with the next pulse.
 - If the pulse duration = 0, the output is set until the comparison condition is not longer fulfilled.
 - Range of values: 0...510ms in steps of 2ms

5.6.6.6 Hysteresis function


Hysteresis

- The *hysteresis* serves the avoidance of many toggle processes of the output and the interrupt, if the *counter value* is in the range of the *comparison value*.
- For the hysteresis you may set a range of 0 to 255.
- The settings 0 and 1 deactivate the hysteresis.
- The *hysteresis* influences zero run, comparison, over- and underflow.
- An activated hysteresis remains active after a change. The new hysteresis range is activated with the next hysteresis event.

The following pictures illustrate the output behavior for *hysteresis* 0 and *hysteresis* 3 for the according conditions:

Effect at counter value ≥ comparison value

Counter value




- 1 Counter value ≥ comparison value → output is set and hysteresis activated
- 2 Leave *hysteresis* range → output is reset
- 3 Counter value ≥ comparison value → output is set and hysteresis activated
- 4 Leave hysteresis range, output remains set for counter value ≥ comparison value
- 5 counter value < comparison value and hysteresis active → output is reset
- 6 counter value ≥ comparison value → output is not set for hysteresis active
- 7 Leave *hysteresis* range, output remains set for *counter value* ≥ *comparison value*

With reaching the comparison condition the *hysteresis* gets active. At active *hysteresis* the comparison result remains unchanged until the *counter value* leaves the set *hysteresis* range. After leaving the *hysteresis* range a new *hysteresis* is only activated with again reaching the comparison conditions.

Effect at pulse at comparison value with pulse duration Zero

Counter value




- 1 Counter value = comparison value → output is set and hysteresis activated
- 2 Leave *hysteresis* range → output is reset and *counter value < comparison value*
- 3 Counter value = comparison value → output is set and hysteresis activated
- 4 Output is reset for leaving hysteresis range and counter value > comparison value
- 5 Counter value = comparison value → output is set and hysteresis activated
- 6 Counter value = comparison value and hysteresis active → output remains set
- 7 Leave *hysteresis* range and *counter value* > comparison value → output is reset

With reaching the comparison condition the *hysteresis* gets active. At active *hysteresis* the comparison result remains unchanged until the *counter value* leaves the set *hysteresis range*. After leaving the *hysteresis* range a new *hysteresis* is only activated with again reaching the comparison conditions.

Counting > Diagnostics and interrupt

Effect at pulse at comparison value with pulse duration not zero

Counter value



- 1 Counter value = comparison value → pulse of the parameterized pulse duration is put out, the hysteresis is activated and the counting direction stored
- 2 Leaving the *hysteresis* range contrary to the stored counting direction → pulse of the parameterized *pulse duration* is put out, the *hysteresis* is de-activated
- 3 Counter value = comparison value → pulse of the parameterized pulse duration is put out, the hysteresis is activated and the counting direction stored
- 4 Leaving the *hysteresis* range without changing counting direction → *hysteresis* is de-activated
- 5 Counter value = comparison value → pulse of the parameterized pulse duration is put out, the hysteresis is activated and the counting direction stored
- 6 Counter value = comparison value and hysteresis active → no pulse
- 7 Leaving the *hysteresis* range contrary to the stored counting direction → pulse of the parameterized *pulse duration* is put out, the *hysteresis* is de-activated

With reaching the comparison condition the *hysteresis* gets active and a pulse of the parameterized duration is put out. As long as the *counter value* is within the *hysteresis* range, no other pulse is put out. With activating the *hysteresis* the counting direction is stored in the module. If the *counter value* leaves the *hysteresis* range <u>contrary</u> to the stored counting direction, a pulse of the parameterized duration is put out. Leaving the *hysteresis* range without direction change, no pulse is put out.

5.6.7 Diagnostics and interrupt

Overview

GSDML

Edge at an digital interrupt input

Via the hardware configuration you can define the following trigger for a hardware interrupt that can trigger a diagnostics interrupt:

- Reaching the comparison value
- Overflow respectively at overrun upper counter limit
- Underflow respectively at underrun lower counter limit
- Opening the HW gate with open SW gate except for counter 3
- Closing the HW gate with open SW gate except for counter 3

Frequency measurement > Properties


5.7 Frequency measurement

5.7.1 Properties

- In this operating mode the CPU counts the incoming pulses during a specified integration time and outputs them as frequency value.
- Integration time 10ms ... 10000ms in steps of 1ms configurable
- Control by the user program via SFB 48

j


More information about the usage of this block may be found in the manual "SPEED7 Operation List".



- 1 Integration time
- 2 Counting pulse
- 3 SW gate
- 4 Frequency measurement start
- 5 Frequency measurement stop

Measuring procedure

- The measurement is carried out during the integration time and is updated after the integration time has expired.
- If the period of the measured frequency exceeds the assigned integration time, this means there was no edge 0-1 during the measurement, the measurement value 0 is returned.
- The calculated frequency value is supplied in "mHz" units.
- The measurement value can be read with MEAS VAL from SFB 48.
- As long as the SW gate is open, you can request the calculated frequency.
- The number of activated channels does not influence the max. frequency, which is defined in the technical data.



- 1 Integration time
- 2 Counting pulse
- 3 SW gate
- 4 Evaluated frequency

Frequency measurement > Wiring


The counting function is disabled during the pulse width modulation on the same channel.

5.7.2 Wiring

5.7.2.1 Frequency measurement inputs


Connect the signal to be measured at input B of the corresponding counter.

X1: DI byte 0



X1	Function	Type	LED green	Description
1	DI 0.7	1		Frequency measurement 21
4	DI 0.4	I		Frequency measurement 1 ¹
7	DI 0.1	1		Frequency measurement 01
9	0 V	1		3M: GND for frequency measurement
10	DC 24V	I		3L+: DC 24V power section supply for frequency measurement
1) Max. input frequency 100kHz otherwise 1kHz.				

X5: DI byte 1



Frequency measurement > Parametrization

X5	Function	Туре	LED green	Description
5	DI 1.2	I		Frequency measurement 31
1) Max. input frequency 100kHz otherwise 1kHz.				

5.7.3 Proceeding

Hardware configuration

In the Siemens SIMATIC Manager the following steps should be executed:

- 1. ▶ Perform a hardware configuration for the CPU. → 'Hardware configuration CPU'...page 72
- 2. Double-click the counter sub module of the CPU 314C-2 PN/DP (314-6EH04-0AB0 V3.3).
 - → The dialog 'Properties' is opened.
- As soon as you select the operating mode for the corresponding channel, a dialog box with default values for this counter mode is created and shown. Select for the corresponding channel the operating mode *'Frequency counting'*.
- **4.** Perform the required parameter settings.
- **5.** ▶ Safe your project with 'Station → Safe and compile'.
- **6.** Transfer your project to your CPU.

User program

- The SFB 48 should cyclically be called (e.g. OB 1) for controlling the frequency measurement.
- The SFB is to be called with the corresponding instance DB. Here the parameters of the SFB are stored.

5.7.4 Parametrization

5.7.4.1 Address assignment

Sub module	Input address	Access	Description
Counter	816	DINT	Channel 0: Frequency value
	820	DINT	Channel 1: Frequency value
	824	DINT	Channel 2: Frequency value
	828	DINT	Channel 3: Frequency value

Sub module	Output address	Access	Description
Counter	816	DWORD	reserved
	820	DWORD	reserved
	824	DWORD	reserved
	828	DWORD	reserved

Frequency measurement > Parametrization

5.7.4.2 Interrupt selection


Via 'Basic parameters' you can reach 'Select interrupt'. Here you can define the interrupts the CPU will trigger. The following parameters are supported:

- None: The interrupt function is de-activated.
- Process: The following events of the frequency measurement can trigger a hardware interrupt (selectable via 'Frequency counting'):
 - End of measurement
- Diagnostics and process: A diagnostics interrupt is only triggered when a hardware interrupt was lost.

5.7.4.3 Frequency measurement

Parameter hardware configuration

Default values and structure of this dialog box depend on the selected 'Operating mode'. The following parameters are relevant for frequency measurement, which must be specified or determined:



- 1 Integration time
- 2 Counting pulse
- 3 SW gate
- 4 Evaluated frequency

Parameter overview

Operating parameters	Description	Assignment	
Integration time	Specify the integratio	n time	100ms
	Range of values: 10n	ns 10000ms in steps of 1ms	
max. counting frequency	Specify the max. freq	uency for the corresponding input	60kHz
	Frequency	shortest permissible count pulse	
	1kHz	400µs	
	2kHz	200µs	
	5kHz	80µs	
	10kHz	40µs	
	30kHz	13µs	
	60kHz	6.7µs	

Hardware interrupt	Description	Assignment
End of measurement	Hardware interrupt at end of measurement	de-activated

Frequency measurement > Status indication

5.7.5 Status indication

X1	Function	Туре	LED	Description
			green	
1	DI 0.7	I		Digital input DI 7 / Counter 2 (B) / Frequency 21
2	DI 0.6	I		Digital input DI 6 / Counter 2 (A) ¹
3	DI 0.5	I		Digital input DI 5
4	DI 0.4	I		Digital input DI 4 / Counter 1 (B) / Frequency 1 ¹
5	DI 0.3	I		Digital input DI 3 / Counter 1 (A) ¹
6	DI 0.2	I		Digital input DI 2
7	DI 0.1	I		Digital input DI 1 / Counter 0 (B) / Frequency 01
8	DI 0.0	I		Digital input DI 0 / Counter 0 (A) ¹
9	0 V	I		3M: GND for onboard DI power section supply
10	DC 24V	I		3L+: DC 24V for onboard DI power section supply
1) Max. input frequency 100kHz otherwise 1kHz.				

X5	Function	Туре	LED	Description
			green	
1	-	-		reserved
2	-	-		reserved
3	DI 1.0	I		Digital input DI 8
4	DI 1.1	I		Digital input DI 9 / Counter 3 (A) ¹
5	DI 1.2	I		Digital input DI 10 / Counter 3 (B) / Frequency 31
6	DI 1.3	I		Digital input DI 11 / Gate 31
7	DI 1.4	1		Digital input DI 12
8	DI 1.5	I		Digital input DI 13
9	DI 1.6	1		Digital input DI 14
10	DI 1.7	I		Digital input DI 15 / Latch 3 ¹
1) Max. input frequency 100kHz otherwise 1kHz.				

DI +x

Digital input	LED	Description
	green	
DI +0.0 DI +0.7		Digital I+0.0 0.7 has "1" signal
		Digital I+0.0 0.7 has "0" signal
DI +1.0 DI +1.7		Digital input I+1.0 1.7 has "1" signal
		Digital input I+1.0 1.7 has "0" signal

Pulse width modulation - PWM > Properties

xL+

Power supply	LED	Description
	green	
1L+		DC 24V electronic section supply
		DC 24V electronic section supply not available
3L+		DC 24V power section supply inputs OK
		DC 24V power section supply inputs not available
4L+		DC 24V power section supply outputs OK
		DC 24V power section supply outputs not available

хF


Error	LED	Description
	green / red	
4M		Error, overload respectively short circuit on the outputs
		no error

5.8 Pulse width modulation - PWM

5.8.1 Properties

- By presetting of time parameters, the CPU evaluates a pulse sequence with according pulse/pause ratio and outputs it via the according output channel.
- Channel 0 and 1 are supported
- Control by the user program via SFB 49

More information about the usage of this block may be found in the manual "SPEED7 Operation List".



- 1 Period
- 2 On-delay
- 3 Pulse duration
- 4 Pulse pause




The counting function is disabled during the pulse width modulation on the same channel.

Pulse width modulation - PWM > Proceeding

5.8.2 Wiring

5.8.2.1 Pulse width modulation outputs

X2: DO byte 0



X2	Function	Туре	LED	Description
			green	
			red	
7	DO 0.1	0		PWM 1
8	DO 0.0	0		PWM 0
9	0 V	1		4M: GND for PWM
				LED (red) is on at short circuit respectively overload
10	DC 24V	1		4L+: DC 24V power section supply for PWM

5.8.3 Proceeding

Hardware configuration

PWM and *pulse train* output use the same hardware configuration. Switching between these modes is done within the SFB 49. In the Siemens SIMATIC Manager the following steps should be executed:

- 1. ▶ Perform a hardware configuration for the CPU. → 'Hardware configuration CPU'...page 72
- 2. Double-click the counter sub module of the CPU 314C-2 PN/DP.
 - → The dialog 'Properties' is opened.
- 3. As soon as you select the operating mode for the corresponding channel, a dialog box with default values for this counter mode is created and shown. For *PWM* respectively *pulse train* output select for the corresponding channel the operating mode '*Pulse width modulation PWM*'.
- 4. Perform the required parameter settings.
- **5.** Safe your project with 'Station → Safe and compile'.
- **6.** ▶ Transfer your project to your CPU.

User program

- The SFB 49 should cyclically be called (e.g. OB 1) for controlling the pulse width modulation.
 - The SFB 49 is used for *PWM* and *pulse train* output.
 - The switching between the modes takes place by the presetting of the pulse number (JOB_ID = 08h/09h). As soon as you specify a pulse number > 0, you switch to the pulse train mode, otherwise PWM is active.
- The SFB is to be called with the corresponding instance DB. Here the parameters of the SFB are stored.

Pulse width modulation - PWM > Parametrization

5.8.4 Parametrization

5.8.4.1 Address assignment


Sub module	Input address	Access	Description
Counter	816	DINT	reserved
	820	DINT	reserved
	824	DINT	reserved
	828	DINT	reserved

Sub module	Output address	Access	Description
Counter	816	DWORD	reserved
	820	DWORD	reserved
	824	DWORD	reserved
	828	DWORD	reserved

5.8.4.2 Pulse width modulation

Parameter hardware configuration

Default values and structure of this dialog box depend on the selected 'Operating mode'. The following parameters are relevant for PWM, which must be specified or determined:



- 1 Period
- 2 On-delay
- 3 Pulse duration
- 4 Pulse pause

Parameter overview

Operating parameters	Description	Assignment
Output format	Here specify the range of values for the output. The CPU hereby determines the pulse duration:	Per mil
	 Per mil Output value is within 0 1000 Pulse duration = (Output value / 1000) x Period S7 Analog value: Output value is Siemens S7 analog value 0 27648 Pulse duration = (Output value / 27648) x Period 	
Time base	Here you can set the time base, which will apply for resolution and range of values of the period duration, minimum pulse duration and on-delay. 1ms: Die Time base is 1ms 0.1ms: Time base is 0.1ms	0.1ms

Pulse width modulation - PWM > Status indication

Operating parameters	Description	Assignment			
On-delay	Enter here a value for the time to expire from the start of the output sequence to the output of the pulse. The pulse sequence is output at the output channel, on expiration of the on-delay.	0			
	Range of values: 0 65535 from this there are the following effective values:				
	Time base 1ms: 0 65535msTime base 0.1ms: 0 6553.5ms				
Period	With the period you define the length of the output sequence, which consists of pulse duration and pulse pause.	50 ¹			
	Range of values:				
	Time base 1ms: 1 87ms				
	Time base 0.1ms: 0.4 87.0ms				
Minimum pulse duration	With the minimum pulse duration you can suppress short output pulses and short pulse pauses. All pulses or pauses, which are smaller than the minimum pulse duration, are suppressed. This allows you to filter very short pulses (spikes), which can not be recognized by the periphery.	2			
	Range of values:				
	Time base 1ms: 0 Period / 2 * 1ms				
	Time base 0.1ms: 2 Period / 2 * 0.1ms				
1) This value can vary depending on the configuration tool and can be out of range. Values, which are out of range are invalid and must be adjusted accordingly!					

5.8.5 Status indication

Digital output	LED	Description
	green	
DO +0.0		PWM 0 has "1" signal
		PWM 0 has "0" signal
DO +0.1		PWM 1 has "1" signal
		PWM 1 has "0" signal

Pulse train > Properties

xL+

Power supply	LED	Description
	green	
1L+		DC 24V electronic section supply
		DC 24V electronic section supply not available
3L+		DC 24V power section supply inputs OK
		DC 24V power section supply inputs not available
4L+		DC 24V power section supply outputs OK
		DC 24V power section supply outputs not available

хF

Error	LED	Description
	green / red	
4M		Error, overload respectively short circuit on the outputs
		no error

5.9 Pulse train


5.9.1 Properties

- By presetting of time parameters, the CPU evaluates a pulse sequence with according pulse/pause ratio and outputs it via the according output channel.
- The output is as a pulse-direction command (P/D).
 - Output frequency pattern via pulse train channel
 - To output the direction, an additional output is to be used, which is to be controlled via your user program.
- Channel 0 and 1 are supported
- Control by the user program via SFB 49



More information about the usage of this block may be found in the manual "SPEED7 Operation List".

Pulse train > Wiring



- 1 Number of pulses
- 2 Period duration
- 3 Pulse duration
- 4 Pulse pause




The counting function is disabled during the pulse train output on the same channel.

5.9.2 Wiring

5.9.2.1 Pulse train outputs

X2: DO byte 0



X2	Function	Туре	LED	Description
			green	
			red	
7	DO 0.1	0		Pulse train 1
8	DO 0.0	0		Pulse train 0
9	0 V	I		4M: GND for pulse train
				LED (red) is on at short circuit respectively overload
10	DC 24V	1		4L+: DC 24V power section supply for pulse train

Pulse train > Parametrization

5.9.3 Proceeding

Hardware configuration

PWM and *pulse train* output use the same hardware configuration. Switching between these modes is done within SFB 49. In the Siemens SIMATIC Manager the following steps should be executed:

- 1. ▶ Perform a hardware configuration for the CPU. → 'Hardware configuration CPU'...page 72
- 2. Double-click the counter sub module of the CPU 314C-2 PN/DP.
 - → The dialog 'Properties' is opened.
- 3. As soon as you select the operating mode for the corresponding channel, a dialog box with default values for this counter mode is created and shown. For *PWM* respectively *pulse train* output select for the corresponding channel the operating mode '*Pulse width modulation PWM*'.
- **4.** Perform the required parameter settings.
- **5.** ▶ Safe your project with 'Station → Safe and compile'.
- **6.** Transfer your project to your CPU.

User program

- The SFB 49 should cyclically be called (e.g. OB 1) for controlling the pulse train output.
 - The SFB 49 is used for PWM and pulse train output.
 - The switching between the modes takes place by the presetting of the pulse number (JOB_ID = 08h/09h). As soon as you specify a pulse number > 0, you switch to the pulse train mode, otherwise PWM is active.
 - To output the direction, an additional output is to be used, which is to be controlled via your user program.
- The SFB is to be called with the corresponding instance DB. Here the parameters of the SFB are stored.

5.9.4 Parametrization

5.9.4.1 Address assignment

Sub module	Input address	Access	Description
Counter	816	DINT	reserved
	820	DINT	reserved
	824	DINT	reserved
	828	DINT	reserved


Sub module	Output address	Access	Description
Counter 816 820 824 828 828	816	DWORD	reserved
	820	DWORD	reserved
	824	DWORD	reserved
	828	DWORD	reserved

Pulse train > Parametrization

5.9.4.2 Pulse train output

Parameter hardware configuration

Default values and structure of this dialog box depend on the selected 'Operating mode'. For pulse train following parameters are relevant, to be specified or determined:



- Number of pulses
- Period duration 2
- Pulse duration
- 3 Pulse pause

Parameter overview

Operating parameters	Description	Assignment
Output format	Here specify the range of values for the output. The CPU hereby determines the pulse duration:	Per mil
	■ Per mil	
	 Output value is within 0 1000 	
	 Pulse duration = (Output value / 1000) x period duration 	
	S7 Analog value:	
	 Output value is Siemens S7 analog value 0 27648 	
	 Pulse duration = (Output value / 27648) x period duration 	
Time base	Here you can set the time base, which will apply for resolution and range of values of the period duration, minimum pulse duration and on-delay.	0.1ms
	■ 1ms: The time base is 1ms	
	■ 0.1ms: Time base is 0.1ms	
On-delay	This parameter is ignored.	0
Period duration	With <i>period duration</i> you define the length of the output sequence, which consists of pulse duration and pulse pause.	50 ¹
	Range of values:	
	Time base 1ms: 1 87ms	
	Time base 0.1ms: 0.4 87.0ms	

Pulse train > Status indication

Operating parameters	Description	Assignment
Minimum pulse duration	With the <i>minimum pulse duration</i> you can suppress short output pulses and short pulse pauses. All pulses or pauses, which are smaller than the <i>minimum pulse duration</i> , are suppressed. This allows you to filter very short pulses (spikes), which can not be recognized by the periphery.	2
	Range of values:	
	Time base 1ms: 0 Period duration / 2 * 1ms	
	Time base 0.1ms: 2 Period duration / 2 * 0.1ms	
1) This value can vary depending on the configuration tool and can be out of range. Values, which are out of range are invalid and must be adjusted accordingly!		

5.9.5 Status indication

Digital output	LED	Description
	green	
DO +0.0		Pulse train 0 has "1" signal
		Pulse train 0 has "0" signal
DO +0.1		Pulse train 1 has "1" signal
		Pulse train 1 has "0" signal

xL+

Power supply	LED	Description
	green	
1L+		DC 24V electronic section supply
		DC 24V electronic section supply not available
3L+		DC 24V power section supply inputs OK
		DC 24V power section supply inputs not available
4L+		DC 24V power section supply outputs OK
		DC 24V power section supply outputs not available

хF

Error	LED	Description
	green / red	
4M		Error, overload respectively short circuit on the outputs
		no error

Diagnostic and interrupt > Process interrupt

5.10 Diagnostic and interrupt

5.10.1 Overview

Hardware interrupt

The parametrization allows you to define the following trigger for a hardware interrupt:

- Edge at an digital interrupt input
- Reaching the comparison value
- Overflow respectively at overrun upper counter limit
- Underflow respectively at underrun lower counter limit
- Opening the HW gate with open SW gate except for counter 3
- Closing the HW gate with open SW gate except for counter 3

Diagnostics interrupt

164

The product specific parameters allow you to define the following trigger for a diagnostics interrupt (Setting product specific CPU parameters'...page 82:

- Hardware interrupt lost
- Error: 4L+ DC 24V DO power section supply
- Error: 3L+: DC 24V DI power section supply
- Short circuit overload: DO

5.10.2 Process interrupt



An interrupt for the corresponding channel operating mode can only be triggered if you have additionally parameterized 'Diagnostics+Process' at 'Select interrupt' of the 'Basic parameters'.

A process interrupt causes a call of the OB 40. Within the OB 40 you may find the logical basic address of the module that initialized the process interrupt by using the Local word 6. More detailed information about the initializing event is to find in the *local double word* 8. The assignment of *local double word* 8 depends on the parameterized operating mode of each channel.

Local double word 8 of OB 40 at Alarm Inputs

Local byte	Bit 70
8	 Bit 0: Edge at I+0.0 Bit 1: Edge at I+0.1 Bit 2: Edge at I+0.2 Bit 3: Edge at I+0.3 Bit 4: Edge at I+0.4 Bit 5: Edge at I+0.5 Bit 6: Edge at I+0.6 Bit 7: Edge at I+0.7
9	 Bit 0: Edge at I+1.0 Bit 1: Edge at I+1.1 Bit 2: Edge at I+1.2 Bit 3: Edge at I+1.3 Bit 4: Edge at I+1.4 Bit 5: Edge at I+1.5 Bit 6: Edge at I+1.6 Bit 7: Edge at I+1.7

Diagnostic and interrupt > Process interrupt

Local byte	Bit 70
1011	■ Bit 7 0: reserved

Local double word 8 of OB 40 at counter function

Local byte	Bit 70
8	 Bit 1, 0: 0 (fix) Bit 2: Over-/underflow value counter 0 Bit 3: Counter 0 reached comparison value Bit 7 4: 0 (fix)
9	 Bit 1, 0: 0 (fix) Bit 2: Over-/underflow value counter 1 Bit 3: Counter 1 reached comparison value Bit 7 4: 0 (fix)
10	 Bit 1, 0: 0 (fix) Bit 2: Over-/underflow value counter 2 Bit 3: Counter 2 reached comparison value Bit 7 4: 0 (fix)
11	 Bit 0: Gate counter 3 open (activated) Bit 1: Gate counter 3 closed Bit 2: Over-/underflow value counter 3 Bit 3: Counter 3 reached comparison value Bit 4: Counter 3 new latch value Bit 7 5: 0 (fix)

Local double word 8 of OB 40 at frequency measurement

Local byte	Bit 70
8	 Bit 0: End of measurement channel 0 (end of the integration time) Bit 7 1: 0 (fix)
9	 Bit 0: End of measurement channel 1 (end of the integration time) Bit 7 1: 0 (fix)
10	 Bit 0: End of measurement channel 2 (end of the integration time) Bit 7 1: 0 (fix)
11	 Bit 0: End of measurement channel 3 (end of the integration time) Bit 7 1: 0 (fix)

5.10.3 Diagnostic interrupt


Function



An interrupt for the corresponding channel operating mode can only be triggered if you have additionally parameterized 'Diagnostics+Process' at 'Select interrupt' of the 'Basic parameters'.

Via the parameterization (record set 7Fh) you may activate a global diagnostic interrupt for the module. A diagnostic interrupt occurs when during a process interrupt execution in OB 40 another process interrupt is thrown for the same event. The initialization of a diagnostic interrupt interrupts the recent process interrupt execution in OB 40 and branches in OB 82 to diagnostic interrupt processing incoming. If during the diagnostic interrupt processing other events are occurring at other channels that may also cause a process res. diagnostic interrupt, these are interim stored. After the end of the diagnostic interrupt processing at first all interim stored diagnostic interrupts are processed in the sequence of their occurrence and then all process interrupts. If a channel where currently a diagnostic interruptincoming is processed res. interim stored initializes further process interrupts, these get lost. When a process interrupt for which a diagnostic interruptincoming has been released is ready, the diagnostic interrupt processing is called again as diagnostic interruptoutgoing. All events of a channel between diagnostic interruptincoming and diagnostic interruptoutgoing are not stored and get lost. Within this time window (1. diagnostic interruptincoming until last diagnostic interruptoutgoing) the SF-LED of the CPU is on. Additionally for every diagnostic interruptincoming/outgoing an entry in the diagnostic buffer of the CPU occurs.

Example:



Diagnostic interrupt processing

Every OB 82 call causes an entry in the diagnostic buffer of the CPU containing error cause and module address. By using the SFC 59 you may read the diagnostic bytes. At de-activated diagnostic interrupt you have access to the last recent diagnostic event. If you've activated the diagnostic function in your hardware configuration, the contents of record set 0 are already in the local double word 8 when calling the OB 82. The SFC 59 allows you to also read the record set 1 that contains additional information. After leaving the OB 82 a clear assignment of the data to the last diagnostic interrupt is not longer possible. The record sets of the diagnostic range have the following structure:

Record set 0 Diagnosticincoming

Byte	Bit 70
0	 Bit 0: set at module failure Counter/Frequency measurement: Process interrupt lost Digital input: Process interrupt lost Missing power supply DI or DO Digital output: short circuit/overload Bit 1: set at internal error Missing power supply DI or DO Digital output: short circuit/overload Bit 2: set at external error Bit 3: set at channel error Bit 4: set at missing external power supply Bit 7 5: 0 (fix)
1	 Bit 3 0: Module class 1111b: Digital module or 1000b: Function module Bit 4: Channel information present Counter/Frequency measurement: Process interrupt lost Digital input: Process interrupt lost Missing power supply DI or DO Digital output: short circuit/overload Bit 7 5: 0 (fix)
2	 Bit 3 0: 0 (fix) Bit 4: set at missing internal power supply Missing power supply DI or DO Bit 7 5: 0 (fix)
3	 Bit 5 0: 0 (fix) Bit 6: Process interrupt lost Bit 7: 0 (fix)

Record set 0 Diagnostic_{out-going}

After the removing error a diagnostic message_{outgoing} takes place if the diagnostic interrupt release is still active.

Byte	Bit 70
0	 Bit 0: set at module failure Counter/Frequency measurement: Process interrupt lost Digital input: Process interrupt lost Missing power supply DI or DO Digital output: short circuit/overload Bit 1: set at internal error Missing power supply DI or DO Digital output: short circuit/overload Bit 2: set at external error Bit 3: set at channel error Bit 4: set at missing external power supply Bit 7 5: 0 (fix)

Byte	Bit 70
1	 Bit 3 0: Module class 1111b: Digital module or 1000b: Function module Bit 4: Channel information present Counter/Frequency measurement: Process interrupt lost Digital input: Process interrupt lost Missing power supply DI or DO Digital output: short circuit/overload Bit 7 5: 0 (fix)
2	 Bit 3 0: 0 (fix) Bit 4: set at missing internal power supply Missing power supply DI or DO Bit 7 5: 0 (fix)
3	■ Bit 7 0: 0 (fix)



The record set 0 of the alarm interrupts, counter function, frequency measurement and pulse width modulation has the same structure. There are differences in the structure of record set 1.

Diagnostic record set 1 at *Alarm Inputs*

The record set 1 contains the 4byte of the record set 0 and additionally 12byte module specific diagnostic data. The diagnostic bytes have the following assignment:

Byte	Bit 70
0 3	Content record set 0 → 'Record set 0 Diagnostic _{incoming} 'page 167
4	 Bit 6 0: Channel type (here 70h) 70h: Digital input Bit 7: More channel types present 0: no 1: yes
5	Number of diagnostic bits per channel (here 08h)
6	Number of channels of a module (here 08h)
7	 Bit 0: Error in channel group 0 (I+0.0 I+0.3) Bit 1: Error in channel group 1 (I+0.4 I+0.7) Bit 2: Error in channel group 2 (I+1.0 I+1.3) Bit 3: Error in channel group 2 (I+1.4 I+1.7) Bit 7 4: reserved

Byte	Bit 70
8	Diagnostic interrupt due to "process interrupt lost" at Bit 0: input I+0.0 Bit 1: 0 (fix) Bit 2: input I+0.1 Bit 3: 0 (fix) Bit 4: input I+0.2 Bit 5: 0 (fix) Bit 6: input I+0.3 Bit 7: 0 (fix)
9	Diagnostic interrupt due to "process interrupt lost" at Bit 0: input I+0.4 Bit 1: 0 (fix) Bit 2: input I+0.5 Bit 3: 0 (fix) Bit 4: input I+0.6 Bit 5: 0 (fix) Bit 6: input I+0.7 Bit 7: 0 (fix)
10	Diagnostic interrupt due to "process interrupt lost" at Bit 0: input I+1.0 Bit 1: 0 (fix) Bit 2: input I+1.1 Bit 3: 0 (fix) Bit 4: input I+1.2 Bit 5: 0 (fix) Bit 6: input I+1.3 Bit 7: 0 (fix)
11	Diagnostic interrupt due to "process interrupt lost" at Bit 0: input I+1.4 Bit 1: 0 (fix) Bit 2: input I+1.5 Bit 3: 0 (fix) Bit 4: input I+1.6 Bit 5: 0 (fix) Bit 5: 0 (fix) Bit 7: 0 (fix)
12 15	■ Bit 7 0: reserved

Diagnostic record set 1 at counter function

The record set 1 contains the 4byte of the record set 0 and additionally 12byte module specific diagnostic data. The diagnostic bytes have the following assignment:

Byte	Bit 70
0 3	Content record set 0 → 'Record set 0 Diagnosticincoming'page 167

Byte	Bit 70						
4	 Bit 6 0: Channel type (here 76h) 76h: Function module Bit 7: More channel types present 0: no 1: yes 						
5	Number of diagnostic bits per channel (here 08h)						
6	Number of channels of a module (here 04h)						
7	 Bit 0: Error in channel group 0 (Counter 0) Bit 1: Error in channel group 1 (Counter 1) Bit 2: Error in channel group 2 (Counter 2) Bit 3: Error in channel group 3 (Counter 3) Bit 7 4: reserved 						
8	Diagnostic interrupt due to "process interrupt lost" at Bit 1, 0: reserved Bit 2: Over-/underflow/end value counter 0 Bit 3: Counter 0 reached comparison value Bit 7 4: 0 (fix)						
9	Diagnostic interrupt due to "process interrupt lost" at Bit 1, 0: reserved Bit 2: Over-/underflow/end value counter 1 Bit 3: Counter 1 reached comparison value Bit 7 4: 0 (fix)						
10	Diagnostic interrupt due to "process interrupt lost" at Bit 1, 0: reserved Bit 2: Over-/underflow/end value counter 2 Bit 3: Counter 2 reached comparison value Bit 7 4: 0 (fix)						
11	Diagnostic interrupt due to "process interrupt lost" at Bit 0: Gate counter 3 open (activated) Bit 1: Gate counter 3 closed Bit 2: Over-/underflow/end value counter 3 Bit 3: Counter 3 reached comparison value Bit 4: Counter 3 new latch value Bit 7 5: 0 (fix)						
1215	■ Bit 7 0: reserved						

Diagnostic Record set 1 at frequency measurement

The record set 1 contains the 4byte of the record set 0 and additionally 12byte module specific diagnostic data. The diagnostic bytes have the following assignment:

Byte	Bit 70						
0 3	Content record set 0 → 'Record set 0 Diagnosticincoming'page 167						
4	 Bit 6 0: Channel type (here 76h) 76h: Function module Bit 7: More channel types present 0: no 1: yes 						
5	Number of diagnostic bits per channel (here 08h)						
6	Number of channels of a module (here 04h)						
7	 Bit 0: Error in channel group 4 (Frequency meter 0) Bit 1: Error in channel group 5 (Frequency meter 1) Bit 2: Error in channel group 6 (Frequency meter 2) Bit 3: Error in channel group 7 (Frequency meter 3) Bit 7 4: 0 (fix) 						
8	Diagnostic interrupt due to "process interrupt lost" at						
	 Bit 0: End of measurement channel 0 (End of integration time) Bit 7 1: 0 (fix) 						
9	Diagnostic interrupt due to "process interrupt lost" at						
	 Bit 0: End of measurement channel 1 (End of integration time) Bit 7 1: 0 (fix) 						
10	Diagnostic interrupt due to "process interrupt lost" at						
	Bit 0: End of measurement channel 2 (End of integration time)Bit 7 1: 0 (fix)						
11	Diagnostic interrupt due to "process interrupt lost" at						
	 Bit 0: End of measurement channel 3 (End of integration time) Bit 7 1: 0 (fix) 						
12 15	0 (fix)						

General

6 Deployment OPC UA

Ӭ́

Please note that the simultaneous use of OPC UA and WebVisu on the same interface is not supported! When attempting to activate them, both servers are stopped and the diagnostic message 0xE989 or 0xE9AB is output.

- With an OPC UA project there is the possibility to configure an OPC UA server on your CPU.
- The configuration of an *OPC UA* project is only possible with the *SPEED7 Studio* V1.8.6 and up.
- Since a OPC UA project is only executable by memory card, a Yaskawa memory card (VSD, VSC) must be plugged. Please note that you must always use a VSC card suitable for your CPU. → 'Deployment storage media VSD, VSC'...page 108
- If the memory card is removed for a short time, the SF LED gets on. This indicates that a feature is missing and the *OPC UA* server will quit after 72 hours.
- When the project is transferred from the *SPEED7 Studio*, the *OPC UA* project is automatically transferred as TAR file to the inserted memory card.
- The OPC UA server must be activated in the CPU. → 'Activate WebVisu functionality'...page 201
- The access is made with an OPC UA client via the 'Endpoint URL' of the corresponding interface. The 'Endpoint URL' can be found on the Device web page of the CPU. → 'Tab: 'OPC UA'...page 96

6.1 General

Term definitions

- OPC Open Platform Communications
 - OPC is an interoperability standard for secure and reliable data exchange in industrial automation.
 - OPC is platform-independent and ensures a seamless flow of information between devices from different manufacturers.
- UA Unified Architecture
 - UA specifies security features and data modelling based on a service-oriented architecture (SOA).

Precondition

- SPEED7 Studio from Version V1.8.6
 - The functionality for the OPC UA configuration is integrated in the SPEED7 Studio.
- Siemens SIMATIC Manager from version V5.5 and SPEED7 Studio from version V1.8.6
 - The OPC UA configuration is done with the OPC UA Configurator. This is part of the SPEED7 Studio from version V1.8.6.
 - When calling the OPC UA Configurator, the SPEED7 Studio opens with functionality limited to OPC UA configuration.
 - The OPC UA Configurator is to be called from the Siemens SIMATIC Manager as external device tool.
 - To be able to call the *OPC UA Configurator* as an external device tool, you must first register it in the Siemens SIMATIC Manager. This is done with *SPEED7 Tools Integration*, which is automatically installed during the installation of the *SPEED7 Studio*.
 - The OPC UA Configurator is to be called from the Siemens SIMATIC Manager after project creation and online configuration.

Basics OPC UA > OPC UA

- The OPC UA Configurator automatically imports the data for the OPC UA configuration from the project data of the Siemens SIMATIC Manager.
- The OPC UA configuration is transferred online from the OPC UA Configurator.
 The OPC UA Configurator automatically imports the data for the OPC UA configuration from the project data of the Siemens SIMATIC Manager.
- Siemens TIA Portal from version V15.0 and SPEED7 Studio from version V1.8.6
 - The OPC UA configuration is done with the OPC UA Configurator. This is part of the SPEED7 Studio from version V1.8.6.
 - When calling the OPC UA Configurator, the SPEED7 Studio opens with functionality limited to OPC UA configuration.
 - The OPC UA Configurator is to be called from the Siemens TIA Portal as external device tool.
 - To be able to call the OPC UA Configurator as an external device tool, you must first register it in the Siemens TIA Portal. This is done with SPEED7 Tools Integration, which is automatically installed during the installation of the SPEED7 Studio.
 - The OPC UA Configurator is to be called from the Siemens TIA Portal after project creation and online configuration.
 - The OPC UA Configurator automatically imports the data for the OPC UA configuration from the project data of the Siemens TIA Portal.
 - The OPC UA configuration is transferred online from the OPC UA Configurator.
 The OPC UA Configurator automatically imports the data for the OPC UA configuration from the project data of the Siemens TIA Portal.

6.2 Basics OPC UA

6.2.1 OPC UA

Standard for data and information exchange

OPC UA defines a common standard for data and information exchange in an 'Industry 4.0' environment. Due to the platform independence, the integrated security concept and the data type information supplied with the data, *OPC UA* provides the basis for machine-readable and cross-level communication.

OPC - Open Platform Communications

- Classic variant not scalable and exclusively for Microsoft Windows®
- For each type of data transfer, such as real-time data, history data, interrupts, events, etc., a separate solution with its own semantics is required, such as OPC DA, OPC HDA, OPC A&E, etc.
- Separate and complex effort required for security settings.
- OPC requires a complex DCOM configuration.
- OPC requires separate complex firewall settings.

OPC UA - Open Platform Communications Unified Architecture

- Scalable and platform-independent communication standard specified in IEC 62541.
- Standardization of classic OPC specifications with integrated security concept.
- The OPC UA security concept includes user and application authentication, message signing, and encryption of transmitted data.
- IP-based, optimized, binary protocol for Internet and firewall communication via one port (4840).
- With OPC UA, any type of information is available at any time and place for any authorized application and authorized person. For example, raw data and preprocessed information can be transported safely from the sensor and field level to the control system and into the production planning systems.

Basics OPC UA > Information modeling

- SOA (Service Oriented Architecture) replaces the Microsoft DCOM technology with open, platform-independent protocols with integrated security mechanisms.
 - Communication takes place via standardized services based on the *Information model* of OPC UA.
 - The services are divided into different task groups.
 - Based on a basic model, arbitrarily complex, object-oriented extensions of the services can be carried out, without affecting interoperability.

OPC UA server

- An OPC UA server provides information within a network that can be retrieved from an OPC UA client.
- The data exchange can take place via security certificates, which have to be stored accordingly in the server.
- The *OPC UA server* provides basic services such as data exchange or navigation through the address space.
- The OPC UA configuration is used to define the variables or contents that an OPC UA server should provide.
- The OPC UA configuration is done via an external tool such as for Yaskawa CPUs the OPC UA Configurator.

OPC UA client

OPC UA clients are programs with the following functionality:

- Read or write access to information of the OPC UA server.
- Access is controlled by access rights.
- Execute services on the OPC UA server.

Communication types

- Client/Server
 - An OPC UA client accesses information from the OPC UA server via services, provided by the OPC UA server. Here a fix defined connection is used.
 - Example: OPC UA client retrieves status of an input in the CPU.
- Publisher/Subscriber
 - A Publisher sends to unknown Subscriber (clients) without a fixed connection.
 - Example: Sensors send data to the cloud.

6.2.2 Information modeling

Information model

- Information models are used to describe devices and their data.
- The basis is the *Core specification*. The *Core specification* describes the structure of the address range and of the services, such as the entry points for the clients in the address space of an *OPC UA* server.
- In an information model, the content of the address space of the OPC UA server is described.
- The Information models are structured in layers. Each higher-order type is based on certain basic rules. Thus, clients who only know the basic rules can still edit complex information models, e.g. navigate through the address space and read or write data variables.
- In the address space, all information is represented by Nodes, which are interconnected via references.
- A node is always an instance of a NodeClass.
- OPC UA offers basic services such as data exchange or navigation through the address space. The services are grouped in Service Sets.

Basics OPC UA > Information modeling

Node classes

The following *NodeClasses* are defined in the *OPC UA* specification:

- Variable class of variables
- Method class of functions
- Object class of objects
- View Class of view of a subset of nodes
- DataType Class of the data types of the value of a variable
- VariableType Class of the data types of a variable
- ObjectType class of object types
- ReferenceType class of reference types

Node attributes

Each *node* consists of attributes and references. Some attributes may also be optional. The following attributes of each *NodeClass* must be published:

- NodeID Unique identifier of a nodes in the address space
- NodeClass class of node instance
- BrowseName name of the node in plain text
- DisplayName display name of the Node for the user
- Description Description of the node (optional)

OPC UA services

- OPC UA services are abstract descriptions defined by request and response messages.
- The available services of an *OPC UA* server are defined in the server profile and grouped together in service sets.

Basic service sets

- Discovery Service Set
 - Services for discovering existing servers and endpoints.
- SecureChannel Service Set
 - Services for opening and closing secure communication channels.
- Session Service Set
 - Services for the client to create and manage a session.
- NodeManagement Service Set
 - Services for creating and deleting nodes and references.
- View Service Set
 - Services for the client to navigate in the address space or in the view.
- Query Service Set
 - Services for search queries in the address space.
- Attribute Service Set
 - Services for accessing attributes of nodes.
- Method Service Set
 - Service for calling a method of an object.
- MonitoredItem Service Set
 - Services for the client to create and manage monitored items.
 - Monitored items are used to log in for data and event notifications.
- Subscription Service Set
 - Services for the client to create and manage subscriptions.
 - Subscriptions control the way of the data and event notification.

Basics OPC UA > Information modeling

Access

- To access an *OPC UA* server, the *endpoint* must be known.
- You can navigate via the endpoint using the navigation function through the address space of the OPC UA server. Here you receive information about the OPC UA server and the CPU and have access to the objects created in the OPC UA configuration, such as tags, data blocks, etc.
- Lower network load through 'subscriptions'
 - If variables are to be transmitted only if their value has changed, you have to use subscriptions.
 - To activate a subscription, enter the transmission interval "Publishing Interval" in the OPC UA client.
 - When the subscription is created, tell the server which variables to monitor. Among
 other things, you can specify the amount by which a value must change in order a
 transfer takes place.
 - Since only a change in value of a transmission takes place, the use of subscriptions leads to a reduced network load.
- Fast access through 'registration'
 - Normally the addressing takes place by means of identifier strings. By using a numeric identifier access can be accelerated. For this reason, you should use the registration for regular access to certain variables.
 - During registration, the OPC UA client assigns the variable to the OPC UA server.
 The OPC UA server then generates a numeric identifier and sends it back to the OPC UA client.
 - The numerical identifier is valid for the duration of the session.
 - In the properties of the CPU, you can set the maximum number of registered nodes. This must be taken into account by the OPC UA clients.
 - Since the registration takes time, you should put them in the start-up phase of the OPC UA server.

 \int_{1}^{0}

Due to the system, access to data in complex structures is not consistent.



Setting the sampling intervals (sampling interval, publishing interval) too short may cause too much network load. Always choose intervals that are still sufficient for your application.

Basics OPC UA > OPC UA data types and their conversion

6.2.3 *OPC UA* data types and their conversion

Siemens S7 data types are mapped in the namespace via SPEED7 PLC OPC UA data types. Siemens S7 data types do not always match the *OPC UA* built-in data types. The CPU provides variables to the *OPC UA* server as an *OPC UA* built-in data type so that *OPC UA* clients can access these variables with *OPC UA* built-in data types via the server interface. A client can read the "DataType" attribute from such a variable and reconstruct the original data type.

Data type mapping

Siemens S7 data type		SPEED7 PLC OPC UA data type		OPC UA built-in data type
BOOL	→	BOOL		Boolean
BYTE		BYTE		Byte
WORD		WORD		UInt16
DWORD		DWORD		UInt32
INT		INT		Int16
DINT		DINT		Int32
REAL		REAL		Float
S5TIME		S5TIME	\rightarrow	UInt16
TIME	7	TIME		Int32
DATE		DATE		UInt16
TIME_OF_DAY (TOD)		TIME_OF_DAY		UInt32
CHAR		CHAR		Byte
COUNTER		COUNTER		UInt16 (Only valid values)
TIMER		TIMER		UInt16 (Only valid values)
STRING		STRING		String
DT		DT		Byte[8]

Particularities

String

- The data type STRING in Siemens S7 is a byte array in which the maximum length and the current length are stored in the first 2 bytes. The other bytes store the string.
- The OPC UA data type String should be defined in the same way.

Array

- A read or write job in OPC UA is always an Array access, i.e. always provided with index and length.
- A single variable is a special case of an *Arrays* (index 0 and length 1). On the line, the data type is simply sent several times in succession. For the variable, the *Data-Type* attribute points to the base data type. The *ValueRank* and *ArrayDimensions* attributes determine if it is an array and how large the array is.

Structure

- A structure describes a complex data type.
- You can describe your own structures as a subtype of the abstract data type Structures, which inherits from the data type BaseDataType.
- Since a client may not know user-specific structures, the variables of the data type of this structure are uniformly published in an *ExtensionObject*. The structure *ExtensionObject* can be read by any client and also publishes the *DataTypeId* of the user-specific structure.

Basics OPC UA > Integrated security concept

- All structures that are not described by structures of the basic data types are published on the server in a TypeDictionary.
- With the description of the structure by the TypeDictionary and the DataTypeId, which is published by the ExtensionObject, the structure of the ExtensionObject can be decoded by a client.
- If a client knows in advance the description of a user-specific structure, it can be decoded without reading the *TypeDictionary*. In this approach, a client needs to read and decode the entire tree to access individual elements.

6.2.4 Integrated security concept

Generals to data security

The topic of data security and access protection have become increasingly important in the industrial environment. The increased networking of entire industrial systems to the network levels within the company together with the functions of remote maintenance have all served to increase vulnerability. Threats can arise from internal manipulation like technical errors, operator and program errors respectively from external manipulation like software viruses and worms, trojans and password phishing.

The most important precautions to prevent manipulation and loss of data security in the industrial environment are:

- Encrypting the data traffic by means of certificates.
- Filtering and inspection of the traffic by means of VPN "Virtual Private Networks".
- Identification of the nodes by "Authentication" via save channels.
- Segmenting in protected automation cells, so that only devices in the same group can exchange data.

Guidelines for information security

With the "VDI/VDE 2182 sheet 1", Information Security in the Industrial Automation - General procedural model, VDI guidelines, the VDI/VDE society for measuring and automation engineering has published a guide for implementing a security architecture in the industrial environment. The guideline can be found at www.vdi.de PROFIBUS & PROFINET International (PI) can support you in setting up security standards by means of the "PROFINET Security Guideline". More concerning this can be found at the corresponding web site such as www.profibus.com

Security mechanisms in OPC UA

- Verifying the identity of OPC UA servers and clients.
- Checking the identity of the users.
- Signed and encrypted data exchange between OPC UA server and clients.
- In the connection settings in the OPC UA Configurator, you can specify how a user of an OPC UA client must legitimize access to the OPC UA server.

Safety rules:

- Only activate 'Anonymous-Login' or 'Unsecured data traffic' in exceptional cases.
- Only allow access to variables and data blocks via OPC UA if it is actually required.



Activate only security guidelines that are compatible with the protection concept for your machine or Application. Deactivate all other security guidelines.

Basics OPC UA > Integrated security concept

X.509 certificates

OPC UA has integrated security mechanisms in multiple layers. An important component here are X.509 certificates, which are also used in the PC world. When using certificates, the *OPC UA* server delivers data to the client only if the security certificate has been accepted as valid on both sides. An X.509 certificate includes the following information:

- Version and serial number of the certificate.
- Name of the certification authority.
- Information about the algorithm used by the certification authority to sign the certificate.
- Start and end of the validity of the certificate.
- Name of the program, person, or organization for which the certificate was signed by the certification authority.
- The public key of the program, person or organization.

OPC UA uses three types of X.509 certificates when establishing a client-to-server connection:

- OPC UA application certificates
- OPC UA software certificates
- OPC UA user certificates

Check when establishing a connection

- When establishing a connection between client and server, the participants check all information from the certificate that is required to establish integrity.
- Among other things, the period of validity which is stored in the certificate is checked. Please ensure that the date and time are set correctly for the participants, otherwise no communication can take place.

Sign and encrypt

- To avoid tampering, certificates are signed.
- Within the OPC UA Configurator, you can use the 'Server settings' to import certificates or create and sign them yourself.

Self-signed certificate

- Each participant generates his own certificate and signs it.
- Self-signed certificates are to be transferred to the CPU.
- From a self-signed certificate no new certificates can be derived.
- Sample applications: Static configuration with limited number of communication participants.

■ CA certificate:

- All certificates are created and signed by a certification authority.
- Only the derived and signed certificate of the certification authority is to be transferred to the CPU.
- The certification authority can generate new certificates. Adding partner devices is possible at any time.
- Sample applications: Dynamically growing plants.

Basics OPC UA > Integrated security concept

Digital signature

The signature can be used to prove the integrity and origin of a message.

- 1. The sender forms a hash value as a check value from the clear message.
- **2.** The hash value and a private key result in the digital signature.
- The clear message is sent to the recipient together with the digital signature.
- The recipient decrypts the received signature with the public key and thus gets back the original hash value.
- 5. The receiver also forms a hash value from the clear message and checks it with the original hash value. The public key and hash method are included in the X.509 certificate.
 - If both hash values are identical, sender and clear message were not manipulated.
 - If both hash values are not identical, the clear message was manipulated or falsified during transmission.

Encrypting

- X.509 certificates are not encrypted; they are public and anyone can see them.
- Encrypting data prevents unauthorized users from knowing the content.
- When encrypting, the sender encrypts the clear message with the recipient's public key from the X.509 certificate.
- The recipient decrypts the message with his private key. Each owner of the private key can decrypt a received message.

Secure Channel

- OPC UA uses private and public keys to establish secure channels between client and server
- Once a secure connection is established, the client and server generate a shared private key for signing and encrypting messages.

Security policies

OPC UA uses the following security policies to protect messages:

No security

All messages are unsecured. To use these security policies, connect to a "None" endpoint of a server.

Sign

All messages are signed. This allows the integrity of the received messages to be checked. Manipulations are detected. To use these security policies, connect to a "Sign" endpoint of a server.

Sign & encrypt

All messages are signed and encrypted. This allows the integrity of the received messages to be checked. Manipulations are detected. Due to the encryption, no attacker can read the content of the message. To use these security policies, connect to a "Sign & Encrypt" endpoint of a server.

The security guidelines are additionally named according to the algorithms used. Example: "Basic256Sha256 - Sign & Encrypt" means: Secure Endpoint, supports a set of algorithms for 256-bit hashing and 256-bit encryption.



Please note that the encryption of the communication can affect CPU performance and therefore the response time of the entire system!

Usage in Siemens SIMATIC Manager > Precondition

6.3 Activate OPC UA functionality

Proceeding

For your CPU can process a OPC UA project, you have to activate the OPC UA functionality.

- 1. Insert a Yaskawa memory card (VSD, VSC) into your CPU. Please note that you must always use a VSC card suitable for your CPU. → 'Deployment storage media VSD, VSC'...page 108
- 2. Turn on the CPU, to activate the *OPC UA* functionality, you have to establish an *Overall reset*.
 - → As long as the memory card is inserted, the OPC UA functionality remains activated even after a power cycle. When the project is transferred from the OPC UA Configurator, the OPC UA project is automatically transferred to the inserted memory card.



Please regard that the memory card must remain plugged when you've executed activated the OPC UA functionality. Otherwise the SF LED is on and the OPC UA functionality is deactivated after 72 hours. As long as an activated memory card is not inserted, the SF LED is on and the "TrialTime" timer counts from 72 hours down to 0. After that the OPC UA functionality is de-activated. By inserting the memory card, the LED goes off and the CPU runs again without restrictions.



Please note that the use of a OPC UA project, depending on the scope of the OPC UA project and the PLC project, can influence the performance and thus the response time of your application.

6.4 Usage in SPEED7 Studio

Precondition

- SPEED7 Studio from Version V1.8.6
 - The functionality for the OPC UA configuration is integrated in the SPEED7 Studio.
 For more information, see the according online help.

6.5 Usage in Siemens SIMATIC Manager

6.5.1 Precondition

Siemens SIMATIC Manager from V5.5 and SPEED7 Studio from V1.8.6

- The OPC UA configuration happens by the external OPC UA Configurator.
- The OPC UA Configurator is the SPEED7 Studio reduced to OPC UA functionality.
- The OPC UA Configurator can be registered in the Siemens SIMATIC Manager by means of the SPEED7 Tools Integration.
- The OPC UA Configurator is to be called from the Siemens SIMATIC Manager after project creation and online configuration.
- The OPC UA Configurator automatically imports the data for the OPC UA configuration from the project data of the Siemens SIMATIC Manager.
- The OPC UA configuration is transferred online from the OPC UA Configurator. The OPC UA Configurator automatically imports the data for the OPC UA configuration from the project data of the Siemens SIMATIC Manager.

Usage in Siemens SIMATIC Manager > Installation OPC UA Configurator



Please note that only the objects of the LD, FBD and IL languages can be transferred to the OPC UA Configurator.

6.5.2 Installation *OPC UA Configurator*

Proceeding

Installation and activation of SPEED7 Studio The OPC UA Configurator is part of the SPEED7 Studio with OPC UA functionality. With the SPEED7 Tools Integration, which is also installed when installing the SPEED7 Studio the OPC UA Configurator is to be registered in the Siemens SIMATIC Manager as external tool.

1. The latest version of the SPEED7 Studio can be found in the 'Download Center' of www.yaskawa.eu.com. Double-click on the installation program an follow the instructions on the monitor.



The use of the SPEED7 Studio requires that you agree with the license agreement. During installation, you must confirm this.

Further components are required in order to operate *SPEED7 Studio*. If the following programs are not already present on your PC, they are automatically installed:

- Microsoft .NET Framework 4.52
- Microsoft SQL Server[©] 2014 SP1
- WinPcap
- 2. You can use a 30-day demo version or activate a license.

In order to use *SPEED7 Studio* without restrictions, you require a licence, which you can obtain from your local Yaskawa customer service organisation.

If the PC, on which you would like to use the *SPEED7 Studio*, is connected to the Internet, you can activate the licence online. If no license is activated, the dialog box for activating the license opens with each new start of *SPEED7 Studio*.


Click on 'Yes'.

- → The 'Product activation' dialog window will open.
- **3.** Enter the serial number that you received with your order of *SPEED7 Studio* in the *'Licence key'* input field.
- **4.** Enter your name in the 'Your name' input field.
- **5.** If you enter your e-mail address in the *'E-mail address'* input field, you receive an e-mail confirmation regarding the product activation.
- **6.** Click at 'Activate'.
 - → The licence is activated and the SPEED7 Studio is started.

Registration of SPEED7 Studio in the Siemens SIMATIC Manager as OPC UA Configurator. SPEED7 Tools Integration is automatically listed in the Windows Start menu during the installation of the SPEED7 Studio.

Usage in Siemens SIMATIC Manager > Steps of the OPC UA configuration

- 1. To start the SPEED7 Tools Integration, click in the Windows Start menu on 'VIPA ... → SPEED7 Tools Integration'.
 - ➡ For SPEED7 Tools Integration can start, you have to acknowledge the security prompt to change the data on your computer with 'Yes'. Afterwards SPEED7 Tools Integration will be started.



- 2. Click at 'GSDML ...'.
- 3. Navigate to your GSDML file of your CPU, which you also use for your configuration in the Siemens 'SIMATIC Manager'. Select these and click at 'Confirm'. You can also select and use several GSDML files.
 - ➡ The identified GSDML files are listed and the selection for the configuration tools is enabled.
- **4.** Select the Siemens 'SIMATIC Manager', in which the SPEED7 Studio is to be registered as OPC UA Configurator.
- 5. Click on 'Start'.
 - SPEED7 Studio is registered in the Windows registry as OPC UA Configurator.
 - In the Siemens SIMATIC Manager the *OPC UA Configurator* is registered as externally callable program.
 - All changes are recorded in a log file, which you can output via 'Log file'.
- 6. ▶ 'Close' closes SPEED7 Tools Integration.
 - ➡ With the next start of the Siemens hardware configurator, the SPEED7 Studio can be called as OPC UA Configurator with to OPC UA configuration limited functions. More information about the usage can be found in the in the online help of the OPC UA Configurator.

6.5.3 Steps of the *OPC UA* configuration

Steps of configuration

When using the Siemens SIMATIC Manager, the *OPC UA* configuration happens by the following steps:

- 1. Create your project in the Siemens SIMATIC Manager with the corresponding hardware configuration. → 'Hardware configuration CPU'...page 72
- 2. Configure the corresponding Ethernet connection for PG/OP communication and establish an online connection. → 'Hardware configuration Ethernet PG/OP channel'...page 74

Usage in Siemens TIA Portal > Precondition

- 3. ▶ Save translate and transfer your project. → 'Project transfer'...page 90
- **4.** Call the external *OPC UA Configurator* from the Siemens SIMATIC Manager. For this click in the hardware configurator on the CPU and select 'Start Device Tool → VIPA Framework → OPC UA Configurator'.
- **5.** Confirm to start an external program with [YES].



NOTICE

Data exchange between platforms of different vendors

If you allow access, you permit the exchange of data between *OPC UA Configurator* and your project data of the Siemens SIMATIC Manager.

- Ensure that the necessary security guidelines are complied with.
- ➡ The OPC UA Configurator is started. For the OPC UA configuration, the data is taken from the Siemens SIMATIC Manager project and listed in the table for the OPC UA configuration.



Please note that only the objects of the LD, FBD and IL languages can be transferred to the OPC UA Configurator.

- **6.** Configure the *OPC UA* server and the data for the *OPC UA* communication.
- 7. In the OPC UA Configurator switch to the online dialog and transfer the OPC UA configuration. For communication the IP address data are taken from the Siemens SIMATIC Manager project.
 - The OPC UA configuration is now complete. For check you will find information about your OPC UA configuration on the device web page at 'OPC UA'...page 96

6.6 Usage in Siemens TIA Portal

6.6.1 Precondition

Siemens TIA Portal from version V15.0 and SPEED7 Studio from V1.8.6

- The OPC UA configuration happens by the external OPC UA Configurator.
- The OPC UA Configurator is the SPEED7 Studio reduced to OPC UA functionality.
- The OPC UA Configurator can be registered in the Siemens TIA Portal by means of the SPEED7 Tools Integration.
- The *OPC UA Configurator* is to be called from the Siemens TIA Portal after project creation and online configuration.
- The OPC UA Configurator automatically imports the data for the OPC UA configuration from the project data of the Siemens TIA Portal.
- The OPC UA configuration is transferred online from the OPC UA Configurator. For the communication the OPC UA Configurator automatically uses the IP address data of the Siemens TIA Portal project.



Please note that only the objects of the LD, FBD and IL languages can be transferred to the OPC UA Configurator.

Usage in Siemens TIA Portal > Installation OPC UA Configurator

6.6.2 Installation *OPC UA Configurator*

Proceeding

Installation and activation of SPEED7 Studio The OPC UA Configurator is part of the SPEED7 Studio with OPC UA functionality. With the SPEED7 Tools Integration, which is also installed when installing the SPEED7 Studio the OPC UA Configurator is to be registered in the Siemens TIA Portal as external tool.

1. The latest version of the SPEED7 Studio can be found in the 'Download Center' of www.yaskawa.eu.com. Double-click on the installation program an follow the instructions on the monitor.



The use of the SPEED7 Studio requires that you agree with the license agreement. During installation, you must confirm this.

Further components are required in order to operate *SPEED7 Studio*. If the following programs are not already present on your PC, they are automatically installed:

- Microsoft .NET Framework 4.52
- Microsoft SQL Server[©] 2014 SP1
- WinPcap
- 2. You can use a 30-day demo version or activate a license.

In order to use *SPEED7 Studio* without restrictions, you require a licence, which you can obtain from your local Yaskawa customer service organisation.

If the PC, on which you would like to use the *SPEED7 Studio*, is connected to the Internet, you can activate the licence online. If no license is activated, the dialog box for activating the license opens with each new start of *SPEED7 Studio*.


Click on 'Yes'.

- → The 'Product activation' dialog window will open.
- **3.** Enter the serial number that you received with your order of *SPEED7 Studio* in the *'Licence key'* input field.
- **4.** Enter your name in the 'Your name' input field.
- 5. If you enter your e-mail address in the *'E-mail address'* input field, you receive an e-mail confirmation regarding the product activation.
- 6. Click at 'Activate'.
 - → The licence is activated and the SPEED7 Studio is started.

Registration of SPEED7 Studio in the Siemens TIA Portal as OPC UA Configurator SPEED7 Tools Integration is automatically listed in the Windows Start menu during the installation of the SPEED7 Studio.

- 1. ▶ To start the SPEED7 Tools Integration, click in the Windows Start menu on 'VIPA ... → SPEED7 Tools Integration'.
 - → For SPEED7 Tools Integration can start, you have to acknowledge the security prompt to change the data on your computer with 'Yes'. Afterwards SPEED7 Tools Integration will be started.

Usage in Siemens TIA Portal > Steps of the OPC UA configuration



- 2. Click at 'GSDML ...'.
- 3. Navigate to your GSDML file of your CPU, which you also use for your configuration in the Siemens 'TIA Portal'. Select these and click at 'Confirm'. You can also select and use several GSDML files.
 - ➡ The identified GSDML files are listed and the selection for the configuration tools is enabled.
- **4.** Select 'TIA Portal', in which the SPEED7 Studio is to be registered as OPC UA Configurator.
- 5. Click on 'Start'.
 - SPEED7 Studio is registered in the Windows registry as OPC UA Configurator.
 - In the Siemens TIA Portal the OPC UA Configurator is registered as externally callable program.
 - The current Windows user is registered in the user group Siemens TIA Openness of the Siemens TIA Portal.
 - All changes are recorded in a log file, which you can output via 'Log file'.
- **6.** ▶ 'Close' closes SPEED7 Tools Integration.
 - ➡ With the next start of the Siemens TIA Portal, the SPEED7 Studio can be called as OPC UA Configurator with to OPC UA configuration limited functions. More information about the usage can be found in the in the online help of the OPC UA Configurator.

6.6.3 Steps of the OPC UA configuration

Steps of configuration

When using the Siemens TIA Portal, the *OPC UA* configuration happens by the following steps:

- Create your project in the Siemens TIA Portal with the corresponding hardware configuration. → 'TIA Portal - Hardware configuration - CPU'...page 291
- 2. Configure the corresponding Ethernet connection for PG/OP communication and establish an online connection. → 'TIA Portal Hardware configuration Ethernet PG/OP channel'...page 293
- 3. ▶ Save translate and transfer your project. → 'TIA Portal Project transfer'...page 314

Usage in Siemens TIA Portal > Steps of the OPC UA configuration

- 4. Call the external *OPC UA Configurator* from the Siemens TIA Portal. For this click at 'Devices & networks' on the CPU and select 'Start device tool'.
 - → A dialog window opens. Select 'OPC UA Configurator' and click [Start].
- 5. | Ignore the query 'Set interface' with [OK]
 - → The OPC UA Configurator is started.
- **6.** If not yet confirmed, you will now receive an access request in the TIA Portal.



Please note that due to the software the access request does not appear in the foreground. To show the access request, you must again bring the Siemens TIA Portal to the foreground. Once the access has been selected, you must again bring the 'OPC UA Configurator' to the foreground.

You have the following options for access:

- 'No': Deny access the OPC UA Configurator is not started.
- 'Yes': Access is permitted once and the OPC UA Configurator is started.
- 'Yes to all': Access is permitted and the OPC UA Configurator is started. At the next call, the access request is no longer shown.

Allow access with 'Yes' respectively 'Yes to all'.

>



NOTICE

Data exchange between platforms of different vendors

If you allow access, you permit the exchange of data between *OPC UA Configurator* and your project data of the Siemens TIA Portal.

- Ensure that the necessary security guidelines are complied with.

For the *OPC UA* configuration, the data is taken from the Siemens TIA Portal project and listed in the table for the *OPC UA* configuration.



Please note that only the objects of the LD, FBD and IL languages can be transferred to the OPC UA Configurator.

- **7.** Configure the *OPC UA* server and the data for the *OPC UA* communication.
- 8. In the OPC UA Configurator switch to the online dialog and transfer the OPC UA configuration. For communication the IP address data are taken from the TIA Portal project.
 - The OPC UA configuration is now complete. For check you will find information about your OPC UA configuration on the device web page at 'OPC UA'. → 'Tab: 'OPC UA'...page 96




You can use the CMD auto commands OPCUA_PGOP_ENABLE and OPCUA_PGOP_DISABLE to enable or disable OPC UA. After a power cycle or loading a hardware configuration, the settings are retained. With reset to the factory settings or over all reset, the OPC UA project is set to the default value "enabled". → 'CMD - auto commands'...page 110

Usage OPC UA Configurator > OPC UA Configurator

6.7 Usage OPC UA Configurator

6.7.1 OPC UA Configurator

The user interface of the OPC UA Configurator is divided into the following areas:



- 1 Menu bar
- 2 Toolbar
- 3 Project tree
- 4 Workspace
- 5 Output area

Menu bar

In the menu bar you will find a few general commands on the *OPC UA Configurator*. Further commands can be called up via context menus with the right mouse button, e.g. functions for an object in the project tree.

Toolbar

Store OPC UA configuration





Compile OPC UA configuration



Transfer OPC UA configuration into the control

Project tree

The *Project tree* gives you access to the *'Device properties'* and to the following areas of the *'OPC UA configuration'*:

- Server settings
- Data access
- User management

Workspace

In the *Work space*, you can edit the settings in the following areas of the *OPC UA* configuration:

- Device properties General
 - Information about the CPU such as device name, name and firmware version.

Usage OPC UA Configurator > Project tree

- Device properties Communication
 - Configuration of the interface for data exchange.
 - The IP address data are automatically imported from the project when the OPC UA
 Configurator is called and can be viewed here.
- Device properties Server configuration
 - Administration and interface assignment of the OPC UA server in the Project tree
- Server settings Connection
 - Legitimation of the user for access to the OPC UA server.
 - Port for communication.
 - Security policy for encryption and corresponding exceptions.
- Server settings Certificate
 - Create, view, import or export X.509 ITU-T standard certificate.
 - Re-creating or importing replaces an existing certificate.
- Data access
 - Selection of the variables that can be accessed via OPC UA.
 - Filter option to limit the selection.
- User management
 - Creation of a user list with password and role assignment.

Output area

The output area shows information about activities performed and background operations.

6.7.2 Project tree

You can edit the *OPC UA* configuration via the project tree. The project tree contains the *OPC UA* configurations, which you have created. You can create a maximum of two *OPC UA* configurations: One configuration for the CPU and one configuration for the CP (if exists).

Show project tree

If the project tree is not shown select 'View → Project tree' or press [Strg]+[Shift]+[P].

Show/hide objects

The objects in the project tree are arranged in a tree structure. You can show or hide objects:

- Hide all objects ('Project → Collapse project tree')
- Show all objects ('Project → Expand project tree')
- Hide slave objects / close folder
- Show slave objects / open folder

Deployment OPC UA System MICRO

Usage OPC UA Configurator > Device properties In

Edit configurations and OPC UA configuration

Device properties	
Device properties	■ Edit device name and comment → 'General device properties'page 190
	■ Perform communication settings → 'Communication settings'page 191
	■ Create OPC UA configuration → 'Server configuration'page 192
OPC UA	
Server settings ■	→ 'Server settings - Connection 63'page 192
	→ 'Server settings - Certificate iii'page 194
m Data access	→ 'Data access m'page 195
4 User management	→ 'User management ♣ 'page 196
	→ 'Role management ♣'page 196

6.7.3 Device properties to


6.7.3.1 Overview

Here you can edit the device name and the comment, perform the communication settings as well as create the *OPC UA* configuration.

- Click in the project tree at 'Device properties'.
 - → The 'Device properties' editor opens.

The 'Device properties' editor is divided into several sections:

- → 'General device properties'...page 190
- 'Server configuration'...page 192



6.7.3.2 General device properties

To show or change the device properties, proceed as follows:

- 1. Click in the project tree at 'Device properties'.
 - The editor of the 'Device properties' opens.
- 2. Select the area 'General'.

'Device type' Name of the CPU
'Firmware' Firmware version of the CPU
'Name' Device name: This name is shown in the project tree.
'Author' Name of the responsible person who created the device 'Comment' Any comment, e.g. an annotation or explanation

Click on the input field and enter any comment, e.g. an annotation or explanation. With the *[Enter]* key, you can add a new line to the input field.


Usage OPC UA Configurator > Device properties

6.7.3.3 Communication settings

The communication settings are used to configure the interface for the data exchange between programming device and destination station. Since the IP address parameters for the *OPC UA* configuration are imported from the project, you simply have to set the interface via which you are connected to the destination station.



- 1. Click in the project tree at 'Device properties'.
 - → The editor of the 'Device properties' opens.
- 2. Select the area 'Communication settings'.



Setting the Ethernet interface

- 1. 'Active PC interface': Select 'Ethernet interface'.
- 2. ** 'PC interface': Select the network adapter for the communication connection from the list.
 - → If an IP address is already configured in the network adapter, it is shown under the input field 'IP address'. If necessary, select a different IP address.
- 3. \(\rightarrow\) 'CPU interface': Select the interface of the control from the list.
 - Since the IP address is imported from the project, it is shown below the input field.
- **4.** To configure further settings of the interface, click on 'Interface configuration'.
 - → The 'Interface properties' dialog window will open.
- 5. In order to check whether a connection between the programming device and the control can be established with the selected communication settings, click on *'Verify connection'*.
 - You can see in the status line, whether the connection could be established successfully.

Usage OPC UA Configurator > Server settings - Connection 🚮

- 6. In order to check whether your programming device is connected with the correct control, you can retrieve information from the connected control. For this click on 'Accessible partners'.
 - → The 'Search for accessible partners' dialog window will open.

6.7.3.4 Server configuration



Here you can create the OPC UA configurations.

- 1. Click in the project tree at 'Device properties'.
 - → The editor of the 'Device properties' opens.
- 2. Select the area 'Server configuration'.

You can create a maximum of two *OPC UA* configurations: One configuration for the CPU and one configuration for the CP (if exists).

Create configuration

- 1. Select in the selection field 'OPC UA Configuration' and click on \(\displies\) 'Add Server'.
 - → A new OPC UA configuration is created and listed in the project tree.
- Click in the selection field 'Active server CP' or 'Active server CP' and choose which configuration is to be assigned. With the selection 'None' the configuration remains saved in the project. However, it is not transferred to the device.


You can create a maximum of two OPC UA configurations.

Remove server


Right-click on the OPC UA configuration (PLC) in the project tree and select 'Remove OPC UA server'.

6.7.4 Server settings - Connection 🐻

Here you can perform the connection settings of the OPC UA server.



- → The 'Server settings editor' editor opens.
- 2. Select the area 'Connection'.



Usage OPC UA Configurator > Server settings - Connection

General

You can set for the *OPC UA* server how a user of an *OPC UA* client must prove their identity for access to the server. Select at least one of the following login methods. You can also combine the two login methods with each other.

- 'Activate anonymous login'
 - The OPC UA server does not check the authorisation of the OPC UA client.
- 'Activate user/password login'
 - The OPC UA server checks using the user name and password whether the access of the OPC UA client is authorised. To do this, the server evaluates the role assigned to the user. → 'Role management ♣'...page 196
- 'Allow obsolete security guideline'
 - Allows the selection of the two obsolete security guidelines 'Basic128Rsa15' and 'Basic256' (not recommended)
- 'Application name'
 - Clear identification of the application in the OPC name space.

Network

- 'End point port'
 - TCP port for binary data exchange (standard: 4840).

Security



Activate only security guidelines that are compatible with the protection concept for your machine or system. Deactivate all other security guidelines.

- 'None'
 - Insecure data traffic between server and client.
- 'Basic128Rsa15'
 - Secured data traffic, 128-bit encoding with key wrap algorithm RSA-15, (allow option with 'Allow obsolete security guideline' see above).
- 'Basic256'
 - Secured data traffic, 256-bit encoding (allow option with 'Allow obsolete security guideline' see above).
- 'Basic256Sha256'
 - Secured data traffic, 256-bit encoding with hash algorithm SHA-256 (recommended).

Encoding:

- 'Sian'
 - Endpoint secures the integrity of the data through signing.
- 'SignAndEncrypt'
 - Endpoint secures the integrity and confidentiality of the data through signing and encoding.
- 'Both'
 - The OPC UA server offers both encryption methods 'Sign' and 'SignAndEncrypt'.
 The OPC UA client can use one of the two encoding methods.

Security Check Overrides

Here you can allow various exceptions in the security check, in order to increase the error tolerance.


Deployment OPC UA System MICRO

Usage OPC UA Configurator > Server settings - Certificate

6.7.5 Server settings - Certificate

A secure connection between the *OPC UA* client and the server can only be established if the server classifies and accepts the client's digital certificate as trusted. Currently, the server accepts every valid client certificate. The server accepts self-signed certificates. In addition, the client also checks the server's certificate.

Here you can create, show, import or export an ITU-T standardized X.509 certificate for the *OPC UA* server. The certificate shown here is transferred into the *OPC UA* server.



- 1. Under Project tree at 'OPC UA configuration' click on 'Server settings'.
 - → The 'Server settings' editor opens.
- 2. Select the area 'Certificate'.

The current X.509 certificate is shown in the work space. If you create or import a new certificate, the previously shown certificate is replaced.

Toolbar

Create new certificate: Opens the dialog window 'Create new certificate'





Display certificate: Shows information on the current certificate



Export certificate: Opens the dialog window 'Save certificate'



Import certificate: Opens the dialog window 'Open certificate'

Create new certificate

- 1. Click on to create a new certificate.
 - → The dialog window 'Create new certificate' opens.
- 2. Enter the data for the certificate and click on 'OK'.
 - → The previously shown certificate is replaced by the new certificate.

Display certificate

- ▶ Click on 🔄 to show information about the current certificate.
 - → The dialog window 'Certificate' opens.

Export certificate

You can export the current certificate e.g. to use it on different computers.

- 1. Click on 3.
 - ➡ The dialog window 'Save certificate' opens.
- 2. Select a directory and enter a file name.
- 3. Click on 'Save'.
 - → The current certificate is saved in the export file (pfx file format).

Import certificate

You can import a certificate, e.g. to use it for the current *OPC UA* configuration. For a successful import, the certificate must have the following characteristics:


- The certificate must be available as a PFX file.
- The 'Common name' and 'Organization' fields must be completed.
- The maximum key strength must not exceed 2048bit.
- The certificate must contain a valid Private key.
- 1. Click at .
 - ➡ The dialog window 'Open certificate' opens.
- Select the desired certificate (pfx file format).

Usage OPC UA Configurator > Data access

- 3. ▶ Click on 'Open'.
 - → The previously shown certificate is replaced by the imported certificate.

6.7.6 Data access

Here you can select the variables belonging to the CPU or CP (if exists) that can be accessed via *OPC UA*.



- ▶ Under Project tree at 'OPC UA configuration' click on 'Data access'.
 - ➡ The editor for 'Data access' opens.

Toolbar

Refresh variables: Apply changed filter settings to the result table.



Filter settings

Here you can select the operands and address ranges that will be shown in the results table.

- 1. Activate [v] 'All operand areas' or individual operand ranges to be shown in the result table.
- **2.** To limit the addresses of an operand range, enter the start and end byte addresses in the two adjacent fields, e.g. 0 to 1000.
- 3. Click on 3 or activate 4 'Apply filter changes immediately'.
 - The result table is updated with the filter settings.

Result

In the results table, select the variables that are to be used in the *OPC UA* configuration. *OPC UA* clients may access these variables.

▶ Activate (OPC UA) of the desired variables.

Group operands

For a better overview, you can sort the table entries by groups.



- (1) Select column (hold left mouse button down)
- (2) Drag the column
- (3) Drop column in the field (release mouse button)
- 1. Drag the desired column header into the field above the table.
 - The contents of the column will be grouped. The number of lines is shown for each group.
- 2. ▶ Click on ▶ to open the group. Click on ▼ to close the group.

You can repeat steps 1 to 2 in order to structure the group into further sub-groups.

In order to cancel a grouping, click on the close icon next to the group name.

Deployment OPC UA System MICRO

Usage OPC UA Configurator > Role management 🌲

6.7.7 User management 4

P OPC UA Configuration

Server Settings

Data access

📤 User management

The user management allows you to create a user list. For each user, you can define a password and a role.

- 1. Under Project tree at 'OPC UA configuration' click on 'User management'.
 - → The editor for 'User management' opens.
- **2.** Select the area 'User management'.

Toolbar

Add new user: Input mode for new user



Remove user: Deletes the selected user



Edit current user: Input mode for selected user



Save input: Save input Save user settings



Cancel input: Cancel user settings without saving

Adding a user

- 1. Click on ...
- **2.** Enter the desired user name in the input field 'Name'.
- **3.** Enter the password in the input field 'Password' and repeat the input under 'Reenter password'.
- **4.** Select a role for the user. With this role, the access rights to the *OPC UA* server are established.
- 5. Click on .
 - → The user will be entered in the user list.

Edit user

- 1. In the user list, select the user whose data you want to change.
- 2. Click on /.
- 3. Enter the desired changes and click on ...

Removing a user

- 1. In the user list, select the user you want to delete.
- 2. Click on =.
 - A dialog box opens where you can choose whether the user should be deleted or not.

6.7.8 Role management 4

Here you establish the roles and access rights that you can assign to the users. When you activate the authentication via User/password login → 'Server settings - Connection in the logged-in user and the assigned role.

Example:

Role: Operator


Username: "I myself"

Server settings: User/password login activated

The user "Me Self" receives write permission and reading rights to the *OPC UA* server when he has successfully logged in with the password.

System MICRO Deployment OPC UA

Usage OPC UA Configurator > Output



- 1. Under Project tree at 'OPC UA configuration' click on 'User management'.
 - → The editor for 'User management' opens.
- 2. Select the area 'Role management'.

Configure roles

The following two roles are currently available for selection; further roles can not be added at the moment.

- Operator: Write permission and reading rights
- Observer: Reading rights only

6.7.9 Output

Information on executed activities and background operations are displayed in the "Output" window.



(1) Delete all messages in the output window

WebVisu editor

7 Deployment WebVisu - Web visualization



Please note that the simultaneous use of OPC UA and WebVisu on the same interface is not supported! When attempting to activate them, both servers are stopped and the diagnostic message 0xE989 or 0xE9AB is output.

- With a WebVisu project there is the possibility to configure a web visualization on your CPU
- The configuration of a *WebVisu* project is only possible with the *SPEED7 Studio* V1.7.0 and up.
- Since a WebVisu project is only executable by memory card, a Yaskawa memory card (VSD, VSC) must be plugged. Please regard that you always use a VSC card that fits to your CPU. → 'Deployment storage media - VSD, VSC'...page 108
- If the memory card is removed for a short time, the SF LED lights up. This indicates that a feature is missing and the *WebVisu* will quit after 72 hours.
- The WebVisu functionality must be activated in the CPU. → 'Activate WebVisu functionality'...page 201
- When the project is transferred from the *SPEED7 Studio*, the *WebVisu* project is automatically transferred as TAR file to the inserted memory card.
- Access to the WebVisu project of the CPU happens by the IP address of the Ethernet PG/OP channel and the correspondingly configured port or via the device web page of the CPU.
- You can access your web visualization via a web browser. Web browsers based on Windows CE are currently not supported.



Please note that the use of a WebVisu project, depending on the scope of the WebVisu project and the PLC project, can influence the performance and thus the response time of your application.

7.1 WebVisu editor


The configuration of a *WebVisu* project is shown below. This is only the basic use of the *WebVisu* editor in the *SPEED7 Studio* together with the CPU. Please note that software changes can not always be considered and it may thus be deviations to the description.



For more information on the SPEED7 Studio and how to use the WebVisu editor, refer to its online help.

WebVisu editor > Creating a WebVisu project

7.1.1 Working environment



- (1) Toolbar
- (2) Editor surface
- (3) Status bar
- (4) Catalog
- (5) Properties window

(1) Toolbar

The toolbar provides important commands for working with the *WebVisu* editor.

(2) Editor area

The editor area is your workspace. Here you can place and edit texts and graphics objects.

(3) Status bar

With a slider you can enlarge or reduce your view.

(4) Catalog

Via *Catalog* you can access all the *WebVisu* elements. You can use Drag & Drop to place them on the *Editor surface* and adjust them using properties.

(5) Properties window


By enabling 'View \rightarrow Properties' the 'Properties' are shown. The properties of the selected element are shown here. You can adjust these if necessary.

7.1.2 Creating a WebVisu project

Add WebVisu

- 1. Start the SPEED7 Studio with your project for the CPU for which a WebVisu project is to be created.
- 2. If not already done, add a CPU by clicking 'Add new device'.
- 3. Click in the 'Project tree' at the CPU and select 'Context menu → Device properties'.
 - → The 'Device properties' of your CPU opens.
- **4.** ▶ Here click at 'WebVisu configuration'
 - ▶ In this settings window, you can create a WebVisu project for your CPU.

WebVisu editor > Creating a WebVisu project



- 5. To create a WebVisu project, click at [Add WebVisu].
 - → A new WebVisu project is created and listed in the 'Project tree'. At 'WebVisu general configurations' and 'WebVisu SSL configurations', you can make further settings.

WebVisu - general configurations

- Port number
 - Enter the port number under which the WebVisu should be accessible.
 - Port number: 8080 (default): The WebVisu can be accessed via the IP address and port 8080. The Device web page can be accessed via the IP address and port 80.
 - Port number: 80: The WebVisu can be accessed via the IP address and port 80. The Device web page can be accessed via the IP address and port 8080.
- Polling interval (ms)
 - Enter here the interval for the cyclical refresh of the web content.
- Execution device
 - Select 'CPU' as device on which this WebVisu project is to be executed.
 - WebVisu projects for Ethernet CPs are not supported by this CPU.

WebVisu - SSL configurations

- Enabling encoding
 - When enabled, you have SSL-encrypted access to your WebVisu.
- Disable HTTP
 - When activated, the access happens via HTTPS.
- SSL port number
 - SSL port number 443 (default): The secure access to the WebVisu takes place via the IP address and port 443. The Device web page can be accessed via the IP address of the CPU and port 8080.
- Original path of the certificate used
 - Here you can upload a security certificate.
 - Only security certificates in PEM format are supported.
 - The file must contain the certificate and the private key.

Delete WebVisu

- Click in the 'Project tree' at WebVisu Project and select 'Context menu → Delete WebVisu'.
 - ➡ The WebVisu project is removed from the configuration.

Start-up of the WebVisu project

Edit WebVisu



- In the 'Project tree', navigate to 'WebVisu Project > Images' and click at 'Main'.

 Select 'Context menu → Open image'
 - → The WebVisu editor opens. Here, you can configure your web visualization by dragging and dropping elements from the 'Catalog' onto the editor area and using the 'Properties' to interconnect them with a variable.

7.2 Activate WebVisu functionality

Proceeding

For your CPU can process a WebVisu project, you have to activate the WebVisu functionality.

- 1. Insert a Yaskawa memory card (VSD, VSC) into your CPU. Please note that you must always use a VSC card suitable for your CPU. → 'Deployment storage media VSD, VSC'...page 108
- **2.** Turn on the CPU, to activate the *WebVisu* functionality, you have to establish an *Overall reset*.
 - ◆ As long as the memory card is inserted, the WebVisu functionality remains activated even after a power cycle. When the project is transferred from the SPEED7 Studio, the WebVisu project is automatically transferred to the inserted memory card.



Please regard that the memory card must remain plugged when you've executed activated the WebVisu functionality. Otherwise the SF LED is on and the WebVisu functionality is deactivated after 72 hours. As long as an activated memory card is not inserted, the SF LED is on and the "TrialTime" timer counts from 72 hours down to 0. After that the WebVisu functionality is de-activated. By inserting the memory card, the LED goes off and the CPU runs again without restrictions.

7.3 Start-up of the WebVisu project

The following preconditions must be fulfilled for the *WebVisu* project to start-up:

- 1. Activate WebVisu functionality if not already done. Activate WebVisu functionality'...page 201
- **2.** Configure your CPU and perform a hardware configuration.
- 3. Configure your WebVisu project.
- **4.** Safe and translate your project.
- 5. If you are online connected to your CPU, you can transfer your project to the CPU with 'AG → Transfer all'.
 - ➡ Here the configuration is transferred in the CPU and the WebVisu project is transferred to the memory card. Immediately after the transfer you have access to your WebVisu.

Access to the WebVisu > Status of the WebVisu



You can use the CMD auto commands WEBVISU_PGOP_ENABLE and WEBVISU_PGOP_DISABLE to enable or disable the WebVisu. After a power cycle or loading a hardware configuration, the settings are retained. With reset to the factory settings or over all reset, the WebVisu project is set to the default value "enabled". → 'CMD - auto commands'...page 110

7.4 Access to the WebVisu

- When connected via Ethernet PG/OP channel, you have access to the WebVisu and Device web page of the CPU, controlled via ports.
- Access to the WebVisu can be password-protected and encrypted by means of SSL certificates. If you want to use SSL certificates, you must integrate them in the SPEED7 Studio accordingly.
- You can create users in the SPEED7 Studio via 'WebVisu project > User administration', who can access the WebVisu.
- Via 'Device properties > WebVisu configuration' you can specify the port, the WebVisu can be accessed and upload SSL certificates. This changes the port for accessing the device web page.
 - Port number: 8080 (default): The WebVisu can be accessed via the IP address and port 8080. The Device web page can be accessed via the IP address and port 80.
 - Port number: 80: The WebVisu can be accessed via the IP address and port 80.
 The Device web page can be accessed via the IP address and port 8080.
 - SSL port number 443 (default): The secure access to the WebVisu takes place via the IP address and port 443. The Device web page can be accessed via the IP address and port 8080.

ĥ

- Please note that once you have made adjustments to the user management, you will need to restart your web browser. Otherwise you receive system-related error messages about invalid user information!
- Please note that the encryption of the communication can affect CPU performance and therefore the response time of the entire system!

7.4.1 Status of the WebVisu

On the device web page at the tab 'WebVisu' via 'Status' you get the status of your WebVisu project. ¬ 'Tab: 'WebVisu''...page 97


Basics - Industrial Ethernet in automation

8 Deployment PG/OP communication - productive

8.1 Basics - Industrial Ethernet in automation

Overview

The flow of information in a company presents a vast spectrum of requirements that must be met by the communication systems. Depending on the area of business the bus system or LAN must support a different number of users, different volumes of data must be transferred and the intervals between transfers may vary, etc. It is for this reason that different bus systems are employed depending on the respective task. These may be subdivided into different classes. The following model depicts the relationship between the different bus systems and the hierarchical structures of a company:



Industrial Ethernet

Industrial Ethernet is an electrical net based on shielded twisted pair cabling or optical net based on optical fibre. Industrial Ethernet is defined by the international standard IEEE 802.3

The net access of Industrial Ethernet corresponds to IEEE 802.3 - CSMA/CD (Carrier Sense Multiple Access/Collision Detection) scheme:

- Every station "listens" on the bus cable and receives communication messages that are addressed to it.
- Stations will only initiate a transmission when the line is unoccupied.
- In the event that two participants should start transmitting simultaneously, they will detect this and stop transmitting to restart after a random delay time has expired.
- Using switches there is the possibility for communication without collisions.

Basics - ISO/OSI reference model

8.2 Basics - ISO/OSI reference model

Overview

The ISO/OSI reference model is based on a proposal that was developed by the International Standards Organization (ISO). This represents the first step towards an international standard for the different protocols. It is referred to as the ISO-OSI layer model. OSI is the abbreviation for Open System Interconnection, the communication between open systems. The ISO/OSI reference model does not represent a network architecture as it does not define the services and protocols used by the different layers. The model simply specifies the tasks that the different layers must perform. All current communication systems are based on the ISO/OSI reference model, which is defined by the ISO 7498 standard. The reference model structures communication systems into 7 layers that cover different communication tasks. In this manner the complexity of the communication between different systems is divided amongst different layers to simplify the task.

The following layers have been defined:

- Layer 7 Application Layer
- Layer 6 Presentation Layer
- Layer 5 Session Layer
- Layer 4 Transport Layer
- Layer 3 Network Layer
- Layer 2 Data Link Layer
- Layer 1- Physical Layer

Depending on the complexity and the requirements of the communication mechanisms a communication system may use a subset of these layers.

Layer 1 - Bit communication layer (physical layer)

The bit communication layer (physical layer) is concerned with the transfer of data bits via the communication channel. This layer is therefore responsible for the mechanical, electrical and the procedural interfaces and the physical communication medium located below the bit communication layer:

- Which voltage represents a logical 0 or a 1?
- The minimum time the voltage is present to be recognized as a bit.
- The pin assignment of the respective interface.

Layer 2 - Security layer (data link layer)

This layer performs error-checking functions for bit strings transferred between two communicating partners. This includes the recognition and correction or flagging of communication errors and flow control functions. The security layer (data link layer) converts raw communication data into a sequence of frames. This is where frame limits are inserted on the transmitting side and where the receiving side detects them. These limits consist of special bit patterns that are inserted at the beginning and at the end of every frame. The security layer often also incorporates flow control and error detection functions. The data security layer is divided into two sub-levels, the LLC and the MAC level. The MAC (Media Access Control) is the lower level and controls how senders are sharing a single transmit channel. The LLC (Logical Link Control) is the upper level that establishes the connection for transferring the data frames from one device into the other.

Layer 3 - Network layer

The network layer is an agency layer. Business of this layer is to control the exchange of binary data between stations that are not directly connected. It is responsible for the logical connections of layer 2 communications. Layer 3 supports the identification of the single network addresses and the establishing and disconnecting of logical communication channels. Additionally, layer 3 manages the prior transfer of data and the error processing of data packets. IP (Internet Protocol) is based on Layer 3.

Layer 4 - Transport layer

Layer 4 connects the network structures with the structures of the higher levels by dividing the messages of higher layers into segments and passes them on to the network layer. Hereby, the transport layer converts the transport addresses into network addresses. Common transport protocols are: TCP, SPX, NWLink and NetBEUI.

Basics - Terms

Layer 5 - Session layer

The session layer is also called the communication control layer. It relieves the communication between service deliverer and the requestor by establishing and holding the connection if the transport system has a short time fail out. At this layer, logical users may communicate via several connections at the same time. If the transport system fails, a new connection is established if needed. Additionally this layer provides methods for control and synchronization tasks.

Layer 6 - Presentation layer

This layer manages the presentation of the messages, when different network systems are using different representations of data. Layer 6 converts the data into a format that is acceptable for both communication partners. Here compression/decompression and encrypting/decrypting tasks are processed. This layer is also called interpreter. A typical use of this layer is the terminal emulation.

Layer 7 - Application layer

The application layer is the link between the user application and the network. The tasks of the application layer include the network services like file, print, message, data base and application services as well as the according rules. This layer is composed from a series of protocols that are permanently expanded following the increasing needs of the user.

8.3 Basics - Terms

Network (LAN)

A network res. LAN (Local Area Network) provides a link between different stations that enables them to communicate with each other. Network stations consist of PCs, IPCs, TCP/IP adapters, etc. Network stations are separated by a minimum distance and connected by means of a network cable. The combination of network stations and the network cable represent a complete segment. All the segments of a network form the Ethernet (physics of a network).

Twisted Pair

In the early days of networking the Triaxial- (yellow cable) or thin Ethernet cable (Cheapernet) was used as communication medium. This has been superseded by the twisted-pair network cable due to its immunity to interference. The CPU has a twisted-pair connector. The twisted-pair cable consists of 8 cores that are twisted together in pairs. Due to these twists this system is provides an increased level of immunity to electrical interference. For linking please use twisted pair cable which at least corresponds to the category 5. Where the coaxial Ethernet networks are based on a bus topology the twisted-pair network is based on a point-to-point scheme. The network that may be established by means of this cable has a star topology. Every station is connected to the star coupler (hub/switch) by means of a separate cable. The hub/switch provides the interface to the Ethernet.

Hub (repeater)

The hub is the central element that is required to implement a twisted-pair Ethernet network. It is the job of the hub to regenerate and to amplify the signals in both directions. At the same time it must have the facility to detect and process segment wide collisions and to relay this information. The hub is not accessible by means of a separate network address since it is not visible to the stations on the network. A hub has provisions to interface to Ethernet or to another hub res. switch.

Switch

A switch also is a central element for realizing Ethernet on Twisted Pair. Several stations res. hubs are connected via a switch. Afterwards they are able to communicate with each other via the switch without interfering the network. An intelligent hardware analyses the incoming telegrams of every port of the switch and passes them collision free on to the destination stations of the switch. A switch optimizes the bandwidth in every connected segment of a network. Switches enable exclusive connections between the segments of a network changing at request.

Basics - Protocols

8.4 Basics - Protocols

Overview

Protocols define a set of instructions or standards that enable computer to establish communication connections and exchange information as error free as possible. A commonly established protocol for the standardization of the complete computer communication is the so called ISO/OSI layer model, a model based upon seven layers with rules for the usage of hardware and software ***** 'Basics - ISO/OSI reference model'...page 204

The following protocols are used:

- Siemens S7 connections
- Open communication
 - TCP native according to RFC 793
 - ISO on TCP according to RFC 1006
 - UDP according to RFC 768

Siemens S7 connections

With the Siemens S7 connection large data sets may be transferred between PLC systems based on Siemens STEP®7. Here the stations are connected via Ethernet. Precondition for the Siemens S7 communication is a configured connection table, which contains the defined connections for communication. Here NetPro from Siemens may be used.

Properties:

- A communication connection is specified by a connection ID for each connection partner.
- The acknowledgement of the data transfer is established from the partner station at level 7 of the ISO/OSI reference model.
- At the PLC side product specific FB/SFB handling blocks are necessary for data transfer for the Siemens S7 connections.



More information about the usage of these blocks may be found in the manual "SPEED7 Operation List".

Basics - IP address and subnet

Open communication

In the 'open communication' the communication takes place via the user program by means of handling blocks. These blocks are also part of the Siemens SIMATIC Manager. You will find these in the 'Standard Library' at 'Communication Blocks'.

Connection-oriented protocols:

Connection-oriented protocols establish a (logical) connection to the communication partner before data transmission is started. And if necessary they terminate the connection after the data transfer was finished. Connection-oriented protocols are used for data transmission when reliable, guaranteed delivery is of particular importance. In general, many logical connections can exist on one physical line. The following connection-oriented protocols are supported with FBs for open communication via Industrial Ethernet:

TCP native accord. to RFC 793:

During data transmission, no information about the length or about the start and end of a message is transmitted. However, the receiver has no means of detecting where one message ends in the data stream and the next one begins. The transfer is stream-oriented. For this reason, it is recommended that the data length of the FBs is identical for the sending and receiving station. If the number of received data does not fit to the preset length you either will get not the whole data, or you will get data of the following job.

ISO on TCP accord, to RFC 1006:

During data transmission, information on the length and the end of the message is also transmitted. If you have specified the length of the data to be received greater than the length of the data to be sent, the receive block will copy the received data completely into the receive range.

Connection-less protocol:

There is thus no establishment and termination of a connection with a remote partner. Connection-less protocols transmit data with no acknowledge and with no reliable guaranteed delivery to the remote partner.

UDP accord. to RFC 768:

In this case, when calling the sending block you have to specify the address parameters of the receiver (IP address and port number). During data transmission, information on the length and the end of the message is also transmitted. In order to be able to use the sending and receiving blocks first you have to configure the local communications access point at both sides. With each new call of the sending block, you re-reference the remote partner by specifying its IP address and its port number.

8.5 Basics - IP address and subnet

IP address structure

Exclusively IPv4 is supported. At IPv4 the IP address is a 32bit address that must be unique within the network and consists of 4 numbers that are separated by a dot. Every IP address is a combination of a *Net-ID* and a *Host-ID* and has the following structure: xxx.xxx.xxx

Range: 000.000.000.000 to 255.255.255.255

Net-ID, Host-ID

The **Net**work-ID identifies a network res. a network controller that administrates the network. The Host-ID marks the network connections of a participant (host) to this network.

Basics - IP address and subnet

Subnet mask

The Host-ID can be further divided into a *Subnet-ID* and a new *Host-ID* by using a bit for bit AND assignment with the Subnet mask.

The area of the original Host-ID that is overwritten by 1 of the Subnet mask becomes the Subnet-ID, the rest is the new Host-ID.

Subnet mask	binary all "1"		binary all "0"
IPv4 address	Net-ID	Host-ID	
Subnet mask and IPv4 address	Net-ID	Subnet-ID	new Host-ID

Address at first start-up

At the first start-up of the CPU, the Ethernet PG/OP channel does not have an IP address.

Information about the assignment of IP address data to the Ethernet PG/OP channel may be found in → 'Hardware configuration - Ethernet PG/OP channel'...page 74.

Address classes

For IPv4 addresses there are five address formats (class A to class E) that are all of a length of 4byte = 32bit.

Class A	0 Network-ID (1+7bit)		Host-ID	(24bit)		
Class B	10 Network-ID (2+14bit)			Host-ID	(16bit)	
Class C	110 Network-ID (3+21bit)				Host-ID (8bit)	
Class D	1110 Multicast group					
Class E	11110		Reserved			

The classes A, B and C are used for individual addresses, class D for multicast addresses and class E is reserved for special purposes. The address formats of the 3 classes A, B, C are only differing in the length of Network-ID and Host-ID.

Private IP networks

These addresses can be used as net-ID by several organizations without causing conflicts, for these IP addresses are neither assigned in the Internet nor are routed in the Internet. To build up private IP-Networks within the Internet, RFC1597/1918 reserves the following address areas (Host-ID is underlined):

Class	from IP	to IP	Standard subnet mask
Α	10. <u>0.0.0</u>	10. <u>255.255.255</u>	255. <u>0.0.0</u>
В	172.16. <u>0.0</u>	172.31. <u>255.255</u>	255.255. <u>0.0</u>
С	192.168.0. <u>0</u>	192.168.255. <u>255</u>	255.255.255. <u>0</u>

Reserved Host-IDs

Some Host-IDs are reserved for special purposes.

Host-ID = "0"	Identifier of this network, reserved!
Host-ID = maximum (binary complete "1")	Broadcast address of this network

 $\frac{\circ}{1}$

Never choose an IP address with Host-ID=0 or Host-ID=maximum! (e.g. for class B with subnet mask = 255.255.0.0, the "172.16.0.0" is reserved and the "172.16.255.255" is occupied as local broadcast address for this network.)

Hardware configuration

8.6 Fast introduction

Overview

At the first commissioning respectively after an overall reset with PowerON again of the CPU, the Ethernet PG/OP channel has no IP address. This can only be reached by its MAC address. By means of the MAC address, which is printed at the front as 'MAC PG/OP:...', you can assign IP address data. The assignment takes place directly via the hardware configuration of the Siemens SIMATIC Manager.

Steps of configuration

For the configuration of the Ethernet PG/OP channel for productive connections please follow the following approach:

- Hardware configuration CPU
- Hardware configuration Ethernet PG/OP channel
- Configure connections
 - Siemens S7 connections
 (Configuration via Siemens NetPro, communication via product specific handling blocks)
 - Open communication
 (Configuration and communication happens by standard handling blocks)
- Transfer of the complete project to CPU

8.7 Hardware configuration

Overview

At the first commissioning respectively after an overall reset with PowerON again of the CPU, the Ethernet PG/OP channel has no IP address. This can only be reached by its MAC address. By means of the MAC address, which is printed at the front as 'MAC PG/OP:...', you can assign IP address data. The assignment takes place directly via the hardware configuration of the Siemens SIMATIC Manager.

- CPU
 - → 'Hardware configuration CPU'...page 72
- Ethernet PG/OP channel
 - → 'Hardware configuration Ethernet PG/OP channel'...page 74

8.8 Configure Siemens S7 connections

Overview


The project engineering of connections i.e. the "link-up" between stations happens in NetPro from Siemens. NetPro is a graphical user interface for the link-up of stations. A communication connection enables the program controlled communication between two participants at the Industrial Ethernet. The communication partners may here be part of the same project or - at multi projects - separated within related part projects. Communication connections to partners outside of a project are configured via the object "In unknown project" or via deputy objects like "Other stations" or Siemens "SIMATIC S5 Station". The communication is controlled by the user program with product specific handling blocks. To use this blocks, configured communication connections are always necessary in the active station.

- → 'Link-up stations'...page 211
- → 'Projecting connections'...page 212
- → 'Siemens S7 connection Communication functions'...page 214

Properties communication connection

The following properties are characterizing a communication connection:

- One station always executes an active connection establishment.
- Bi-directional data transfer (Send and receive on one connection)
- Both participant have equal rights, i.e. every participant may initialize the send res. receive process event controlled.
- Except of the UDP connection, at a communication connection the address of the communication partner is set via the project engineering. Here the connection is active established by one station.



Requirements

- Siemens SIMATIC Manager V 5.5 SP2 or higher and SIMATIC NET are installed.
- With the hardware configuration the according CP was assigned with IP address data by its properties.




Every station outside of the recent project must be configured as replacement objects like e.g. Siemens "SIMATIC S5" or "other station" or with the object "In unknown project". When creating a connection you may also choose the partner type "unspecified" and set the required remote parameter directly in the connection dialog.

Work environment of NetPro


For the project engineering of connections, a thorough knowledge with NetPro from Siemens is required! The following passage only describes the basic usage of NetPro. More detailed information about NetPro is to be found in the according online manual res. documentation. Start NetPro by clicking on a "net" in the Siemens SIMATIC Manager or on "connections" within the CPU.

The environment of NetPro has the following structure:



- 1 Graphic net view: All stations and networks are displayed in a graphic view. By clicking on the according component you may access and alter the concerning properties
- 2 Net objects: This area displays all available net objects in a directory view. By dragging a wanted object to the net view you may include further net objects and open them in the hardware configurator.
- 3 Connection table: The connection table lists all connections in a table. This list is only shown when you highlighted a connectable module like e.g. a CPU. You may insert new connections into this table with the according command.

PLC stations




You receive the following graphical display for every PLC station and their component. By selecting the single components, the context menu offers you several functions:

- Station: This includes a PLC station with rack, CPU and communication components. Via the context menu you may configure a station added from the net objects and its concerning components in the hardware configurator. After returning to NetPro, the new configured components are shown.
- 2 *CPU:* A click onto the CPU shows the connection table. The connection table shows all connections that are configured for the CPU.
- Internal communication components: This displays the communication components that are available in your CPU. The PROFINET IO controller is to be configured by the PN-IO component.
- 4 Ethernet PG/OP channel: The internal Ethernet PG/OP channel must always be configured as external CP in the hardware configuration.

Link-up stations


NetPro offers you the option to link-up the communicating stations. You may link-up the stations via the properties in the hardware configuration or graphically via NetPro. For this you point the mouse on the coloured net mark of the according CP and drag and drop it to the net you want to link. Now the CP is linked up to the wanted net by means of a line.



Projecting connections



- **1.** For the project engineering of connections, open the connection list by selecting the according CPU. Choose *Insert new connection* in the context menu:
 - Connection partner (partner station)
 A dialog window opens where you may choose the connection partner and the connection type.
 - Specified connection partner
 Each station configured in the Siemens SIMATIC Manager is listed in the table of connection partner. These stations are unique specified by an IP address and a subnet mask.
 - Unspecified connection partner
 Here the connection partner may exist in the current project or in an unknown project. Connection jobs to an unknown project must be defined by an unique connection name, which is to be used in the projects of both stations. Due to this allocation the connection remains unspecified.
- 2. Choose the connection partner and the type of connection and confirm with [OK].
 - If activated, a properties dialog for the according connection opens as link to your PLC user program.



3. After every connection was configured by this way, you may save and compile your project and exit NetPro.

Connection types

With this CPU exclusively Siemens S7 connection may be configured with Siemens NetPro.

Siemens S7 connection

- For data transfer with Siemens S7 connections the product specific FB/SFB handling blocks are necessary; the deployment is described in the manual "Operation list" of your CPU.
- At Siemens S7 connections the communication connections are specified by a connection ID for each communication partner.
- A connection is specified by the local and partner connection end point.
- At Siemens S7 connections the TSAPs must be congruent crosswise. The following parameters define a connection end point:

The following parameters define a connection end point:

Station A				Station B
remote TSAP	\rightarrow	Siemens	\rightarrow	local TSAP
local TSAP	←	S7 connection	←	remote TSAP
ID A				ID B

Combination options with deployment of the product specific FB/SFB handling blocks

Connection partner	Connection establishing	Connection
specified in NetPro	active/passive	specified
(in the current project)		
unspecified in NetPro	active	specified
(in the current project)	passive	unspecified
unspecified in NetPro	active/passive	specified (connection name in an other
(in the unknown project)		project)

In the following every relevant parameter of a Siemens S7 connection is described:

Local connection end point:

Here you may define how the connection is to be established. Since the Siemens SIMATIC Manager can identify the communication options by means of the end points, some options are already preset and may not be changed.

Establish an active connection:

An established connection is precondition for data transfer. By activating the option Establish an active connection the local station establishes the connection. Please regard not every station is able to establish a connection. Here the job is to be made by the partner station.

One-way:

If activated only one-way communication blocks like PUT and GET may be used for communication in the user program. Here the partner station acts as server, which neither may send active nor receive active

■ Block parameters

Local ID:

The ID is the link to your PLC program. The ID must be identical to the ID of the call interface of the product specific FB/SFB handling block.

[Default]:

As soon as you click at [Default], the ID is reset to system generated ID.

■ Connection path:

In this part of the dialog window the connection path between the local and the partner station may be set. Depending on the linking of the modules the possible interfaces for communication are listed in a selection field.

[Address details]:

With this button a dialog window is opened, which shows address information about the local and partner station. The parameters may also be changed.

– TSAP:

With Siemens S7 connections a TSAP is automatically generated of the connection resource (one-way/two-way) and state of place (rack/slot respectively system internal ID at PC stations).

Connection resource:

The connection resource is part of the TSAP of the local station respectively of the partner. Not every connection resource may be used for every connection type. Depending on the connection partner and the connection type the range of values is limited respectively the connection resource is fix specified.

Configure Open Communication

Siemens S7 connection - Communication functions

With the SPEED7 CPUs there are two possibilities for the deployment of the communication functions:

- Siemens S7-300 communication functions:
 By integration of the product specific function blocks FB 12 ... FB 15 you may access the Siemens S7-300 communication functions.
- Siemens S7-400 communication functions:

For the Siemens S7-400 communication functions the SFB 12 ... SFB 15 are to be used, which were integrated to the operating system of the CPU. Here copy the interface description of the SFBs from the standard library at system function block to the directory container, generate an instance data block for each call and call the SFB with the associated instance data block.

Function blocks

FB/SFB	Label	Description
FB/SFB 12	BSEND	Sending data in blocks:
		FB/SFB 12 BSEND sends data to a remote partner FB/SFB of the type BRCV (FB/SFB 13). The data area to be transmitted is segmented. Each segment is sent individually to the partner. The last segment is acknowledged by the partner as it is received, independently of the calling up of the corresponding FB/SFB/FB BRCV. With this type of data transfer, more data can be transported between the communications partners than is possible with all other communication FBs/SFBs for configured S7 connections, namely 65534bytes.
FB/SFB 13	BRCV	Receiving data in blocks:
		The FB/SFB 13 BRCV can receive data from a remote partner FB/SFB of the type BSEND (FB/SFB 12). The parameter R_ID of both FB/SFBs must be identical. After each received data segment an acknowledgement is sent to the partner FB/SFB and the LEN parameter is updated.
FB/SFB 14	GET	Remote CPU read:
		The FB/SFB 14 GET can be used to read data from a remote CPU. The respective CPU must be in RUN mode or in STOP mode.
FB/SFB 15	PUT	Remote CPU write:
		The FB/SFB 15 PUT can be used to write data to a remote CPU. The respective CPU may be in RUN mode or in STOP mode.

8.9 Configure Open Communication

You can use *Open Communication* to communicate with other users on the Ethernet via your user program. For this the following protocols are available.

Connection-oriented protocols

- Connection-oriented protocols establish a (logical) connection to the communication partner before data transmission is started.
- And if necessary they terminate the connection after the data transfer was finished.
- Connection-oriented protocols are used for data transmission when reliable, guaranteed delivery is of particular importance.
- In general, many logical connections can exist on one physical line.

The following connection-oriented protocols are supported with FBs for open communication via Industrial Ethernet:

- TCP/IP native according to RFC 793 (connection types 01h and 11h):
 - During data transmission, no information about the length or about the start and end of a message is transmitted.
 - The receiver has no means of detecting where one message ends in the data stream and the next one begins.

Configure Open Communication

- The transfer is stream-oriented. For this reason, it is recommended that the data length of the FBs is identical for the sending and receiving station.
- If the number of received data does not fit to the preset length you either will get not the whole data, or you will get data of the following job. The receive block copies as many bytes into the receive area as you have specified as length. After this, it will set NDR to TRUE and write RCVD_LEN with the value of LEN. With each additional call, you will thus receive another block of sent data.
- ISO on TCP according to RFC 1006:
 - During data transmission, information on the length and the end of the message is also transmitted.
 - The transfer is block-oriented
 - If you have specified the length of the data to be received greater than the length of the data to be sent, the receive block will copy the received data completely into the receive range. After this, it will set NDR to TRUE and write RCVD_LEN with the length of the sent data.
 - If you have specified the length of the data to be received less than the length of the sent data, the receive block will not copy any data into the receive range but instead will supply the following error information: ERROR = 1, STATUS = 8088h.

Connection-less protocol

- There is thus no establishment and termination of a connection with a remote partner.
- Connection-less protocols transmit data with no acknowledge and with no reliable guaranteed delivery to the remote partner.

The following connection-oriented protocol is supported with FBs for open communication via Industrial Ethernet:

- UDP according to RFC 768 (with connection type 13h):
 - In this case, when calling the sending block you have to specify the address parameters of the receiver (IP address and port number).
 - During data transmission, information on the length and the end of the message is also transmitted.
 - In order to be able to use the sending and receiving blocks first you have to configure the local communications access point at both sides.
 - With each new call of the sending block, you re-reference the remote partner by specifying its IP address and its port number.
 - If you have specified the length of the data to be received greater than the length of the data to be sent, the receive block will copy the received data completely into the receive range. After this, it will set NDR to TRUE and write RCVD_LEN with the length of the sent data.
 - If you have specified the length of the data to be received less than the length of the sent data, the receive block will not copy any data into the receive range but instead will supply the following error information: ERROR = 1, STATUS = 8088h.

Handling blocks

Those in the following listed UTDs and FBs serve for "open communication" with other Ethernet capable communication partners via your user program. These blocks are part of the Siemens SIMATIC Manager. You will find these in the "Standard Library" at "Communication Blocks". Please consider when using the blocks for open communication that the partner station does not have to be configured with these blocks. This can be configured with AG_SEND/AG_RECEIVE or IP_CONFIG. First you have to establish a hardware configuration of the CPU and Ethernet PG/OP channel before you can use the handling blocks.

Hardware configuration:

- CPU
 - → 'Hardware configuration CPU'...page 72
- Ethernet PG/OP channel
 - → 'Hardware configuration Ethernet PG/OP channel'...page 74

Configure Open Communication

To specify the Ethernet PG/OP channel, the following values are defined in the UDT 65:

- local_device_id
 - 00h: Ethernet PG/OP channel of the CPU
- next_staddr_len
 - 01h: Ethernet PG/OP channel of the CPU
- next_staddr
 - 04h: Ethernet PG/OP channel of the CPU

UDTs

FB	Designation	Connection-oriented protocols: TCP native as per RFC 793, ISO on TCP as per RFC 1006	Connectionless protocol: UDP according to RFC 768
UDT 65	TCON_PAR	Data structure for assigning connection parameters	Data structure for assigning parameters for the local communications access point
UDT 66	TCON_ADR		Data structure for assigning addressing parameters for the remote partner

FBs

FB	Designation	Connection-oriented protocols: TCP native as per RFC 793, ISO on TCP as per RFC 1006	Connectionless protocol: UDP according to RFC 768
FB 63	TSEND	Sending data	
FB 64	TRCV	Receiving data	
FB 65	TCON	Establishing a connection	Configuring the local communications access point
FB 66	TDISCON	Terminating a connection	Closing the local communications access point
FB 67	TUSEND		Sending data
FB 68	TURCV		Receiving data



More information about the usage of these blocks may be found in the manual "SPEED7 Operation List".

Basics PROFINET

9 Deployment PG/OP communication - PROFINET

- With firmware version V2.4.0, there is a PROFINET IO controller available via the Ethernet PG/OP channel.
- As soon as you use the PROFINET functionality via the Ethernet PG/OP channel, this affects the performance and response time of your system and due to the system the cycle time of the OB1 is extended by 2ms.

9.1 Basics PROFINET

General

- PROFINET is an open Industrial Ethernet Standard from PROFIBUS & PROFINET International (PI) for automation.
- PROFINET is standardized in the IEC 61158.
- PROFINET uses TCP/IP and IT standards and supplements the PROFIBUS technology for applications, where fast data communication with industrial IT functions is demanded.

There are 2 PROFINET function classes:

- PROFINET IO
- PROFINET CBA

These may be realized in 3 performance steps:

- TCP/IP communication
- RT communication
- IRT communication

PROFINET IO

- With PROFINET IO an I/O data sight to the distributed periphery is described.
- PROFINET IO describes the whole data transfer between IO controller and IO device.
- PROFINET is configured like PROFIBUS.
- PROFINET IO always contains the real time concept.
- Contrary to the master-slave procedure of PROFIBUS, PROFINET uses the provider-consumer model. This supports the communication relations (AR = Application Relation) between equal participants in the Ethernet. Here the provider sends its data without a request of the communication partner.
- Apart from the user data exchange also functions for parametrization and diagnostics are supported.

PROFINET CBA

- PROFINET CBA means Component Based Automation.
- This component model describes the communication between autonomously working stations.
- It makes a simple modularization of complex plants possible, by distributed intelligence by means of graphic configuration for communication of intelligent modules.

TCP/IP communication

This is the open communication via Ethernet TCP/IP without any demand on real-time.

RT Communication

- RT means Real-Time.
- The RT communication represents the basics for data transfer at PROFINET IO.
- Here RT data are handled with higher priority.

Basics PROFINET

IRT Communication

- IRT means Isochronous Real-Time.
- With the IRT communication the bus cycle begins clock-exactly i.e. with a maximum permissible tolerance and is again synchronized. Thereby the time-controlled and synchronous transfer of data is guaranteed.
- Here sync telegrams of a sync master in the network serve for.

Properties of PROFINET

PROFINET of IEC 61158 has the following properties:

- Full-duplex transfer with 100MBit/s via copper respectively fibre optics.
- Switched Ethernet
- Auto negotiation (negotiates the transfer parameters)
- Auto crossover (transmission and receipt lines are crossed automatically if necessary)
- Wireless communication via WLAN
- UDP/IP is used as overlaid protocol. UDP means User Datagram Protocol and contains the unprotected connectionless broadcast communication within IP.

PROFINET devices

Like PROFIBUS DP also with PROFINET IO the following devices are classified according to their tasks:

- IO controller
 - The IO controller is equivalent to the master of PROFIBUS.
 - This is the PLC with PROFINET connection, in which the PLC program runs.
- IO device
 - The IO device is a distributed I/O field device, which is connected to PROFINET.
 - The IO device is equal to the slave of PROFIBUS.
- IO supervisor
 - The IO supervisor is an engineering station as e.g. programming unit, PC or HMI interface for commissioning and diagnostics.

AR

AR (Application Relation) corresponds to a connection to an IO controller or IO supervisor.

API

- API means Application Process Identifier and defines besides Slot and Subslot a further addressing level.
- With this additional addressing mode with using of different applications, the overlapping of data areas can be prevented.
- The following APIs are currently supported by the PROFINET IO devices:
 - DEFAULT_API (0x00000000)
 - DRIVE API (0x00003A00)
 - ENCODER_API (0x00003D00)
 - FIELDBUS_INTEGRATION_API (0x00004600)
 - PROFINET_IO_LINK_API (0x00004E01)
 - RFID_READER_API (0x00005B00)
 - BARCODE_READER_API (0x00005B10)
 - INTELLIGENT_PUMP_API (0x00005D00)
 - PROCESS AUTOMATION API (0x00009700)

PROFINET installation guidelines

GSDML file

- To configure a device I/O connection in your own configuration tool, you've got all the information about your PROFINET components in form of a GSDML file. This file may be found for System MICRO in the 'Download Center' of www.yaskawa.eu.com under 'GSDML MICRO'.
- Please install the GSDML file in your configuration tool.
- More information about installing the GSDML file may be found at the manual of the according engineering tool.
- Structure and content of the GSDML file are defined by IEC 61158.

Addressing

In contrast to the PROFIBUS address, in PROFINET each device may be definitely identified with its PROFINET interface:

- Device name
- IP address respectively MAC address

Transfer medium

PROFINET is compatible to Ethernet in accordance with the IEEE standards. The connection of the PROFINET IO field devices is exclusively established via switches as network components. This is made either as star via multi-port switches or as line by means of switches, integrated to the field devices.

9.2 PROFINET installation guidelines

Generals to data security

The topic of data security and access protection have become increasingly important in the industrial environment. The increased networking of entire industrial systems to the network levels within the company together with the functions of remote maintenance have all served to increase vulnerability. Threats can arise from internal manipulation like technical errors, operator and program errors respectively from external manipulation like software viruses and worms, trojans and password phishing.

Precautions

The most important precautions to prevent manipulation and loss of data security in the industrial environment are:

- Encrypting the data traffic by means of certificates.
- Filtering and inspection of the traffic by means of VPN "Virtual Private Networks".
- Identification of the nodes by "Authentication" via save channels.
- Segmenting in protected automation cells, so that only devices in the same group can exchange data.

Guidelines for information security

With the "VDI/VDE 2182 sheet 1", Information Security in the Industrial Automation - General procedural model, VDI guidelines, the VDI/VDE society for measuring and automation engineering has published a guide for implementing a security architecture in the industrial environment. The guideline can be found at www.vdi.de PROFIBUS & PROFINET International (PI) can support you in setting up security standards by means of the "PROFINET Security Guideline". More concerning this can be found at the corresponding web site e.g. www.profibus.com

Industrial Ethernet

- Due to the open standard of PROFINET standard Ethernet components may be used.
- For industrial environment and due to the high transfer rate of 100MBit/s your PROFINET system should consist of Industrial Ethernet components.
- All the devices interconnected by switches are located in one and the same network. All the devices in a network can communicate directly with each other.
- A network is physically limited by a router.
- If devices need to communicate beyond the limits of a network, you have to configure the router so that it allows this communication to take place.

Deployment as PROFINET IO controller > Steps of configuration

Topology

Linear

- With the linear structure all the communication devices are connected via a linear bus topology.
- Here the linear bus topology is realized with switches that are already integrated into the PROFINET device.
- If a communication member fails, communication across the failed member is no longer possible.

Star

- If you connect communication devices to a switch with more than 2 PROFINET interfaces, you automatically create a star network topology.
- If an individual PROFINET device fails, this does not automatically lead to failure of the entire network, in contrast to other structures.
- It is only if a switch fails that part of the communication network will fail as well.

Ring

- In order to increase the availability of a network the both open ends of a linear bus topology may be connected by a switch.
- By configuring the switch as redundancy manager on a break in the network it ensures that the data is redirected over an intact network connection.

Tree

If you interconnect several star structures, you obtain a tree network topology.

9.3 Deployment as PROFINET IO controller

9.3.1 Steps of configuration



- With firmware version V2.4.0, there is a PROFINET IO controller available via the Ethernet PG/OP channel.
- As soon as you use the PROFINET functionality via the Ethernet PG/OP channel, this affects the performance and response time of your system and due to the system the cycle time of the OB1 is extended by 2ms.

5

Range of functions

Please regard that the PROFINET IO controller supports only the PROFINET functions, which are described in this manual, even if the Siemens CPU, which is used for configuration, offers further functions! To use some described PROFINET functions, it is necessary to deploy another Siemens CPU for configuration. Here, however, is pointed to explicitly.

The configuration of the PROFINET IO controller for PROFINET communication should be done by the following procedure:

- 1. Commissioning and Initialization (assignment IP address data)
- 2. Hardware configuration CPU
- 3. Configuration PROFINET IO controller
- 4. Configuration PROFINET IO devices



With the Siemens SIMATIC Manager, the System MICRO CPU M13-CCF0001 is to be configured as

CPU 314C-2 PN/DP (314-6EH04-0AB0 V3.3)!

Deployment as PROFINET IO controller > Configuration PROFINET IO controller

9.3.2 Commissioning and initialization

Assembly and commissioning

- 1. Install your System MICRO with your CPU.
- 2. Wire the system by connecting cables for voltage supply and signals
- 3. Connect your PROFINET IO controller with Ethernet.
- **4.** Switch on the power supply.
 - → After a short boot time, the CP is in idle.

At the first commissioning respectively after an overall reset of the CPU, the PROFINET IO controller has no IP address.

Assign IP address parameters

This function is supported only if the PROFINET IO controller is not yet configured. You get valid IP address parameters from your system administrator. The assignment of the IP address data happens online in the Siemens SIMATIC Manager starting with version V 5.5 & SP2 with the following proceeding:

- 1. Start the Siemens SIMATIC Manager.
- 2. ▶ Switch to "TCP/IP -> Network card " using 'Options → Set PG/PC interface → '.
- 3. Open the dialog for initialization of a station with 'PLC → Edit Ethernet node'.
- **4.** To get the stations and their MAC address, use the [Browse] button or type in the MAC address. The Mac address may be found at the front of the CPU.
- **5.** Choose if necessary the known MAC address of the list of found stations. To check this with [Blink] you may cause the MT LED to blink.
- **6.** Either type in the IP configuration like IP address, subnet mask and gateway. Or your station is automatically provided with IP parameters by means of a DHCP server. Depending of the chosen option the DHCP server is to be supplied with MAC address, equipment name or client ID. The client ID is a numerical order of max. 63 characters. The following characters are allowed: Hyphen "-", 0-9, a-z, A-Z
- 7. Confirm with [Assign IP configuration].

Directly after the assignment the PROFINET IO controller is online reachable using the set IP address data. You can take the IP address data to your project by means of the hardware configuration.

'Hardware configuration - CPU'...page 72

9.3.3 Configuration PROFINET IO controller

9.3.3.1 Precondition

To parameterize the PROFINET IO controller of the CPU, the following conditions must be fulfilled:

- The PROFINET IO controller is online reachable, this means an initialization was established.
- The hardware configuration described before was established and the PROFINET IO controller is networked.




The PROFINET IO controller supports a maximum IO block size of 512 bytes (consistent).

Proceeding

Open the properties dialog of the PROFINET IO controller by a double-click at PN-IO.

Deployment as PROFINET IO controller > Configuration PROFINET IO controller



The PROFINET interface of the PROFINET IO controller is parametrized with PN-IO, the port with Port 1. In the following these parameters for PN-IO and Port 1 are described.

9.3.3.2 PN-IO

Tab: 'General'

Short description

Designation of the IO controller. For the IO controller, the short description is "PN-IO".

Device name

The device name on the Ethernet subnet must be unique. During initialization the device name is derived from the short description. You can change this at any time.

Support device replacement without exchangeable medium This parameter is not evaluated. With configured topology the *device replacement* without exchangeable medium is supported. → 'Device replacement without exchangeable medium/PG'…page 233

Properties

With *properties* you can enter the IP address, subnet mask and gateway for the PROFINET interface and select the subnet to be connected.

Tab: 'Addresses'

The CPU reports errors of the IO controller via the *interface address*, as soon as e.g. an error during synchronization of the IO controller occurs. With the *PROFINET IO system address* the CPU reports e.g. failure/return of the PROFINET IO system. This address is also used to identify the IO system to which the device belongs, if an IO device fails.

Tab: 'PROFINET'

With the operation field "OB82 / I/O fault task..." you can cause the CPU to call the OB 82 at an error event of the PROFINET interface. An entry to the diagnostics buffer is always done. The other parameters here are not relevant for the use of the PROFINET CPU.



Please leave 'Send clock' in Tab 'PROFINET' at 1ms, otherwise this leads to a configuration error!

Tab: 'I-Device'

These settings are not required for the use of the PROFINET IO controller as an I-Device and should not be changed. → 'Deployment as PROFINET I-Device'...page 224

Tab: 'Synchronization'

These settings are not relevant and should not be changed.

Tab: 'Media Redundancy' (MRP)

MRP is supported exclusively as a redundancy client. → 'MRP'...page 231

Deployment as PROFINET IO controller > Configuration PROFINET IO device

Tab: 'Time-of-day synchronization'

In this area you can configure time-of-day master for time-of-day synchronization in the network.

'Time-of-day synchronization'...page 77

Tab: 'Options'

Interval

Here you can set the interval time with which "Keep-Alive" telegrams are to be sent to a connection partner. This ensures that a communication partner can still be reached because the connection resources are automatically released again after the expiration *interval* time.

9.3.3.3 Port 1

Tab: 'General'

Shown is the short name "Port...". In the field Name another designation may be selected, which is also shown in the configuration table At *comment* you may describe your entry near more. The comment also appears in the configuration table.

Tab: 'Addresses'

Via the port address the diagnostics information of the IO controller may be accessed.

Tab: 'Topology'

These parameters serve for the port setting for topology. → 'Topology'...page 232

Tab: 'Options'

These parameters serve for the port setting. Here the following parameters are supported:

Connection

- Here you can make settings for transmission medium and type. Ensure that the setting for the local port and the partner port are identical.
- PROFINET requires 100Mbit/s in duplex mode.

Ä

Please regard that at activated 'Autonegotiation' the communication with a communication partner that has fixed transmission parameters always happens in 'Full-duplex' mode!

Boundaries

 Boundaries are limitations for the transfer of certain Ethernet frames. The following Boundaries are supported:

'End of detection of accessible nodes': DCP frames for detecting accessible nodes are not forwarded. When enabled, participants which are lying behind this port, are no longer recognized and can not be reached by the controller.

'End of topology discovery': When enabled, this port does not support topology discovery, i.e. LLDP frames are not forwarded.

9.3.4 Configuration PROFINET IO device

Precondition


- The modules, which may be configured here are listed in the hardware catalog.
- For the deployment of the PROFINET IO devices you have to include the modules into the hardware catalog by means of the VIPA GSDML file.
- After the installation of the GSDML file the PROFINET IO devices may be found in the hardware catalog at 'PROFINET IO → Additional field devices → I/O → VIPA ... '

Configure IO devices

Now the project engineering of the PROFINET IO controller is finished. Please link up now your IO devices with periphery to your IO controller.

Deployment as PROFINET I-Device > Steps of configuration

- 1. For the project engineering of PROFINET IO device you search the concerning PROFINET IO device in the hardware catalog at *PROFINET-IO* and drag&drop it in the subnet of your IO controller.
- 2. Assign a name to the IO device. The configured name must match the name of the device. Information about setting the device name can be found in the manual of the IO device.
- **3.** Enter a valid IP address. The IP address is normally assigned automatically by the hardware configurator. If this is not desired, you can assign the IP address manually.
- **4.** Link up the modules of your IO device in the plugged sequence and add the addresses that should be used by the modules.
- **5.** If needed, parametrize the modules.
- 6. ▶ Save, compile and transfer your project. → 'Project transfer'...page 90



9.4 Deployment as PROFINET I-Device

9.4.1 Steps of configuration

Functionality

- With firmware version V2.4.0, there is a PROFINET IO controller available via the Ethernet PG/OP channel, which can be configured as I-Device.
- As soon as you use the PROFINET functionality via the Ethernet PG/OP channel, this affects the performance and response time of your system and due to the system the cycle time of the OB1 is extended by 2ms.

$\frac{3}{1}$

Range of functions

Please regard that the PROFINET IO controller supports only the PROFINET functions, which are described in this manual, even if the Siemens CPU, which is used for configuration, offers further functions! To use some described PROFINET functions, it is necessary to deploy another Siemens CPU for configuration. Here, however, is pointed to explicitly.

Deployment as PROFINET I-Device > Steps of configuration

The *I-Device* (Intelligent IO device) functionality of a CPU allows data to be exchanged with an IO controller, which are preprocessed by the CPU. In this case, the I-Device is connected as an IO device to a higher-level IO controller. The process values recorded in central or decentralized periphery can be preprocessed via a user program and made available to the higher-level PROFINET IO controller by means of PROFINET.

- The configuration of the integrated PROFINET IO controller of the CPU as an I-Device is made via a virtual PROFINET devices, which is to be installed by means of a product specific GSDML in the hardware catalog.
- The communication takes place via input/output areas, which are defined in the I-Device.
- The size of the areas for input and output data is max. 768byte.
- The I-Device is made available to a deterministic PROFINET IO system via a PROFINET IO interface and thus supports the real-time communication *Real-Time*.
- The I-Device functionality meets the requirements of the RT class I (A) and corresponds to the PROFINET specification version V2.3.
- The configuration of a PROFINET CPU as an IO controller and at the same time as an I-Device is possible. The influence of the I-Device configuration on the system limits or performance of the PROFINET controller is equated with that of a device. This means that when the IO controller and I-Device are used at the same time on the PROFINET controller, the I-Device is to be regarded as an additional device for determining the system limits.
- In order for the higher-level IO controller to communicate with the I-Device, the following must be observed:
 - The device name of the PROFINET controller of the I-Device must match the device name of the I-Device at the higher-level IO controller.
 - When using the Siemens SIMATIC Manager respectively the TIA Portal you have to configure I-Device and IO-Controller in different logical networks to avoid name conflicts.



The PROFINET IO controller supports a maximum IO block size of 512 bytes (consistent).

Configuration

The configuration of the PROFINET IO controller as I-Device should be done by the following procedure:

- 1. Installation of the GSDML files
- 2. Configuration as I-Device
- 3. Configuration in the higher-level IO controller

Transfer I-Device from SPEED7 Studio

If the configuration of the *I-Device* from the *SPEED7 Studio* is to be applied to the IO controller of a third-party system, then you must export from the *SPEED7 Studio* the according GSDLM file and import it into the IO controller of the third-party system.

- 1. Start the SPEED7 Studio with your PROFINET project.
- 2. Click at the CPU in 'Devices and networking' and select 'Context menu → Create GSDML file'. Specify an 'Export path' and an unique 'Device name'.
 - ➡ The GSDML file is created and exported. Import this GSDML file into your third-party system.

Deployment as PROFINET I-Device > Configuration as I-Device

9.4.2 Installing the GSDML file

The following GSDML files are required for configuring the integrated PROFINET IO controller of the System MICRO CPU as I-Device in the Siemens SIMATIC Manager:

- GSDML for I-Device
- GSDML for I-Device at IO controller

Proceeding


The installation of the PROFINET IO device '... Micro CPU' happens in the hardware catalog with the following approach:

- 1. Go to the 'Download Center' of www.yaskawa.eu.com.
- 2. ▶ Load under 'GSDML MICRO' the according file for your System MICRO.
- 3. Extract the file into your working directory.
- **4.** Start the Siemens SIMATIC Manager and install via 'Options → Install new GSD file' both GSD files.
 - After the installation you can find the following virtual devices in the hardware catalog at 'PROFINET IO → Additional field devices → VIPA ... → ... Micro System → Micro I-Device':
 - PN I-Device for System MICRO CPU
 - This allows you to configure the Input/output areas in the I-Device of the System MICRO CPU.
 - PN I-Device config M13-CCF0001 for higher-level CPU
 - This allows you to connect the I-Device M13-CCF0001 to the higher-level IO controller.

9.4.3 Configuration as I-Device

It is assumed that a hardware configuration of the CPU exists. → 'Hardware configuration - CPU'...page 72

1. After installing the GSDML the 'PN I-Device for System MICRO CPU' can be found in the hardware catalog at 'PROFINET IO → Other field devices → I/O → ... Micro System → Micro I-Device'. Drag 'PN I-Device for System MICRO CPU' from the hardware catalog to the PROFINET subnet.




Open the properties dialog of the PROFINET IO controller of the CPU by a double-click at 'PN-IO' and assign a 'Device name' for the I-Device in the Register 'General'.



Write down the Name. This name must also be specified as the 'device name' of the I-Device for the higher-level IO controller.


Deployment as PROFINET I-Device > Configuration in the higher-level IO controller



- 3. For 'PN-IO' at 'slot' 'X...' assign an IP address via the properties dialog.
- 4. Create the transfer areas by dragging them to the 'slots' as I/O areas from the hardware catalog. There must be no gaps in the slots. To create the transfer areas, the following input and output areas are available that can be assigned to the virtual I-Device:
 - Input: 1, 8, 16, 32, 64, 128, 256, 512 byte
 - Output: 1, 8, 16, 32, 64, 128, 256, 512 byte

The data direction for *Input* or *Output* refers to the view of the I-Device.

- Input areas define data that are sent from the higher-level IO controller to the I-Device and which are mapped to the input address area of the CPU.
- Output areas define data that are sent to the higher-level IO controller and which are to stored in the output address area of the CPU.



5. Save and transfer your project to the CPU.

9.4.4 Configuration in the higher-level IO controller

It is assumed that a CPU is configured with IP address with the higher-level IO controller. The IP address must be in the same IP circuit as the IP address of the I-Device.

- 1. Dopen the project of the CPU with the higher-level IO controller.
- **2.** For the project engineering of I-Device in the high-level IO controller you have to search the device *'PN I-Device for high-level CPU'* in the hardware catalog at *PROFINET-IO* and drag&drop it in the PROFINET subnet.


Deployment as PROFINET I-Device > Configuration in the higher-level IO controller



3. Open the properties dialog by double-clicking 'PN-I-Device' and enter at 'device name' the previously noted name of the I-Device.




The configured name must match the name of the PROFINET IO controller 'PN-IO' of the I-Device CPU, which you have noted before! → 'Configuration as I-Device'...page 226



- Configure an input area of the same size for each output area of the I-Device in the IO controller and vice versa. Here also no gaps may arise. In particular, make sure that the order of the transfer areas matches that of the I-Device configuration. The following transfer units are available:
 - Input: 1, 8, 16, 32, 64, 128, 256, 512 byte per slot
 - Output: 1, 8, 16, 32, 64, 128, 256, 512 byte per slot
- 5. Save and transfer your project to the CPU.
 - → Your System MICRO PROFINET controller is now connected as an I-Device to the higher-level PROFINET IO controller.

0

I-Device with S7 routing



detected internally and used appropriately for S7 routing.

Deployment as PROFINET I-Device > Error behavior and interrupts

9.4.5 Error behavior and interrupts

Error behavior

The system shows the following error behavior ...

- ... at gaps in the 'slot' configuration:
 - If the configuration of the I-Device contains gaps in the 'slot' configuration (i.e. there are free 'slots' before used 'slots'), the configuration is rejected and 0xEA64 is returned as a configuration error in the diagnostic buffer.
 - If the configuration of the higher-level IO controller contains gaps in the 'slot' configuration (i.e. there are free 'slots' before used 'slots'), the connection is rejected with the PN IO Status ErrorCode1 = 0x40 and ErrorCode2 = 0x04 (AR OUT OF RESOURCE).
- ... at modules, which differ from the configured:
 - A *ModuleDiffBlock* is generated and the wrong modules are not served.
- ... if the number of configured modules in the IO controller is greater than the number of configured modules in the I-Device:
 - The IO controller receives a ModuleDiffBlock with ModuleStatus "NoModule" for modules that are not configured in the I-Device. The I-Device sets the status of the non-configured modules to "bad".
- ... if the number of configured modules in the I-Device is greater than the number of configured modules in the IO controller:
 - The IO controller does not receive an error because the additional modules are unknown.

Starting position	IO controller in RUN, I-Device in RUN					
Event	I-Device CPU goes to STOP					
Reaction	 An OB 85 is called in the IO controller for each input and output transfer area, which is located in the process image, if messages of process image transfer errors are parametrized. → 80 An OB 122 is triggered in the IO controller for each peripheral direct access to an input or output transfer area. 					
Starting position	IO controller in RUN, I-Device in RUN					
Event	IO controller goes to STOP					
Reaction	■ An OB 85 is called in the I-Device for each input transfer area, which is located in the process image, if messages of process image transfer errors are parametrized. → 80					
	In the I-Device, an OB 122 is triggered for each peripheral direct access to an input transfer area.					
	Note: Output transfer areas can still be accessed!					

Deployment as PROFINET I-Device > Error behavior and interrupts

Starting position	IO controller in RUN, I-Device in RUN						
Event	Station failure I-Device, e.g. by bus interruption						
Condition	I-Device must remain operational without a bus connection, i.e. the power supply must further exist.						
Reaction	 An OB 86 (station failure) is called up in the IO controller. An OB 85 is called in the IO controller for each input and output transfer area, which is located in the process image, if messages of process image transfer errors are parametrized. → 80 An OB 122 is triggered in the IO controller for each peripheral direct access to an input or output transfer area. An OB 86 (station failure) is called up in the I-device. An OB 85 is called in the IO controller for each input and output transfer area, which is located in the process image, if messages of process image transfer errors are parametrized. → 80 In the I-device, an OB 122 is triggered for each peripheral direct access to an input or output transfer area. 						
Starting position	IO controller in RUN, I-Device in RUN						
Event	Station recovery						
Reaction	 An OB 86 (recovery) is called in the IO controller. An OB 85 is called in the IO controller until the OB 86 has been called, for each input and output transfer area, which is in the process diagram, if messages of process image transfer errors are parametrized. → 80 An OB 122 is triggered in the IO controller until the OB 86 is called, for each peripheral direct access to an input or output transfer area. An OB 86 (return) is called in the I-Device. An OB 83 (sub module recovery) is called for each input transfer area in the I-Device. In the I-device, an OB 85 is called for each input transfer area, which is in the process image, if messages of process image transfer errors are parametrized and the corresponding OB 83 has not yet been called. → 80 An OB 122 is triggered in the I-Device for each peripheral direct access to an input transfer area, until the corresponding OB 83 has been called. 						
Starting position	Controller in RUN, I-Device in STOP						
Event	I-Device starts						
Reaction	 The OB 100 (start-up) is called in the I-Device. The OB 83 (Return-of-Submodule) for input sub modules of the transfer areas to the higher-level IO controller is called in the I-Device. An OB 85 is called in the I-device for each input transfer area, which is located in the process image, if messages of process image transfer errors are parametrized. → 80 In the I-Device, an OB 122 is triggered for each peripheral direct access to an input transfer area. OB 83 (Return-of-Submodule) for input and output sub modules of the transfer areas to the I-Device is called in the IO controller. An OB 85 is called in the IO controller for each input and output transfer area, which is located in the process diagram, if messages of process image transfer errors are parametrized and the corresponding OB 83 has not yet been called. → 80 In the IO controller, an OB 122 is triggered for each peripheral direct access 						

MRP

Starting position	IO controller is in STOP, I-Device in RUN					
Event	IO controller starts					
Reaction	The OB 83 (Return-of-Submodule) for input sub modules of the transfer areas to the higher-level IO controller is called in the I-Device.					
	■ An OB 85 is called for each transfer area, which is located in the process image, in the I-device if messages of process image transfer errors are parametrized and the corresponding OB 83 has not yet been called. → 80					
	 An OB 122 is triggered in the I-Device for each peripheral direct access to an input transfer area, until the corresponding OB 83 has been called. The OB 100 (startup) is called in the IO controller. 					

9.5 MRP

Overview

To increase the network availability of an industrial Ethernet network, you can connect a *line topology* together to a *ring topology*. To set up a ring topology with media redundancy, you have to bring together the two free ends of a linear bus topology in one device. Closing the linear bus topology to form a ring is achieved with two ports (ring ports) of a device in the ring. At least one device of the ring takes the role of the *redundancy manager*. All other devices in the ring are *redundancy clients*. A standard media redundancy method is MRP (Media Redundancy Protocol). Up to 50 devices per ring can participate. The MRP (Media Redundancy Protocol) is specified in the standard IEC 61158 Type 10 "PROFINET".

Precondition

- The ring in which you want to use MRP may consist only of devices that support this function.
- "MRP" must be activated for all devices in the ring.
- All devices must be connected via their ring ports.
- The ring may contain max. 50 devices.
- The connection setting (transmission medium/duplex) must be set to "full duplex" and at least 100Mbit/s for all ring ports. Otherwise there may be a loss of data traffic.

Function

- The data paths between the individual devices are automatically reconfigured if the ring is interrupted at any point. After reconfiguration, the devices are accessible again.
- In the redundancy manager, one of the both ring ports are blocked for uninterrupted network operation for normal communication so that no data telegrams are circulated. In terms of data transmission, the ring topology is a linear bus topology.
- The *redundancy manager* monitors the ring for interruptions. For this he sends test frames from both ring port 1 and ring port 2. The test frames run through the ring in both directions until they arrive at the other ring port of the redundancy manager.
- As soon as the interruption is removed, the original transmission paths are restored, the two ring ports of the redundancy manager are disconnected and the redundancy clients informed of the change. The redundancy clients then use the new paths to the other devices.

Reconfiguration time

The time between the ring interruption and restoration of a functional linear topology is known as the *reconfiguration time*. At *MRP* the *reconfiguration time* is typically 200ms.

System MICRO PROFINET CP as redundancy client

MRP is only supported as *redundancy client*. If the ring is opened or closed, you will be informed via the OB 82 "Neighbourhood change". With SFB 54 you can get more information.

Topology

Я

The use of MRP in the operating mode I-Device is not permissible and is rejected during the configuration!

9.6 Topology

Overview

By configuring the topology you specify for the PROFINET IO controller the physical connections between the stations in your PROFINET IO system These "neighbourhood relations" are used among others at "Device replacement without exchangeable medium". Here by comparison of target and current topology, the IO device without a name is detected and automatically integrated to the user data traffic. By configuring the topology you have the following options:

- You can evaluate topological errors in your application program
- You have greater flexibility in planning and expansion of a plant

$^{\circ}$

Support Topology editor is limited

Please consider that the support for the topology editor of the Siemens SIMATIC Manager is limited. Here you have only the possibility to configure the target topology offline. An online matching is currently not possible. An interconnection of the ports is also possible by means of the port properties!

Interconnection by means of the *Port* properties

- Click in the hardware configurator at the according PROFINET port and open the properties dialog via 'Context menu → Object properties' and select the register 'Topology'.
 - → The properties dialog to interconnect the ports is opened.
- **2.** Here you have the following parameters:
 - Port interconnection
 - Local port: Name of the local port
 - Medium: Specifying the line type (copper, fibre optic cable). Currently, this parameter is not evaluated.
 - Cable name Specifying a cable name
 - Partners
 - Partner port: Name of the port to which the selected port is interconnected.
 - Alternating partner ports: By specifying at 'Partner port' "Any partner", you
 can configure alternating partner ports for the I/O devices. Currently, this
 parameter is not evaluated.
 - Cable data
 - Cable length: Depending on the port medium you can set in the select list the cable length, if the medium between two stations does not change. Here the signal delay time is automatically calculated. Currently, this parameter is not evaluated.
 - Signal delay time: If the medium between two stations changes, a signal delay time can be defined here. Currently, this parameter is not evaluated.
- 3. ▶ Close the properties dialog with [OK] again.

Commissioning and start-up behavior

9.7 Device replacement without exchangeable medium/PG

Overview

IO devices, which support the PROFINET function *Device replacement without exchangeable medium/PG* get their device name from the controller with the exchange. These can be replaced without installing an "exchangeable medium" (memory card) with the stored device name respectively without assigning a device name by a PG. To assign the device name the IO controller uses the configured *Topology* and the "neighbourhood relationship", which is determined by the IO devices.

Thus the *Device replacement without exchangeable medium/PG* is possible, the following requirements must be met:

- The *Topology* of your PROFINET IO system with the corresponding IO devices must be configured.
- The IO controller and the respective adjacent to the unit to be replaced IO device must support the functionality *Device replacement without exchangeable medium/PG*.
- In the IO controller in the 'Properties' the option Support device replacement without exchangeable medium must be enabled.
- The replaced device must be reset to delivery state, before.

Configuring the function

The configuration of the function *Device replacement without exchangeable medium/PG* in your PROFINET IO system happens with the following approach:

- 1. Double-click at the PROFINET interface of the IO controller of the CPU.
 - ➡ The properties dialog of this PROFINET interface is opened
- **2.** Enable in the register 'General' the option 'Support device replacement without exchangeable medium'.
- 3. Apply the settings with [OK].
- **4.** Safe and translate the hardware configuration.
- 5. Configure your *Topology.* → 'Topology'...page 232
- 6. Transfer your project to the CPU.

Prepare the replace device

For the replacement the "replace device" must be in "delivery state". If you have not received a new "replace device" from Yaskawa, you have to prepare this with the following approach:

- 1. For this connect your "replace device" local at your PG.
- 2. ▶ Start the Siemens SIMATIC Manager and execute 'PLC → Edit Ethernet node'
- 3. Click at 'Nodes accessible online' at [Browse].
- 4. Select the according IO device, which you identify as your "replace device".
- 5. Click at 'Reset to factory settings' at [Reset].
 - → Your IO device is now reset and has then "delivery state".

Replace device

For the replacement the "replace device" must be in "delivery state".

- 1. Disconnect if not already done your device to be exchanged from power.
- Replace this by your "replace device".
- 3. Connect the "replaced device" to power and turn it ON.
 - ➡ Here by comparison of target and current topology, the "replaced device" is automatically detected by the IO controller and automatically integrated to the user data traffic.

9.8 Commissioning and start-up behavior

Start-up on delivery state

In the delivery state the CPU is overall reset. After power ON the PROFINET part has no configuration the PROFINET has no configuration. The PROFINET part is passive and can be found by the device search.

Commissioning and start-up behavior

Online with bus parameters without project

- For the communication between IO controller and IO device the ways for the communication are to be defined before. For the clear specification of the communication ways, these are established during the start-up by the IO controller, based on the project data. Here the configuration takes place by a hardware configuration.
- As soon as the project data were transmitted, the IO controller performs a new system start-up.
- In this state the IO controller may be accessed and its CPU may be configured via Ethernet by the IO controller by means of the IP address.

IO device configuration

- The PROFINET IO controller is configured by a hardware configuration. After the transmission of the project into the IO controller, the IO controller has the whole information for the addressing of and the data exchange with the IO devices.
- During the system start-up of the IO controller the IO devices are supplied with their configured IP address by means of the DCP protocol. After PowerON and after transmitting a new hardware configuration, due to the project data the system start-up of the IO controller is initialized and it runs automatically. During the system start-up the IO controller establishes a clear communication relation (CR) and an application relation (AR) to an IO device. Here the cyclic IO data, the acyclic R/W services and the expected modules/sub modules are specified.
- The PROFINET IO controller does not have any physical LEDs to show the status. The status information are stored as virtual LED states. During runtime, you can determine their status using the SSL partial lists xy19h or xy74h. → 'Diagnostics status indication via SSLs'...page 237
 - The BF3 LED is on when a PROFINET IO device is configured as "linked" but o bus cable is connected.
 - If the IO controller has received a valid configuration with at least one IO device, the BS2-LED gets on.
 - With Ethernet interface parameters, which are unsuitable for PROFINET operation, the BS2-LED flashes at 1Hz.
 - If the IP address of the IO controller can not be used because e.g. it is duplicated, the BS2-LED flashes at 0.5Hz.
 - If at least one IO device is not in cyclic data exchange after the start-up, the BF3 LED blinks.
 - If all IO devices are in cyclic data exchange, the BF3 LED gets off. After a successful system start-up the system is ready for communication.

CPU state influences the IO process data

After PowerON respectively a receipt of a new hardware configuration the configuration data are automatically transferred to the IO controller. Dependent on the CPU state the following behavior is shown by the IO controller:

Behavior at CPU STOP

- In the STOP state of the CPU an output telegram is further cyclically sent, but the contained data are marked as "invalid" and as output data zeros are transmitted.
- The IO controller further receives the input data of the IO devices and transfers them cyclically to the input area of the CPU.

Behavior at CPU RUN

- The IO controller cyclically reads the output data from the CPU and transfers these as telegram to the configured IO devices.
- The IO controller receives the input data of the IO devices and transfers them
 cyclically to the input area of the CPU.

PROFINET diagnostics > Diagnostics during runtime in the user program

9.9 PROFINET diagnostics

9.9.1 Overview

There are the following possibilities to get diagnostics information from your system:


- Diagnostics with the configuration and engineering tool
- Diagnostics during runtime in the user program (OB 1, SFB 52)
- Diagnostics via OB start information
- Diagnostics status indication via SSLs

9.9.2 Diagnostics with the configuration and engineering tool

If you are connected from your configuration respectively engineering tool via Ethernet with the PROFINET IO controller, online diagnostics information may be accessed.

E.g. with 'Station → Open online' you get information about the state of your system. Here missing respectively faulty components are shown by symbols.

In the following figure e.g. there is shown that the configured device 3 is missing and device 4 reports an error.



9.9.3 Diagnostics during runtime in the user program

With SFB 52 RDREC (read record) you can access diagnostics data from your user program e.g. in OB 1. The SFB 52 RDREC operates asynchronously, that is, processing covers multiple SFB calls.

 $\tilde{\mathbb{I}}$

More information about the usage of this block may be found in the manual "SPEED7 Operation List".

PROFINET diagnostics > Diagnostics during runtime in the user program

Example OB 1

For the cyclic access to the diagnostics data of the counter module 050-1BA00 the following example may be used in the OB 1:

```
AN M10.3 'If the reading terminated (BUSY=0) and
AN M10.1 'there is no job triggered (REQ=0) then
S M10.1 'start transfer of record (REQ:=1)
L W#16#4000 'Number of record set (0x4000)
T MW12
CALL SFB 52, DB52 'Call SFB 52 with Instance DB
 REQ :=M10.1 'Trigger flag
 ID :=DW#16#0018 'Smaller addr. of mixed module
 INDEX :=MW12
                 'Length record set 0x4000
 MLEN :=14
                 'with 1 entry
 VALID :=M10.2
                 'Validity of the record set
                'Flag job just running
 BUSY :=M10.3
 ERROR :=M10.4 'Error bit during read access
 STATUS :=MD14
                 'Error codes
 LEN :=MW16
                 'Length of the read record set
 RECORD :=P#M 100.0 Byte 40
                 'Target (MB100, 40byte)
U M10.1
R M10.1
                  'Reset REQ
```

Diagnostics data

The counter module 050-1BA00 serves for 20byte diagnostics data. The diagnostics data of the module 050-1BA00 have the following structure:

Name:	Bytes	Function	Default
ERR_A	1	Diagnostics	00h
MODTYP	1	Module information	18h
ERR_C	1	reserved	00h
ERR_D	1	Diagnostics	00h
CHTYP	1	Channel type	76h
NUMBIT	1	Number diagnostics bits per channel	08h
NUMCH	1	Number channels of the module	01h
CHERR	1	Channel error	00h
CH0ERR	1	Channel-specific error	00h
CH1ERRCH7ERR	7	reserved	00h
DIAG_US	4	μs ticker	00h



More information about the diagnostics data may be found in the System SLIO manual HB300_FM_050-1BA00.

PROFINET diagnostics > Diagnostics status indication via SSLs

9.9.4 Diagnostics via OB start information

- On an error the faulty system generates a diagnostics message for the CPU. Then
 the CPU calls the according diagnostics OB. Here the CPU operating system transfers
 start information to the local data of the OB.
- By evaluating the start information of the according OB you can get information about cause and location of the error.
- During runtime you can access the start information with the system function SFC 6 RD SINFO.
- Please consider that you can even read the start information in the OB himself, because the data are temporary data.

Depending on the type of error, the following OBs are called in a diagnostics event:

- OB 82 on an error of an module at the IO device (Diagnostics interrupt)
- OB 83 on inserting respectively removing a module on a IO device
- OB 86 on failure respectively return of a IO device



More information about the OBs and their start information may be found in the online help of your programming tool and in the manual "SPEED7 Operation List".

9.9.5 Diagnostics status indication via SSLs

The PROFINET IO controller does not have any physical LEDs to show the status. The status information are stored as virtual LED states. During runtime, you can determine their status using the SSL partial lists xy19h or xy74h. More can be found in the manual "SPEED7 Operation List".

Virtual LEDs PROFINET

BF3	BS2	MT2	Meaning
(bus error)	(Bus status)	(Maintenance)	
			PROFINET is not configured.
			PROFINET is configured with valid Ethernet interface parameter, valid IP address and at least one IO device.
•	X	Х	 Bus error, no connection to sub net/switch. Wrong transfer rate Full-duplex-transmission is not activated.
2Hz	X	X	 Failure of a connected IO device. At least one IO device is not access-able. Faulty configuration I device is configured, but no connection exists yet.
X	1Hz	X	 Ethernet interface parameter are not valid. I-Device is configured and Link mode does not correspond to '100 Mbps full duplex'.
X	0.5Hz	X	There was no IP address assigned.
X	Х		Maintenance event of an IO device is pending respectively an internal error happened.

PROFINET diagnostics > Diagnostics status indication via SSLs

BF3	BS2	MT2	Meaning
(bus error)	(Bus status)	(Maintenance)	
4s on, 1s off	X	4s on, 1s off	Simultaneous blinking indicates a not valid configuration.
✓ 4Hz		4Hz	The alternate blinking indicates that a firmware update of the PROFINET IO controller is executed.
•			Firmware update of the PROFINET IO controller is finished without error.
X	X	2Hz	With a suited configuration tool you can cause the MT LED to blink by means of the function 'Member blink test'. This can be useful for e.g. identification of the module.
on: off:	blinking: no	t relevant: X	

Deployment BS LED - Bus status

- BS LED: off
 - PROFINET is not configured.
- BS LED: blinks with 1Hz
 - Ethernet interface parameter are not valid.
- BS LED: blinks with 0.5Hz
 - There was no IP address assigned.
- BS LED: on
 - PROFINET is configured with valid Ethernet interface parameter, valid IP address and at least one IO device.

Deployment of the MT LED - Maintenance

- MT LED: off
 - There is no maintenance event pending.
- MT LED: on
 - Maintenance event of an IO device is pending respectively an internal error happened.
 - Here in the diagnostic buffer of the CPU, an entry was created, where you can find more information about the maintenance event and to resolve it. → 'Diagnostic entries'...page 114

Resolve the error and execute PowerOFF/ON.

- Currently you need to perform a power cycle, to switch the MT-LED off again.
- MT LED: blinks
 - With a suited configuration tool you can cause the LED to blink by means of the function 'Member blink test'. This can be useful for e.g. identification of the module.
 - Simultaneous blinking together with BF2 LED (4s on, 1s off) indicates that the configuration is invalid.
 - The alternate blinking with BF2 LED with 4Hz indicates that a firmware update of the PROFINET IO controller is executed.

PROFINET system limits

9.10 PROFINET system limits

Maximum number devices and configurable connections

$$D = \sum_{i=1}^{n} \frac{1}{A_i}$$

Based on the devices, which have to communicate with the IO controller per ms, you can determine the maximum number of devices. This also results in the maximum number of configurable connections. The *Devices per ms* can be determined by the sum formula of the individual refresh times (A).

- D Devices per ms
- n Number of devices
- A Refresh time device

Please note that the value D must always be rounded to the nearest smaller integer!

The PROFINET IO controller has the following system limits							
Devices per ms (D)	Max. number of devices	Max. number of configurable connections					
3	8	0					
2	8	2					
1	8	2					
0	8	2					

Output bytes per ms

$$O = \sum_{i=1}^{n} \frac{B_i}{A_i}$$

O Output bytes per ms

n Number of devices

B Number output bytes per device

A Refresh time per device

The PROFINET IO controller has the following system limits:

Max. Number output bytes per ms: 800

■ Max. Number output bytes per device: 768

Input bytes per ms

$$I = \sum_{i=1}^{n} \frac{C_i}{A_i}$$

I Input bytes per ms

n Number of devices

C Number input bytes per device

A Refresh time per device

The PROFINET IO controller has the following system limits:

Max. number input bytes per ms: 800

Max. number input bytes per device: 768

Fast introduction

10 Option: PtP communication

10.1 Fast introduction

General

For the PtP communication the use of the optionally available extension module EM M09 is required. The extension module provides interface X1: PtP (RS422/485) with fixed pin assignment.

'Mounting'...page 17

- PtP functionality
 - Using the PtP functionality the interface is allowed to connect via serial point-topoint connection to different source res. target systems.

Protocols

The protocols respectively procedures ASCII, STX/ETX, 3964R, USS and Modbus are supported.

Parametrization

The parametrization of the serial interface happens during runtime using the FC/SFC 216 (SER_CFG). For this you have to store the parameters in a DB for all protocols except ASCII.

Communication

The FCs/SFCs are controlling the communication. Send takes place via FC/SFC 217 (SER_SND) and receive via FC/SFC 218 (SER_RCV). The repeated call of the FC/SFC 217 SER_SND delivers a return value for 3964R, USS and Modbus via RetVal that contains, among other things, recent information about the acknowledgement of the partner station. The protocols USS and Modbus allow to evaluate the receipt telegram by calling the FC/SFC 218 SER_RCV after SER_SND. The FCs/SFCs are included in the consignment of the CPU.



Use FCs instead SFCs

Please regard that the special product specific SFCs are not shown in the CPU. Please use for programming tools e.g. Siemens SIMATIC Manager and TIA Portal the according FCs of the 'Conrols Library'.

Overview FCs/SFCs for serial communication

The following FCs/SFCs are used for the serial communication:

FC/S	SFC	Description
FC/SFC 216	SER_CFG	RS485 parameterize
FC/SFC 217	SER_SND	RS485 send
FC/SFC 218	SER_RCV	RS485 receive



More information about the usage of these blocks may be found in the manual "SPEED7 Operation List".


Principle of the data transfer

10.2 Principle of the data transfer

RS485 PtP communication

The data transfer is handled during runtime by using FC/SFCs. The principle of data transfer is the same for all protocols and is shortly illustrated in the following.

- Data, which are written into the according data channel by the CPU, is stored in a FIFO send buffer (first in first out) with a size of 2x1024byte and then put out via the interface.
- When the interface receives data, this is stored in a FIFO receive buffer with a size of 2x1024byte and can there be read by the CPU.
- If the data is transferred via a protocol, the embedding of the data to the according protocol happens automatically.
- In opposite to ASCII and STX/ETX, the protocols 3964R, USS and Modbus require the acknowledgement of the partner.
- An additional call of the FC/SFC 217 SER_SND causes a return value in RetVal that includes among others recent information about the acknowledgement of the partner.
- Further on for USS and Modbus after a SER_SND the acknowledgement telegram must be evaluated by a call of the FC/SFC 218 SER_RCV.



- 1 Program
- 2 Protocol
- 3 FIFO buffer
- 4 Interface

PtP communication via extension module EM M09

10.3 PtP communication via extension module EM M09

X1 PtP (RS422/485)



9pin SubD jack: (isolated)

Using the *PtP* functionality the RS485 interface is allowed to connect via serial point-to-point connection to different source res. target systems.

- Protocols:
 - ASCII
 - STX/ETX
 - 3964R
 - USS
 - Modbus master (ASCII, RTU)
- Serial bus connection
 - Full-duplex Four-wire operation (RS422)
 - Half-duplex Two-wire operation (RS485)
 - Data transfer rate: max 115 kBaud

Enable PtP functionality







A hardware configuration to enable the PtP functionality is not necessary.

- 1. Turn off the power supply.
- 2. ▶ Mount the extension module. → 'Mounting'...page 17
- **3.** Establish a cable connection to the communication partner.
- **4.** Switch on the power supply.
 - → After a short boot time the interface X1 PtP is ready for PtP communication.


PtP communication via extension module EM M09

RS485 cabling with PROFIBUS cable

X1 PtP



- ① n. c.
- ② TxD-P (line B) RS422
- 3 RxD-P (line B) RS422 RxD/TxD-P (line B) RS485
- ⑤ M5V
- ⑥ P5V
- 7 TxD-N (line A) RS422
- RxD-N (line A) RS422
 RxD/TxD-N (line A) RS485



- X1 PtP interface
- Periphery 2




- *) For traffic-free data transfer use a terminating resistor of approximately 120Ω .
- Never connect the cable shield and the M5V (pin 5) together, due to the compensation currents the interfaces could be destroyed!

PtP communication via extension module EM M09


RS485 cabling with defined static voltage levels

X1 PtP



- ① n. c.
- ② TxD-P (line B) RS422
- 3 RxD-P (line B) RS422 RxD/TxD-P (line B) RS485
- 4 RTS
- ⑤ M5V
- 6 P5V
- 7 TxD-N (line A) RS422
- RxD-N (line A) RS422 RxD/TxD-N (line A) - RS485


For isolated interfaces you have 5V (P5V) isolated at pin 6 and the corresponding ground (M5V) at pin 5. With this isolated voltage, you can assign defined static voltage levels to the signal lines and so ensure a low reflection level.




- X1 PtP interface
- 2 Periphery

RS422 cabling

X1 PtP



- ② TxD-P (line B) RS422
- 3 RxD-P (line B) RS422 RxD/TxD-P (line B) RS485
- 4 RTS
- ⑤ M5V
- 6 P5V
- 7 TxD-N (line A) RS422
- 8 RxD-N (line A) RS422 RxD/TxD-N (line A) RS485




- X1 PtP interface
- Periphery 2
- 3 Send
- Receive
- For line lengths >50m, you have to solder a terminating resistor of approx. 330Ω on the receiver side for traffic-free data transfer.

Parametrization > FC/SFC 216 - SER CFG - Parametrization PtP


RS422 cabling with defined static voltage levels

X1 PtP



- ① n. c.
- ② TxD-P (line B) RS422
- 3 RxD-P (line B) RS422 RxD/TxD-P (line B) RS485
- 4 RTS
- 5 M5V
- 6 P5V
- 7 TxD-N (line A) RS422
- RxD-N (line A) RS422
- RxD/TxD-N (line A) RS485
- 9 n.c.

For isolated interfaces you have 5V (P5V) isolated at pin 6 and the corresponding ground (M5V) at pin 5. With this isolated voltage, you can assign defined static voltage levels to the signal lines and so ensure a low reflection level.



- 1 X1 PtP interface
- 2 Periphery
- Send
- 4 Receive
- For line lengths >50m, you have to solder a terminating resistor of approx. 330Ω on the receiver side for traffic-free data transfer.

Status indication



X1 PtP	Description
TxD	
green flickers	Send activity
	No send activity

10.4 **Parametrization**

FC/SFC 216 - SER CFG - Parametrization PtP 10.4.1

The parametrization happens during runtime deploying the FC/SFC 216 (SER_CFG). You have to store the parameters for STX/ETX, 3964R, USS and Modbus in a DB.

10.5 Communication

10.5.1 FC/SFC 217 - SER SND - Send to PtP

This block sends data via the serial interface. The repeated call of the FC/SFC 217 SER_SND delivers a return value for 3964R, USS and Modbus via RETVAL that contains, among other things, recent information about the acknowledgement of the partner station. The protocols USS and Modbus require to evaluate the receipt telegram by calling the FC/SFC 218 SER_RCV after SER_SND.

10.5.2 FC/SFC 218 - SER_RCV - Receive from PtP

This block receives data via the serial interface. Using the FC/SFC 218 SER_RCV after SER_SND with the protocols USS and Modbus the acknowledgement telegram can be read.



More information about the usage of these blocks may be found in the manual "SPEED7 Operation List".

10.6 Protocols and procedures

Overview

The CPU supports the following protocols and procedures:

- ASCII communication
- STX/ETX
- 3964R
- USS
- Modbus

ASCII

ASCII data communication is one of the simple forms of data exchange. Incoming characters are transferred 1 to 1. At ASCII, with every cycle the read FC/SFC is used to store the data that is in the buffer at request time in a parametrized receive data block. If a telegram is spread over various cycles, the data is overwritten. There is no reception acknowledgement. The communication procedure has to be controlled by the concerning user application. For this you can use the FB 1 - Receive_ASCII.



More information about the usage of this block may be found in the manual "SPEED7 Operation List".

STX/ETX

STX/ETX is a simple protocol with start and end ID, where STX stands for **S**tart of **Text** and ETX for **E**nd of **Text**.

- Any data transferred from the periphery must be preceded by a Start followed by the data characters and the end character. Depending of the byte width the following ASCII characters can be transferred: 5bit: not allowed: 6bit: 20...3Fh, 7bit: 20...7Fh, 8bit: 20...FFh.
- The effective data, which includes all the characters between Start and End are transferred to the CPU when the End has been received.
- When data is send from the CPU to a peripheral device, any user data is handed to the FC/SFC 217 (SER_SND) and is transferred with added Start- and End-ID to the communication partner.
- You may work with 1, 2 or no Start- and with 1, 2 or no End-ID.
- If no End-ID is defined, all read characters are transferred to the CPU after a parameterizable character delay time (Timeout).

As Start-res. End-ID all Hex values from 01h to 1Fh are permissible. Characters above 1Fh are ignored. In the user data, characters below 20h are not allowed and may cause errors. The number of Start- and End-IDs may be different (1 Start, 2 End res. 2 Start, 1 End or other combinations). For not used start and end characters you have to enter FFh in the hardware configuration.

Message structure:



3964

The 3964R procedure controls the data transfer of a point-to-point link between the CPU and a communication partner. The procedure adds control characters to the message data during data transfer. These control characters may be used by the communication partner to verify the complete and error free receipt.

The procedure employs the following control characters:

STX: Start of Text

■ DLE: Data Link Escape


■ ETX: End of Text

BCC: Block Check Character

NAK: Negative Acknowledge

You may transfer a maximum of 255byte per message.

Procedure



ĭ

When a DLE is transferred as part of the information it is repeated to distinguish between data characters and DLE control characters that are used to establish and to terminate the connection (DLE duplication). The DLE duplication is reversed in the receiving station.

The 3964R procedure <u>requires</u> that a lower priority is assigned to the communication partner. When communication partners issue simultaneous send commands, the station with the lower priority will delay its send command.

USS

The USS protocol (**U**niverselle **s**erielle **S**chnittstelle = universal serial interface) is a serial transfer protocol defined by Siemens for the drive and system components. This allows to build-up a serial bus connection between a superordinated master and several slave systems. The USS protocol enables a time cyclic telegram traffic by presetting a fix telegram length.

The following features characterize the USS protocol:

- Multi point connection
- Master slave access procedure
- Single master system
- Max. 32 participants
- Simple and secure telegram frame

It is essential:

- You may connect 1 master and max. 31 slaves at the bus
- The single slaves are addressed by the master via an address sign in the telegram.
- The communication happens exclusively in half-duplex operation.
- After a send command, the acknowledgement telegram must be read by a call of the FC/SFC 218 SER_RCV.

The telegrams for send and receive have the following structure:

Master slave telegram

STX	LGE	ADR	PKE		IND		PWE		STW		HSW		BCC
02h			Н	L	Н	L	Н	L	Н	L	Н	L	

Slave master telegram

STX	LGE	ADR	PKE		IND		PWE		ZSW		HIW		BCC
02h			Н	L	Н	L	Н	L	Н	L	Н	L	

with	
STX	Start sign
STW	Control word
LGE	Telegram length
ZSW	State word
ADR	Address
HSW	Main set value
PKE	Parameter ID
HIW	Main effective value
IND	Index
BCC	Block Check Character
PWE	Parameter value

Broadcast with set bit 5 in ADR byte



A request can be directed to a certain slave ore be send to all slaves as broadcast message. For the identification of a broadcast message you have to set bit 5 to 1 in the ADR byte. Here the slave addr. (bit 0 ... 4) is ignored. In opposite to a "normal" send command, the broadcast does not require a telegram evaluation via FC/SFC 218 SER_RCV. Only write commands may be sent as broadcast.

Modbus

- The Modbus protocol is a communication protocol that fixes a hierarchic structure with one master and several slaves.
- Physically, Modbus works with a serial half-duplex connection. There are no bus conflicts occurring, because the master can only communicate with one slave at a time.
- After a request from the master, this waits for a preset delay time for an answer of the slave. During the delay time, communication with other slaves is not possible.
- After a send command, the acknowledgement telegram must be read by a call of the FC/SFC 218 SER RCV.
- The request telegrams send by the master and the respond telegrams of a slave have the following structure:

Telegram structure

Start sign	Slave address	Function Code	Data	Flow control	End sign
------------	---------------	---------------	------	--------------	----------

Broadcast with slave address = 0

- A request can be directed to a special slave or at all slaves as broadcast message.
- To mark a broadcast message, the slave address 0 is used.
- In opposite to a "normal" send command, the broadcast does not require a telegram evaluation via FC/SFC 218 SER_RCV.
- Only write commands may be sent as broadcast.

ASCII, RTU mode

Modbus offers 2 different transfer modes. The mode selection happens during runtime by using the FC/SFC 216 SER_CFG.

- ASCII mode: Every byte is transferred in the 2 sign ASCII code. The data are marked with a start and an end sign. This causes a transparent but slow transfer.
- RTU mode: Every byte is transferred as one character. This enables a higher data pass through as the ASCII mode. Instead of start and end sign, a time control is used.

Supported Modbus protocols

The following Modbus Protocols are supported by the RS485 interface:


- Modbus RTU Master
- Modbus ASCII Master

Modbus - Function codes

10.7 Modbus - Function codes

Naming convention

Modbus has some naming conventions:



- Modbus differentiates between bit and word access; bits = "Coils" and words = "Register".
- Bit inputs are referred to as "Input-Status" and bit outputs as "Coil-Status".
- word inputs are referred to as "Input-Register" and word outputs as "Holding-Register".

Range definitions

Normally the access at Modbus happens by means of the ranges 0x, 1x, 3x and 4x.

0x and 1x gives you access to digital bit areas and 3x and 4x to analog word areas.

For the CPs is not differentiating digital and analog data, the following assignment is valid:

0x Bit area for master output data

Access via function code 01h, 05h, 0Fh

1x Bit area for master input data


Access via function code 02h

3x word area for master input data

Access via function code 04h

4x word area for master output data

Access via function code 03h, 06h, 10h



A description of the function codes follows below.

Overview

With the following Modbus function codes a Modbus master can access a Modbus slave. The description always takes place from the point of view of the master:


Code	Command	Description
01h	Read n bits	Read n bits of master output area 0x
02h	Read n bits	Read n bits of master input area 1x
03h	Read n words	Read n words of master output area 4x

Modbus - Function codes

Code	Command	Description
04h	Read n words	Read n words master input area 3x
05h	Write 1 bit	Write 1 bit to master output area 0x
06h	Write 1 word	Write 1 word to master output area 4x
0Fh	Write n bits	Write n bits to master output area 0x
10h	Write n words	Write n words to master output area 4x

Point of View of "Input" and "Output" data

The description always takes place from the point of view of the master. Here data, which were sent from master to slave, up to their target are designated as "output" data (OUT) and contrary slave data received by the master were designated as "input" data (IN).



Respond of the slave

If the slave announces an error, the function code is send back with an "ORed" 80h.

Without an error, the function code is sent back.

Slave answer: Function code OR 80h \rightarrow Error Function code \rightarrow OK

Byte sequence in a word

1 w	ord
High-byte	Low-byte

Check sum CRC, RTU, LRC

The shown check sums CRC at RTU and LRC at ASCII mode are automatically added to every telegram. They are not shown in the data block.

Read n bits 01h, 02h

Code 01h: Read n bits of master output area 0x

Code 02h: Read n bits of master input area 1x

Command telegram

Slave address	Function code	Address 1. bit	Number of bits	Check sum CRC/LRC
1byte	1byte	1word	1word	1word

Modbus - Function codes

Respond telegram

Slave address	Function code	Number of read bytes	Data 1. byte	Data 2. byte	 Check sum CRC/LRC
1byte	1byte	1byte	1byte	1byte	1word
				max. 250byte	

Read n words 03h, 04h 03h: Read n words of master output area 4x

04h: Read n words master input area 3x

Command telegram

Slave address	Function code	Address 1. bit	Number of words	Check sum CRC/LRC
1byte	1byte	1word	1word	1word

Respond telegram

Slave address	Function code	Number of read bytes	Data 1. word	Data 2. word	 Check sum CRC/LRC
1byte	1byte	1byte	1word	1word	1word
				max. 125words	

Write 1 bit 05h Code 05h: Write 1 bit to master output area 0x

A status change is via "Status bit" with following values:

"Status bit" = $0000h \rightarrow Bit = 0$ "Status bit" = $FF00h \rightarrow Bit = 1$

Command telegram

Slave address	Function code	Address bit	Status bit	Check sum CRC/LRC
1byte	1byte	1word	1word	1word

Respond telegram

Slave address	Function code	Address bit	Status bit	Check sum CRC/LRC
1byte	1byte	1word	1word	1word

Write 1 word 06h Code 06h: Write 1 word to master output area 4x

Command telegram

Slave address	Function code	Address word	Value word	Check sum CRC/LRC
1byte	1byte	1word	1word	1word

Respond telegram

Slave address	Function code	Address word	Value word	Check sum CRC/LRC
1byte	1byte	1word	1word	1word

Write n bits 0Fh Code 0Fh: Write n bits to master output area 0x

Please regard that the number of bits has additionally to be set in byte.

Modbus - Function codes

Command telegram

Slave address	Function code	Address 1. bit	Number of bits	Number of bytes	Data 1. byte	Data 2. byte		Check sum CRC/LRC
1byte	1byte	1word	1word	1byte	1byte	1byte	1byte	1word
					ı	max. 250byte		

Respond telegram

Slave address	Function code	Address 1. bit	Number of bits	Check sum CRC/LRC
1byte	1byte	1word	1word	1word

Write n words 10h

Code 10h: Write n words to master output area 4x

Command telegram

Slave address	Function code	Address 1. word	Number of words	Number of bytes	Data 1. word	Data 2. word		Check sum CRC/LRC
1byte	1byte	1word	1word	1byte	1word	1word	1word	1word
					m	nax. 125words	3	

Respond telegram

Slave address	Function code	Address 1. word	Number of words	Check sum CRC/LRC
1byte	1byte	1word	1word	1word

PROFIBUS communication

11 Option: Deployment PROFIBUS communication

11.1 Fast introduction

Overview

For the PROFIBUS communication the use of the optionally available extension module EM M09 is required. The extension module provides interface X2: MPI(PB) with fixed pin assignment. — 'Mounting'...page 17 The PROFIBUS DP slave is to be configured in the hardware configurator from Siemens. Here the configuration happens by the sub module X1 (MPI/DP) of the Siemens CPU.

$\frac{\circ}{1}$

Enable bus functionality via VSC

To switch the interface X2 MPI(PB) to PROFIBUS functionality you have to activate the according bus functionality by means of a Yaskawa VSC storage media. By plugging the VSC storage card and then an overall reset the according functionality is activated.

→ 'Deployment storage media - VSD, VSC'…page 108

Steps of configuration

The configuration of the PROFIBUS DP slave should be done with the following approach:

- Activating bus functionality by means of a VSC
- Hardware configuration CPU
- Use as DP slave
 - With activating the bus functionality 'PROFIBUS DP slave' by means of a VSC, the bus functionality 'PROFIBUS DP slave' is unlocked.
- Transfer of the entire project to the CPU



With the Siemens SIMATIC Manager, the CPU M13-CCF0001 is to be configured as

CPU 314C-2 PN/DP (314-6EH04-0AB0 V3.3)

The PROFIBUS DP slave is to be configured and connected via the sub module X1 (MPI/DP).

11.2 PROFIBUS communication

PROFIBUS DP

- PROFIBUS is an international standard applicable to an open and serial field bus for building, manufacturing and process automation that can be used to create a low (sensor-/actuator level) or medium (process level) performance network of programmable logic controllers.
- PROFIBUS comprises an assortment of compatible versions. The following details refer to PROFIBUS DP.
- PROFIBUS DP is a special protocol intended mainly for automation tasks in a manufacturing environment. DP is very fast, offers Plug'n'Play facilities and provides a cost-effective alternative to parallel cabling between PLC and remote I/O. PROFIBUS DP was designed for high-speed data communication on the sensor-actuator level.
- The data transfer referred to as "Data Exchange" is cyclical. During one bus cycle, the master reads input values from the slaves and writes output information to the slaves.

DP slave operation

For the deployment in a super-ordinated master system you first have to project your slave system as Siemens CPU in slave operation mode with configured in-/output areas. Afterwards you configure your master system. Couple your slave system to your master system by dragging the CPU 31x from the hardware catalog at *Configured stations* onto the master system, choose your slave system and connect it.

PROFIBUS communication via extension module EM M09

Operating mode DP slave: Test, commissioning, routing (active/passive)

There is the possibility to enable the option 'Test, commissioning, routing' in the hardware configuration by means of the properties dialog of the PROFIBUS via the register 'Operating mode' at 'DP slave'. The activation affects as follows:

- The PROFIBUS interface gets an "active" PROFIBUS node, this means it is involved in the token rotation.
- Via this interface you have PG/OP functions (programming, status request, control, test).
- The PROFIBUS interface serves as a gateway (S7 routing).
- The bus rotation time can exceed.

When disabled, the PROFIBUS interface operates as passive DP slave with the following characteristics:

- The PROFIBUS interface gets an "passive" PROFIBUS node, this means it is not involved in the token rotation.
- Bus rotation time is not influenced.
- S7 routing is not possible.

11.3 PROFIBUS communication via extension module EM M09

X2 MPI(PB)



9pin SubD jack: (isolated)


The interface supports the following functionalities, which are switch able by an hardware configuration:

- MPI (default / after overall reset)
 The MPI interface serves for the connection between programming unit and CPU. By means of this the project engineering and programming happens. In addition MPI serves for communication between several CPUs or between HMIs and CPU.
- Standard setting is MPI address 2.

 PROFIBUS DP slave (option)

The PROFIBUS slave functionality of this interface can be activated by configuring the sub module 'MPI/DP' of the CPU in the hardware configuration.

Enable PROFIBUS functionality





1. Turn off the power supply.



2. ▶ Mount the extension module. → 'Mounting'...page 17



- **3.** ▶ Switch on the power supply.
 - → After a short boot time the interface X2 MPI(PB) is ready for MPI communication with the MPI address 2.

0


Enable bus functionality via VSC


To switch the interface X2 MPI(PB) to PROFIBUS functionality you have to activate the according bus functionality by means of a Yaskawa VSC storage media. By plugging the VSC storage card and then an overall reset the according functionality is activated.

→ 'Deployment storage media - VSD, VSC'...page 108

Deployment as PROFIBUS DP slave

X2 MPI(PB)





- 1 RS485 interface
- 2 Periphery



Never connect the cable shield and the M5V (pin 5) together, since the interfaces could be destroyed!

Status indication



X2 MPI(PB) DE	Description
green	 Slave is in DE (data exchange). Slave exchanges data with the master. Slave is in RUN state
green blinking	Slave CPU is in state start-up.Slave-CPU is without master.
	There is no power supply.Slave has no configuration.

11.4 Deployment as PROFIBUS DP slave

Fast introduction


In the following the deployment of the PROFIBUS section as "intelligent" DP slave on master system is described, which exclusively may be configured in the Siemens SIMATIC Manager. The following steps are required:

- 1. ▶ Configure a station with a CPU with operating mode DP slave.
- 2. Connect to PROFIBUS and configure the in-/output area for the slave section.
- **3.** Save and compile your project.
- 4. Configure another station with another CPU with operating mode DP master.
- **5.** Connect to PROFIBUS and configure the in-/output ranges for the master section.
- **6.** ▶ Save, compile and transfer your project to your CPU.

Deployment as PROFIBUS DP slave

Project engineering of the slave section

- 1. Start the Siemens SIMATIC Manager and configure a CPU as described at "Hardware configuration CPU".
- 2. Designate the station as "...DP slave".
- 3. Add your modules according to the real hardware assembly.
- Open the properties dialog of the DP interface of the CPU by means of a double-click at 'MPI/DP'.
- 5. Set Interface type to "PROFIBUS".
- **6.** ▶ Connect to PROFIBUS and preset an address (e.g. 3) and confirm with [OK].
- 7. Switch at Operating mode to "DP slave".
- **8.** Via Configuration you define the in-/output address area of the slave CPU, which are to be assigned to the DP slave.
- **9.** ▶ Save, compile and transfer your project to your CPU.




Standard bus: Object properties Operating mode: DP slave Connect: PROFIBUS PROFIBUS address > 1

2 Configuration Input area Output area

Project engineering of the master section

- 1. Insert another station and configure a CPU.
- 2. Designate the station as "...DP master".
- 3. Add your modules according to the real hardware assembly.
- Open the properties dialog of the DP interface of the CPU by means of a double-click at 'MPI/DP'.
- 5. Set Interface: type to "PROFIBUS".
- 6. ▶ Connect to PROFIBUS and preset an address (e.g. 2) and confirm with [OK].
- 7. Switch at Operating mode to "DP master" and confirm the dialog with [OK].
- 8. Connect your slave system to this master system by dragging the "CPU 31x" from the hardware catalog at *Configured stations* onto the master system and select your slave system to be coupled.
- **9.** Open the *Configuration* at *Object properties* of your slave system.
- 10. Via double click to the according configuration line you assign the according input address area on the master CPU to the slave output data and the output address area to the slave input data.
- 11. Save, compile and transfer your project to your CPU.

Deployment as PROFIBUS DP slave > Diagnostic functions



- Standard bus: Object properties Operating mode: DP master PROFIBUS address > 1
- 2 Hardware catalog: CPU 31x from 'Configured stations'
- 3 DP master system: Object properties Input area slave CPU = Output area master CPU Output area slave CPU = Input area master CPU

11.4.1 Diagnostic functions

Overview

PROFIBUS DP provides an extensive set of diagnostic functions for quick error localization. Diagnostic messages are transferred via the bus and collected by the master. In the operating mode DP slave the CPU sends diagnostic data when requested by the master or in case of an error. Since a part of the diagnostic data (Byte 11 ... 15) is located in the peripheral address area of the CPU, you may start the diagnostics and modify the diagnostic data. Diagnostic data consist of:

- Standard diagnostic data (Byte 0 ... 5),
- Device specific diagnostic data (Byte 6 ... 15).

Deployment as PROFIBUS DP slave > Diagnostic functions

Structure

The diagnostic data have the following structure:

Standard diagnostic data

Byte 0	Station status 1
Byte 1	Station status 2
Byte 2	Station status 3
Byte 3	Master address
Byte 4	Ident number (low)
Byte 5	Ident number High

Device specific diagnostic data

Byte 6	Length and code device specific diagnostic
Byte 7	Device specific diagnostic messages
Byte 8	reserved
Byte 10	
Byte 11 Byte 15	User-specific diagnostic data is mapped into the peripheral addressing range of the CPU and may be modified and sent to the master.

Standard diagnostic data

More detailed information to the structure of the slave standard diagnostic data can be found in the standard papers of the PROFIBUS User Organization. The slave diagnostic data have the following structure:

Byte	Bit 7 Bit 0
0	 Bit 0: 0 (fix) Bit 1: Slave is not yet ready for data exchange Bit 2: Configuration data are not identical Bit 3: Slave has external diagnostic data Bit 4: Slave does not provide this function Bit 5: 0 (fix) Bit 6: Wrong parametrization Bit 7: 0 (fix)
1	 Bit 0: Slave needs new parametrization Bit 1: Static diagnostic Bit 2: 1 (fix) Bit 3: Response monitoring active Bit 4: Freeze command received Bit 5: Sync command received Bit 6: reserved Bit 7: 0 (fix)
2	Bit 0 Bit 6: reservedBit 7: Diagnostic data overflow
3	Master address after parametrization
4	ID number high byte
5	ID number low byte

Deployment as PROFIBUS DP slave > Diagnostic functions

Device specific diagnostic data

The device related diagnostic data provide detailed information on the slave and the peripheral modules. The length of the device related diagnostic data is fixed at 10byte

Byte	Bit 7 Bit 0
6	 Bit 0 5: Length device specific diagnostic data 001010: Length 10byte (fix) Bit 6 7: Code for device specific diagnostic 00: Code 00 (fix)
7	 Device specific diagnostic message 12h: Error: Data length parameters 13h: Error: Data length configuration data 14h: Error: Configuration entry 15h: Error: VPC3 buffer calculation 16h: Missing configuration data 17h: Error: Comparison DP parametrization and configuration 40h: User specific diagnostic data is valid
810	reserved
1115	User specific diagnostic data that are stored behind the diagnostic status byte in the process picture of the CPU. This data may be overwritten and forwarded to the master.

Release diagnostic

- In case of a diagnostic the contents of Byte 11 ... 15 of the device specific diagnostic data will be transferred to the process image of the CPU and this preceded by a status byte.
- Where this diagnostic block with a length of 6byte is located in the process image can be defined via the CPU parameters.
- You start diagnostics by means of a status change from 0 → 1 in the diagnostic status byte. This transmits the respective diagnostic message to the master.
- A status of 0000 0011 is ignored!

The diagnostic block of the CPU has the following structure:

Byte	Bit 7 Bit 0
0	Diagnostic status byte
	Bit 0: User specific diagnostic data0: Invalid diagnostic data
	- 1: Valid diagnostic data (starting a diagnostic)
	 Bit 1: Delete diagnostic 0: Diagnostic deletion not valid 1: Diagnostic deletion valid Bit 2 Bit 7: reserved
1 5	User specific diagnostic data equal to
	Byte 11 15 of device specific diagnostic

PROFIBUS installation guidelines

11.5 PROFIBUS installation guidelines

PROFIBUS in general

- A PROFIBUS DP network may only be built up in linear structure.
- PROFIBUS DP consists of minimum one segment with at least one master and one slave.
- A master has always been deployed together with a CPU.
- PROFIBUS supports max. 126 participants.
- Per segment a max. of 32 participants is permitted.
- The max. segment length depends on the transfer rate:

9.6 ... 187.5bit/s → 1000m

500kbit/s $\rightarrow 400$ m

1.5Mbit/s $\rightarrow 200$ m

3 ... 12Mbit/s → 100m


- Max. 10 segments may be built up. The segments are connected via repeaters. Every repeater counts for one participant.
- The bus respectively a segment is to be terminated at both ends.
- All participants are communicating with the same transfer rate. The slaves adjust themselves automatically on the transfer rate.

Transfer medium

- As transfer medium PROFIBUS uses an isolated twisted-pair cable based upon the RS485 interface.
- The RS485 interface is working with voltage differences. Though it is less irritable from influences than a voltage or a current interface. You are able to configure the network as well linear as in a tree structure.
- Max. 32 participants per segment are permitted. Within a segment the members are linear connected. The segments are connected via repeaters. The maximum segment length depends on the transfer rate.
- PROFIBUS DP uses a transfer rate between 9.6kbit/s and 12Mbit/s, the slaves are following automatically. All participants are communicating with the same transfer rate.
- The bus structure under RS485 allows an easy connection res. disconnection of stations as well as starting the system step by step. Later expansions don't have any influence on stations that are already integrated. The system realizes automatically if one partner had a fail down or is new in the network.

Bus connection

The following picture illustrates the terminating resistors of the respective start and end station.



PROFIBUS installation guidelines




The PROFIBUS line has to be terminated with its ripple resistor. Please make sure to terminate the last participants on the bus at both ends by activating the terminating resistor.

EasyConn bus connector



In PROFIBUS all participants are wired parallel. For that purpose, the bus cable must be feed-through. Via the order number 972-0DP10 you may order the bus connector "Easy-Conn" from Yaskawa. This is a bus connector with switchable terminating resistor and integrated bus diagnostic.




Dimensions in mm	0°	45°	90°
A	64	61	66
В	34	53	40
C	15.8	15.8	15.8

j

To connect this EasyConn plug, please use the standard PROFIBUS cable type A (EN50170). Starting with release 5 you also can use highly flexible bus cable:

Lapp cable order no: 2170222, 2170822, 2170322.

With the order no. 905-6AA00 Yaskawa offers the "EasyStrip" de-isolating tool that makes the connection of the EasyConn much easier.








Dimensions in mm

Termination with "Easy-Conn"

The "EasyConn" bus connector is provided with a switch that is used to activate a terminating resistor.

PROFIBUS installation guidelines

Wiring



- [1] 1./last bus participant
- [2] further participants



CAUTION

The terminating resistor is only effective, if the connector is installed at a bus participant and the bus participant is connected to a power supply.

The tightening torque of the screws to fix the connector to a device must not exceed 0.02Nm!



A complete description of installation and deployment of the terminating resistors is delivered with the connector.

Assembly



- 1. Loosen the screw.
- 2. Lift contact-cover.
- 3. Insert both wires into the ducts provided (watch for the correct line colour as below!)
- 4. Please take care not to cause a short circuit between screen and data lines!



- **5.** Close the contact cover.
- **6.** Tighten screw (max. tightening torque 0.08Nm).



The green line must be connected to A, the red line to B!

SPEED7 Studio - Overview

12 Configuration with SPEED7 Studio

12.1 SPEED7 Studio - Overview

SPEED7 Studio - Working environment

In this part the project engineering of the System MICRO CPU in the *SPEED7 Studio* is shown. Here only the basic usage of the *SPEED7 Studio* together with a System MICRO CPU is shown. Please note that software changes can not always be considered and it may thus be deviations to the description. In the *SPEED7 Studio* your PLCs may be configured and linked. For diagnostics online tools are available.




More information can be found in the online help respectively in documentation of the SPEED7 Studio.

Starting the SPEED7 Studio



- Click at the button. You can find SPEED7 Studio in Windows Start at 'VIPA'.
 - ⇒ SPEED7 Studio is started. The start page is opened.

SPEED7 Studio



- (1) Start You can create a new project, open a saved project, or delete projects.
- (2) Project If a project is open, you can open the *'Project overview'* or add a new device.
- (3) Last projects Here recently opened projects are listed.



You can repeatedly run SPEED7 Studio in order to work with different projects. You can not open the same project in the various instances of SPEED7 Studio.

SPEED7 Studio - Work environment


End SPEED7 Studio

- Select one of the following options if you want to end the program:
 - Main window: Click on the Close button of the SPEED7 Studio program window.
 - Menu bar Select 'File → Exit'.
 - Keyboard: Press [Alt] + [F4].

After you have made changes to the project, a dialogue window opens where you can select whether to save or ignore the changes.

⇒ SPEED7 Studio is ended.

12.2 SPEED7 Studio - Work environment



- (1) Menu bar
- (2) Toolbar
- (3) CPU control centre
- (4) Project tree

- (5) Area of operations
- (6) Output range
- (7) Catalog/properties
- (8) Status line

You can show and hide additional windows and the arrangement and size of the windows can be adjusted.

(1) Menu bar

Most of the commands you need for working with *SPEED7 Studio* are provided in the menu bar. Further commands can be accessed via the context menus using the right mouse button, e.g. functions of a device in the project tree.

The menu commands 'Project' and 'Device' are only shown if a project is open. The menu commands 'Image' is only shown if a HMI image is open.

SPEED7 Studio - Work environment > Project tree

You can use the menus with the mouse or the keyboard.

(2) Toolbar

Important commands you need for working with *SPEED7 Studio* are provided in the toolbar. More commands can be accessed via the toolbars and push buttons of different editors.

Some of the commands in the toolbar are only shown if a project is open.

(3) CPU control centre

In the CPU control centre, you can view the current mode and other control data and control the CPU.

(4) Project tree

Any project device and project data can be accessed via the project tree. The project tree includes any object which you have created in the project, e.g. devices, components, program blocks, HMI images. Here you can add or remove devices and components. Furthermore, you can open editors in order to edit settings, configurations, the control program and visualisation.

(5) Area of operations

Devices and project data can be edited in the area of operations. You can open different editors for this purpose. The register in the area of operations is divided into two register levels. You can switch through the editors in the area of operations via the tabs.

(6) Output range

Information on executed activities and background operations are displayed on the output range.

(7) Catalog/properties

Devices and components which you want to add to the project can be selected in the catalog. You can also select objects which you want to add to the PLC program or to HMI images.

(8) Status line

The version of *SPEED7 Studio* is displayed at the left edge of the status line. The progress bar for background operations and status messages is shown at the right edge. As long as there are no background operations, the status message created at last is shown.

12.2.1 Project tree



- (1) Title and author
- (2) Project
- (3) Documentation
- (4) PLC
- (5) Motion Control
- (6) PLC program
- (7) Local components
- (8) Field periphery
- (9) HMI

In the project tree, you can access commands in order to add or delete objects, e.g. add/delete devices or add/delete blocks.

You can open editors via the project tree if you want to edit settings, configurations, the control program and visualisation.

Moreover, you can retrieve information, e.g. project overview, device properties or properties of the bus system.

SPEED7 Studio - Work environment > Catalog

Show project tree

If the project tree is not displayed, you must select either 'View \rightarrow Project tree' or press [Strg]+[Shift]+[P].

Show projects in the project tree

In order to display the project in the project tree, you must create a new project or open a stored project.

It is not possible to edit several projects at the same time. It is possible to run *SPEED7 Studio* simultaneously several times on one PC if you want to use it for various projects.

Show/hide objects


The objects in the project tree are arranged in a tree structure. You can show or hide objects:

- Hide all objects ('Project → Reduce project tree')
- Show all objects ('Project → Expand project tree')
- Hide slave objects / close folder
- Show slave objects / open folder

Recognise object state

Icons behind an object in the project tree provide indications of the object state.

12.2.2 Catalog



- (1) Switching to another view
- (2) Register
- (3) Show/hide objects
- (4) Search
- (5) Filter
- (6) Objects
- (7) Catalog information

Devices and components which you want to add to the project can be selected in the catalog. You can also select objects which you want to add to the PLC program or to HMI images.

Show catalog:

If the catalog is not displayed, you must select either 'View \rightarrow Catalog' or press [Strg]+ [Shift]+[C].

(1) Switch to another view

If the properties are displayed instead of the catalog, you must click on 'Catalog' at the lower screen edge.

SPEED7 Studio - Work environment > Catalog

(2) Register

Certain tabs are displayed in the catalog, depending on which editor window is opened in the foreground.

(3) Show/hide objects

The objects in the catalog are arranged in a tree structure. You can show or hide objects:

Hide all objects ('Project → Reduce project tree')

Hide all objects ('Project → Reduce catalog tree')

Show all objects ('Project → Expand catalog tree')

- Hide slave objects / close folder
- Show slave objects / open folder

(4) Search

You can search for certain objects in the catalog.

- 1. Enter a search text in the input field.
 - Only those objects are displayed in the catalog which contain the search text.
- 2. Click on to delete the search text.
 - → All objects are displayed in the catalog.


★ 313 ★ Filter Active ▲ CPUs ▲ VIPA 300S ▲ CPUs 312 ▲ CPUs 313 — CPU 313-5BF13 — CPU 313-6CF13

(5) Filter

With 'enabled' Filter, only these modules are shown in the Catalog which are relevant for configuration

(6) Add object

- Drag the desired object from the catalog to a suitable position.
 - The object is added.



(7) Catalog information

The catalog information shows detailed information of the selected object, e.g. name, producer, version and order information.

12.3 SPEED7 Studio - Hardware configuration - CPU

Precondition




For project engineering a thorough knowledge of the SPEED7 Studio is required!

Proceeding

For configuration please use the SPEED7 Studio V1.9.2.

- 1. Start the SPEED7 Studio.
- 2. Create a new project in the Work area with 'New project'.
 - → A new project is created and the view 'Devices and networking' is shown.
- 3. Click in the *Project tree* at 'Add new device ...'.
 - A dialog for device selection opens.
- **4.** Select from the 'Device templates' your CPU and click at [OK].
 - ➡ The CPU is inserted in 'Devices and networking' and the 'Device configuration' is opened.





Device configuration

Slot	Module	 	
0	CPU M13-CCF0001		
-X2	MPI interface		
-X3	PG_OP_Ethernet		

12.4 SPEED7 Studio - Hardware configuration - Ethernet PG/OP channel

Overview



Please note!

- At the first commissioning respectively after a reset to factory setting the Ethernet interface has no IP address.
- For online access, you have to assign valid IP address data to it by means of "Initialization".
- After initialization, you can transfer the IP address data to your project.

The CPU has an integrated Ethernet PG/OP channel. This channel allows you to program and remote control your CPU.

- The Ethernet PG/OP channel (X3/X4) is designed as switch. This enables PG/OP communication via the connections X3 and X4.
- Configurable connections are possible.
- DHCP respectively the assignment of the network configuration with a DHCP server is supported.
- Default diagnostics addresses: 2025 ... 2040
- Via the Ethernet PG/OP channel, you have access to:
 - Device website, where you can find information on firmware status, connected peripherals, current cycle times, etc.
 - OPC UA project, which is to be created in the OPC UA Configurator.
 - WebVisu project, which is to be created in the SPEED7 Studio.
 - PROFINET IO controller or the PROFINET I-Device.

Assembly and commissioning

- 1. Install your System MICRO with your CPU.
- 2. Wire the system by connecting cables for voltage supply and signals.
- 3. Connect the one of the Ethernet jacks (X3, X4) of the Ethernet PG/OP channel to Ethernet.
- **4.** Switch on the power supply.
 - → After a short boot time the CP is ready for communication. It possibly has no IP address data and requires an initialization.

The assignment of IP address data takes place via the MAC address. The IP address of your Ethernet PG/OP channel for the interfaces X3 and X4 can be found on the front of your CPU with the name "MAC PG/OP: ...".

X3 PG/OP





X4 PG/OP





MAC PG/OP: 00-20-D5-77-05-10

The assignment of the IP address data happens online in the *SPEED7 Studio* with the following proceeding:

1. Start the SPEED7 Studio with your project.


[&]quot;Initialization"



- 2. Click in the Project tree at 'Devices and networking'.
 - You will get a graphical object view of your CPU.



- 3. ▶ Click at the network 'PG_OP_Ethernet'.
- **4.** Select 'Context menu → Determine accessible partner'.
 - A dialog window opens.



- 5. Select the according network interface card, which is connected to the Ethernet PG/OP channel and click at *'Search'* to determine the via MAC address reachable device.
 - → The network search is started and the found stations are listed in a table.

<u>6.</u>		Devices	IP	MAC	Device	
	1		172.20	00:20:	VIPA	
	2					

Click in the list at the module with the known MAC address. This can be found at the front of the CPU labelled as "MAC PG/OP: ...".

- Click at 'Set IP address'. Now set the IP configuration by entering 'IP address', 'Subnet mask' and 'Gateway'. You get valid IP address parameters from your system administrator.
- 8. Click at 'Set IP address'.
 - ➡ The IP address is transferred to the module and the list is refreshed. Directly after the assignment the Ethernet PG/OP channel is online reachable using the set IP address data. The value remains as long as it is reassigned, it is overwritten by a hardware configuration or a factory reset is executed.
- **9.** With clicking at 'Apply settings' the IP address data are stored in the project.

If you are not online, you can assign IP address data to your Ethernet PG/OP channel with following proceeding:

1. Start the SPEED7 Studio with your project.

Take IP address parameters in project

- 2. Click in the Project tree at 'Devices and networking'.
 - → You will get a graphical object view of your CPU.



- 3. Click at the network 'PG_OP_Ethernet'.
- **4.** ▶ Select 'Context menu → Interface properties'.
 - ➡ A dialog window opens. Here you can enter the IP address data for your Ethernet PG/OP channel.
- 5. Confirm with [OK].
 - → The IP address data are stored in your project listed in 'Devices and networking' at 'Local components'.

After transferring your project your CPU can be accessed via Ethernet PG/OP channel with the set IP address data.

Local components


Slot	Module	 	IP address	
0	CPU M13-CCF0001			
-X3	PG_OP_Ethernet		172.20.120.40	

Deployment I/O periphery > Overview

12.5 SPEED7 Studio - Hardware configuration - I/O modules

Hardware configuration of the modules

- 1. Device configuration.
- Starting with slot 1 place in the 'Device configuration' your System MICRO modules in the plugged sequence. For this drag from the hardware catalog the corresponding module to the corresponding position in the Device configuration.



Parametrization

For parametrization double-click in the 'Device configuration' on the module you want to parametrize. Then the parameters of the module are shown in a dialog. Here you can make your parameter settings.

Parametrization during runtime

By using the SFCs 55, 56 and 57 you may alter and transfer parameters for wanted modules during runtime. For this you have to store the module specific parameters in so called "record sets". More detailed information about the structure of the record sets is to find in the according module description.

12.6 Deployment I/O periphery

12.6.1 Overview

Project engineering and parametrization

- On this CPU the connectors for digital respectively analog signal and *Technological functions* are combined in one casing.
- Die Project engineering happens in the SPEED7 Studio as CPU M13-CCF0001.
- For parametrization of the digital I/O periphery and the *technological functions* the corresponding sub modules of the CPUM13-CCF0001 are to be used.
- The controlling of the operating modes of the *technological functions* happens by means of handling blocks of the user program.

Deployment I/O periphery > Analog input

12.6.2 Analog input

12.6.2.1 Overview

- Al 2x12Bit U, I
- Voltage measurement for encoders with 0 ... 10V
- Current measurement for encoders with 4 ... 20mA
- Sub module: 'AI2'

12.6.2.2 Parametrization in SPEED7 Studio

12.6.2.2.1 'I/O addresses'

Sub module	Input address	Access	Assignment
AI2	800	WORD	Analog input channel 0 (X6)
	802	WORD	Analog input channel 1 (X6)

12.6.2.2.2 'Channel x'

Function

This setting is only available in the *SPEED7 Studio* from V1.9.2. Select via *'Channel x'* the channel and select via "Measuring range" the according range. The following measuring ranges are supported:

- Voltage 0 ... 10V
- Current 4 ... 20mA

By default, both channels are set to voltage measurement 0 ... 10V.

Filter

The analog input part has a filter integrated. The filter uses the "moving averaging method". By specifying a time, you can determine here how many samples the mean value has to be calculated over. In during continuous measurement, the most recent sampled values are always used in "sliding" averaging. Since a sample value is recorded every 2ms, the mean value is calculated from the 50 most current sample values, e.g. with a filter time of 100ms. The default value of the filter is 1000ms. The following values can be entered:

- 2ms no filter
- 100ms small filter, mean value from the 50 most recent samples
- 1000ms medium filter, mean value from the 500 most recent samples
- 10000ms large filter, mean value from the 5000 most recent samples.

Deployment I/O periphery > Digital output

12.6.3 Digital input

12.6.3.1 Overview

- 16xDC 24V
- Sub module 'DI16/DO12'
- → 'Digital input'...page 122

12.6.3.2 Parametrization in SPEED7 Studio

12.6.3.2.1 'I/O addresses'

Sub module	Input address	Access	Assignment
DI16/DO12	136	BYTE	Digital input I+0.0 I+0.7 (X4)
	137	BYTE	Digital input I+1.0 I+1.7 (X4)

12.6.3.2.2 'Inputs'

'Trigger for process interrupt'

Here you can specify a hardware interrupt for each input in groups of 2 channels for the corresponding edge. The hardware interrupt is disabled, if nothing is selected (default setting). A diagnostics interrupt is only supported with *Hardware interrupt lost*.

Here is valid:

Rising edge: Edge 0-1Falling edge: Edge 1-0

Input delay

- The input delay can be configured per channel in groups of 4.
- An input delay of 0.1ms is only possible with "fast" inputs, which have a max. input frequency of 100kHz → 'Digital input'...page 122. Within a group, the input delay for slow inputs is limited to 0.5ms.
- Range of values: 0.1ms / 0.5ms / 3ms / 15ms

12.6.4 Digital output

12.6.4.1 Overview

- 12xDC 24V, 0.5A
- Sub module 'DI16/DO12'
- → 'Digital output'...page 126

12.6.4.2 Parametrization in SPEED7 Studio

12.6.4.2.1 'I/O addresses'

Sub module	Output address	Access	Assignment
DI16/DO12	136	BYTE	Digital output Q+0.0 Q+0.7 (X2)
	137	BYTE	Digital output Q+1.0 Q+1.3 (X6)

Deployment I/O periphery > Counter

12.6.5 Counter

12.6.5.1 Overview

4 channels

Sub module: 'Count'

■ → 'Counting'...page 128

12.6.5.2 Parametrization in SPEED7 Studio

12.6.5.2.1 'I/O addresses'

Sub module	Input address	Access	Assignment
Count	816	DINT	Channel 0: Counter value / Frequency value
	820	DINT	Channel 1: Counter value / Frequency value
	824	DINT	Channel 2: Counter value / Frequency value
	828	DINT	Channel 3: Counter value / Frequency value

12.6.5.2.2 Basic parameters

Select interrupt

Via 'Basic parameters' you can reach 'Select interrupt'. Here you can define the interrupts the CPU will trigger. The following parameters are supported:

- None: The interrupt function is disabled.
- Process: The following events of the counter can trigger a hardware interrupt (selectable via 'Count'):
 - Hardware gate opening
 - Hardware gate closing
 - On reaching the comparator
 - on Counting pulse
 - on overflow
 - on underflow
- Diagnostics+process: A diagnostics interrupt is only triggered when a hardware interrupt was lost.

12.6.5.2.3 'Channel x'

Operating mode

Select via 'Channel' the channel select via 'Operating' the counter operating mode. The following counter operating modes are supported:

- Not parametrized: Channel is de-activated
- Count endless
- Count once
- Count periodical

Counter

Operating mode

Default values and structure of this dialog box depend on the selected 'Operating mode'.

Deployment I/O periphery > Counter

Parameter overview

Operating parameters	Description	Assignment
Main count direction	 None No restriction of the counting range Up: Restricts the up-counting range. The counter starts from 0 or load value, counts in positive direction up to the declaration end value -1 and then jumps back to load value at the next positive transducer pulse. Down: Restricts the down-counting range. The counter starts from the declared start value or load value in negative direction, counts to 1 and then jumps to start value at the next negative encoder pulse. Function is disable with count continuously. 	■ None
Gate function	 Cancel count: The count starts when the gate opens and resumes at the load value when the gate opens again. Stop count: The count is interrupted when the gate closes and resumed at the last actual counter value when the gate opens again. Gate function'page 143 	Abort count process
Start value	Start value with counting direction backward.	2147483647 (231-1)
End value	End value with main counting direction forward. Range of values: 22147483647 (2 ³¹ -1)	
Comparison value	The count value is compared with the <i>comparison value</i> . See also the parameter "Characteristics of the output": No main counting direction Range of values: -2) ³¹ to +2) ³¹ -1 Main counting direction forward Range of values: -2 ³¹ to end value-1 Main counting direction backward Range of values: 1 to +2 ³¹ -1	0
Hysteresis	The <i>hysteresis</i> serves the avoidance of many toggle processes of the output, if the counter value is in the range of the <i>comparison value</i> . 0, 1: <i>Hysteresis</i> disabled	0
	Range of values: 0 to 255	

Input	Description	Assignment		
Signal evaluation	Specify the signal of the connected encoder:	Pulse/direction		
	 Pulse/direction At the input count and direction signal are connected 			
	At the input there is an encoder connected with the following evaluation:			
	 Rotary encoder single 			
	 Rotary encoder quadruple 			

Deployment I/O periphery > Counter

Input	Description	Assignment
Hardware gate	Gate control exclusively via channel 3:	disabled
	enabled: The gate control for channel 3 happens via SW and HW gate	
	disabled: The gate control for channel 3 exclusively happens via SW gate	
	→ 'Gate function'page 143	
Count direction inverted	Invert the input signal 'Direction':	disabled
	enabled: The input signal is inverteddisabled: The input signal is not inverted	

Output	Description	Assignment
Characteristics of the output	The output and the "Comparator" (STS_CMP) status bit are set, dependent on this parameter.	No comparison
	No comparison: The output is used as normal output and STS_CMP remains reset.	
	■ Comparator	
	 Counter value ≥ Comparison value 	
	 Counter value ≤ Comparison value 	
	Pulse at comparison value	
	 To adapt the used actuators you can specify a pulse duration. The output is set for the specified pulse duration when the counter value reaches the comparison value. When you've set a main counting direction the output is only set at reaching the comparison value from the main counting direction. 	
Pulse duration	Here you can specify the <i>pulse duration</i> for the output signal.	0
	The pulse duration starts with the setting of the according digital output.	
	■ The inaccuracy of the <i>pulse duration</i> is less than 1ms.	
	There is no past triggering of the pulse duration when the comparison value has been left and reached again during pulse output.	
	If the pulse duration is changed during operation, it will take effect with the next pulse.	
	■ If the <i>pulse duration</i> = 0, the output is set until the comparison condition is not longer fulfilled.	
	Range of values: 0510ms in steps of 2ms	

Frequency	Description	Assignment	
Max. counting frequency	Specify the max tion, Latch and h	. frequency for track A/pulse, track B/direc- HW gate	60kHz
	Frequency	shortest permissible count pulse	
	1kHz	400µs	
	2kHz	200µs	
	5kHz	80µs	

Deployment I/O periphery > Frequency measurement

Frequency	Description		Assignment
	10kHz	40µs	
	30kHz	13µs	
	60kHz	6.7µs	
	100kHz	4µs	

Hardware interrupt	Description	Assignment
Hardware gate opening	Hardware interrupt by edge 0-1 exclusively at HW gate channel 3	disabled
	 enabled: Process interrupt by edge 0-1 exclusively at HW gate channel 3 with open SW gate 	
	disabled: no hardware interrupt	
Hardware gate closing	Hardware interrupt by edge 1-0 exclusively at HW gate channel 3	disabled
	 enabled: Process interrupt by edge 1-0 exclusively at HW gate channel 3 with open SW gate disabled: no hardware interrupt 	
0 11	·	
On reaching comparator	Hardware interrupt on reaching comparator	disabled
	enabled: Hardware interrupt when comparator is trig- gered, can be configured via 'Characteristics of the output'	
	disabled: no hardware interrupt	
Overflow	Hardware interrupt overflow	disabled
	enabled: Hardware interrupt on overflow the upper counter limit	
	disabled: no hardware interrupt	
Underflow	Hardware interrupt on underrun	disabled
	enabled: Hardware interrupt on underflow the lower counter limit	
	disabled: no hardware interrupt	

12.6.6 Frequency measurement

12.6.6.1 Overview

- 4 channels
- Sub module 'Counter'
- → 'Frequency measurement'...page 150

Deployment I/O periphery > Frequency measurement

12.6.6.2 Parametrization in SPEED7 Studio

12.6.6.2.1 *'I/O addresses'*

Sub module	Input address	Access	Assignment
Count	816	DINT	Channel 0: Counter value / Frequency value
	820	DINT	Channel 1: Counter value / Frequency value
	824	DINT	Channel 2: Counter value / Frequency value
	828	DINT	Channel 3: Counter value / Frequency value

Sub module	Output address	Access	Assignment
Count	816	DWORD	reserved
	820	DWORD	reserved
	824	DWORD	reserved
	828	DWORD	reserved

12.6.6.2.2 Basic parameters

Select interrupt


Via 'Basic parameters' you can reach 'Select interrupt'. Here you can define the interrupts the CPU will trigger. The following parameters are supported:

- None: The interrupt function is disabled.
- Process: The following events of the frequency measurement can trigger a hardware interrupt (selectable via 'Frequency counting'):
 - End of measurement
- Diagnostics+process: A diagnostics interrupt is only triggered when a hardware interrupt was lost.

12.6.6.2.3 'Channel x:'

Operating mode

Select via 'Channel' the channel and select for frequency measurement via 'Operating mode' the operating mode 'Frequency counting'. Default values and structure of this dialog box depend on the selected 'Operating mode'. The following parameters are supported:



- 1 Integration time
- 2 Counting pulse
- 3 SW gate
- 4 Evaluated frequency

Parameter overview

Operating parameters	Description	Assignment
Integration time	Specify the integration time	100ms
	Range of values: 10ms 10000ms in steps of 1ms	

Deployment I/O periphery > Pulse width modulation - PWM

Operating parameters	Description	Assignment	
max. counting frequency	Specify the max. freq	60kHz	
	Frequency	shortest permissible count pulse	
	1kHz	400µs	
	2kHz	200µs	
	5kHz	80µs	
	10kHz	40µs	
	30kHz	13µs	
	60kHz	6.7µs	
	100kHz	4µs	

Hardware interrupt	Description	Assignment
End of measurement	Hardware interrupt at end of measurement	de-activated

12.6.7 Pulse width modulation - PWM

12.6.7.1 Overview

- Channel 0 and 1 are supported
- Sub module 'Count'
- Control by the user program via SFB 49
- → 'Pulse width modulation PWM'...page 155

12.6.7.2 Parametrization in SPEED7 Studio

12.6.7.2.1 *'I/O addresses'*

Sub module	Input address	Access	Assignment
Count	816	DINT	reserved
	820	DINT	reserved
	824	DINT	reserved
	828	DINT	reserved


Sub module	Output address	Access	Assignment
Count	816	DWORD	reserved
	820	DWORD	reserved
	824	DWORD	reserved
	828	DWORD	reserved

Deployment I/O periphery > Pulse width modulation - PWM

12.6.7.2.2 'Channel x'

Operating mode

PWM and *pulse train* output use the same hardware configuration. Switching between these modes is done within the SFB 49. Select via *'Channel x'* the channel and select for pulse width modulation via *'Operating mode'* the operating mode *'Pulse width modulation'* Default values and structure of this dialog box depend on the selected *'Operating mode'*. The following parameters are relevant for PWM, which must be specified or determined:



- 1 Period
- 2 On-delay
- 3 Pulse duration
- 4 Pulse pause

Parameter overview

Operating parameters	Description	Assignment
Output format	Here specify the range of values for the output. The CPU hereby determines the pulse duration: ■ Per mil - Output value is within 0 1000 - Pulse duration = (Output value / 1000) x Period ■ S7 Analog value: - Output value is Siemens S7 analog value 0 27648 - Pulse duration = (Output value / 27648) x Period	Per mil
Time base	Here you can set the time base, which will apply for resolution and range of values of the period duration, minimum pulse duration and on-delay. 1ms: The time base is 1ms 0.1ms: The time base is 0.1ms 1µs: The time base is 1µs	0.1ms
On-delay	Enter here a value for the time to expire from the start of the output sequence to the output of the pulse. The pulse sequence is output at the output channel, on expiration of the on-delay. Range of values: 0 65535 from this there are the following effective values: Time base 1ms: 0 65535ms Time base 0.1ms: 0 6553.5ms Time base 1µs: 0 65535µs	0
Period	With the period you define the length of the output sequence, which consists of pulse duration and pulse pause. Range of values: ■ Time base 1ms: 1 87ms ■ Time base 0.1ms: 0.4 87.0ms ■ Time base 1µs: 1 87µs	20000

Deployment I/O periphery > Pulse train

Operating parameters	Description	Assignment
Minimum pulse duration	With the minimum pulse duration you can suppress short output pulses and short pulse pauses. All pulses or pauses, which are smaller than the minimum pulse duration, are suppressed. This allows you to filter very short pulses (spikes), which can not be recognized by the periphery.	2
	Range of values:	
	■ Time base 1ms: 0 Period / 2 * 1ms	
	■ Time base 0.1ms: 2 Period / 2 * 0.1ms ■ Time base 1µs: 0 Period / 2 * 1µs	

12.6.8 Pulse train

12.6.8.1 Overview

- 2 channels
- Sub module 'Count'
- Control by the user program via SFB 49
- → 'Pulse train'...page 159

12.6.8.2 Parametrization in SPEED7 Studio

12.6.8.2.1 'I/O addresses'

Sub module	Input address	Access	Assignment
Count	816	DINT	reserved
	820	DINT	reserved
	824	DINT	reserved
	828	DINT	reserved


Sub module	Output address	Access	Assignment
Count	816	DWORD	reserved
	820	DWORD	reserved
	824	DWORD	reserved
	828	DWORD	reserved

12.6.8.2.2 'Channel x'

Operating mode

PWM and *pulse train* output use the same hardware configuration. Switching between these modes is done within the SFB 49. Select via 'Channel x' the channel and select for pulse train via 'Operating mode' the operating mode'Pulse width modulation'. Default values and structure of this dialog box depend on the selected 'Operating mode'. The following parameters are relevant for pulse train, which must be specified or determined:

Deployment I/O periphery > Pulse train



- Number of pulses Period duration
- 2 Pulse duration
- Pulse pause

Parameter overview

Operating parameters	Description	Assignment
Output format	Here specify the range of values for the output. The CPU hereby determines the pulse duration:	Per mil
	■ Per mil	
	 Output value is within 0 1000 	
	 Pulse duration = (Output value / 1000) x Period 	
	S7 Analog value:	
	 Output value is Siemens S7 analog value 0 27648 Pulse duration = (Output value / 27648) x Period 	
Time base	Here you can set the time base, which will apply for resolution and range of values of the period duration, minimum pulse duration and on-delay.	0.1ms
	■ 1ms: The time base is 1ms	
	■ 0.1ms: The time base is 0.1ms	
	■ 1µs: The time base is 1µs	
On-delay	This parameter is ignored.	0
Period	With the period you define the length of the output sequence, which consists of pulse duration and pulse pause.	50
	Range of values:	
	■ Time base 1ms: 1 87ms	
	■ Time base 0.1ms: 0.4 87.0ms	
	■ Time base 1µs: 1 87µs	

SPEED7 Studio - Project transfer > Transfer via MPI

Operating parameters	Description	Assignment
Minimum pulse duration	With the minimum pulse duration you can suppress short output pulses and short pulse pauses. All pulses or pauses, which are smaller than the minimum pulse duration, are suppressed. This allows you to filter very short pulses (spikes), which can not be recognized by the periphery.	2
	Range of values:	
	■ Time base 1ms: 0 Period / 2 * 1ms	
	■ Time base 0.1ms: 2 Period / 2 * 0.1ms	
	■ Time base 1µs: 0 Period / 2 * 1µs	

12.7 Deployment OPC UA

→ 'Deployment OPC UA'...page 172

12.8 Deployment WebVisu - Web visualization

→ 'Deployment WebVisu - Web visualization'...page 198

12.9 SPEED7 Studio - Project transfer

Overview

There are the following possibilities for project transfer into the CPU:

- Transfer via MPI
- Transfer via Ethernet
- Transfer via memory card

12.9.1 Transfer via MPI

General

For the transfer via MPI the use of the optionally available extension module EM M09 is required. The extension module provides the interface X2: MPI(PB) with fixed pin assignment. — 'Mounting'...page 17

Net structure

The structure of a MPI net is electrically identical with the structure of a PROFIBUS net. This means the same rules are valid and you use the same components for the build-up. The single participants are connected with each other via bus interface plugs and PROFIBUS cables. Per default the MPI net runs with 187.5kbaud. The CPUs are delivered with MPI address 2.


MPI programming cable

The MPI programming cables are available at Yaskawa in different variants. The cables provide a RS232 res. USB plug for the PC and a bus enabled RS485 plug for the CPU. Due to the RS485 connection you may plug the MPI programming cables directly to an already plugged plug on the RS485 jack. Every bus participant identifies itself at the bus with an unique address, in the course of the address 0 is reserved for programming devices.

Terminating resistor

A cable has to be terminated with its surge impedance. For this you switch on the terminating resistor at the first and the last participant of a network or a segment. Please make sure that the participants with the activated terminating resistors are always power supplied. Otherwise it may cause interferences on the bus.


SPEED7 Studio - Project transfer > Transfer via MPI



- MPI programming cable
- 2 Activate the terminating resistor via switch
- 3 MPI network

Proceeding transfer via MPI

- 1. Connect your PC to the MPI jack of your CPU via a MPI programming cable.
- 2. Switch-ON the power supply of your CPU and start the SPEED7 Studio with your project.
- 3. Set at 'Active PC interface' the "Serial interface".
- **4.** Click in the 'Project tree' to your project and select 'Context menu → Recompile'.
 - → Your project will be translated and prepared for transmission.



- **5.** To transfer the user program and hardware configuration click in the *Project tree* at your CPU and select *'Context menu → Transfer all'*.
 - → A dialog window for project transfer opens
- **6.** Select the 'Port type' "Serial interface" and start the transfer with 'Transfer'.
- 7. Confirm the request that the CPU is to be brought into the state STOP.
 - → The user program and the hardware configuration are transferred via MPI to the CPU.

SPEED7 Studio - Project transfer > Transfer via Ethernet


- **8.** Close after transmission the dialog.
- <u>9.</u> With 'Context menu → Copy RAM to ROM' you can save your project on a memory card, if one is plugged.

12.9.2 Transfer via Ethernet

Proceeding transfer via Ethernet

For transfer via Ethernet the CPU has an Ethernet PG/OP channel. For online access to this, you have to assign IP address parameters to this by means of "initialization" and transfer them into your project. For the transfer, connect, if not already done, the Ethernet PG/OP channel jack to your Ethernet. The connection happens via an integrated 2-port switch (X3, X4).

- **1.** Switch-ON the power supply of your CPU and start the *SPEED7 Studio* with your project.
- 2. Set at 'Active PC interface' the "Ethernet interface".
- 3. Click in the 'Project tree' to your project and select 'Context menu → Recompile'.
 - → Your project will be translated and prepared for transmission.



- **4.** To transfer the user program and hardware configuration click in the *Project tree* at your CPU and select *'Context menu → Transfer all'*.
 - → A dialog window for project transfer opens
- **5.** Select the *'Port type'* "Ethernet interface" and start the transfer with *'Transfer'*.
- **6.** Confirm the request that the CPU is to be brought into the state STOP.
 - ➡ The user program and the hardware configuration are transferred via Ethernet to the CPU.
- 7. Close after transmission the dialog.
- **8.** With 'Context menu → Copy RAM to ROM' you can save your project on a memory card, if one is plugged.

SPEED7 Studio - Project transfer > Transfer via memory card

12.9.3 Transfer via memory card

Proceeding transfer via memory card

The memory card serves as external storage medium. There may be stored several projects and sub-directories on a memory card. Please regard that your current project is stored in the root directory and has one of the following file names:

- S7PROG.WLD
- AUTOLOAD.WLD
- 1. Start the SPEED7 Studio with your project.
- 2. Click in the 'Project tree' at the CPU.
- 3. Create in the SPEED7 Studio with 'Context menu → Export device configuration (WLD)' a wld file.
 - → The wld file is created. This contains the user program and the hardware configuration
- **4.** Copy the wld file at a suited memory card. Plug this into your CPU and start it again.
 - → The transfer of the application program from the memory card into the CPU takes place depending on the file name after an overall reset or PowerON.

S7PROG.WLD is read from the memory card after overall reset.

AUTOLOAD.WLD is read from the memory card after PowerON.

The flickering of the yellow LED ______ of the status bar of the CPU marks the active transfer. Please regard that your user memory serves for enough space for your user program, otherwise your user program is not completely loaded and the red LED ______ of the status bar lights up.

TIA Portal - Work environment > Work environment of the TIA Portal

13 Configuration with TIA Portal

13.1 TIA Portal - Work environment

13.1.1 General

General


In this chapter the project engineering of the System MICRO CPU in the Siemens TIA Portal is shown. Here only the basic usage of the Siemens TIA Portal together with a System MICRO CPU is shown. Please note that software changes can not always be considered and it may thus be deviations to the description. TIA means Totally integrated Automation from Siemens. Here your PLCs may be configured and linked. For diagnostics online tools are available.

Information about the Siemens TIA Portal can be found in the online help respectively in the according online documentation.

Starting the TIA Portal

To start the Siemens TIA Portal with Windows select 'Start \rightarrow Programs \rightarrow Siemens Automation \rightarrow TIA ...'

Then the TIA Portal opens with the last settings used.



Exiting the TIA Portal

With the menu 'Project \to Exit' in the 'Project view' you may exit the TIA Portal. Here there is the possibility to save changes of your project before.

13.1.2 Work environment of the TIA Portal

Basically, the TIA Portal has the following 2 views. With the button on the left below you can switch between these views:

Portal view

The 'Portal view' provides a "task oriented" view of the tools for processing your project. Here you have direct access to the tools for a task. If necessary, a change to the Project view takes place automatically for the selected task.


Project view

The 'Project view' is a "structured" view to all constituent parts of your project.

TIA Portal - Functional limitations

Areas of the Project view

The Project view is divided into the following areas:



- 1 Menu bar with toolbars
- 2 Project tree with Details view
- 3 Project area
- 4 Device overview of the project respectively area for block programming
- 5 Properties dialog of a device (parameter) respectively information area
- 6 Hardware catalog and tools
- 7 "Task-Cards" to select hardware catalog, tasks and libraries
- 8 Jump to Portal or Project view

13.2 TIA Portal - Functional limitations

Limitation of performance data

Please note that the performance data of the System MICRO CPU is limited to the performance data of the Siemens CPU used for the configuration.

No 'Upload device as new station...'

Due to the system 'Upload device as new station...' is currently not supported. Instead, use the backup and restore functions in the Siemens TIA Portal:

- 1. ▶ To backup an online connected CPU, select 'Online → Backup from online device'.
 - → A backup object is created and stored in the project navigation at 'Online backups'. The backup contains all blocks of the project and the current device status.
- To restore into an online connected CPU it must be overall reset first. Then click in the project navigation under 'Online backups' on the created backup and select 'Context menu → Download to device'.
 - → The backup data is transferred online to the CPU.

No online blocks

Due to the system, online blocks of CPUs connected via 'Accessible devices' are currently not listed.

TIA Portal - Hardware configuration - CPU

13.3 TIA Portal - Hardware configuration - CPU

Overview

The hardware configuration of the CPU happens in the Siemens TIA Portal by means of a virtual PROFINET IO device. For the PROFINET interface is standardized software sided, the functionality is guaranteed by including a GSDML file into the Siemens TIA Portal.

The hardware configuration of the CPU is divided into the following parts:

- Installation GSDML '... MICRO PLC' for PROFINET
- Configuration Siemens CPU
- Connection '... MICRO PLC' as PROFINET IO device

Installation GSDML CPU for PROFINET

The installation of the PROFINET IO devices '... MICRO PLC' happens in the hardware catalog with the following approach:

- 1. Go to the 'Download Center' of www.yaskawa.eu.com.
- 2. Load under 'GSDML MICRO' the GSDML file V107 and up for your System MICRO.
- **3.** Extract the file into your working directory.
- **4.** Start the Siemens TIA Portal.
- **5.** Close all the projects.
- **6.** ▶ Switch to the *Project view*.
- 7. ▶ Select 'Options → Install general station description file (GSD)'.
- **8.** Navigate to your working directory and install the according GSDML file.
 - After the installation the hardware catalog is refreshed and the Siemens TIA Portal is finished.

After restarting the Siemens TIA Portal the according PROFINET IO device can be found at *Other field devices > PROFINET > IO > VIPA ... > ... Micro System*.




Thus, the Yaskawa components can be displayed, you have to deactivate the "Filter" of the hardware catalog.

Configuration CPU

With the Siemens TIA Portal, the System MICRO CPU is to be configured as CPU 314C-2 PN/DP (314-6EH04-0AB0 V3.3) from Siemens.

- 1. Start the Siemens TIA Portal.
- 2. Create a new project in the Portal view with 'Create new project'.
- 3. Switch to the *Project view*.
- **4.** Click in the *Project tree* at 'Add new device'.
- Select the following CPU in the input dialog:SIMATIC S7-300 > CPU 314C-2 PN/DP (314-6EH04-0AB0 V3.3)
 - ➡ The CPU is inserted with a profile rail.

TIA Portal - Hardware configuration - CPU



Device overview:

Module	 Slot	 Туре	
PLC	2	CPU 314C-2PN/DP	
MPI interface	2 X1	MPI/DP interface	
PROFINET inter- face	2 X2	PROFINET interface	
DI24/DO16	2 5	DI24/DO16	
AI5/AO2	2 6	AI5/AO2	
Counter	27	Counter	



- For parametrization of the digital I/O periphery and the technological functions the corresponding sub modules of the CPU 314C-2 PN/DP (314-6EH04-0AB0 V3.3) is to be used.
- The controlling of the operating modes of the technological functions happens by means of handling blocks of the user program.

Setting standard CPU parameters

Since the System MICRO CPU is configured as Siemens CPU, so the setting of the non-product specific parameters takes place via the Siemens CPU. For parametrization click in the *Project area* respectively in the *Device overview* at the CPU part. Then the parameters of the CPU part are shown in the *Properties dialog*. Here you can make your parameter settings.

'Setting standard CPU parameters'...page 79

Connection System MICRO CPU as PROFINET IO device


- 1. Switch in the *Project area* to 'Network view'.
- 2. After installing the GSDML the IO device for the CPU may be found in the hardware catalog at *Other field devices > PROFINET > IO > VIPA ... > ... MICRO PLC*. Connect the slave system to the CPU by dragging&dropping it from the hardware catalog to the *Network view* and connecting it via PROFINET to the CPU.
- 3. Click in the *Network view* at the PROFINET part of the Siemens CPU and enter at valid IP address data in *'Properties'* at *'Ethernet address'* in the area *'IP protocol'*.

TIA Portal - Hardware configuration - Ethernet PG/OP channel

4. Enter at 'PROFINET' a 'PROFINET device name'. The device name must be unique at the Ethernet subnet.



Please leave 'Send clock' at 'Advanced options → Realtime settings → IO communication' at 1ms, otherwise this leads to a configuration error!



- 5. Select in the *Network view* the IO device '... *MICRO PLC*' and switch to the *Device overview*.
 - ▶ In the *Device overview* of the PROFINET IO device '... MICRO PLC' the CPU is already placed at slot 0. From slot 1 you can place your Extension module.

Setting product specific CPU parameters

For parametrization click at the CPU at slot 0 in the *Device overview* of the PROFINET IO device '... MICRO PLC'. Then the parameters of the CPU part are shown in the *Properties dialog*. Here you can make your parameter settings. Setting product specific CPU parameters'...page 82

13.4 TIA Portal - Hardware configuration - Ethernet PG/OP channel

Overview

ñ

Please note!

- At the first commissioning respectively after a reset to factory setting the Ethernet interface has no IP address.
- For online access, you have to assign valid IP address data to it by means of "Initialization".
- After initialization, you can transfer the IP address data to your project.

TIA Portal - Hardware configuration - Ethernet PG/OP channel > Take IP address parameters in project

The CPU has an integrated Ethernet PG/OP channel. This channel allows you to program and remote control your CPU.

- The Ethernet PG/OP channel (X3/X4) is designed as switch. This enables PG/OP communication via the connections X3 and X4.
- Configurable connections are possible.
- DHCP respectively the assignment of the network configuration with a DHCP server is supported.
- Default diagnostics addresses: 2025 ... 2040
- Via the Ethernet PG/OP channel, you have access to:
 - Device website, where you can find information on firmware status, connected peripherals, current cycle times, etc.
 - OPC UA project, which is to be created in the OPC UA Configurator.
 - WebVisu project, which is to be created in the SPEED7 Studio.
 - PROFINET IO controller or the PROFINET I-Device.

Assembly and commissioning

- 1. Install your System MICRO with your CPU.
- 2. Wire the system by connecting cables for voltage supply and signals.
- **3.** Connect the one of the Ethernet jacks (X3, X4) of the Ethernet PG/OP channel to Ethernet.
- **4.** Switch on the power supply.
 - → After a short boot time the CP is ready for communication. It possibly has no IP address data and requires an initialization.

"Initialization"

The assignment of IP address data takes place via the MAC address. The IP address of your Ethernet PG/OP channel for the interfaces X3 and X4 can be found on the front of your CPU with the name "MAC PG/OP: ...".

X3 PG/OP





X4 PG/OP





MAC PG/OP: 00-20-D5-77-05-10

13.4.1 Take IP address parameters in project

2 variants for configuration

From firmware version V2.4.0 and up, you have the following options for configuring the Ethernet PG/OP channel:

- Configuration via integrated CPU interface (firmware version V2.4.0 and up only).
- Configuration via additional CP (all firmware versions).

TIA Portal - Hardware configuration - Ethernet PG/OP channel > Take IP address parameters in project

13.4.1.1 Configuration via integrated CPU interface

Proceeding

From firmware version V2.4.0 this variant for configuration is recommended. The following advantages result:

- The configuration becomes clearer, because the periphery modules and the PROFINET IO devices are configured on the PROFINET line of the CPU and no additional CP is to be configured.
- There are no address collisions, because the S7 addresses for all components are assigned from the address area of the CPU.

Unless during the hardware configuration of the CPU ~ 291 there was no IP address data assigned yet or these are to be changed, the configuration happens to the following proceeding, otherwise the Ethernet PG/OP channel is configured.

- 1. Open the Siemens TIA Portal and, if not already done, configure the Siemens CPU 314C-2 PN/DP (314-6EH04-0AB0 V3.3).
- Click in the Network view at the PROFINET part of the Siemens CPU and enter the previous assigned IP address data and subnet in 'Properties' at 'Ethernet address' in the area 'IP protocol'. The IP address data are not accepted without subnet assignment!
- 3. Transfer your project.

13.4.1.1.1 Time-of-day synchronization

NTP method

In the NTP mode (Network Time Protocol) the module sends as client time-of-day queries at regular intervals to all configured NTP servers within the sub net. You can define up to 4 NTP server. Based on the response from the servers, the most reliable and most exact time-of-day is determined. Here the time with the lowest *stratum* is used. *Stratum 0* is the time standard (atomic clock). *Stratum 1* are directly linked to this NTP server. Using the NTP method, clocks can be synchronized over subnet boundaries. The configuration of the NTP servers is carried out in the Siemens TIA Portal via the CP, which is already configured.

- 1. In the 'Device configuration', click at 'PROFINET interface' of the Siemens CPU and open the 'Properties' dialog.
- **2.** In the 'Properties', select 'Time-of-day synchronization'.
- 3. Enable the NTP method.
- **4.** Add the appropriate NTP servers by specifying their IP addresses.
- **5.** Set the *'Update interval'* you want. Within this interval, the time of the module is synchronized once.
- 6. ▶ Save and transfer your project to the CPU.
 - → After transmission, the NTP time is requested by each configured time server and the best response for the time synchronization is used.



Please note that although the time zone is evaluated, an automatic changeover from winter to summer time is not supported. Industrial systems with time-of-day synchronization should always be set in accordance to the winter time.

With the FC 61 you can determine the local time in the CPU. More information about the usage of this block may be found in the manual "SPEED7 Operation List".

TIA Portal - Hardware configuration - Ethernet PG/OP channel > Take IP address parameters in project

13.4.1.2 Configuration via additional CP

Proceeding

This is the conventional variant for configuration and is supported by all firmware versions. If possible, always use the configuration via the internal interface, otherwise the following disadvantages result:

- Address overlaps are not recognized in the Siemens TIA Portal.
- For PROFINET devices only the address range 0 ... 1023 is available.
- The addresses of the PROFINET devices are not checked with the address space of the CPU from the Siemens TIA portal for address overlaps.

The configuration happens according to the following procedure:


- 1. Open your project.
- 2. If not already done, configure in the 'Device configuration' a Siemens CPU 314C-2 PN/DP (314-6EH04-0AB0 V3.3).
- 3. As Ethernet PG/OP channel place at slot 4 the Siemens CP 343-1 (6GK7 343-1EX30 0XE0 V3.0).



CAUTION

Please configure the diagnostic addresses of the CP343-1EX30 for 'PN-IO', 'Port1' and 'Port2' so that no overlaps occur in the periphery input area. Otherwise your CPU can not start-up and you receive the diagnostic entry 0xE904. Address overlaps are not recognized in the Siemens TIA Portal.

- 4. Open the 'Property' dialog by clicking on the CP 343-1EX30 and enter for the CP at 'Properties' at 'Ethernet address' the IP address data and subnet, which you have assigned before. The IP address data are not accepted without subnet assignment!
- 5. Transfer your project.



1 Ethernet PG/OP channel

Device overview

Module	 Slot	 Туре	
PLC	2	CPU 314C-2 PN/DP	
MPI/DP interface	2 X1	MPI/DP interface	
PROFINET interface	2 X2	PROFINET interface	
CP 343-1	4	CP 343-1	

TIA Portal - Hardware configuration - I/O modules

13.4.1.2.1 Time-of-day synchronization

NTP method

In the NTP mode (**N**etwork **T**ime **P**rotocol) the module sends as client time-of-day queries at regular intervals to all configured NTP servers within the sub net. You can define up to 4 NTP server. Based on the response from the servers, the most reliable and most exact time-of-day is determined. Here the time with the lowest *stratum* is used. *Stratum 0* is the time standard (atomic clock). *Stratum 1* are directly linked to this NTP server. Using the NTP method, clocks can be synchronized over subnet boundaries. The configuration of the NTP servers is carried out in the Siemens TIA Portal via the CP, which is already configured.

- 1. In the 'Device configuration', click the CP 343-1EX30.
- 2. Click on 'PROFINET interface' in the 'Device overview'.
- 3. In the 'Properties', select 'Time-of-day synchronization'.
- **4.** Enable the NTP method by enabling 'Activate time-of-day synchronization' and selecting 'NTP' at 'Method'.
- 5. ▶ Add the appropriate NTP servers by specifying their IP addresses.
- Select your 'Time zone'. In the NTP method, UTC (Universal Time Coordinated) is generally transmitted; this corresponds to GMT (Greenwich Mean Time). By configuring the local time zone, you can set a time offset to UTC.
- **7.** Set the 'Update interval' you want. Within this interval, the time of the module is synchronized once.
- 8. Save and transfer your project to the CPU.
 - → After transmission, the NTP time is requested by each configured time server and the best response for the time synchronization is used.



Please note that although the time zone is evaluated, an automatic changeover from winter to summer time is not supported. Industrial systems with time-of-day synchronization should always be set in accordance to the winter time.


With the FC 61 you can determine the local time in the CPU. More information about the usage of this block may be found in the manual "SPEED7 Operation List".

13.5 TIA Portal - Hardware configuration - I/O modules

Hardware configuration of the modules

Starting with slot 1 place in the *Device overview* of the PROFINET IO device '... *Micro CPU*' your System Micro modules in the plugged sequence. For this drag from the hardware catalog the corresponding module to the corresponding position in the *Device overview*.

TIA Portal - Deployment PG/OP communication - PROFINET



Parametrization

To provide specific addressing of the installed peripheral modules, certain addresses must be allocated in the CPU. For parametrization click in the *Device overview* at the module you want to parametrize. Then the parameters of the module are shown in the *Properties* dialog. Here you can make your parameter settings.

13.6 TIA Portal - Deployment PG/OP communication - PROFINET



- With firmware version V2.4.0, there is a PROFINET IO controller available via the Ethernet PG/OP channel.
- As soon as you use the PROFINET functionality via the Ethernet PG/OP channel, this affects the performance and response time of your system and due to the system the cycle time of the OB 1 is extended by 2ms.

13.6.1 Deployment as PROFINET IO controller

13.6.1.1 Steps of configuration

5

Range of functions

Please regard that the PROFINET IO controller supports only the PROFINET functions, which are described in this manual, even if the Siemens CPU, which is used for configuration, offers further functions! To use some described PROFINET functions, it is necessary to deploy another Siemens CPU for configuration. Here, however, is pointed to explicitly.

The configuration of the PROFINET IO controller for PROFINET communication should be done by the following procedure:

- 1. Commissioning and Initialization (assignment IP address data)
- 2. Hardware configuration CPU
- 3. Configuration PROFINET IO controller
- 4. Configuration PROFINET IO device



With the Siemens TIA Portal, the Yaskawa CPU M13-CCF0001 is to be configured as

CPU 314C-2 PN/DP (314-6EH04-0AB0 V3.3)!

13.6.1.2 Commissioning and initialization

Assembly and commissioning

- 1. Install your System MICRO with your CPU.
- 2. Wire the system by connecting cables for voltage supply and signals
- 3. Connect your PROFINET IO controller with Ethernet.
- **4.** Switch on the power supply.
 - → After a short boot time, the CP is in idle.

At the first commissioning respectively after an overall reset of the CPU, the PROFINET IO controller has no IP address.

Assign IP address parameters

This function is supported only if the PROFINET IO controller is not yet configured. You get valid IP address parameters from your system administrator. The assignment of the IP address data happens online in the Siemens TIA Portal with the following proceeding:

- 1. Start the Siemens TIA Portal.
- 2. Switch to the 'Project view'.
- **3.** Click in the *'Project tree'* at *'Online access'* and choose here by a doubleclick your network card, which is connected to the PROFINET interface.
- **4.** To get the stations and their MAC address, use the *'Accessible device'*. This can be found at the front of the CPU labelled as "MAC ETH: ...".
- **5.** Choose from the list the module with the known MAC address and open with "Online & Diagnostics" the diagnostics dialog in the Project area.
- 6. Navigate to *Functions > Assign IP address*. Type in the IP configuration like IP address, subnet mask and gateway.

- 7. Confirm with [Assign IP configuration].
 - Directly after the assignment the PROFINET IO controller is online reachable using the set IP address data. The hardware configuration allows you to transfer the IP address data to your project. → 'TIA Portal Hardware configuration CPU'...page 291

13.6.1.3 Configuration PROFINET IO controller

13.6.1.3.1 Proceeding


Precondition

To parametrize the PROFINET IO controller of the CPU, the following conditions must be fulfilled:

- The PROFINET IO controller is online reachable, this means an initialization was established.
- The hardware configuration described before was established and the PROFINET IO controller is networked.

Proceeding

- 1. For parametrization click in the *Project area* at the CPU part.
- 2. Click on 'PROFINET interface' in the Device overview.
 - → The parameters of the PROFINET interface are listed in the properties dialog.
- <u>3.</u> Open the properties dialog of the PROFINET IO controller by a double-click at PN-IO.
 - The PROFINET interface of the PROFINET IO controller is parametrized with 'PROFINET interface ...'.
 - With 'Port_1' the port of the PROFINET interface of the PROFINET IO controller is parametrized.



Device overview

Module	 Slot	 Туре	
PLC	2	CPU 314C-2 PN/DP	
MPI/DP interface	2 X1	MPI/DP interface	
PROFINET inter- face	2 X2	PROFINET interface	

13.6.1.3.2 PROFINET interface

General

- Name
 - Here you can change the name of the interface.
- Comment
 - Here you can describe the interface in more detail.

Time-of-day synchronization

- NTP method
 - In this area you can configure time-of-day master for time-of-day synchronization in the network.

Ethernet address

- Interface networked with
 - Here you can connect the PROFINET interface to the desired subnet.
- IP protocol
 - Here you can specify the IP address, subnet mask and gateway for the PROFINET interface.
- PROFINET
 - Here you can specify a 'PROFINET device name'. On the Ethernet subnet, the 'PROFINET device name' must be unique. For an integrated PROFINET interface the 'PROFINET device name' is derived from the short description. You can change this at any time.

Operating mode

- Operating mode
 - You should not change anything here, as the settings for using the PROFINET IO controller as an I-Device are not relevant.

PROFINET interface - Advanced options

Interface Options

- Support device replacement without exchangeable medium
 - This parameter is not evaluated. With configured topology the device replacement without exchangeable medium is supported.



Please leave 'Send clock' at 'Advanced options → Realtime settings → IO communication' at 1ms, otherwise this leads to a configuration error!

PROFINET interface - Advanced options Port ...1

General

- Name
 - Here you can change the name of the port, which is also shown in the configuration table.
- Comment
 - Here you can describe the port in more detail. The comment also appears in the configuration table.

Port interconnection

These parameters serve for the port setting of the topology.

Port options

These parameters serve for the port setting. Here the following parameters are supported:

Connection

- Here you can make settings for transmission medium and type. Ensure that the setting for the local port and the partner port are identical.
- PROFINET requires 100Mbps in duplex mode.



Please regard that at activated 'Autonegotiation' the communication with a communication partner that has fixed transmission parameters always happens in 'Full-duplex' mode!

Boundaries

 Boundaries are limitations for the transfer of certain Ethernet frames. The following Boundaries are supported:

'End of detection of accessible nodes': DCP frames for detecting accessible nodes are not forwarded. When enabled, participants which are lying behind this port, are no longer recognized and can not be reached by the controller.

'End of topology discovery': When activated, this port does not support topology detection, i.e. the LLDP telegrams are not forwarded.

Diagnostic addresses

Start address

The CPU reports errors of the IO controller via the 'Start address', as soon as e.g. an error during synchronization of the IO controller occurs. This address is also used to identify the IO system to which the device belongs, if an IO device fails.

13.6.1.4 Configuration PROFINET IO device

Precondition

- The modules, which may be configured here are listed in the hardware catalog.
- For the deployment of the PROFINET IO devices you have to include the modules into the hardware catalog by means of the VIPA GSDML file.
- After the installation of the GSDML file the System MICRO PROFINET IO devices may be found in the hardware catalog at Additional field devices > PROFINET > IO > VIPA ... > ... Micro System




Thus, the System MICRO components can be shown, you have to deactivate the "Filter" of the hardware catalog.

Configure IO devices

Now the project engineering of the PROFINET IO controller is finished. Please link up now your IO devices with periphery to your IO controller.

- 1. For the project engineering of the PROFINET IO device you search the concerning PROFINET IO device in the hardware catalog at *PROFINET-IO* and drag&drop it in the subnet of your IO controller.
- 2. Assign a name to the IO device. The configured name must match the name of the device. Information about setting the device name can be found in the manual of the IO device.
- Enter a valid IP address. The IP address is normally assigned automatically by the hardware configurator. If this is not desired, you can assign the IP address manually.
- **4.** Link up the modules of your IO device in the plugged sequence and add the addresses that should be used by the modules.
- **5.** If needed, parametrize the modules.
- 6. ▶ Save, compile and transfer your project. → 'TIA Portal Project transfer'...page 314



Device overview

Module	 Slot	 Туре	
IO device	 0	 IO device	
	 0	 	
Module	 1	 Periphery modules	
	 2	 	

13.6.2 Deployment as PROFINET I-Device

13.6.2.1 Steps of configuration

Functionality



Range of functions

Please regard that the PROFINET IO controller supports only the PROFINET functions, which are described in this manual, even if the Siemens CPU, which is used for configuration, offers further functions! To use some described PROFINET functions, it is necessary to deploy another Siemens CPU for configuration. Here, however, is pointed to explicitly.

The *I-Device* (Intelligent IO device) functionality of a CPU allows data to be exchanged with an IO controller, which are preprocessed by the CPU. In this case, the I-Device is connected as an IO device to a higher-level IO controller. The process values, recorded in central or decentralized periphery, can be preprocessed via a user program and made available to the higher-level PROFINET IO controller by means of PROFINET.

- The configuration of the integrated PROFINET IO controller of the System MICRO CPU as an I-Device is made via a virtual PROFINET devices, which is to be installed by means of a product specific GSDML in the hardware catalog.
- The communication takes place via input/output areas, which are defined in the I-Device.
- The size of the areas for input and output data is max. 768byte.
- The I-Device is made available to a deterministic PROFINET IO system via a PROFINET IO interface and thus supports the real-time communication *Real-Time*.
- The I-Device functionality meets the requirements of the RT class I (A) and corresponds to the PROFINET specification version V 2.3.
- The configuration of a System MICRO PROFINET CPU as an IO controller and at the same time as an I-Device is possible. The influence of the I-Device configuration on the system limits or performance of the PROFINET controller is equated with that of a device. This means that when the IO controller and I-Device are used at the same time on the PROFINET controller, the I-Device is to be regarded as an additional device for determining the system limits.
- In order for the higher-level IO controller to communicate with the I-Device, the following must be observed:
 - The device name of the PROFINET controller of the I-Device must match the device name of the I-Device at the higher-level IO controller.
 - When using the Siemens SIMATIC Manager or the TIA Portal, in order to avoid name conflicts, I-Device and IO controller must be configured in different logical networks.



The PROFINET IO controller supports a maximum IO block size of 512 bytes (consistent).

Configuration

The configuration of the PROFINET IO controller as I-Device should be done by the following procedure:

- 1. Installation of the GSDML files
- 2. Configuration as I-Device
- 3. Configuration in the higher-level IO controller

Transfer I-Device from SPEED7 Studio

If the configuration of the *I-Device* from the *SPEED7 Studio* is to be applied to the IO controller of a third-party system, then you must export from the *SPEED7 Studio* the according GSDLM file and import it into the IO controller of the third-party system.

- 1. Start the SPEED7 Studio with your PROFINET project.
- 2. Click at the CPU in 'Devices and networking' and select 'Context menu → Create GSDML file'. Specify an 'Export path' and an unique 'Device name'.
 - → The GSDML file is created and exported. Import this GSDML file into your third-party system.

13.6.2.2 Installation of the GSDML files

The following GSDML files are required for configuring the integrated PROFINET IO controller of the System MICRO CPU as I-Device:

- GSDML for I-Device
- GSDML for I-Device at IO controller

Proceeding

The installation of the PROFINET IO device '... *Micro CPU*' happens in the hardware catalog with the following approach:

- **1.** Go to the *'Download Center'* of www.yaskawa.eu.com.
- **2.** Load under 'GSDML MICRO' the according file for your System MICRO.
- **3.** Extract the file into your working directory.
- 4. Start the Siemens TIA Portal.
- 5. Close all the projects.
- **6.** ▶ Switch to the *Project view*.
- 7. ▶ Select 'Options → Install general station description file (GSD)'.
- 8. Navigate to your working directory and install the according GSDML file.
 - → After the installation the hardware catalog is refreshed and the Siemens TIA Portal is closed.

After restarting the Siemens TIA Portal following virtual devices can be found in the Hardware catalog at 'PROFINET IO → Other field devices → VIPA ... → ... Micro System → Micro I-Device':


- PN I-Device for ... CPU
 - This allows you to configure the Input/output areas in the I-Device of the System MICRO CPU.
- PN I-Device config M13-CCF0001 for higher-level CPU
 - This allows you to connect the I-Device ... CPU to the higher-level IO controller.

 \int_{1}^{0}


Thus, the System MICRO components can be shown, you have to deactivate the "Filter" of the hardware catalog.

13.6.2.3 Configuration as I-Device


It is assumed that a hardware configuration of the CPU exists. → 'TIA Portal - Hardware configuration - CPU'...page 291




1. After installing the GSDML the 'PN I-Device for ... CPU' can be found in the hardware catalog at 'Other field devices → PROFINET IO → I/O → VIPA ... → ... Micro System → Micro I-Device'. Drag 'PN I-Device for ... CPU' from the hardware catalog to Network view.



2. To connect to the CPU, click at 'not assigned' and select the PROFINET interface of the CPU.




3. ▶ Click at the CPU and select 'Context menu → Properties'.



➡ The properties dialog of the CPU is opened.

4. Under 'Properties', click at 'PROFINET interface ... ' and navigate to 'PROFINET'. Disable 'Generate PROFINET device name automatically' and enter a name for the I-Device at 'PROFINET device name'.


Write down the PROFINET device name. This name must also be specified as the 'PROFINET device name' of the I-Device for the higher-level IO controller!



- **5.** Click in the *Network view* at the PN I-Device and switch to the *Device overview*.
- **6.** Activate the 'Filter' in the hardware catalog.
- Create the transfer areas by dragging them to the 'Slots' as I/O areas from the hardware catalog to the Device view. There must be no gaps in the slots. To create the transfer areas, the following input and output areas are available that can be assigned to the virtual I-Device:
 - Input: 1, 8, 16, 32, 64, 128, 256, 512 byte
 - Output: 1, 8, 16, 32, 64, 128, 256, 512 byte

The data direction for *Input* or *Output* refers to the view of the I-Device.

- Input areas define data that are sent from the higher-level IO controller to the I-Device and which are mapped to the input address area of the CPU.
- Output areas define data that are sent to the higher-level IO controller and which are to stored in the output address area of the CPU.



8. Save and transfer your project to the CPU.


13.6.2.4 Configuration in the higher-level IO controller

It is assumed that a CPU with the higher-level IO controller, such as a Siemens CPU 1516-3 PN/DP with IP address is configured. The IP address must be in the same IP circuit as the IP address of the I-Device.


- 1. Open the project of the CPU with the higher-level IO controller.
- **2.** For the project engineering of I-Device in the higher-level IO controller you have to search the device 'PN I-Device M13-CCF0001 for higher-level CPU' in the hardware catalog at PROFINET-IO and drag&drop it in the Network view.



3. To connect to the CPU, click at 'not assigned' and select the PROFINET interface of the CPU.



4. ▶ Click at 'PN-I-Device' and select 'Context menu → Properties'.




- → The properties dialog of the CPU is opened.
- 5. Under 'Properties', click at 'PROFINET interface ... ' and navigate to 'PROFINET'. Disable 'Generate PROFINET device name automatically' and enter at 'PROFINET device name' the previously noted name of the I-Device.




The 'PROFINET device name' must match 'PROFINET device name' of the I-Device CPU, which you have written down before!

→ 'Configuration as I-Device'...page 306

TIA Portal - Option: Deployment PROFIBUS communication > Fast introduction



- 6. Configure an input area of the same size for each output area of the I-Device in the IO controller and vice versa. Here also no gaps may arise. In particular, make sure that the order of the transfer areas matches that of the I-Device configuration. The following transfer units are available:
 - Input: 1, 8, 16, 32, 64, 128, 256, 512 byte per slot
 - Output: 1, 8, 16, 32, 64, 128, 256, 512 byte per slot



- 7. Save and transfer your project to the CPU.
 - → Your PROFINET CPU is now connected as an I-Device to the higher-level PROFINET IO controller.

9

I-Device with S7 routing



S7 routing is not possible with the procedure above. S7 routing is only possible if the I-Device and the higher-level I/O controller are configured in the same network. The device names must not be identical. By using identical names and extending the name of the I-Device with "-x", this is detected internally and used appropriately for S7 routing.

13.7 TIA Portal - Option: Deployment PROFIBUS communication

13.7.1 Fast introduction

Overview

For the PROFIBUS communication the use of the optionally available extension module EM M09 is required. The extension module provides interface X2: MPI(PB) with fixed pin assignment.

'Mounting'...page 17 The PROFIBUS DP slave is to be configured in the Project view from Siemens. Here the configuration happens by the sub module X1 (MPI/DP) of the Siemens CPU.

TIA Portal - Option: Deployment PROFIBUS communication > PROFIBUS communication via extension module EM M09



Enable bus functionality via VSC

To switch the interface X2 MPI(PB) to PROFIBUS functionality you have to activate the according bus functionality by means of a Yaskawa VSC storage media. By plugging the VSC storage card and then an overall reset the according functionality is activated. → 'Deployment storage media - VSD, VSC'…page 108

Steps of configuration

The configuration of the PROFIBUS DP slave should be done with the following approach:

- Activating bus functionality by means of a VSC
- Hardware configuration CPU
- Use as DP slave
 - With activating the bus functionality 'PROFIBUS DP slave' by means of a VSC, the bus functionality 'PROFIBUS DP slave' is unlocked.
- Transfer of the entire project to the CPU



With the Siemens TIA Portal, the Yaskawa CPU M13-CCF0001 is to be configured as

CPU 314C-2 PN/DP (314-6EH04-0AB0 V3.3)

The PROFIBUS DP slave is to be configured and connected via the sub module X1 (MPI/DP).

13.7.2 PROFIBUS communication via extension module EM M09

X2 MPI(PB)



9pin SubD jack: (isolated)

The interface supports the following functionalities, which are switch able by an hardware configuration:

- MPI (default / after overall reset)
 - The MPI interface serves for the connection between programming unit and CPU. By means of this the project engineering and programming happens. In addition MPI serves for communication between several CPUs or between HMIs and CPU. Standard setting is MPI address 2.
- PROFIBUS DP slave (option)

The PROFIBUS slave functionality of this interface can be activated by configuring the sub module 'MPI/DP' of the CPU in the hardware configuration.

TIA Portal - Option: Deployment PROFIBUS communication > PROFIBUS communication via extension module EM M09

The activation of the PROFIBUS functionality of the extension module EM M09 happens

Enable PROFIBUS functionality



with the following proceeding:

1. Turn off the power supply.



2. ▶ Mount the extension module. → 'Mounting'...page 17



- **3.** Switch on the power supply.
 - → After a short boot time the interface X2 MPI(PB) is ready for MPI communication with the MPI address 2.


9

Enable bus functionality via VSC


To switch the interface X2 MPI(PB) to PROFIBUS functionality you have to activate the according bus functionality by means of a Yaskawa VSC storage media. By plugging the VSC storage card and then an overall reset the according functionality is activated.

→ 'Deployment storage media - VSD, VSC'...page 108

X2 MPI(PB)



- ① n. c. ② n. c.
- 3 RxD/TxD-P (line B)
- 8 RxD/TxD-N (line A)



- 1 RS485 interface
- 2 Periphery



Never connect the cable shield and the M5V (pin 5) together, since the interfaces could be destroyed!

TIA Portal - Option: Deployment PROFIBUS communication > Deployment as PROFIBUS DP slave

Status indication



X2 MPI(PB)	Description
DE	
green	 Slave is in DE (data exchange). Slave exchanges data with the master. Slave is in RUN state
green blinking	Slave CPU is in state start-up.Slave-CPU is without master.
	There is no power supply.Slave has no configuration.

13.7.3 Hardware configuration - CPU

Perform a hardware configuration for the CPU. → 'TIA Portal - Hardware configuration - CPU'...page 291

13.7.4 Deployment as PROFIBUS DP slave

Fast introduction

In the following the deployment of the PROFIBUS section as "intelligent" DP slave on master system is described, which exclusively may be configured in the Siemens TIA Portal. The following steps are required:

- 1. Configure a station with a CPU with operating mode DP slave.
- 2. Connect to PROFIBUS and configure the in-/output area for the slave section.
- 3. Save and compile your project.
- **4.** Configure another station with another CPU with operating mode DP master.
- 5. Connect to PROFIBUS and configure the in-/output ranges for the master section.
- **6.** ▶ Save, compile and transfer your project to your CPU.

Configuration of the master part

- 1. Start the Siemens TIA Portal and configure a CPU.
- 2. Designate the station as "... DP master".
- **3.** Integrate the modules according to the hardware configuration of the master system.
- **4.** Select the PROFIBUS interface of the master CPU and select 'Context menu → Properties'.
 - ➡ The 'Properties' dialog is shown.
- 5. ▶ Set at *interface*: Type "PROFIBUS".
- **6.** Connect to PROFIBUS and preset an address (e.g. 2).
- 7. Switch at Operating mode to "DP master".


Configuration of the slave part

- 1. ▶ Configure a Siemens CPU 314C-2 PN/DP (314-6EH04-0AB0 V3.3) as another CPU

 → 'TIA Portal Hardware configuration CPU'...page 291
- 2. Designate the station as "... DP slave".
- 3. Integrate your modules according to your hardware configuration.
- **4.** Select the PROFIBUS interface of your CPU and select 'Context menu → Properties'.
 - → The 'Properties' dialog is shown.
- 5. Set at interface: Type "PROFIBUS".
- **6.** Connect to PROFIBUS and preset an address (e.g. 3).

TIA Portal - Include Controls Library

- 7. Switch at 'Operating mode' to "DP slave".
- **8.** Under 'Assigned DP master', select your master system.
- **9.** Use *'Transfer area'* to define the I/O address areas of the slave CPU that are to be assigned to the DP slave.
- **10.** Save, translate and transfer the respective project into the corresponding master or slave CPU.



13.8 Deployment OPC UA

→ 'Deployment OPC UA'...page 172

13.9 TIA Portal - Include Controls Library

Overview

- The product specific blocks can be found at www.yaskawa.eu.com in the 'Download Center' under 'Controls Library' as library download file.
- The library is available as packed zip file for the corresponding TIA Portal version.
- As soon as you want to use product specific blocks you have to import them into your project.

Execute the following steps:

- Load an unzip the file ...TIA_Vxx.zip (note TIA Portal version)
- Open library and transfer blocks into the project

Unzip ...TIA_Vxx.zip


Start your un-zip application with a double click on the file TIA_Vxx.zip and copy all the files and folders in a work directory for the Siemens TIA Portal.

Open library and transfer blocks into the project

- 1. Start the Siemens TIA Portal with your project.
- **2.** Switch to the *Project view*.
- **3.** Choose "Libraries" from the task cards on the right side.
- 4. Click at "Global libraries".
- 5. Click at "Open global libraries".

TIA Portal - Project transfer > Transfer via Ethernet

6. ▶ Navigate to your directory and load the file ...TIA.alxx.



Copy the necessary blocks from the library into the "Program blocks" of the *Project tree* of your project. Now you have access to the product specific blocks via your user application.

13.10 TIA Portal - Project transfer

Overview

There are the following possibilities for project transfer into the CPU:

- Transfer via Ethernet
- Transfer via memory card
- Option: Transfer via MPI

13.10.1 Transfer via Ethernet

Transfer via Ethernet

For transfer via Ethernet the CPU has the following interface:

X3/X4: Ethernet PG/OP channel via an integrated 2-port switch

Initialization

So that you may the according Ethernet interface, you have to assign IP address parameters by means of the "initialization".

'TIA Portal - Hardware configuration - Ethernet PG/OP channel'...page 293

Please consider to use the same IP address data in your project for the CP 343-1.

Transfer

- 1. For the transfer, connect, if not already done, the appropriate Ethernet jack to your Ethernet.
- **2.** Open your project with the Siemens TIA Portal.
- **3.** Click in the *Project tree* at *Online access* and choose here by a double-click your network card, which is connected to the Ethernet PG/OP interface.
- **4.** Select in the *Project tree* your CPU and click at [Go online].
- 5. Set the access path by selecting "PN/IE" as type of interface, your network card and the according subnet. Then a net scan is established and the corresponding station is listed.
- **6.** ▶ Establish with [Connect] a connection.

TIA Portal - Project transfer > Option: Transfer via MPI

- 7. ▶ Click to 'Online → Download to device'.
 - ➡ The according block is compiled and by a request transferred to the target device. Provided that no new hardware configuration is transferred to the CPU, the entered Ethernet connection is permanently stored in the project as transfer channel.

13.10.2 Transfer via memory card

Proceeding

The memory card serves as external storage medium. There may be stored several projects and sub-directories on a memory card. Please regard that your current project is stored in the root directory and has one of the following file names:

- S7PROG.WLD
- AUTOLOAD.WLD
- 1. Start the Siemens TIA Portal with your project.
- **2.** Create a wld file with 'Project \rightarrow Memory card file \rightarrow New'.
 - ➡ The wld file is shown in the Project tree at "SIMATIC Card Reader" as "Memory card file".
- **3.** Copy the blocks from the *Program blocks* to the wld file. Here the hardware configuration data are automatically copied to the wld file as "System data".
- **4.** Copy the wld file at a suited memory card. Plug this into your CPU and start it again.
 - ➡ The transfer of the application program from the memory card into the CPU takes place depending on the file name after an overall reset or PowerON.

S7PROG.WLD is read from the memory card after overall reset.

AUTOLOAD.WLD is read from the memory card after PowerON.

The flickering of the yellow LED ______ of the status bar of the CPU marks the active transfer. Please regard that your user memory serves for enough space for your user program, otherwise your user program is not completely loaded and the red LED ______ of the status bar lights up.

13.10.3 Option: Transfer via MPI

General

For the transfer via MPI the use of the optionally available extension module EM M09 is required. The extension module provides the interface X2: MPI(PB) with fixed pin assignment.

'Mounting'...page 17


Net structure

The structure of a MPI net is electrically identical with the structure of a PROFIBUS net. This means the same rules are valid and you use the same components for the build-up. The single participants are connected with each other via bus interface plugs and PROFIBUS cables. Per default the MPI net runs with 187.5kbaud. The CPUs are delivered with MPI address 2.

Terminating resistor

A cable has to be terminated with its surge impedance. For this you switch on the terminating resistor at the first and the last participant of a network or a segment. Please make sure that the participants with the activated terminating resistors are always power supplied. Otherwise it may cause interferences on the bus.

TIA Portal - Project transfer > Option: Transfer via MPI



- MPI programming cable
- 2 Activate the terminating resistor via switch
- MPI network

Proceeding enabling the interface







A hardware configuration to enable the MPI interface is not necessary. By installing the extension module EM M09 the MPI interface is enabled.

- 1. Turn off the power supply.
- 2. ▶ Mount the extension module. → 'Mounting'...page 17
- 3. Switch on the power supply.
 - → After a short boot time the interface X2 MPI(PB) is ready for MPI communication with the MPI address 2.

Proceeding transfer via MPI interface

Currently the Yaskawa programming cables for transfer via MPI are not supported. This is only possible with the programming cable from Siemens. The cables provide a RS232 res. USB plug for the PC and a bus enabled RS485 plug for the CPU. Due to the RS485 connection you may plug the MPI programming cables directly to an already plugged plug on the RS485 jack. Every bus participant identifies itself at the bus with an unique address, in the course of the address 0 is reserved for programming devices.

- 1. Establish a connection to your extension module via MPI with an appropriate programming cable. Information may be found in the corresponding documentation of the programming cable.
- 2. Start the Siemens TIA Portal with your project.
- Select in the *Project tree* your CPU and choose 'Context menu → Download to device → Hardware configuration' to transfer the hardware configuration.
- **4.** ▶ To transfer the PLC program choose 'Context menu → Download to device → Software'. Due to the system you have to transfer hardware configuration and PLC program separately.



System MICRO Content

Content

Α	System specific event IDs	321
В	Integrated blocks	374
С	SSL partial list	377

Content System MICRO

A System specific event IDs

Event IDs

→ 'Diagnostic entries'...page 114

Ox15C Manufacture interrupt (OB 57) for EtherCAT OB: OB number ZINFO1: Input / Output address ZINFO2: Interrupt type 0: Reserved 1: Diagnostic interrupt (incoming) 2: Process interrupt 4: Plug interrupt 4: Plug interrupt 5: Status interrupt 6: Update interrupt 7: Redundancy interrupt 8: Controlled by the supervisor 9: Enabled 10: Wrong sub module plugged 11: Recovery of the sub module 12: Diagnostic interrupt (outgoing) 13: Cross traffic connection message 14: Neighbourhood change message 15: Synchronisation message (bus) 16: Synchronisation message (device) 17: Network component message 18: Clock synchronisation message (bus) 31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output DatID: Output DatID: Output ElimFO3: Logical address of the IO system ZINFO1: Logical address of the Virtual device	Event ID	Description
ZINFO1: Input / Output address ZINFO2: Interrupt type 0: Reserved 1: Diagnostic interrupt (incoming) 2: Process interrupt 3: Pull interrupt 4: Plug interrupt 5: Status interrupt 6: Update interrupt 7: Redundancy interrupt 8: Controlled by the supervisor 9: Enabled 10: Wrong sub module plugged 11: Recovery of the sub module 12: Diagnostic interrupt (outgoing) 13: Cross traffic connection message 14: Neighbourhood change message 15: Synchronisation message (bus) 16: Synchronisation message (device) 17: Network component message 18: Clock synchronisation message (bus) 31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt max. ZINFO3: CoE error code DattD: Input DattD: Output 0x38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system	0x115C	Manufacture interrupt (OB 57) for EtherCAT
ZINFO2: Interrupt type 0: Reserved 1: Diagnostic interrupt (incoming) 2: Process interrupt 3: Pull interrupt 4: Plug interrupt 5: Status interrupt 6: Update interrupt 7: Redundancy interrupt 8: Controlled by the supervisor 9: Enabled 10: Wrong sub module plugged 11: Recovery of the sub module 12: Diagnostic interrupt (outgoing) 13: Cross traffic connection message 14: Neighbourhood change message 15: Synchronisation message (bus) 16: Synchronisation message (device) 17: Network component message 18: Clock synchronisation message (bus) 31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt train. 33: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output DatID: Output Discount of the IO system ZINFO1: Logical address of the IO system		OB: OB number
0: Reserved 1: Diagnostic interrupt (incoming) 2: Process interrupt 3: Pull interrupt 4: Plug interrupt 5: Status interrupt 6: Update interrupt 7: Redundancy interrupt 8: Controlled by the supervisor 9: Enabled 10: Wrong sub module plugged 11: Recovery of the sub module 12: Diagnostic interrupt (outgoing) 13: Cross traffic connection message 14: Neighbourhood change message 15: Synchronisation message (bus) 16: Synchronisation message (device) 17: Network component message 18: Clock synchronisation message (bus) 31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt topology change 127: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output 0x38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		ZINFO1: Input / Output address
1: Diagnostic interrupt 2: Process interrupt 3: Pull interrupt 4: Plug interrupt 5: Status interrupt 6: Update interrupt 7: Redundancy interrupt 8: Controlled by the supervisor 9: Enabled 10: Wrong sub module plugged 11: Recovery of the sub module 12: Diagnostic interrupt (outgoing) 13: Cross traffic connection message 14: Neighbourhood change message 15: Synchronisation message (bus) 16: Synchronisation message (device) 17: Network component message 18: Clock synchronisation message (bus) 31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt topology change 127: Vendor-specific interrupt max. ZINFO3: CoE error code DatlD: Input DatlD: Output 0x38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		ZINFO2: Interrupt type
2: Process interrupt 3: Pull interrupt 4: Plug interrupt 5: Status interrupt 6: Update interrupt 7: Redundancy interrupt 8: Controlled by the supervisor 9: Enabled 10: Wrong sub module plugged 11: Recovery of the sub module 12: Diagnostic interrupt (outgoing) 13: Cross traffic connection message 14: Neighbourhood change message 15: Synchronisation message (bus) 16: Synchronisation message (bus) 16: Synchronisation message (bus) 31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt min. 33: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output 0x38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		0: Reserved
3: Pull interrupt 4: Plug interrupt 5: Status interrupt 6: Update interrupt 7: Redundancy interrupt 8: Controlled by the supervisor 9: Enabled 10: Wrong sub module plugged 11: Recovery of the sub module 12: Diagnostic interrupt (outgoing) 13: Cross traffic connection message 14: Neighbourhood change message 15: Synchronisation message (bus) 16: Synchronisation message (bus) 17: Network component message 18: Clock synchronisation message (bus) 31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt topology change 127: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output 0x38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		1: Diagnostic interrupt (incoming)
4: Plug interrupt 5: Status interrupt 6: Update interrupt 7: Redundancy interrupt 8: Controlled by the supervisor 9: Enabled 10: Wrong sub module plugged 11: Recovery of the sub module 12: Diagnostic interrupt (outgoing) 13: Cross traffic connection message 14: Neighbourhood change message 15: Synchronisation message (bus) 16: Synchronisation message (device) 17: Network component message (bus) 31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output 0x38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		2: Process interrupt
5: Status interrupt 6: Update interrupt 7: Redundancy interrupt 8: Controlled by the supervisor 9: Enabled 10: Wrong sub module plugged 11: Recovery of the sub module 12: Diagnostic interrupt (outgoing) 13: Cross traffic connection message 14: Neighbourhood change message 15: Synchronisation message (bus) 16: Synchronisation message (device) 17: Network component message (bus) 31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output 0x38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		3: Pull interrupt
6: Update interrupt 7: Redundancy interrupt 8: Controlled by the supervisor 9: Enabled 10: Wrong sub module plugged 11: Recovery of the sub module 12: Diagnostic interrupt (outgoing) 13: Cross traffic connection message 14: Neighbourhood change message 15: Synchronisation message (bus) 16: Synchronisation message (device) 17: Network component message 18: Clock synchronisation message (bus) 31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt max. ZINFO3: CoE error code DattD: Input DattD: Output 0x38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		4: Plug interrupt
7: Redundancy interrupt 8: Controlled by the supervisor 9: Enabled 10: Wrong sub module plugged 11: Recovery of the sub module 12: Diagnostic interrupt (outgoing) 13: Cross traffic connection message 14: Neighbourhood change message 15: Synchronisation message (bus) 16: Synchronisation message (device) 17: Network component message 18: Clock synchronisation message (bus) 31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt topology change 127: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output Ox38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		5: Status interrupt
8: Controlled by the supervisor 9: Enabled 10: Wrong sub module plugged 11: Recovery of the sub module 12: Diagnostic interrupt (outgoing) 13: Cross traffic connection message 14: Neighbourhood change message 15: Synchronisation message (bus) 16: Synchronisation message (device) 17: Network component message 18: Clock synchronisation message (bus) 31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt topology change 127: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output 0x38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		6: Update interrupt
9: Enabled 10: Wrong sub module plugged 11: Recovery of the sub module 12: Diagnostic interrupt (outgoing) 13: Cross traffic connection message 14: Neighbourhood change message 15: Synchronisation message (bus) 16: Synchronisation message (device) 17: Network component message 18: Clock synchronisation message (bus) 31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt topology change 127: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output 0x38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		7: Redundancy interrupt
10: Wrong sub module plugged 11: Recovery of the sub module 12: Diagnostic interrupt (outgoing) 13: Cross traffic connection message 14: Neighbourhood change message 15: Synchronisation message (bus) 16: Synchronisation message (device) 17: Network component message 18: Clock synchronisation message (bus) 31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt topology change 127: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output Ox38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		8: Controlled by the supervisor
11: Recovery of the sub module 12: Diagnostic interrupt (outgoing) 13: Cross traffic connection message 14: Neighbourhood change message 15: Synchronisation message (bus) 16: Synchronisation message (device) 17: Network component message 18: Clock synchronisation message (bus) 31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt topology change 127: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output 0x38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		9: Enabled
12: Diagnostic interrupt (outgoing) 13: Cross traffic connection message 14: Neighbourhood change message 15: Synchronisation message (bus) 16: Synchronisation message (device) 17: Network component message 18: Clock synchronisation message (bus) 31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt topology change 127: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output 0x38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		10: Wrong sub module plugged
13: Cross traffic connection message 14: Neighbourhood change message 15: Synchronisation message (bus) 16: Synchronisation message (device) 17: Network component message 18: Clock synchronisation message (bus) 31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt topology change 127: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output 0x38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		11: Recovery of the sub module
14: Neighbourhood change message 15: Synchronisation message (bus) 16: Synchronisation message (device) 17: Network component message 18: Clock synchronisation message (bus) 31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt topology change 127: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output 0x38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		12: Diagnostic interrupt (outgoing)
15: Synchronisation message (bus) 16: Synchronisation message (device) 17: Network component message 18: Clock synchronisation message (bus) 31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt topology change 127: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output 0x38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		13: Cross traffic connection message
16: Synchronisation message (device) 17: Network component message 18: Clock synchronisation message (bus) 31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt topology change 127: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output 0x38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		14: Neighbourhood change message
17: Network component message 18: Clock synchronisation message (bus) 31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt topology change 127: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output DatID: Output 0: OB PK: Priority class ZINFO1: Logical address of the IO system		15: Synchronisation message (bus)
18: Clock synchronisation message (bus) 31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt topology change 127: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output DatID: Output 0: OB PK: Priority class ZINFO1: Logical address of the IO system		16: Synchronisation message (device)
31: Pull interrupt component 32: Vendor-specific interrupt min. 33: Vendor-specific interrupt topology change 127: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output DatID: Output 0: OB PK: Priority class ZINFO1: Logical address of the IO system		17: Network component message
32: Vendor-specific interrupt min. 33: Vendor-specific interrupt topology change 127: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output 0x38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		18: Clock synchronisation message (bus)
33: Vendor-specific interrupt topology change 127: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		31: Pull interrupt component
127: Vendor-specific interrupt max. ZINFO3: CoE error code DatID: Input DatID: Output 0x38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		32: Vendor-specific interrupt min.
ZINFO3: CoE error code DatID: Input DatID: Output 0x38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		33: Vendor-specific interrupt topology change
DatID: Input DatID: Output 0x38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		127: Vendor-specific interrupt max.
DatID: Output 0x38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		ZINFO3: CoE error code
0x38D0 Bus recovery 0: OB PK: Priority class ZINFO1: Logical address of the IO system		DatID: Input
0: OB PK: Priority class ZINFO1: Logical address of the IO system		DatID: Output
PK: Priority class ZINFO1: Logical address of the IO system	0x38D0	Bus recovery
ZINFO1: Logical address of the IO system		0: OB
		PK: Priority class
ZINFO2: Logical address of the virtual device		ZINFO1: Logical address of the IO system
		ZINFO2: Logical address of the virtual device

Event ID	Description
	ZINFO3 - Position 0: Station number
	ZINFO3 - Position 11: IO system ID
	ZINFO3 - Bit 15: System ID DP/PN
0x38D1	Bus recovery, but expected configuration does not match actual configuration
	0: OB
	PK: Priority class
	ZINFO1: Logical address of the IO system
	ZINFO2: Logical address of the virtual device
	ZINFO3 - Position 0: Station number
	ZINFO3 - Position 11: IO system ID
	ZINFO3 - Bit 15: System ID DP/PN
0x39D0	Bus failure
	OB: OB number
	PK: Priority class
	ZINFO1: Logical address of the IO system
	ZINFO2: Logical address of the virtual device
	ZINFO3 - Position 0: Station number
	ZINFO3 - Position 11: IO system ID
	ZINFO3 - Bit 15: System ID DP/PN
0x454B	STOP: Maximum number of time-outs of a synchronous OB reached
	OB: CPU mode
	PK:
	ZINFO1: ZInfo1
	ZINFO2: ZInfo2
	ZINFO3: ZInfo3
	DatID: Block type
0x49CA	PROFINET IO system failure (Watchdog)
	0: OB
	1: Cyclic program (OB 1)
	16: Time of day interrupt OB (OB 16)
	17: Time of day interrupt OB (OB 17)
	32: Cyclic interrupt OB (OB 32)
	33: Cyclic interrupt OB (OB 33)
	34: Cyclic interrupt OB (OB 34)
	35: Cyclic interrupt OB (OB 35)
	36: Cyclic interrupt OB (OB 36)
	37: Cyclic interrupt OB (OB 37)
	38: Cyclic interrupt OB (OB 38)

Event ID	Description
	64: Synchronous cycle interrupt (OB 64)
	65: Synchronous technology interrupt (OB 65)
	80: Time error OB (OB 80)
	81: Power supply error OB (OB 81)
	82: Diagnostic interrupt OB (OB 82)
	83: Plug/Pull OB (OB 83)
	85: Program sequence error OB (OB 85)
	86: Component rack failure OB (OB 86)
	PK: Priority class
	ZINFO1: Logical address of the IO system
	ZINFO2: Interrupt reason
	0: Unknown
	1: Alarm overflow
	2: Message box overflow
	3: Cyclic data not in bus cycle
	4: Application bus cycle error
	5: Watchdog
	6: Error handler
	7: Time-out when receiving cyclic data
	8: No not-IO-task available
	ZINFO3 - Position 0: Station number
	ZINFO3 - Position 11: IO system ID
	ZINFO3 - Bit 15: System ID DP/PN
0xE003	Error in access to periphery
	ZINFO1: Transfer type
	ZINFO2: Periphery address
	ZINFO3: Slot
0xE004	Multiple configuration of a periphery address
	ZINFO1: Periphery address
	ZINFO2: Slot
0xE005	Internal error - Please contact the hotline!
	ZINFO1: Not user relevant
	ZINFO2: Not user relevant
	ZINFO3: Not user relevant
0xE007	Configured input/output bytes do not fit in the periphery area
0xE008	Internal error - Please contact the hotline!
0xE009	Error on accessing the standard backplane bus
0xE010	Non-defined component recognised at the standard backplane bus

0xE011 M 0xE012 E 0xE013 E	ZINFO2: Slot ZINFO3: Type identifier Master project engineering at slave CPU not possible or wrong slave configuration Error at configuration standard backplane bus Error at shift register access to standard backplane bus digital modules Error in Check Sys
0xE011	Master project engineering at slave CPU not possible or wrong slave configuration Error at configuration standard backplane bus Error at shift register access to standard backplane bus digital modules
0xE012 E	Error at configuration standard backplane bus Error at shift register access to standard backplane bus digital modules
0xE013	Error at shift register access to standard backplane bus digital modules
0xF014 F	Error in Check_Sys
ONEO I I	
0xE015	Error in access to master
Z	ZINFO2: Slot of the master
Z	ZINFO2: Page frame master
0xE016	Maximum block size exceeded in master transfer
Z	ZINFO1: Periphery address
Z	ZINFO2: Slot
0xE017	Error in access to integrated slave
0xE018	Error in mapping the master periphery
0xE019	Error on standard backplane bus system detection
0xE01A E	Error at detection of the operating mode (8/9 bit)
0xE01B	Error: Maximum number of plug-in components exceeded
0xE020 E	Error: Interrupt information undefined
Z	ZINFO1: Rack/Slot
Z	ZINFO3: Error type
4	4: Rack/Slot (in ZINFO1) undefined
5	5: Alarm type (in DatID) undefined
C	DatID: Interrupt type
0xE030	Error of the standard backplane bus
0xE033	nternal error - Please contact the hotline!
0xE0B0 S	SPEED7 is not stoppable
Z	ZINFO1: Not user relevant
Z	ZINFO2: Not user relevant
Z	ZINFO3: Not user relevant
C	DatID: Not user relevant
0xE0C0	Not enough memory space in the working memory for code block (block too large)
0xE0CB	Error on SSL access
Z	ZINFO1: Error
4	4: SSL wrong
5	5: Sub-SSL wrong
6	6: Index wrong
Z	ZINFO2: SZL-ID
Z	ZINFO3: Index

Event ID	Description
0xE0CC	Communication error
	ZINFO1: Error code
	1: Wrong priority
	2: Buffer overrun
	3: Telegram format error
	4: Wrong SSL request (SSL-ID invalid)
	5: Wrong SSL request (SSL-Sub-ID invalid)
	6: Wrong SSL request (SSL-Index invalid)
	7: Wrong value
	8: Wrong return value
	9: Wrong SAP
	10: Wrong connection type
	11: Wrong sequence number
	12: Faulty block number in the telegram
	13: Faulty block type in the telegram
	14: Inactive function
	15: Wrong size in the telegram
	20: Error in writing on MMC
	90: Faulty buffer size
	98: Unknown error
	99: Internal error
0xE0CD	Error at DP-V1 job management
	ZINFO1: Not user relevant
	ZINFO2: Not user relevant
	ZINFO3: Not user relevant
	DatID: Not user relevant
0xE0CE	Error: Time out when sending I-Slave diagnostics
0xE100	Memory card access error
0xE101	Memory card error file system
0xE102	Memory card error FAT
0xE104	Memory card error at saving
	ZINFO3: Not user relevant
0xE200	Memory card writing finished (Copy Ram2Rom)
	OB: Not user relevant
	PK: Not user relevant
0xE210	Memory card reading finished (reload after memory reset)
	OB: Not user relevant
	PK: Not user relevant

Event ID	Description
	ZINFO1 - Position 0: Not user relevant
0xE21D	Memory card reading: Error on reload (after memory reset), error in the block header
	ZINFO1: Block type
	56: OB
	65: DB
	66: SDB
	67: FC
	68: SFC
	69: FB
	70: SFB
	97: VDB
	98: VSDB
	99: VFC
	100: VSFC
	101: VFB
	102: VSFB
	111: VOB
	ZINFO2: Block number
	ZINFO3: Block length
0xE21E	Memory card reading: Error in recharging (after memory reset), "Protect.wld" file too large
	OB: Not user relevant
0xE21F	Memory card reading: Error at reload (after memory reset), checksum error when reading
	OB: Not user relevant
	PK: Not user relevant
	ZINFO1: Not user relevant
	ZINFO2: Block type
	56: OB
	65: DB
	66: SDB
	67: FC
	68: SFC
	69: FB
	70: SFB
	97: VDB
	98: VSDB
	99: VFC
	100: VSFC
	101: VFB

Event ID	Description
	102: VSFB
	111: VOB
	ZINFO3: Block number
0xE300	Internal flash writing completed (copy Ram2Rom)
0xE310	Internal flash reading completed (recharging after battery failure)
0xE400	FSC card was plugged
	OB: FSC activated from this slot (PK)
	OB: The inserted FSC is the activated FSC
	OB: The inserted FSC is compatible with the CPU
	PK: FSC source
	0: CPU
	1: Card
	ZINFO1: FSC(CRC)
	1146: 955-C000070
	1736: 955-C0NE040
	2568: FSC-C0ME040
	3450: 955-C000M30
	3903: 955-C000S30
	4361: FSC-C000M30
	4940: FSC-C000S30
	5755: 955-C0ME040
	6843: FSC-C0NE040
	8561: FSC-C000S20
	9012: FSC-C000M20
	13895: 955-C000060
	15618: 955-C000S20
	16199: 955-C000M20
	17675: FSC-C000S00
	18254: FSC-C000M00
	20046: FSC-C000040
	21053: 955-C000040
	22904: 955-C000S00
	23357: 955-C000M00
	24576: 955-C000050
	35025: 955-C00MC10
	36351: FSC-C000S40
	36794: FSC-C000M40
	37260: 955-C000S40

Event ID	Description
	37833: 955-C000M40
	38050: FSC-C00MC10
	41460: 955-C000M50
	41526: 955-C0PE040
	42655: FSC-C00MC00
	47852: 955-C00MC00
	48709: FSC-C0PE040
	50574: 955-C000M70
	52366: 955-C000030
	53501: FSC-C000030
	58048: FSC-C000020
	63411: 955-C000M60
	65203: 955-C000020
	ZINFO2: FSC serial number (high word)
	ZINFO3: FSC serial number (low word)
0xE401	FSC card was removed
	OB: Action after the end of the trial time
	0: No action
	1: CPU STOP
	2: CPU STOP and FSC deactivated
	3: Factory reset
	255: FSC was not activated
	PK: FSC source
	0: CPU
	1: Card
	ZINFO1: FSC(CRC)
	1146: 955-C000070
	1736: 955-C0NE040
	2568: FSC-C0ME040
	3450: 955-C000M30
	3903: 955-C000S30
	4361: FSC-C000M30
	4940: FSC-C000S30
	5755: 955-C0ME040
	6843: FSC-C0NE040
	8561: FSC-C000S20
	9012: FSC-C000M20
	13895: 955-C000060

Event ID	Description
	15618: 955-C000S20
	16199: 955-C000M20
	17675: FSC-C000S00
	18254: FSC-C000M00
	20046: FSC-C000040
	21053: 955-C000040
	22904: 955-C000S00
	23357: 955-C000M00
	24576: 955-C000050
	35025: 955-C00MC10
	36351: FSC-C000S40
	36794: FSC-C000M40
	37260: 955-C000S40
	37833: 955-C000M40
	38050: FSC-C00MC10
	41460: 955-C000M50
	41526: 955-C0PE040
	42655: FSC-C00MC00
	47852: 955-C00MC00
	48709: FSC-C0PE040
	50574: 955-C000M70
	52366: 955-C000030
	53501: FSC-C000030
	58048: FSC-C000020
	63411: 955-C000M60
	65203: 955-C000020
	ZINFO2: FSC serial number (high word)
	ZINFO3: FSC serial number (low word)
	DatID: FeatureSet Trialtime in minutes
0xE402	A configured functionality is not activated. The configuration is accepted, but the PLC can not go to RUN.
	ZINFO1: Required FSC: PROFIBUS
	ZINFO1: Required FSC: MOTION
	ZINFO2: Number of released axes
	ZINFO3: Number of configured axes
0xE403	FSC can not be activated in this CPU
	OB: FCS error code
	PK: FSC source

Event ID	Description
	0: CPU
	1: Card
	ZINFO1: FSC(CRC)
	1146: 955-C000070
	1736: 955-C0NE040
	2568: FSC-C0ME040
	3450: 955-C000M30
	3903: 955-C000S30
	4361: FSC-C000M30
	4940: FSC-C000S30
	5755: 955-C0ME040
	6843: FSC-C0NE040
	8561: FSC-C000S20
	9012: FSC-C000M20
	13895: 955-C000060
	15618: 955-C000S20
	16199: 955-C000M20
	17675: FSC-C000S00
	18254: FSC-C000M00
	20046: FSC-C000040
	21053: 955-C000040
	22904: 955-C000S00
	23357: 955-C000M00
	24576: 955-C000050
	35025: 955-C00MC10
	36351: FSC-C000S40
	36794: FSC-C000M40
	37260: 955-C000S40
	37833: 955-C000M40
	38050: FSC-C00MC10
	41460: 955-C000M50
	41526: 955-C0PE040
	42655: FSC-C00MC00
	47852: 955-C00MC00
	48709: FSC-C0PE040
	50574: 955-C000M70
	52366: 955-C000030
	53501: FSC-C000030

Event ID	Description
	58048: FSC-C000020
	63411: 955-C000M60
	65203: 955-C000020
	ZINFO2: FSC serial number (high word)
	ZINFO3: FSC serial number (low word)
0xE404	Feature set deleted due to CRC error
0xE405	The trial time of a feature set/memory card has expired
	OB: Action after the end of the trial time
	0: No action
	1: CPU STOP
	2: CPU STOP and FSC deactivated
	3: Factory reset
	255: FSC was not activated
	PK: FSC source
	0: CPU
	1: Card
	ZINFO1: FSC(CRC)
	1146: 955-C000070
	1736: 955-C0NE040
	2568: FSC-C0ME040
	3450: 955-C000M30
	3903: 955-C000S30
	4361: FSC-C000M30
	4940: FSC-C000S30
	5755: 955-C0ME040
	6843: FSC-C0NE040
	8561: FSC-C000S20
	9012: FSC-C000M20
	13895: 955-C000060
	15618: 955-C000S20
	16199: 955-C000M20
	17675: FSC-C000S00
	18254: FSC-C000M00
	20046: FSC-C000040
	21053: 955-C000040
	22904: 955-C000S00
	23357: 955-C000M00
	24576: 955-C000050

Event ID	Description
	35025: 955-C00MC10
	36351: FSC-C000S40
	36794: FSC-C000M40
	37260: 955-C000S40
	37833: 955-C000M40
	38050: FSC-C00MC10
	41460: 955-C000M50
	41526: 955-C0PE040
	42655: FSC-C00MC00
	47852: 955-C00MC00
	48709: FSC-C0PE040
	50574: 955-C000M70
	52366: 955-C000030
	53501: FSC-C000030
	58048: FSC-C000020
	63411: 955-C000M60
	65203: 955-C000020
	ZINFO2: FSC serial number (high word)
	ZINFO3: FSC serial number (low word)
	DatID: FeatureSet Trialtime in minutes
0xE406	The inserted feature set is corrupt
	PK: FSC source
	0: CPU
	1: Card
0xE410	A CPU feature set was activated
	PK: FSC source
	0: CPU
	1: Card
	ZINFO1: FSC(CRC)
	1146: 955-C000070
	1736: 955-C0NE040
	2568: FSC-C0ME040
	3450: 955-C000M30
	3903: 955-C000S30
	4361: FSC-C000M30
	4940: FSC-C000S30
	5755: 955-C0ME040
	6843: FSC-C0NE040

Event ID	Description
	8561: FSC-C000S20
	9012: FSC-C000M20
	13895: 955-C000060
	15618: 955-C000S20
	16199: 955-C000M20
	17675: FSC-C000S00
	18254: FSC-C000M00
	20046: FSC-C000040
	21053: 955-C000040
	22904: 955-C000S00
	23357: 955-C000M00
	24576: 955-C000050
	35025: 955-C00MC10
	36351: FSC-C000S40
	36794: FSC-C000M40
	37260: 955-C000S40
	37833: 955-C000M40
	38050: FSC-C00MC10
	41460: 955-C000M50
	41526: 955-C0PE040
	42655: FSC-C00MC00
	47852: 955-C00MC00
	48709: FSC-C0PE040
	50574: 955-C000M70
	52366: 955-C000030
	53501: FSC-C000030
	58048: FSC-C000020
	63411: 955-C000M60
	65203: 955-C000020
	ZINFO2: FSC serial number (high word)
	ZINFO3: FSC serial number (low word)
0xE500	Memory management: Deleted block without corresponding entry in BstList
	ZINFO2: Block type
	56: OB
	65: DB
	66: SDB
	67: FC
	68: SFC

Event ID	Description
	69: FB
	70: SFB
	97: VDB
	98: VSDB
	99: VFC
	100: VSFC
	101: VFB
	102: VSFB
	111: VOB
	ZINFO3: Block number
0xE501	Parser error
	ZINFO1: Error code
	1: Parser error: SDB structure
	2: Parser error: SDB is not a valid SDB type
	ZINFO2: SDB type
	ZINFO3: SDB number
0xE502	Invalid block type in protect.wld (block was not loaded)
	ZINFO2: Block type
	56: OB
	65: DB
	66: SDB
	67: FC
	68: SFC
	69: FB
	70: SFB
	97: VDB
	98: VSDB
	99: VFC
	100: VSFC
	101: VFB
	102: VSFB
	111: VOB
	ZINFO3: Block number
0xE503	Inconsistency of code sizes and block sizes in the working memory
	ZINFO1: Code size
	ZINFO2: Block size (high word)
	ZINFO3: Block size (low word)
0xE504	Additional information for CRC error in the working memory

ZINFO2: Block address (high word) ZINFO3: Block address (low word) 0xE505 Internal error - Please contact the hotline! ZINFO1: Cause for MemDump 0: Unknown	
0xE505 Internal error - Please contact the hotline! ZINFO1: Cause for MemDump	
ZINFO1: Cause for MemDump	
0: Unknown	
1: Manual request	
2: Invalid OP value	
3: CRC code error	
4: Processor exception	
5: Processor exception with dump after reboot	
6: Block-CRC error	
0xE604 Multiple configuration of a periphery address for Ethernet PG/OP channel	
ZINFO1: Periphery address	
ZINFO3: 0: periphery address is input, 1: periphery address is output	
0xE605 Too many productive connections configured	
ZINFO1: Interface slot	
ZINFO2: Number of configured connections	
ZINFO3: Number of admissible connections	
0xE610 On-board PROFIBUS/MPI: Bus error removed	
PK: Not user relevant	
ZINFO1: Interface	
ZINFO2: Not user relevant	
ZINFO3: Not user relevant	
DatID: Not user relevant	
0xE701 Internal error - Please contact the hotline!	
ZINFO1: Not user relevant	
ZINFO2: Not user relevant	
ZINFO3: Not user relevant	
DatID: Not user relevant	
0xE703 Internal error - Please contact the hotline!	
0: Master system ID	
PK: Not user relevant	
ZINFO1: Not user relevant	
ZINFO2: Slave address	
ZINFO3: Not user relevant	
DatID: Not user relevant	
0xE705 Too many PROFIBUS slaves configured	
ZINFO1: Diagnostic address of the PROFIBUS master	

ZINFO2: Number of configured slaves ZINFO3: Number of admissible slaves ZINFO3: Number of admissible slaves ZINFO1: Logical base address of the DP master ZINFO1: Logical base address of the DP master ZINFO2 - Position 8: DP master system ID	Event ID	Description
DXE70A PROFIBUS configured, but access way disabled ZINFO1: Logical base address of the DP master ZINFO2 - Position 8: DP master system ID OXE710 On-board PROFIBUS/MPI: Bus error occurred PK: Not user relevant ZINFO1: Interface ZINFO3: Not user relevant DatID: Not user relevant ZINFO3: Not user relevant ZINFO3: Not user relevant ZINFO3: Not user relevant DatID: Master system ID OXE720 Internal error - Please contact the hotline! ZINFO3: Not user relevant ZINFO3: Not user system ID OXE721 Internal error - Please contact the hotline! PK: Error code 1: Error when assigning diagnostic address for slave (no. in ZINFO3) 2: Error when assigning diagnostic address when de/activating for slave (no. in ZINFO3) 4: Error when assigning slots for slave (no. in ZINFO3) 5: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 6: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant DatID: Not user relevant DatID: Not user relevant Internal error - Please contact the hotline! ZINFO2: Master system ID ZINFO1: Channel-Event O: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID ZINFO3: M		ZINFO2: Number of configured slaves
ZINFO1: Logical base address of the PP master ZINFO2 - Position 8: DP master system ID OxE710 On-board PROFIBUS/MPI: Bus error occurred PK: Not user relevant ZINFO1: Interface ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Not user relevant DatID: Not user relevant DatID: Not user relevant OXE720 Internal error - Please contact the hotline! ZINFO3: Not user relevant ZINFO3: Not user relevant DatID: Master system ID OXE721 Internal error - Please contact the hotline! PK: Error code 1: Error when assigning diagnostic address for slave (no. in ZINFO3) 2: Error when assigning diagnostic address for master 3: Error when assigning slots for slave (no. in ZINFO3) 4: Error when assigning slots for slave (no. in ZINFO3) 5: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 6: Error in DPV1 configuration (outputs) for slave (no. in ZINFO3) 7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID OXE722 Internal error - Please contact the hotline! 2INFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		ZINFO3: Number of admissible slaves
ZINFO2 - Position 8: DP master system ID OxE710 On-board PROFIBUS/MPI: Bus error occurred PK: Not user relevant ZINFO1: Interface ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Not user relevant DatID: Not user relevant DatID: Not user relevant DatID: Not user relevant Internal error - Please contact the hotline! ZINFO3: Not user relevant ZINFO3: Not user relevant DatID: Master system ID OxE721 Internal error - Please contact the hotline! PK: Error code 1: Error when assigning diagnostic address for slave (no. in ZINFO3) 2: Error when assigning diagnostic address for master 3: Error when assigning logical address when de/activating for slave (no. in ZINFO3) 4: Error when assigning logical address when de/activating for slave (no. in ZINFO3) 6: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 6: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant DatID: Not user relevant DatID: Not user relevant DatID: Not user relevant Internal error - Please contact the hotline! 2: INFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID	0xE70A	PROFIBUS configured, but access way disabled
OxE710 On-board PROFIBUS/MPI: Bus error occurred PK: Not user relevant ZINFO1: Interface ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Not user relevant DatID: Not user relevant DatID: Not user relevant Internal error - Please contact the hotline! ZINFO1: Slave no ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Master system ID OXE721 Internal error - Please contact the hotline! PK: Error when assigning diagnostic address for slave (no. in ZINFO3) 2: Error when assigning diagnostic address for master 3: Error when assigning diagnostic address for master 3: Error when assigning slots for slave (no. in ZINFO3) 4: Error when assigning slots for slave (no. in ZINFO3) 5: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 6: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant DatID: Not user relevant DatID: Not user relevant DatID: Not user relevant 1NFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error		ZINFO1: Logical base address of the DP master
PK: Not user relevant ZINFO1: Interface ZINFO2: Not user relevant ZINFO3: Not user relevant ZINFO3: Not user relevant DatID: Not user relevant Internal error - Please contact the hotline! ZINFO3: Not user relevant DatID: Master system ID OxE721 Internal error - Please contact the hotline! PK: Error code 1: Error when assigning diagnostic address for slave (no. in ZINFO3) 2: Error when assigning diagnostic address for master 3: Error when assigning logical address when de/activating for slave (no. in ZINFO3) 4: Error when assigning slots for slave (no. in ZINFO3) 5: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 6: Error in DPV1 configuration (outputs) for slave (no. in ZINFO3) 7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant DatID: Not user relevant 0xE722 Internal error - Please contact the hotline! 2INFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		ZINFO2 - Position 8: DP master system ID
ZINFO1: Interface ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Not user relevant DatID: Not user relevant DatID: Not user relevant Internal error - Please contact the hotline! ZINFO2: Slave no ZINFO2: Not user relevant DatID: Master system ID OXE721 Internal error - Please contact the hotline! PK: Error code 1: Error when assigning diagnostic address for slave (no. in ZINFO3) 2: Error when assigning diagnostic address for slave (no. in ZINFO3) 4: Error when assigning logical address when de/activating for slave (no. in ZINFO3) 5: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 6: Error in DPV1 configuration (outputs) for slave (no. in ZINFO3) 7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant DatID: Not user relevant 0xE722 Internal error - Please contact the hotline! 2INFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID	0xE710	On-board PROFIBUS/MPI: Bus error occurred
ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Not user relevant DatID: Not user relevant Internal error - Please contact the hotline! ZINFO1: Slave no ZINFO2: Not user relevant ZINFO3: Not user relevant ZINFO3: Not user relevant DatID: Master system ID OxE721 Internal error - Please contact the hotline! PK: Error code 1: Error when assigning diagnostic address for slave (no. in ZINFO3) 2: Error when assigning diagnostic address for master 3: Error when assigning logical address when de/activating for slave (no. in ZINFO3) 4: Error when assigning slots for slave (no. in ZINFO3) 5: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 6: Error in DPV1 configuration (outputs) for slave (no. in ZINFO3) 7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant Unternal error - Please contact the hotline! 2: Bus error 2: Internal error ZINFO2: Master system ID ZINFO3: Master system ID		PK: Not user relevant
ZINFO3: Not user relevant DatID: Not user relevant OxE720 Internal error - Please contact the hotline! ZINFO1: Slave no ZINFO2: Not user relevant ZINFO3: Not user relevant ZINFO3: Not user relevant DatID: Master system ID OXE721 Internal error - Please contact the hotline! PK: Error code 1: Error when assigning diagnostic address for slave (no. in ZINFO3) 2: Error when assigning diagnostic address for master 3: Error when assigning logical address when de/activating for slave (no. in ZINFO3) 4: Error when assigning slots for slave (no. in ZINFO3) 5: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 6: Error in DPV1 configuration (outputs) for slave (no. in ZINFO3) 7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant OxE722 Internal error - Please contact the hotline! ZINFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		ZINFO1: Interface
DatID: Not user relevant Internal error - Please contact the hotline! ZINFO1: Slave no ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Master system ID OxE721 Internal error - Please contact the hotline! PK: Error code 1: Error when assigning diagnostic address for slave (no. in ZINFO3) 2: Error when assigning diagnostic address for master 3: Error when assigning logical address for master 3: Error when assigning logical address when de/activating for slave (no. in ZINFO3) 4: Error when assigning slots for slave (no. in ZINFO3) 5: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 6: Error in DPV1 configuration (outputs) for slave (no. in ZINFO3) 7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant OxE722 Internal error - Please contact the hotline! ZINFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		ZINFO2: Not user relevant
Internal error - Please contact the hotline! ZINFO1: Slave no ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Master system ID OxE721 Internal error - Please contact the hotline! PK: Error code 1: Error when assigning diagnostic address for slave (no. in ZINFO3) 2: Error when assigning diagnostic address for master 3: Error when assigning logical address when de/activating for slave (no. in ZINFO3) 4: Error when assigning slots for slave (no. in ZINFO3) 5: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 6: Error in DPV1 configuration (outputs) for slave (no. in ZINFO3) 7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant DatID: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		ZINFO3: Not user relevant
ZINFO1: Slave no ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Master system ID 0xE721 Internal error - Please contact the hotline! PK: Error code 1: Error when assigning diagnostic address for slave (no. in ZINFO3) 2: Error when assigning diagnostic address for master 3: Error when assigning logical address when de/activating for slave (no. in ZINFO3) 4: Error when assigning slots for slave (no. in ZINFO3) 5: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 6: Error in DPV1 configuration (outputs) for slave (no. in ZINFO3) 7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant OxE722 Internal error - Please contact the hotline! ZINFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		DatID: Not user relevant
ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Master system ID 0xE721 Internal error - Please contact the hotline! PK: Error code 1: Error when assigning diagnostic address for slave (no. in ZINFO3) 2: Error when assigning logical address when de/activating for slave (no. in ZINFO3) 4: Error when assigning slots for slave (no. in ZINFO3) 5: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 6: Error in DPV1 configuration (outputs) for slave (no. in ZINFO3) 7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant OxE722 Internal error - Please contact the hotline! 2: Internal error 2: Internal error 2: Internal error ZINFO2: Master system ID	0xE720	Internal error - Please contact the hotline!
ZINFO3: Not user relevant DatID: Master system ID 0xE721 Internal error - Please contact the hotline! PK: Error code 1: Error when assigning diagnostic address for slave (no. in ZINFO3) 2: Error when assigning diagnostic address for master 3: Error when assigning logical address when de/activating for slave (no. in ZINFO3) 4: Error when assigning slots for slave (no. in ZINFO3) 5: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 6: Error in DPV1 configuration (outputs) for slave (no. in ZINFO3) 7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant DatID: Not user relevant 0xE722 Internal error - Please contact the hotline! ZINFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		ZINFO1: Slave no
DatID: Master system ID Internal error - Please contact the hotline! PK: Error code 1: Error when assigning diagnostic address for slave (no. in ZINFO3) 2: Error when assigning diagnostic address for master 3: Error when assigning logical address when de/activating for slave (no. in ZINFO3) 4: Error when assigning slots for slave (no. in ZINFO3) 5: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 6: Error in DPV1 configuration (outputs) for slave (no. in ZINFO3) 7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant OXE722 Internal error - Please contact the hotline! ZINFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		ZINFO2: Not user relevant
Internal error - Please contact the hotline! PK: Error code 1: Error when assigning diagnostic address for slave (no. in ZINFO3) 2: Error when assigning diagnostic address for master 3: Error when assigning logical address when de/activating for slave (no. in ZINFO3) 4: Error when assigning slots for slave (no. in ZINFO3) 5: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 6: Error in DPV1 configuration (outputs) for slave (no. in ZINFO3) 7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant DatID: Not user relevant OxE722 Internal error - Please contact the hotline! ZINFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		ZINFO3: Not user relevant
PK: Error code 1: Error when assigning diagnostic address for slave (no. in ZINFO3) 2: Error when assigning diagnostic address for master 3: Error when assigning logical address when de/activating for slave (no. in ZINFO3) 4: Error when assigning slots for slave (no. in ZINFO3) 5: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 6: Error in DPV1 configuration (outputs) for slave (no. in ZINFO3) 7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant DatID: Not user relevant OxE722 Internal error - Please contact the hotline! ZINFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		DatID: Master system ID
1: Error when assigning diagnostic address for slave (no. in ZINFO3) 2: Error when assigning diagnostic address for master 3: Error when assigning logical address when de/activating for slave (no. in ZINFO3) 4: Error when assigning slots for slave (no. in ZINFO3) 5: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 6: Error in DPV1 configuration (outputs) for slave (no. in ZINFO3) 7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant OxE722 Internal error - Please contact the hotline! ZINFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID	0xE721	Internal error - Please contact the hotline!
2: Error when assigning diagnostic address for master 3: Error when assigning logical address when de/activating for slave (no. in ZINFO3) 4: Error when assigning slots for slave (no. in ZINFO3) 5: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 6: Error in DPV1 configuration (outputs) for slave (no. in ZINFO3) 7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant OxE722 Internal error - Please contact the hotline! ZINFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		PK: Error code
3: Error when assigning logical address when de/activating for slave (no. in ZINFO3) 4: Error when assigning slots for slave (no. in ZINFO3) 5: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 6: Error in DPV1 configuration (outputs) for slave (no. in ZINFO3) 7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant OxE722 Internal error - Please contact the hotline! ZINFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		1: Error when assigning diagnostic address for slave (no. in ZINFO3)
4: Error when assigning slots for slave (no. in ZINFO3) 5: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 6: Error in DPV1 configuration (outputs) for slave (no. in ZINFO3) 7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant DatID: Not user relevant OxE722 Internal error - Please contact the hotline! ZINFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		2: Error when assigning diagnostic address for master
5: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3) 6: Error in DPV1 configuration (outputs) for slave (no. in ZINFO3) 7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant 0xE722 Internal error - Please contact the hotline! ZINFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		3: Error when assigning logical address when de/activating for slave (no. in ZINFO3)
6: Error in DPV1 configuration (outputs) for slave (no. in ZINFO3) 7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant OxE722 Internal error - Please contact the hotline! ZINFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		4: Error when assigning slots for slave (no. in ZINFO3)
7: SubnetID for master (in ZINFO2) invalid 8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant DatID: Not user relevant OxE722 Internal error - Please contact the hotline! ZINFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		5: Error in DPV1 configuration (inputs) for slave (no. in ZINFO3)
8: Slave (no. in ZINFO3) could not be configured (CFG length in OB) ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant OxE722 Internal error - Please contact the hotline! ZINFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		6: Error in DPV1 configuration (outputs) for slave (no. in ZINFO3)
ZINFO1: Not user relevant ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant 0xE722 Internal error - Please contact the hotline! ZINFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		7: SubnetID for master (in ZINFO2) invalid
ZINFO2: Master system ID ZINFO3: Not user relevant DatID: Not user relevant 0xE722 Internal error - Please contact the hotline! ZINFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		8: Slave (no. in ZINFO3) could not be configured (CFG length in OB)
ZINFO3: Not user relevant DatID: Not user relevant 0xE722 Internal error - Please contact the hotline! ZINFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		ZINFO1: Not user relevant
DatID: Not user relevant 0xE722 Internal error - Please contact the hotline! ZINFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		ZINFO2: Master system ID
0xE722 Internal error - Please contact the hotline! ZINFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		ZINFO3: Not user relevant
ZINFO1: Channel-Event 0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID		DatID: Not user relevant
0: Channel offline 1: Bus error 2: Internal error ZINFO2: Master system ID	0xE722	Internal error - Please contact the hotline!
1: Bus error 2: Internal error ZINFO2: Master system ID		ZINFO1: Channel-Event
2: Internal error ZINFO2: Master system ID		0: Channel offline
ZINFO2: Master system ID		1: Bus error
_		2: Internal error
DatID: Not user relevant		ZINFO2: Master system ID
		DatID: Not user relevant
0xE723 Internal error - Please contact the hotline!	0xE723	Internal error - Please contact the hotline!

ZINFO1: Error code 1: Parameter error 2: Configuration error ZINFO2: Master system ID DatID: Not user relevant OxE780 Error in configuration of a process image ZINFO1: Not user relevant ZINFO2: Logical address ZINFO3: IO Flag OxE781 Address range exceeds process image limit ZINFO2: Length of the address range ZINFO3: Size of the process image DatID: Address range OxE801 CMD - auto command: CMD_START recognized and executed OxE802 CMD - auto command: WAIT1SECOND recognized and executed OxE804 CMD - auto command: WEBPAGE recognized and executed OxE805 CMD - auto command: LOAD_PROJECT recognized and executed OxE806 CMD - auto command: SAVE_PROJECT recognized and executed OxE806 CMD - auto command: SAVE_PROJECT recognized and executed OxE806 CMD - auto command: SAVE_PROJECT recognized and executed OxE806 CMD - auto command: SAVE_PROJECT recognized and executed OxE806 CMD - auto command: SAVE_PROJECT recognized and executed OxE806 CMD - auto command: SAVE_PROJECT recognized and executed OxE806 CMD - auto command: SAVE_PROJECT recognized and executed OxE806 CMD - auto command: SAVE_PROJECT recognized and executed OxE806 CMD - auto command: SAVE_PROJECT recognized and executed
2: Configuration error ZINFO2: Master system ID DatID: Not user relevant Error in configuration of a process image ZINFO1: Not user relevant ZINFO2: Logical address ZINFO3: IO Flag 0xE781 Address range exceeds process image limit ZINFO1: Address ZINFO2: Length of the address range ZINFO3: Size of the process image DatID: Address range OXE801 CMD - auto command: CMD_START recognized and executed 0xE802 CMD - auto command: CMD_End recognized and executed 0xE803 CMD - auto command: WEBPAGE recognized and executed 0xE804 CMD - auto command: WEBPAGE recognized and executed 0xE805 CMD - auto command: LOAD_PROJECT recognized and executed 0xE806 CMD - auto command: SAVE_PROJECT recognized and executed ZINFO3: Status 0: Error
ZINFO2: Master system ID DatID: Not user relevant OXE780 Error in configuration of a process image ZINFO1: Not user relevant ZINFO2: Logical address ZINFO3: IO Flag OXE781 Address range exceeds process image limit ZINFO1: Address ZINFO2: Length of the address range ZINFO3: Size of the process image DatID: Address range OXE801 CMD - auto command: CMD_START recognized and executed OXE802 CMD - auto command: CMD_End recognized and executed OXE803 CMD - auto command: WAIT1SECOND recognized and executed OXE804 CMD - auto command: WEBPAGE recognized and executed OXE805 CMD - auto command: LOAD_PROJECT recognized and executed OXE806 CMD - auto command: SAVE_PROJECT recognized and executed ZINFO3: Status O: Error
DatID: Not user relevant Error in configuration of a process image ZINFO1: Not user relevant ZINFO2: Logical address ZINFO3: IO Flag OxE781 Address range exceeds process image limit ZINFO1: Address ZINFO1: Address ZINFO2: Length of the address range ZINFO3: Size of the process image DatID: Address range DatID: Address range OxE801 CMD - auto command: CMD_START recognized and executed 0xE802 CMD - auto command: WAIT1SECOND recognized and executed 0xE803 CMD - auto command: WEBPAGE recognized and executed 0xE804 CMD - auto command: LOAD_PROJECT recognized and executed 0xE805 CMD - auto command: SAVE_PROJECT recognized and executed CMD - auto command: SAVE_PROJECT recognized and executed ZINFO3: Status 0: Error
Error in configuration of a process image ZINFO1: Not user relevant ZINFO2: Logical address ZINFO3: IO Flag OxE781 Address range exceeds process image limit ZINFO1: Address ZINFO2: Length of the address range ZINFO3: Size of the process image DatID: Address range DatID: Address range OxE801 CMD - auto command: CMD_START recognized and executed 0xE802 CMD - auto command: CMD_End recognized and executed 0xE803 CMD - auto command: WAIT1SECOND recognized and executed 0xE804 CMD - auto command: WEBPAGE recognized and executed 0xE805 CMD - auto command: SAVE_PROJECT recognized and executed ZINFO3: Status 0: Error
ZINFO1: Not user relevant ZINFO2: Logical address ZINFO3: IO Flag OxE781 Address range exceeds process image limit ZINFO1: Address ZINFO2: Length of the address range ZINFO3: Size of the process image DatlD: Address range OxE801 CMD - auto command: CMD_START recognized and executed OxE802 CMD - auto command: CMD_End recognized and executed OxE803 CMD - auto command: WAIT1SECOND recognized and executed OxE804 CMD - auto command: WEBPAGE recognized and executed OxE805 CMD - auto command: LOAD_PROJECT recognized and executed OxE806 CMD - auto command: SAVE_PROJECT recognized and executed ZINFO3: Status O: Error
ZINFO2: Logical address ZINFO3: IO Flag 0xE781 Address range exceeds process image limit ZINFO1: Address ZINFO2: Length of the address range ZINFO3: Size of the process image DatID: Address range 0xE801 CMD - auto command: CMD_START recognized and executed 0xE802 CMD - auto command: CMD_End recognized and executed 0xE803 CMD - auto command: WAIT1SECOND recognized and executed 0xE804 CMD - auto command: WEBPAGE recognized and executed 0xE805 CMD - auto command: LOAD_PROJECT recognized and executed 0xE806 CMD - auto command: SAVE_PROJECT recognized and executed 0xE806 CMD - auto command: SAVE_PROJECT recognized and executed 0xE806 CMD - auto command: SAVE_PROJECT recognized and executed 0xE806 CMD - auto command: SAVE_PROJECT recognized and executed
DXE781 Address range exceeds process image limit ZINFO1: Address ZINFO2: Length of the address range ZINFO3: Size of the process image DatID: Address range OXE801 CMD - auto command: CMD_START recognized and executed OXE802 CMD - auto command: CMD_End recognized and executed OXE803 CMD - auto command: WAIT1SECOND recognized and executed OXE804 CMD - auto command: WEBPAGE recognized and executed OXE805 CMD - auto command: LOAD_PROJECT recognized and executed OXE806 CMD - auto command: SAVE_PROJECT recognized and executed ZINFO3: Status O: Error
Address range exceeds process image limit ZINFO1: Address ZINFO2: Length of the address range ZINFO3: Size of the process image DatID: Address range OxE801
ZINFO1: Address ZINFO2: Length of the address range ZINFO3: Size of the process image DatID: Address range 0xE801
ZINFO2: Length of the address range ZINFO3: Size of the process image DatID: Address range 0xE801
ZINFO3: Size of the process image DatID: Address range OXE801
DatID: Address range 0xE801
OxE801 CMD - auto command: CMD_START recognized and executed OxE802 CMD - auto command: CMD_End recognized and executed OxE803 CMD - auto command: WAIT1SECOND recognized and executed OxE804 CMD - auto command: WEBPAGE recognized and executed OxE805 CMD - auto command: LOAD_PROJECT recognized and executed OxE806 CMD - auto command: SAVE_PROJECT recognized and executed ZINFO3: Status O: Error
0xE802
0xE803 CMD - auto command: WAIT1SECOND recognized and executed 0xE804 CMD - auto command: WEBPAGE recognized and executed 0xE805 CMD - auto command: LOAD_PROJECT recognized and executed 0xE806 CMD - auto command: SAVE_PROJECT recognized and executed ZINFO3: Status 0: Error
0xE804 CMD - auto command: WEBPAGE recognized and executed 0xE805 CMD - auto command: LOAD_PROJECT recognized and executed 0xE806 CMD - auto command: SAVE_PROJECT recognized and executed ZINFO3: Status 0: Error
0xE805 CMD - auto command: LOAD_PROJECT recognized and executed 0xE806 CMD - auto command: SAVE_PROJECT recognized and executed ZINFO3: Status 0: Error
0xE806 CMD - auto command: SAVE_PROJECT recognized and executed ZINFO3: Status 0: Error
ZINFO3: Status 0: Error
0: Error
1: OK
32768: Wrong password
0xE807 CMD - auto command: FACTORY_RESET recognized and executed
0xE808 Internal message
ZINFO2: Not user relevant
ZINFO3: Not user relevant
0xE809 Internal message
ZINFO3: Not user relevant
0xE80A Internal message
ZINFO3: Status
0: OK
65153: File create error
65185: File writing error
65186: Odd address for reading
0xE80B CMD - auto command: DIAGBUF recognized and executed
ZINFO3: Status

Description	Event ID	Description
65153: File create error	LVent ID	·
0xE80C Internal message ZINFO3: Status 0: OK 65153: File create error 65185: File writing error 65186: Odd address for reading 0xE80D 0xE80D Internal message 0xE80F CMD - auto command: SET_NETWORK recognized and executed 0xE80F Internal message 2INFO3: Status 0: OK 65153: File create error 65186: Old address for reading 0xE810 Internal message 0xE811 Internal message 0xE812 Internal message 0xE813 Internal message 0xE814 CMD - auto command: SET_MPI_ADDRESS identified 0xE816 CMD - auto command: SAVE_PROJECT recognized but not executed, because the CPU memory is empty 0xE817 Internal message 0xE820 Internal message 0xE821 Internal message 0xE822 Internal message 0xE823 Internal message 0xE824 Internal message 0xE825 Internal message 0xE826 Internal message 0xE827 Internal messag		
Internal message ZINFO3: Status 0		-
ZINFO3: Status	0.4500	_
0; OK 65153; File create error 65185; File writing error 65185; File writing error 65186; Odd address for reading 0xE80D	UXE80C	-
65153: File create error		
65185: File writing error		
0xE80D Internal message 0xE80E CMD - auto command: SET_NETWORK recognized and executed 0xE80F Internal message ZINFO3: Status 0: OK 65153: File create error 65185: File writing error 65186: Odd address for reading 0xE810 Internal message 0xE811 Internal message 0xE812 0xE812 Internal message 0xE813 Internal message 0xE814 CMD - auto command: SET_MPI_ADDRESS identified 0xE816 CMD - auto command: SAVE_PROJECT recognized but not executed, because the CPU memory is empty 0xE817 Internal message 0xE820 Internal message 0xE821 Internal message 0xE822 Internal message 0xE823 Internal message 0xE824 Internal message 0xE825 Internal message 0xE826 Internal message 0xE827 Internal message 0xE828 Internal message 0xE829 Internal message		
0xE80D Internal message 0xE80E CMD - auto command: SET_NETWORK recognized and executed 0xE80F Internal message ZINFO3: Status 0: OK 65153: File create error 65185: File writing error 65186: Odd address for reading 0xE810 0xE811 Internal message 0xE812 Internal message 0xE813 Internal message 0xE814 CMD - auto command: SET_MPI_ADDRESS identified 0xE816 CMD - auto command: SAVE_PROJECT recognized but not executed, because the CPU memory is empty 0xE817 Internal message 0xE820 Internal message 0xE821 Internal message 0xE822 Internal message 0xE823 Internal message 0xE824 Internal message 0xE825 Internal message 0xE826 Internal message 0xE827 Internal message 0xE828 Internal message 0xE829 Internal message		-
0xE80E CMD - auto command: SET_NETWORK recognized and executed 0xE80F Internal message ZINFO3: Status 0: OK 65153: File create error 65185: File writing error 65186: Odd address for reading 0xE810 0xE811 Internal message 0xE812 Internal message 0xE813 Internal message 0xE814 CMD - auto command: SET_MPI_ADDRESS identified 0xE816 CMD - auto command: SAVE_PROJECT recognized but not executed, because the CPU memory is empty 0xE817 Internal message 0xE820 Internal message 0xE821 Internal message 0xE822 Internal message 0xE823 Internal message 0xE824 Internal message 0xE825 Internal message 0xE826 Internal message 0xE827 Internal message 0xE828 Internal message 0xE829 Internal message	0500	-
Internal message ZINFO3: Status O: OK 65153: File create error 65185: File writing error 65186: Odd address for reading		
ZINFO3: Status 0: OK 65153: File create error 65186: Odd address for reading 0xE810 Internal message 0xE811 Internal message 0xE812 Internal message 0xE813 Internal message 0xE814 CMD - auto command: SET_MPI_ADDRESS identified 0xE816 CMD - auto command: SAVE_PROJECT recognized but not executed, because the CPU memory is empty 0xE817 Internal message ZINFO3: Not user relevant 0xE820 Internal message 0xE821 Internal message 0xE822 Internal message 0xE823 Internal message 0xE824 Internal message 0xE825 Internal message 0xE826 Internal message 0xE827 Internal message 0xE827 Internal message 0xE828 Internal message 0xE828 Internal message 0xE829 Internal message		
0: OK 65153: File create error 65185: File writing error 65186: Odd address for reading 0xE810	UXE80F	-
65153: File create error 65185: File writing error 65186: Odd address for reading 0xE810		
65185: File writing error 65186: Odd address for reading 0xE810 Internal message 0xE811 Internal message 0xE812 Internal message 0xE813 Internal message 0xE814 CMD - auto command: SET_MPI_ADDRESS identified 0xE816 CMD - auto command: SAVE_PROJECT recognized but not executed, because the CPU memory is empty 0xE817 Internal message ZINFO3: Not user relevant 0xE820 Internal message 0xE821 Internal message 0xE822 Internal message 0xE823 Internal message 0xE824 Internal message 0xE825 Internal message 0xE826 Internal message 0xE827 Internal message 0xE827 Internal message 0xE828 Internal message 0xE828 Internal message 0xE829 Internal message		1 1
0xE810 Internal message 0xE811 Internal message 0xE812 Internal message 0xE813 Internal message 0xE814 CMD - auto command: SET_MPI_ADDRESS identified 0xE816 CMD - auto command: SAVE_PROJECT recognized but not executed, because the CPU memory is empty 0xE817 Internal message ZINFO3: Not user relevant 0xE820 Internal message 0xE821 Internal message 0xE822 Internal message 0xE823 Internal message 0xE824 Internal message 0xE825 Internal message 0xE826 Internal message 0xE827 Internal message 0xE828 Internal message 0xE829 Internal message		
0xE810 Internal message 0xE811 Internal message 0xE812 Internal message 0xE813 Internal message 0xE814 CMD - auto command: SET_MPI_ADDRESS identified 0xE816 CMD - auto command: SAVE_PROJECT recognized but not executed, because the CPU memory is empty 0xE817 Internal message ZINFO3: Not user relevant 0xE820 0xE821 Internal message 0xE822 Internal message 0xE823 Internal message 0xE824 Internal message 0xE825 Internal message 0xE826 Internal message 0xE827 Internal message 0xE828 Internal message 0xE829 Internal message		-
OxE811 Internal message OxE812 Internal message OxE813 Internal message OxE814 CMD - auto command: SET_MPI_ADDRESS identified OxE816 CMD - auto command: SAVE_PROJECT recognized but not executed, because the CPU memory is empty OxE817 Internal message ZINFO3: Not user relevant OxE820 Internal message OxE821 Internal message OxE822 Internal message OxE823 Internal message OxE823 Internal message OxE824 Internal message OxE825 Internal message OxE825 Internal message OxE826 Internal message OxE827 Internal message OxE828 Internal message OxE828 Internal message OxE829 Internal message		-
0xE812 Internal message 0xE813 Internal message 0xE814 CMD - auto command: SET_MPI_ADDRESS identified 0xE816 CMD - auto command: SAVE_PROJECT recognized but not executed, because the CPU memory is empty 0xE817 Internal message ZINFO3: Not user relevant 0xE820 Internal message 0xE821 Internal message 0xE822 Internal message 0xE823 Internal message 0xE824 Internal message 0xE825 Internal message 0xE826 Internal message 0xE827 Internal message 0xE828 Internal message 0xE829 Internal message		-
0xE813 Internal message 0xE814 CMD - auto command: SET_MPI_ADDRESS identified 0xE816 CMD - auto command: SAVE_PROJECT recognized but not executed, because the CPU memory is empty 0xE817 Internal message ZINFO3: Not user relevant 0xE820 Internal message 0xE821 Internal message 0xE822 Internal message 0xE823 Internal message 0xE824 Internal message 0xE825 Internal message 0xE826 Internal message 0xE827 Internal message 0xE828 Internal message 0xE829 Internal message		
OxE814 CMD - auto command: SET_MPI_ADDRESS identified CMD - auto command: SAVE_PROJECT recognized but not executed, because the CPU memory is empty OxE817 Internal message ZINFO3: Not user relevant OxE820 Internal message OxE821 Internal message OxE822 Internal message OxE823 Internal message OxE824 Internal message OxE825 Internal message OxE826 Internal message OxE827 Internal message OxE828 Internal message OxE829 Internal message OXE829 Internal message		-
OxE816 CMD - auto command: SAVE_PROJECT recognized but not executed, because the CPU memory is empty OxE817 Internal message ZINFO3: Not user relevant OxE820 Internal message OxE821 Internal message OxE822 Internal message OxE823 Internal message OxE823 Internal message OxE824 Internal message OxE825 Internal message OxE826 Internal message OxE827 Internal message OxE828 Internal message OxE828 Internal message OxE829 Internal message	0xE813	Internal message
memory is empty Internal message ZINFO3: Not user relevant OxE820 Internal message OxE821 Internal message OxE822 Internal message OxE823 Internal message OxE824 Internal message OxE825 Internal message OxE826 Internal message OxE827 Internal message OxE828 Internal message OxE829 Internal message	0xE814	CMD - auto command: SET_MPI_ADDRESS identified
ZINFO3: Not user relevant 0xE820	0xE816	
0xE820Internal message0xE821Internal message0xE822Internal message0xE823Internal message0xE824Internal message0xE825Internal message0xE826Internal message0xE827Internal message0xE828Internal message0xE829Internal message	0xE817	Internal message
0xE821 Internal message 0xE822 Internal message 0xE823 Internal message 0xE824 Internal message 0xE825 Internal message 0xE826 Internal message 0xE827 Internal message 0xE828 Internal message 0xE828 Internal message		ZINFO3: Not user relevant
0xE822 Internal message 0xE823 Internal message 0xE824 Internal message 0xE825 Internal message 0xE826 Internal message 0xE827 Internal message 0xE828 Internal message 0xE829 Internal message	0xE820	Internal message
0xE823 Internal message 0xE824 Internal message 0xE825 Internal message 0xE826 Internal message 0xE827 Internal message 0xE828 Internal message 0xE828 Internal message	0xE821	Internal message
0xE824 Internal message 0xE825 Internal message 0xE826 Internal message 0xE827 Internal message 0xE828 Internal message 0xE828 Internal message 0xE829 Internal message	0xE822	Internal message
0xE825 Internal message 0xE826 Internal message 0xE827 Internal message 0xE828 Internal message 0xE829 Internal message	0xE823	Internal message
0xE826 Internal message 0xE827 Internal message 0xE828 Internal message 0xE829 Internal message	0xE824	Internal message
0xE827 Internal message 0xE828 Internal message 0xE829 Internal message	0xE825	Internal message
0xE828 Internal message 0xE829 Internal message	0xE826	Internal message
0xE829 Internal message	0xE827	Internal message
-	0xE828	Internal message
0xE82A CMD - auto command: CPUTYPE_318 recognized and executed	0xE829	Internal message
	0xE82A	CMD - auto command: CPUTYPE_318 recognized and executed

Event ID	Description
	ZINFO3: Error code
0xE82B	CMD - auto command: CPUTYPE_ORIGINAL recognized and executed
	ZINFO3: Error code
0xE82C	CMD - auto command: WEBVISU_PGOP_ENABLE recognized and executed
0xE82D	CMD - auto command: WEBVISU_PGOP_DISABLE recognized and executed
0xE82E	CMD - auto command: WEBVISU_CP_ENABLE recognized and executed
0xE82F	CMD - auto command: WEBVISU_CP_DISABLE recognized and executed
0xE830	CMD - auto command: OPCUA_PGOP_ENABLE recognized and executed
0xE831	CMD - auto command: OPCUA_PGOP_DISABLE recognized and executed
0xE832	CMD - auto command: OPCUA_CP_ENABLE recognized and executed
0xE833	CMD - auto command: OPCUA_CP_DISABLE recognized and executed
0xE8FB	CMD - auto command: Error: Initialization of the Ethernet PG/OP channel by means of SET_NETWORK is faulty
0xE8FC	CMD - auto command: Error: Some IP parameters missing in SET_NETWORK
0xE8FE	CMD - auto command: Error: CMD_START not found
0xE8FF	CMD - auto command: Error while reading CMD file (memory card error)
0xE901	Checksum error
	ZINFO1: Not user relevant
	ZINFO2: Not user relevant
	DatID: Not user relevant
0xE902	Internal error - Please contact the hotline!
	ZINFO1: Not user relevant
	ZINFO2: Not user relevant
	DatID: Not user relevant
0xE904	PG/OP: Multiple parametrization of a peripheral address
	ZINFO1: Peripheral address
	ZINFO2: Slot
	ZINFO3: Data width
	DatID: 0x54 Peripheral address is input address
	DatID: 0x55 Peripheral address is output address
0xE90A	PROFINET configured, but access way disabled
	ZINFO1: Logical address of the IO system
	ZINFO3: Station number
	ZINFO3: IO system ID
	ZINFO3: System ID DP/PN
0xE910	PG/OP: Input peripheral address out of peripheral area
	ZINFO1: Peripheral address
	ZINFO2: Slot

Event ID	Description
	ZINFO3: Data width
0xE911	PG/OP: Output peripheral address out of peripheral area
	ZINFO1: Peripheral address
	ZINFO2: Slot
	ZINFO3: Data width
0xE920	Configuration error PROFINET
	ZINFO1 - Position 0: Error code
	1: Double IP/PROFINET configuration in slot 2 and 4
	2: PROFINET IO system configured in slot 4
	3: Too many PROFINET IO controller configured
	4: Virtual device multiple configured
	5: EtherCAT devices for PROFINET CP configured
	6: PROFINET devices for EtherCAT CP configured
	7: PROFINET CP configured at slot 2, although this is not supported
	8: A PROFINET IO system (I-Device) must not be configured on the CP on slot 4
	9: A PROFINET IO system (controller) must not be configured on the CP on slot 4
0xE980	Error when loading the WebVisu project file
	ZINFO1: Platform
0xE981	Error in the configuration of the WebVisu project
	ZINFO1: Platform
0xE982	Internal error of the WebVisu server
	ZINFO1: Platform
0xE983	Hardware configuration of the control is not loaded, WebVisu is not started
	ZINFO1: Platform
0xE984	WebVisu is blocked by the user, start of the WebVisu was prevented
	ZINFO1: Platform
0xE985	WebVisu was started
	ZINFO1: Platform
0xE986	WebVisu was stopped
	ZINFO1: Platform
0xE987	WebVisu was enabled by the user
	ZINFO1: Platform
0xE988	WebVisu was disabled by the user
	ZINFO1: Platform
0xE989	WebVisu and OPC UA project not allowed at the same time
	ZINFO1: Platform
0xE9A0	Error when loading the OPC UA project file
	ZINFO1: Platform

Event ID	Description
	ZINFO3 - Bit 0: Error code
0xE9A1	OPC UA: No FSC enabled
	ZINFO1: Platform
0xE9A2	OPC UA: TAR file invalid
	ZINFO1: Platform
	ZINFO3: Error code
0xE9A3	OPC UA: Internal error of the OPC UA server
	ZINFO1: Platform
	ZINFO3: Error code
0xE9A4	OPC UA: Hardware configuration of the control is not loaded, Server is not started
	ZINFO1: Platform
0xE9A5	OPC UA blocked by user, start of the server was prevented
	ZINFO1: Platform
0xE9A6	OPC UA server was started
	ZINFO1: Platform
0xE9A7	OPC UA server was stopped
	ZINFO1: Platform
0xE9A8	OPC UA was disabled by the user
	ZINFO1: Platform
0xE9A9	OPC UA was enabled by the user
	ZINFO1: Platform
0xE9AA	OPC UA: Lock by S7 configuration (access settings)
	ZINFO1: Platform
0xE9AB	OPC UA and WebVisu project not allowed at the same time
	ZINFO1: Platform
0xEA00	Internal error - Please contact the hotline!
	PK: Not relevant to user
	DatID: Not user relevant
0xEA01	Internal error - Please contact the hotline!
	PK: Not user relevant
	ZINFO1: Slot
	DatID: Not user relevant
0xEA02	SBUS: Internal error (internal plugged sub module not recognized)
	PK: Not user relevant
	ZINFO1: Slot
	ZINFO2: Type identifier target
	ZINFO3: Type identifier
	DatID: Not user relevant

Event ID	Description
0xEA03	SBUS: Communication error between CPU and IO controller
	OB: Operating mode
	0: Configuration in operating condition RUN
	1: STOP (update)
	2: STOP (memory reset)
	3: STOP (auto initialization)
	4: STOP (internal)
	5: STARTUP (cold start)
	6: STARTUP (restart/warm start)
	7: STARTUP (hot restart)
	9: RUN
	10: HALT
	11: COUPLING
	12: UPDATING
	13: DEFECTIVE
	14: Error search mode
	15: De-energised
	253: Process image release in STOP
	254: Watchdog
	255: Not set
	PK: Not user relevant
	ZINFO1: Slot
	ZINFO2: Status
	0: OK
	1: Error
	2: Empty
	3: Busy
	4: Time out
	5: Internal blocking
	6: Too many telegrams
	7: Not Connected
	8: Unknown
	DatID: Not user relevant
0xEA04	SBUS: Multiple configuration of a periphery address
	ZINFO1: Periphery address
	ZINFO2: Slot
	ZINFO3: Data width
0xEA05	Internal error - Please contact the hotline!

Event ID	Description
0xEA07	Internal error - Please contact the hotline!
0xEA08	SBUS: Configured input data width not the same as the connected input data width
	ZINFO1: Configured input data width
	ZINFO2: Slot
	ZINFO3: Input data width of the connected component
0xEA09	SBUS: Configured output data width not the same as the connected output data width
	ZINFO1: Configured output data width
	ZINFO2: Slot
	ZINFO3: Output data width of the plugged component
0xEA0A	SBUS: Internal error (internal plugged sub module wrong)
	PK: Not user relevant
	ZINFO1: Slot
	ZINFO2: Type identifier target
	3: PROFINET-CPU
	4: EtherCAT-CPU
	ZINFO3: Type identifier
	3: PROFINET-CPU
	4: EtherCAT-CPU
	DatID: Not user relevant
0xEA10	SBUS: Input periphery address outside the periphery area
	ZINFO1: Periphery address
	ZINFO2: Slot
	ZINFO3: Data width
0xEA11	SBUS: Output periphery address outside the periphery area
	ZINFO1: Periphery address
	ZINFO2: Slot
	ZINFO3: Data width
0xEA12	SBUS: Error in writing dataset
	ZINFO1: Slot
	ZINFO2: Dataset number
	ZINFO3: Dataset length
0xEA14	SBUS: Multiple configuration of a periphery address (diagnostic address)
	ZINFO1: Periphery address
	ZINFO2: Slot
	ZINFO3: Data width
0xEA15	Internal error - Please contact the hotline!
	ZINFO2: Slot of the master
0xEA18	SBUS: Error in mapping the master periphery

PK: Not user relevant ZINFO2: HW slot ZINFO3: Interface type DatID: Not user relevant OXEA1A SBUS: Error in access to SBUS FPGA address table PK: Not user relevant ZINFO2: HW slot ZINFO3: Table O: Read 1: Writing DatID: Not user relevant OXEA20 Error: RS485 interface is not pre-set to PROFIBUS DP master bus a PROFIBUS DP master is configured OXEA21 Error: Configuration RS485 interface X2/X3: PROFIBUS DP master is configured but missing ZINFO2: Interface X is configured incorrectly OXEA22 Error: Configuration RS485 interface X2: Value is outside the limits ZINFO2: Configuration for X2 OXEA23 Error: Configuration RS485 interface X2: Value is outside the limits ZINFO2: Configuration for X2 OXEA24 Error: Configuration for X3 OXEA24 Error: Configuration RS485 interface X2/X3: Interface/protocol missing, default settings are used ZINFO2: Configuration for X3 OXEA24 Internal error - Please contact the hotline! ZINFO3: Not user relevant ZINFO3: Not user relevant ZINFO3: Not user relevant ZINFO4: Version of the CP ZINFO5: Not user relevant ZINFO7: Version of the CP ZINFO7: Version of the CP ZINFO7: Not user relevant	Event ID	Description
PK: Not user relevant ZINFO2: HW slot ZINFO3: Interface type DatID: Not user relevant OXEA1A SBUS: Error in access to SBUS FPGA address table PK: Not user relevant ZINFO2: HW slot ZINFO3: Table 0: Read 1: Writing DatID: Not user relevant OXEA20 Error: RS485 interface is not pre-set to PROFIBUS DP master bus a PROFIBUS DP master is configured OXEA21 Error: Configuration RS485 interface X2/X3: PROFIBUS DP master is configured but missing ZINFO2: Interface X is configured incorrectly OXEA22 Error: Configuration RS485 interface X2: Value is outside the limits ZINFO2: Configuration for X2 OXEA23 Error: Configuration RS485 interface X3: Value is outside the limits ZINFO2: Configuration for X3 OXEA24 Error: Configuration RS485 interface X2/X3: Interface/protocol missing, default settings are used ZINFO2: Configuration for X3 OXEA24 Internal error - Please contact the hotline! ZINFO3: Not user relevant DatID: Line OXEA41		ZINFO2: Slot of the master
ZINFO2: HW slot ZINFO3: Interface type DattD: Not user relevant SBUS: Error in access to SBUS FPGA address table PK: Not user relevant ZINFO2: HW slot ZINFO3: Table 0: Read 1: Writing DattD: Not user relevant 0xEA20 Error: RS485 interface is not pre-set to PROFIBUS DP master bus a PROFIBUS DP master is configured 0xEA21 Error: Configuration RS485 interface X2/X3: PROFIBUS DP master is configured but missing ZINFO2: Interface X is configured incorrectly 0xEA22 Error: Configuration RS485 interface X2: Value is outside the limits ZINFO2: Configuration for X2 0xEA23 Error: Configuration RS485 interface X2: Value is outside the limits ZINFO2: Configuration for X2 0xEA24 Error: Configuration RS485 interface X2/X3: Interface/protocol missing, default settings are used full for the configuration for X3 0xEA24 Internal error - Please contact the hotline! ZINFO3: Not user relevant ZINFO3: Not user relevant ZINFO3: Not user relevant ZINFO1: Version of the CP PK: File number ZINFO1: Version of the CP ZINFO2: Not user relevant DattD: Line 0xEA41 Internal error - Please contact the hotline!	0xEA19	Internal error - Please contact the hotline!
ZINFO3: Interface type DatID: Not user relevant SBUS: Error in access to SBUS FPGA address table PK: Not user relevant ZINFO2: HW slot ZINFO3: Table 0: Read 1: Writing DatID: Not user relevant 0xEA20 Error: RS485 interface is not pre-set to PROFIBUS DP master bus a PROFIBUS DP master is configured 0xEA21 Error: Configuration RS485 interface X2/X3: PROFIBUS DP master is configured but missing ZINFO2: Interface X is configured incorrectly 0xEA22 Error: Configuration RS485 interface X2/X3: PROFIBUS DP master is configured but missing ZINFO2: Configuration for X2 0xEA23 Error: Configuration RS485 interface X3: Value is outside the limits ZINFO2: Configuration for X2 0xEA24 Error: Configuration RS485 interface X2/X3: Interface/protocol missing, default settings are used ZINFO3: Configuration for X3 0xEA24 Internal error - Please contact the hotline! ZINFO1: Status ZINFO2: Not user relevant ZINFO3: Not user relevant ZINFO4: Not user relevant ZINFO3: Not user relevant ZINFO4: Not user relevant ZINFO3: Not user relevant ZINFO4: Not user relevant		PK: Not user relevant
DatID: Not user relevant SBUS: Error in access to SBUS FPGA address table PK: Not user relevant ZINFO2: HW slot ZINFO3: Table 0: Read 1: Writing DatID: Not user relevant 0xEA20 Error: RS485 interface is not pre-set to PROFIBUS DP master bus a PROFIBUS DP master is configured 0xEA21 Error: Configuration RS485 interface X2/X3: PROFIBUS DP master is configured but missing ZINFO2: Interface X is configured incorrectly 0xEA22 Error: Configuration RS485 interface X2: Value is outside the limits ZINFO2: Configuration for X2 0xEA23 Error: Configuration RS485 interface X3: Value is outside the limits ZINFO2: Configuration for X2 0xEA24 Error: Configuration RS485 interface X2/X3: Interface/protocol missing, default settings are used Used Configuration for X2 ZINFO3: Configuration for X2 ZINFO3: Configuration for X3 0xEA30 Internal error - Please contact the hottine! ZINFO1: Status ZINFO2: Not user relevant ZINFO3: Not user relevant ZINFO4: Not user relevant ZINFO3: Not user relevant ZINFO4: Not user relevant ZINFO3: Not user relevant ZINFO4: Not user relevant ZINFO4: Not user relevant ZINFO5: Not user relevant ZINFO6: Not		ZINFO2: HW slot
SBUS: Error in access to SBUS FPGA address table PK: Not user relevant ZINFO2: HW slot ZINFO3: Table 0: Read 1: Writing DatID: Not user relevant OXEA20 Error: RS485 interface is not pre-set to PROFIBUS DP master bus a PROFIBUS DP master is configured OXEA21 Error: Configuration RS485 interface X2/X3: PROFIBUS DP master is configured but missing ZINFO2: Interface X is configured incorrectly OXEA22 Error: Configuration RS485 interface X2: Value is outside the limits ZINFO2: Configuration for X2 OXEA23 Error: Configuration RS485 interface X3: Value is outside the limits ZINFO2: Configuration for X2 OXEA24 Error: Configuration RS485 interface X2:X3: Interface/protocol missing, default settings are used ZINFO2: Configuration for X3 OXEA24 Internal error - Please contact the hotline! ZINFO3: Not user relevant ZINFO3: Not user relevant ZINFO3: Not user relevant ZINFO3: Not user relevant ZINFO1: Version of the CP ZINFO2: Not user relevant ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Line OXEA41 Internal error - Please contact the hotline!		ZINFO3: Interface type
PK: Not user relevant ZINFO2: HW slot ZINFO3: Table 0: Read 1: Writing DatID: Not user relevant 0xEA20 Error: RS485 interface is not pre-set to PROFIBUS DP master bus a PROFIBUS DP master is configured 0xEA21 Error: Configuration RS485 interface X2/X3: PROFIBUS DP master is configured but missing ZINFO2: Interface X is configured incorrectly 0xEA22 Error: Configuration RS485 interface X2: Value is outside the limits ZINFO2: Configuration for X2 0xEA23 Error: Configuration RS485 interface X3: Value is outside the limits ZINFO2: Configuration RS485 interface X3: Value is outside the limits ZINFO2: Configuration for X2 0xEA24 Error: Configuration RS485 interface X2/X3: Interface/protocol missing, default settings are used ZINFO2: Configuration for X3 0xEA24 Error: Configuration for X2 ZINFO3: Configuration for X3 0xEA30 Internal error - Please contact the hotline! ZINFO1: Status ZINFO2: Not user relevant ZINFO3: Not user relevant ZINFO3: Not user relevant ZINFO1: Version of the CP ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Line 0xEA41 Internal error - Please contact the hotline!		DatID: Not user relevant
ZINFO2: HW slot ZINFO3: Table 0: Read 1: Writing DatID: Not user relevant 0xEA20	0xEA1A	SBUS: Error in access to SBUS FPGA address table
ZINFO3: Table 0: Read 1: Writing DatID: Not user relevant 0xEA20 Error: RS485 interface is not pre-set to PROFIBUS DP master bus a PROFIBUS DP master is configured 0xEA21 Error: Configuration RS485 interface X2/X3: PROFIBUS DP master is configured but missing ZINFO2: Interface X is configured incorrectly 0xEA22 Error: Configuration RS485 interface X2: Value is outside the limits ZINFO2: Configuration RS485 interface X3: Value is outside the limits ZINFO2: Configuration RS485 interface X3: Value is outside the limits ZINFO2: Configuration for X2 0xEA23 Error: Configuration for X3 0xEA24 Error: Configuration RS485 interface X2/X3: Interface/protocol missing, default settings are used ZINFO2: Configuration for X2 ZINFO3: Configuration for X3 0xEA30 Internal error - Please contact the hotline! ZINFO3: Not user relevant ZINFO3: Not user relevant OxEA40 Internal error - Please contact the hotline! OxEA40 Internal error - Please contact the hotline! ZINFO3: Not user relevant		PK: Not user relevant
0: Read 1: Writing DatID: Not user relevant 0xEA20 Error: RS485 interface is not pre-set to PROFIBUS DP master bus a PROFIBUS DP master is configured 0xEA21 Error: Configuration RS485 interface X2/X3: PROFIBUS DP master is configured but missing ZINFO2: Interface X is configured incorrectly 0xEA22 Error: Configuration RS485 interface X2: Value is outside the limits ZINFO2: Configuration RS485 interface X3: Value is outside the limits ZINFO2: Configuration for X2 0xEA23 Error: Configuration RS485 interface X3: Value is outside the limits ZINFO2: Configuration for X3 0xEA24 Error: Configuration RS485 interface X2/X3: Interface/protocol missing, default settings are used ZINFO3: Configuration for X2 ZINFO3: Configuration for X3 0xEA30 Internal error - Please contact the hotline! ZINFO1: Status ZINFO2: Not user relevant 0xEA40 Internal error - Please contact the hotline! OB: Slot of the CP PK: File number ZINFO1: Version of the CP ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Line 0xEA41 Internal error - Please contact the hotline!		ZINFO2: HW slot
1: Writing DatID: Not user relevant 0xEA20 Error: RS485 interface is not pre-set to PROFIBUS DP master bus a PROFIBUS DP master is configured 0xEA21 Error: Configuration RS485 interface X2/X3: PROFIBUS DP master is configured but missing ZINFO2: Interface X is configured incorrectly 0xEA22 Error: Configuration RS485 interface X2: Value is outside the limits ZINFO2: Configuration for X2 0xEA23 Error: Configuration RS485 interface X3: Value is outside the limits ZINFO2: Configuration RS485 interface X3: Value is outside the limits ZINFO2: Configuration for X3 0xEA24 Error: Configuration for X3 0xEA24 Error: Configuration RS485 interface X2/X3: Interface/protocol missing, default settings are used ZINFO2: Configuration for X3 0xEA30 Internal error - Please contact the hotline! ZINFO1: Status ZINFO2: Not user relevant ZINFO3: Not user relevant DXEA40 Internal error - Please contact the hotline! OB: Slot of the CP PK: File number ZINFO1: Version of the CP ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Line 0xEA41 Internal error - Please contact the hotline!		ZINFO3: Table
DatID: Not user relevant 0xEA20		0: Read
DXEA20 Error: RS485 interface is not pre-set to PROFIBUS DP master bus a PROFIBUS DP master is configured DXEA21 Error: Configuration RS485 interface X2/X3: PROFIBUS DP master is configured but missing ZINFO2: Interface X is configured incorrectly DXEA22 Error: Configuration RS485 interface X2: Value is outside the limits ZINFO2: Configuration for X2 DXEA23 Error: Configuration RS485 interface X3: Value is outside the limits ZINFO2: Configuration for X3 DXEA24 Error: Configuration RS485 interface X2/X3: Interface/protocol missing, default settings are used ZINFO2: Configuration for X2 ZINFO3: Configuration for X2 ZINFO3: Configuration for X3 DXEA30 Internal error - Please contact the hotline! ZINFO1: Status ZINFO2: Not user relevant ZINFO3: Not user relevant DXEA40 Internal error - Please contact the hotline! DXEA40 Internal error - Please contact the hotline! ZINFO1: Version of the CP PK: File number ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Line DXEA41 Internal error - Please contact the hotline!		1: Writing
configured Error: Configuration RS485 interface X2/X3: PROFIBUS DP master is configured but missing ZINFO2: Interface X is configured incorrectly 0xEA22		DatID: Not user relevant
ZINFO2: Interface X is configured incorrectly Error: Configuration RS485 interface X2: Value is outside the limits ZINFO2: Configuration RS485 interface X3: Value is outside the limits ZINFO2: Configuration RS485 interface X3: Value is outside the limits ZINFO2: Configuration for X3 0xEA24 Error: Configuration RS485 interface X2/X3: Interface/protocol missing, default settings are used ZINFO2: Configuration for X2 ZINFO3: Configuration for X3 0xEA30 Internal error - Please contact the hotline! ZINFO1: Status ZINFO2: Not user relevant ZINFO3: Not user relevant 0xEA40 Internal error - Please contact the hotline! OB: Slot of the CP PK: File number ZINFO1: Version of the CP ZINFO2: Not user relevant ZINFO3: Not user relevant ZINFO3: Not user relevant DatID: Line 0xEA41 Internal error - Please contact the hotline!	0xEA20	
OxEA22 Error: Configuration RS485 interface X2: Value is outside the limits ZINFO2: Configuration for X2 Error: Configuration RS485 interface X3: Value is outside the limits ZINFO2: Configuration RS485 interface X3: Value is outside the limits ZINFO2: Configuration for X3 OXEA24 Error: Configuration RS485 interface X2/X3: Interface/protocol missing, default settings are used ZINFO2: Configuration for X2 ZINFO3: Configuration for X3 OXEA30 Internal error - Please contact the hotline! ZINFO1: Status ZINFO2: Not user relevant ZINFO3: Not user relevant OXEA40 Internal error - Please contact the hotline! OB: Slot of the CP PK: File number ZINFO1: Version of the CP ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Line OXEA41 Internal error - Please contact the hotline!	0xEA21	Error: Configuration RS485 interface X2/X3: PROFIBUS DP master is configured but missing
ZINFO2: Configuration for X2 Error: Configuration RS485 interface X3: Value is outside the limits ZINFO2: Configuration for X3 OXEA24 Error: Configuration RS485 interface X2/X3: Interface/protocol missing, default settings are used ZINFO2: Configuration for X2 ZINFO3: Configuration for X3 OXEA30 Internal error - Please contact the hotline! ZINFO1: Status ZINFO2: Not user relevant ZINFO3: Not user relevant OXEA40 Internal error - Please contact the hotline! OB: Slot of the CP PK: File number ZINFO1: Version of the CP ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Line OXEA41 Internal error - Please contact the hotline!		ZINFO2: Interface X is configured incorrectly
OxEA23 Error: Configuration RS485 interface X3: Value is outside the limits ZINFO2: Configuration for X3 Error: Configuration RS485 interface X2/X3: Interface/protocol missing, default settings are used ZINFO2: Configuration for X2 ZINFO3: Configuration for X3 OxEA30 Internal error - Please contact the hotline! ZINFO1: Status ZINFO2: Not user relevant ZINFO3: Not user relevant ZINFO3: Not user relevant OXEA40 Internal error - Please contact the hotline! OB: Slot of the CP PK: File number ZINFO1: Version of the CP ZINFO2: Not user relevant ZINFO3: Not user relevant ZINFO3: Not user relevant ZINFO3: Not user relevant Internal error - Please contact the hotline!	0xEA22	Error: Configuration RS485 interface X2: Value is outside the limits
ZINFO2: Configuration for X3 0xEA24 Error: Configuration RS485 interface X2/X3: Interface/protocol missing, default settings are used ZINFO2: Configuration for X2 ZINFO3: Configuration for X3 0xEA30 Internal error - Please contact the hotline! ZINFO1: Status ZINFO2: Not user relevant ZINFO3: Not user relevant OXEA40 Internal error - Please contact the hotline! OB: Slot of the CP PK: File number ZINFO1: Version of the CP ZINFO2: Not user relevant ZINFO3: Not user relevant ZINFO3: Not user relevant DatID: Line 0xEA41 Internal error - Please contact the hotline!		ZINFO2: Configuration for X2
OxEA24 Error: Configuration RS485 interface X2/X3: Interface/protocol missing, default settings are used ZINFO2: Configuration for X2 ZINFO3: Configuration for X3 OxEA30 Internal error - Please contact the hotline! ZINFO1: Status ZINFO2: Not user relevant ZINFO3: Not user relevant OxEA40 Internal error - Please contact the hotline! OB: Slot of the CP PK: File number ZINFO1: Version of the CP ZINFO2: Not user relevant ZINFO3: Not user relevant ZINFO3: Not user relevant DatID: Line OXEA41 Internal error - Please contact the hotline!	0xEA23	Error: Configuration RS485 interface X3: Value is outside the limits
used ZINFO2: Configuration for X2 ZINFO3: Configuration for X3 0xEA30 Internal error - Please contact the hotline! ZINFO1: Status ZINFO2: Not user relevant ZINFO3: Not user relevant OxEA40 Internal error - Please contact the hotline! OB: Slot of the CP PK: File number ZINFO1: Version of the CP ZINFO2: Not user relevant ZINFO3: Not user relevant ZINFO3: Not user relevant DatID: Line 0xEA41 Internal error - Please contact the hotline!		ZINFO2: Configuration for X3
ZINFO3: Configuration for X3 Internal error - Please contact the hotline! ZINFO1: Status ZINFO2: Not user relevant ZINFO3: Not user relevant OxEA40 Internal error - Please contact the hotline! OB: Slot of the CP PK: File number ZINFO1: Version of the CP ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Line OxEA41 Internal error - Please contact the hotline!	0xEA24	· · · · · · · · · · · · · · · · · · ·
Internal error - Please contact the hotline! ZINFO1: Status ZINFO2: Not user relevant ZINFO3: Not user relevant OxEA40 Internal error - Please contact the hotline! OB: Slot of the CP PK: File number ZINFO1: Version of the CP ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Line OxEA41 Internal error - Please contact the hotline!		ZINFO2: Configuration for X2
ZINFO1: Status ZINFO2: Not user relevant ZINFO3: Not user relevant 0xEA40 Internal error - Please contact the hotline! OB: Slot of the CP PK: File number ZINFO1: Version of the CP ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Line 0xEA41 Internal error - Please contact the hotline!		ZINFO3: Configuration for X3
ZINFO2: Not user relevant ZINFO3: Not user relevant OxEA40 Internal error - Please contact the hotline! OB: Slot of the CP PK: File number ZINFO1: Version of the CP ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Line OxEA41 Internal error - Please contact the hotline!	0xEA30	Internal error - Please contact the hotline!
ZINFO3: Not user relevant Internal error - Please contact the hotline! OB: Slot of the CP PK: File number ZINFO1: Version of the CP ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Line OxEA41 Internal error - Please contact the hotline!		ZINFO1: Status
OxEA40 Internal error - Please contact the hotline! OB: Slot of the CP PK: File number ZINFO1: Version of the CP ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Line OxEA41 Internal error - Please contact the hotline!		ZINFO2: Not user relevant
OB: Slot of the CP PK: File number ZINFO1: Version of the CP ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Line 0xEA41 Internal error - Please contact the hotline!		ZINFO3: Not user relevant
PK: File number ZINFO1: Version of the CP ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Line 0xEA41 Internal error - Please contact the hotline!	0xEA40	Internal error - Please contact the hotline!
ZINFO1: Version of the CP ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Line 0xEA41 Internal error - Please contact the hotline!		OB: Slot of the CP
ZINFO2: Not user relevant ZINFO3: Not user relevant DatID: Line 0xEA41 Internal error - Please contact the hotline!		PK: File number
ZINFO3: Not user relevant DatID: Line 0xEA41 Internal error - Please contact the hotline!		ZINFO1: Version of the CP
DatID: Line 0xEA41 Internal error - Please contact the hotline!		ZINFO2: Not user relevant
0xEA41 Internal error - Please contact the hotline!		ZINFO3: Not user relevant
		DatID: Line
OB: Slot of the CP	0xEA41	Internal error - Please contact the hotline!
		OB: Slot of the CP

Event ID	Description
	PK: File number
	ZINFO1: Version of the CP
	ZINFO2: Not user relevant
	ZINFO3: Not user relevant
	DatID: Line
0xEA50	PROFINET IO controller: Error in the configuration
	OB: Not user relevant
	PK: Not user relevant
	ZINFO1: Rack/slot of the controller
	ZINFO2: Device number
	ZINFO3: Slot at the device
	DatID: Not user relevant
0xEA51	PROFINET IO controller: There is no PROFINET IO controller at the configured slot
	PK: Not user relevant
	ZINFO1: Rack/slot of the controller
	ZINFO2: Recognized type identifier at the configured slot
	DatID: Not user relevant
0xEA52	PROFINET IO controller: Too many configured PROFINET IO controllers
	PK: Not user relevant
	ZINFO1: Number of configured controllers
	ZINFO2: Slot of the excessively configured controller
	DatID: Not user relevant
0xEA53	PROFINET IO controller: Too many configured PROFINET IO devices
	ZINFO1: Number of configured devices
	ZINFO2: Slot
	ZINFO3: Maximum possible number of devices
0xEA54	PROFINET IO controller: Multiple configuration of a periphery address or range too long
	0: Error type
	0: No error
	1: Range too long
	2: Input address already used
	3: Output address already used
	PK: Not user relevant
	ZINFO1: Logical address of the IO system
	ZINFO2: Rack/slot of the controller
	ZINFO3: Base address of the block which is too large
	DatID: Not user relevant
0xEA55	PROFINET IO controller: Too many slots or too high slot number configured

ZINFO1: Rack/slot of the controller ZINFO2: Device number ZINFO3: Number of configured slots or too high slot number 0xEA56 PROFINET IO controller: Too many subslots or too high sub ZINFO1: Rack/slot of the controller ZINFO2: Device number	o slot number configured
ZINFO3: Number of configured slots or too high slot number 0xEA56 PROFINET IO controller: Too many subslots or too high sub ZINFO1: Rack/slot of the controller ZINFO2: Device number	o slot number configured
0xEA56 PROFINET IO controller: Too many subslots or too high sub ZINFO1: Rack/slot of the controller ZINFO2: Device number	o slot number configured
ZINFO1: Rack/slot of the controller ZINFO2: Device number	-
ZINFO2: Device number	tnumbor
	tnumbor
ZINEGO Newstander of confirment and allot and a bid and allot	tnumber
ZINFO3: Number of configured subslots or too high sub slot	Tiumbei
0xEA57 PROFINET IO controller: The port configuration in the virtual	al device has no effect.
0xEA61 Internal error - Please contact the hotline!	
OB: File number	
PK: Slot of the controller	
ZINFO1: Firmware major version	
ZINFO2: Firmware minor version	
DatID: Line	
0xEA62 Internal error - Please contact the hotline!	
OB: File number.	
PK: Slot of the controller	
ZINFO1: Firmware major version	
ZINFO2: Firmware minor version	
DatID: Line	
0xEA63 Internal error - Please contact the hotline!	
OB: File number	
PK: Slot of the controller	
ZINFO1: Firmware major version	
ZINFO2: Firmware minor version	
DatID: Line	
0xEA64 PROFINET IO controller/EtherCAT-CP: Error in configuration	n
PK: Interface	
ZINFO1 - Bit 0: Too many devices	
ZINFO1 - Bit 1: Too many devices per second	
ZINFO1 - Bit 2: Too many input bytes per millisecond	
ZINFO1 - Bit 3: Too many output bytes per millisecond	
ZINFO1 - Bit 4: Too many input bytes per device	
ZINFO1 - Bit 5: Too many output bytes per device	
ZINFO1 - Bit 6: Too many productive connections	
ZINFO1 - Bit 7: Too many input bytes in the process image	
ZINFO1 - Bit 8: Too many output bytes in the process image	9
ZINFO1 - Bit 9: Configuration not available	

Event ID	Description
	ZINFO1 - Bit 10: Configuration invalid
	ZINFO1 - Bit 11: Refresh interval too small
	ZINFO1 - Bit 12: Refresh interval too large
	ZINFO1 - Bit 13: Invalid device number
	ZINFO1 - Bit 14: CPU is configured as an I device
	ZINFO1 - Bit 15: Assume IP address in another way. Is not supported for the IP address of the controller.
	ZINFO2 - Bit 0: Incompatible configuration (SDB version not supported)
	ZINFO2 - Bit 1: EtherCAT: EoE configured but not supported (Possible cause is a too short cycle time of the EtherCAT master system. When using EoE terminals, at least a cycle time of 4ms must be configured.)
	ZINFO2 - Bit 2: DC parameter invalid
	ZINFO2 - Bit 3: I device configuration invalid (slot gap)
	ZINFO2 - Bit 4: MRP configuration invalid (client)
	ZINFO2 - Bit 5: Transfer rate 10 MBit (HD/FD) configured but not supported
	ZINFO2 - Bit 6: Configuration block size exceeded
	ZINFO2 - Bit 7: Configuration invalid (IRT SyncMaster is not supported)
	ZINFO2 - Bit 8: Transfer rate 100 MBit (HD) configured but not supporte
0xEA65	Internal error - Please contact the hotline!
	PK: Platform
	0: none
	8: CP
	9: Ethernet CP
	10: PROFINET CP
	12: EtherCAT CP
	16: CPU
	ZINFO1: ServiceID in which the error occurred
	ZINFO2: Command in which the error occurred
	1: Request
	2: Connect
	3: Error
0xEA66	PROFINET IO controller: Error in the communication stack
	OB: StackError.Service
	PK: Rack/slot
	ZINFO1: StackError.Error.Code
	ZINFO2: StackError.Error.Detail
	ZINFO3 - Position 0: StackError.Error.AdditionalDetail
	ZINFO3 - Position 8: StackError.Error.AreaCode
	DatID: StackError.DeviceRef

Event ID	Description
0xEA67	PROFINET IO controller: Error reading dataset
	OB: Rack/slot of the controller
	PK: Error type
	0: Dataset error local
	1: Dataset error stack
	2: Dataset error station
	ZINFO1: Dataset number
	ZINFO2: Dataset handle (caller)
	ZINFO3: Internal error code from PN stack
	DatID: Device
0xEA68	PROFINET IO controller: Error writing dataset
	OB: Rack/slot of the controller
	PK: Error type
	0: Dataset error local
	1: Dataset error stack
	2: Dataset error station
	ZINFO1: Dataset number
	ZINFO2: Dataset handle (caller)
	ZINFO3: Internal error code from PN stack
	DatID: Device
0xEA69	Internal error - Please contact the hotline!
	ZINFO1: Minimum version for the FPGA
	ZINFO2: Loaded FPGA version
0xEA6A	PROFINET IO controller: Service error in the communication stack
	OB: Service ID
	PK: Rack/slot
	ZINFO1: ServiceError.Code
	ZINFO2: ServiceError.Detail
	ZINFO3 - Position 0: ServiceError.AdditionalDetail
	ZINFO3 - Position 8: ServiceError.AreaCode
0xEA6B	PROFINET IO controller: Incorrect Vendor-ID
	OB: Operating mode
	0: Configuration in operating condition RUN
	1: STOP (update)
	2: STOP (memory reset)
	3: STOP (auto initialization)
	4: STOP (internal)
	5: STARTUP (cold start)

Event ID	Description
	6: STARTUP (restart/warm start)
	7: STARTUP (hot restart)
	9: RUN
	10: HALT
	11: COUPLING
	12: UPDATING
	13: DEFECTIVE
	14: Error search mode
	15: De-energised
	253: Process image release in STOP
	254: Watchdog
	255: Not set
	PK: Rack/slot
	ZINFO1: Device ID
	ZINFO2: Not user relevant
	ZINFO3: Not user relevant
	DatID: Not user relevant
0xEA6C	PROFINET IO controller: Incorrect Device-ID
	OB: Operating mode
	0: Configuration in operating condition RUN
	1: STOP (update)
	2: STOP (memory reset)
	3: STOP (auto initialization)
	4: STOP (internal)
	5: STARTUP (cold start)
	6: STARTUP (restart/warm start)
	7: STARTUP (hot restart)
	9: RUN
	10: HALT
	11: COUPLING
	12: UPDATING
	13: DEFECTIVE
	14: Error search mode
	15: De-energised
	253: Process image release in STOP
	254: Watchdog
	255: Not set
	PK: Rack/slot

Event ID	Description
	ZINFO1: Device ID
0xEA6D	PROFINET IO controller: No empty name
	OB: Operating mode
	0: Configuration in operating condition RUN
	1: STOP (update)
	2: STOP (memory reset)
	3: STOP (auto initialization)
	4: STOP (internal)
	5: STARTUP (cold start)
	6: STARTUP (restart/warm start)
	7: STARTUP (hot restart)
	9: RUN
	10: HALT
	11: COUPLING
	12: UPDATING
	13: DEFECTIVE
	14: Error search mode
	15: De-energised
	253: Process image release in STOP
	254: Watchdog
	255: Not set
	PK: Rack/slot
	ZINFO1: Device ID
	ZINFO2: Not user relevant
	ZINFO3: Not user relevant
	DatID: Not user relevant
0xEA6E	PROFINET IO controller: Wait for RPC response
	OB: Operating mode
	0: Configuration in operating condition RUN
	1: STOP (update)
	2: STOP (memory reset)
	3: STOP (auto initialization)
	4: STOP (internal)
	5: STARTUP (cold start)
	6: STARTUP (restart/warm start)
	7: STARTUP (hot restart)
	9: RUN
	10: HALT

Event ID	Description
	11: COUPLING
	12: UPDATING
	13: DEFECTIVE
	14: Error search mode
	15: De-energised
	253: Process image release in STOP
	254: Watchdog
	255: Not set
	PK: Rack/slot
	ZINFO1: Device ID
	ZINFO2: Not user relevant
	ZINFO3: Not user relevant
	DatID: Not user relevant
0xEA6F	PROFINET IO controller: PROFINET module deviation
	OB: Operating mode
	0: Configuration in operating condition RUN
	1: STOP (update)
	2: STOP (memory reset)
	3: STOP (auto initialization)
	4: STOP (internal)
	5: STARTUP (cold start)
	6: STARTUP (restart/warm start)
	7: STARTUP (hot restart)
	9: RUN
	10: HALT
	11: COUPLING
	12: UPDATING
	13: DEFECTIVE
	14: Error search mode
	15: De-energised
	253: Process image release in STOP
	254: Watchdog
	255: Not set
	PK: Rack/slot
	ZINFO1: Device ID
	ZINFO2: Not user relevant
	ZINFO3: Not user relevant
	DatID: Not user relevant

Event ID	Description
0xEA70	PROFINET IO controller: PROFINET stack configuration error
	OB: UnsupportedApiError.api
	PK: Rack/slot
	ZINFO1: UnsupportedApiError.slot
	ZINFO2: UnsupportedApiError.subslot
	DatID: UnsupportedApiError.deviceID
0xEA71	Internal error - Please contact the hotline!
	PK: Rack/slot
	ZINFO1: functionIndex
	ZINFO2: Not user relevant
0xEA72	Internal error - Please contact the hotline!
	OB: Connection number
	PK: Slot of the controller
	ZINFO1: Error cause
	129: PNIO
	207: RTA error
	218: AlarmAck
	219: IODConnectRes
	220: IODReleaseRes
	221: IOD/IOXControlRes
	222: IODReadRes
	223: IODWriteRes
	ZINFO2: ErrorDecode
	128: PNIORW: Service Read Write
	129: PNIO: Other Service or internal e.g. RPC errors
	130: Vendor specific
	ZINFO3: Error code (PN spec. V2.722 chapter 5.2.6)
	DatID: Device ID
0xEA81	Internal error - Please contact the hotline!
	OB: Not user relevant
	PK: Not user relevant
	ZINFO1: Filenamehash[0-3]
	ZINFO2: Filenamehash[4-7]
	ZINFO3: Line
	DatID: SvnRevision
0xEA82	Internal error - Please contact the hotline!
	OB: Not user relevant
	PK: Not user relevant

Event ID	Description
	ZINFO1: Filenamehash[0-3]
	ZINFO2: Filenamehash[4-7]
	ZINFO3: Line
	DatID: SvnRevision
0xEA83	Internal error - Please contact the hotline!
	OB: Not user relevant
	PK: Not user relevant
	ZINFO1: Filenamehash[0-3]
	ZINFO2: Filenamehash[4-7]
	ZINFO3: Line
	DatID: SvnRevision
0xEA91	Internal error - Please contact the hotline!
	OB: Current OB number
	PK: Core status
	0: INIT
	1: STOP
	2: READY
	3: PAUSE
	4: RUN
	ZINFO1: Filenamehash[0-3]
	ZINFO2: Filenamehash[4-7]
	ZINFO3: Line
	DatID: Current job number
0xEA92	Internal error - Please contact the hotline!
	OB: Current OB number
	PK: Core status
	0: INIT
	1: STOP
	2: READY
	3: PAUSE
	4: RUN
	ZINFO1: Filenamehash[0-3]
	ZINFO2: Filenamehash[4-7]
	ZINFO3: Line
	DatID: Current job number
0xEA93	Internal error - Please contact the hotline!
	OB: Current OB number
	PK: Core status

0: INIT	Event ID	Description
2: READY 3: PAUSE 4: RUN ZINFO1: Filenamehash[0-3] ZINFO2: Filenamehash[0-3] ZINFO3: Line DatID: Current job number 0xEA97 Internal error - Please contact the hotline! ZINFO3: Slot DxinFO3: Slot DxinFO4: File version on MMC/SD (if not 0) ZinFO2: File version of the SBUS module (if not 0) ZinFO2: File version of the SBUS module (if not 0) ZinFO3: Slot DxinFO3: Slo		0: INIT
3: PAUSE 4: RUN ZINFO1: Filenamehash[0-3] ZINFO2: Filenamehash[0-3] ZINFO3: Line Dattlb: Current job number 0xEA97 Internal error - Please contact the hottine! ZINFO3: Slot 0xEA98 Error in file reading via SBUS PK: Not user relevant ZINFO3: Slot Dattlb: Not user relevant ZINFO3: Slot Dattlb: Not user relevant ZINFO1: File version on MMC/SD (if not 0) ZINFO2: File version of the SBUS module (if not 0) ZINFO3: Slot Dattlb: Not user relevant 0xEA40 Internal error - Please contact the hottine! 0xEA40 OxEAA0 Internal error - Please contact the hottine! 0xEA40 S: STOP (update) 2: STOP (update) 2: STOP (internal) 5: STARTUP (rostart/warm start) 7: STARTUP (not restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		1: STOP
4: RUN ZINFO1: Filenamehash[0-3] ZINFO2: Filenamehash[4-7] ZINFO3: Line DatID: Current job number Internal error - Please contact the hotline! ZINFO3: Slot OxEA98 Error in file reading via SBUS PK: Not user relevant ZINFO3: Slot DatID: Not user relevant ZINFO3: Slot DatID: Not user relevant ZINFO3: Slot DatID: Not user relevant ZINFO1: File version on MMC/SD (if not 0) ZINFO2: File version on MMC/SD (if not 0) ZINFO3: Slot DatID: Not user relevant OXEAA0 Internal error - Please contact the hotline! O8: Current operating mode O3: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (memory reset) 3: STOP (internal) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		2: READY
ZINFO1: Filenamehash[0-3] ZINFO2: Filenamehash[4-7] ZINFO3: Line DattD: Current job number Internal error - Please contact the hotline! ZINFO3: Slot OxEA98 Error in file reading via SBUS PK: Not user relevant ZINFO3: Slot DattD: Not user relevant ZINFO3: Slot DattD: Not user relevant ZINFO1: File version on MMC/SD (if not 0) ZINFO2: File version on MMC/SD (if not 0) ZINFO3: Slot DattD: Not user relevant OXEA90 Internal error - Please contact the hotline! OXEAA0 STOP (update) 2: STOP (update) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		3: PAUSE
ZINFO2: Filenamehash[4-7] ZINFO3: Line DatID: Current job number		4: RUN
ZINFO3: Line DatID: Current job number 0xEA97		ZINFO1: Filenamehash[0-3]
DatID: Current job number 0xEA97		ZINFO2: Filenamehash[4-7]
Internal error - Please contact the hotline! ZINFO3: Slot OxEA98 Error in file reading via SBUS PK: Not user relevant ZINFO3: Slot DatID: Not user relevant ZINFO1: File version on MMC/SD (if not 0) ZINFO2: File version on MMC/SD (if not 0) ZINFO3: Slot DatID: Not user relevant ZINFO1: File version of the SBUS module (if not 0) ZINFO3: Slot DatID: Not user relevant OxEAA0 Internal error - Please contact the hotline! OB: Current operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (restart/warm start) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		ZINFO3: Line
ZINFO3: Slot Error in file reading via SBUS PK: Not user relevant ZINFO3: Slot DatID: Not user relevant OXEA99 Parameter assignment job could not be executed PK: Not user relevant ZINFO1: File version on MMC/SD (if not 0) ZINFO2: File version on MMC/SD (if not 0) ZINFO3: Slot DatID: Not user relevant OXEAA0 Internal error - Please contact the hotline! OB: Current operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		DatID: Current job number
OXEA98 Error in file reading via SBUS PK: Not user relevant ZINFO3: Slot DatID: Not user relevant OXEA99 Parameter assignment job could not be executed PK: Not user relevant ZINFO1: File version on MMC/SD (if not 0) ZINFO2: File version of the SBUS module (if not 0) ZINFO3: Slot DatID: Not user relevant OXEAA0 Internal error - Please contact the hotline! OB: Current operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode	0xEA97	Internal error - Please contact the hotline!
PK: Not user relevant ZINFO3: Slot DatID: Not user relevant OXEA99 Parameter assignment job could not be executed PK: Not user relevant ZINFO1: File version on MMC/SD (if not 0) ZINFO2: File version of the SBUS module (if not 0) ZINFO3: Slot DatID: Not user relevant OXEAA0 Internal error - Please contact the hotline! OB: Current operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		ZINFO3: Slot
ZINFO3: Slot DatID: Not user relevant OXEA99 Parameter assignment job could not be executed PK: Not user relevant ZINFO1: File version on MMC/SD (if not 0) ZINFO2: File version of the SBUS module (if not 0) ZINFO3: Slot DatID: Not user relevant OXEAA0 Internal error - Please contact the hotline! OB: Current operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode	0xEA98	Error in file reading via SBUS
DatID: Not user relevant OxEA99 Parameter assignment job could not be executed PK: Not user relevant ZINFO1: File version on MMC/SD (if not 0) ZINFO2: File version of the SBUS module (if not 0) ZINFO3: Slot DatID: Not user relevant OxEAA0 Internal error - Please contact the hotline! OB: Current operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		PK: Not user relevant
Parameter assignment job could not be executed PK: Not user relevant ZINFO1: File version on MMC/SD (if not 0) ZINFO2: File version of the SBUS module (if not 0) ZINFO3: Slot DatID: Not user relevant OXEAA0 Internal error - Please contact the hotline! OB: Current operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		ZINFO3: Slot
PK: Not user relevant ZINFO1: File version on MMC/SD (if not 0) ZINFO2: File version of the SBUS module (if not 0) ZINFO3: Slot DatID: Not user relevant OxEAA0 Internal error - Please contact the hotline! OB: Current operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		DatID: Not user relevant
ZINFO1: File version on MMC/SD (if not 0) ZINFO2: File version of the SBUS module (if not 0) ZINFO3: Slot DatID: Not user relevant OxEAA0 Internal error - Please contact the hotline! OB: Current operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode	0xEA99	Parameter assignment job could not be executed
ZINFO2: File version of the SBUS module (if not 0) ZINFO3: Slot DatID: Not user relevant OxEAA0 Internal error - Please contact the hotline! OB: Current operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		PK: Not user relevant
ZINFO3: Slot DatID: Not user relevant OxEAA0 Internal error - Please contact the hotline! OB: Current operating mode O: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		ZINFO1: File version on MMC/SD (if not 0)
DatID: Not user relevant OxEAA0 Internal error - Please contact the hotline! OB: Current operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		ZINFO2: File version of the SBUS module (if not 0)
OxEAAO Internal error - Please contact the hotline! OB: Current operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		ZINFO3: Slot
OB: Current operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		DatID: Not user relevant
0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode	0xEAA0	Internal error - Please contact the hotline!
1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		OB: Current operating mode
2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		0: Configuration in operating condition RUN
3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		1: STOP (update)
4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		2: STOP (memory reset)
5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		3: STOP (auto initialization)
6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		4: STOP (internal)
7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		5: STARTUP (cold start)
9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		6: STARTUP (restart/warm start)
10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		7: STARTUP (hot restart)
11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode		9: RUN
12: UPDATING 13: DEFECTIVE 14: Error search mode		10: HALT
13: DEFECTIVE 14: Error search mode		11: COUPLING
14: Error search mode		12: UPDATING
		13: DEFECTIVE
15: De-energised		14: Error search mode
		15: De-energised

Event ID	Description
	253: Process image release in STOP
	254: Watchdog
	255: Not set
	ZINFO1: Diagnostic address of the master
	ZINFO2: Not user relevant
	ZINFO3: Number of errors which occurred
0xEAB0	Invalid link mode
	OB: Current operating mode
	0: Configuration in operating condition RUN
	1: STOP (update)
	2: STOP (memory reset)
	3: STOP (auto initialization)
	4: STOP (internal)
	5: STARTUP (cold start)
	6: STARTUP (restart/warm start)
	7: STARTUP (hot restart)
	9: RUN
	10: HALT
	11: COUPLING
	12: UPDATING
	13: DEFECTIVE
	14: Error search mode
	15: De-energised
	253: Process image release in STOP
	254: Watchdog
	255: Not set
	ZINFO1: Diagnostic address of the master
	ZINFO2: Current connection mode
	1: 10Mbit half-duplex
	2: 10Mbit full-duplex
	3: 100Mbit half-duplex
	4: 100Mbit full-duplex
	5: Connection mode undefined
	6: Auto Negotiation
0xEAC0	Internal error - Please contact the hotline!
	ZINFO1: Error code
	2: Internal error
	3: Internal error

4: Internal error 5: Internal error 6: Internal error 7: Internal error 8: Internal error 2INFO1: Status 0XEB02 System error: Preset configuration does not match actual configuration 2INFO1: Bit mask slots 1-16 2INFO2: Bit mask slots 33-48 DatID: Bit mask slots 33-48 DatID: Bit mask slots 49-64 0XEB03 System error: IO mapping PK: Not user relevant 2INFO1: Error type 1: SDB parser error 2: Configured address already used 3: Mapping error 2INFO2: Slot (0=cannot be determined) DatID: Not user relevant 0XEB04 Bus: Multiple configuration of a periphery address 2INFO1: Periphery address 2INFO2: Slot DatID: Input DatID: Output 0XEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant 0XEB06 System error: Timeout with the isochronous process image 0XEB10 System error: Bus error PK: Not user relevant 2INFO1: Error type 96: Bus enumeration error 129: Queue execution error 129: Queue execution error 130: Error interrupt	Event ID	Description
6: Internal error 7: Internal error 8: Internal error SyncUnit configuration error ZINFO1: Status OXEB02 System error: Preset configuration does not match actual configuration ZINFO1: Bit mask slots 17-32 ZINFO2: Bit mask slots 17-32 ZINFO2: Bit mask slots 49-64 OXEB03 System error: IO mapping PK: Not user relevant ZINFO1: Error type 1: SDB parser error 2: Configured address already used 3: Mapping error ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant OXEB04 Bus: Multiple configuration of a periphery address ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output OXEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Output OXEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		4: Internal error
7: Internal error 8: Internal error 8: Internal error 8: Internal error SyncUnit configuration error ZINFO1: Status 0xEB02 System error: Preset configuration does not match actual configuration ZINFO1: Bit mask slots 1-16 ZINFO2: Bit mask slots 17-32 ZINFO3: Bit mask slots 33-48 DatlD: Bit mask slots 98-44 0xEB03 System error: IO mapping PK: Not user relevant ZINFO1: Error type 1: SDB parser error 2: Configured address already used 3: Mapping error ZINFO2: Slot (0=cannot be determined) DatlD: Not user relevant 0xEB04 Bus: Multiple configuration of a periphery address ZINFO1: Periphery address ZINFO2: Slot DatlD: Input DatlD: Output 0xEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant 0xEB06 System error: Timeout with the isochronous process image 0xEB10 System error: Bus error PK: Not user relevant ZINFO2: Slot O=cannot be determined) DatlD: Not user relevant 0xEB06 System error: Bus error PK: Not user relevant ZINFO2: Slot O=cannot be determined) DatlD: Not user relevant ZINFO2: Slot O=cannot be determined) DatlD: Not user relevant ZINFO2: Slot O=cannot be determined) DatlD: Not user relevant ZINFO2: Slot O=cannot be determined) DatlD: Not user relevant ZINFO2: Slot O=cannot be determined) DatlD: Not user relevant ZINFO2: Slot O=cannot be determined) DatlD: Not user relevant ZINFO2: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		5: Internal error
8: Internal error 8: Internal error 8: Internal error 0xEAD0 SyncUnit configuration error ZINFO1: Status 0xEB02 System error: Preset configuration does not match actual configuration ZINFO1: Bit mask slots 1-16 ZINFO2: Bit mask slots 17-32 ZINFO3: Bit mask slots 49-64 0xEB03 DatiD: Bit mask slots 49-64 0xEB03 PK: Not user relevant ZINFO1: Error type 1: SDB parser error 2: Configured address already used 3: Mapping error ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant 0xEB04 Bus: Multiple configuration of a periphery address ZINFO2: Slot DatID: Input DatID: Output 0xEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Slot (0-cannot be determined) DatID: Output 0xEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0-cannot be determined) DatID: Not user relevant ZINFO1: Fror ibye 96: Bus error: Timeout with the isochronous process image 0xEB10 System error: Bus error PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		6: Internal error
8; Internal error OXEADO SyncUnit configuration error ZINFO1: Status OXEB02 System error: Preset configuration does not match actual configuration ZINFO2: Bit mask slots 1-16 ZINFO2: Bit mask slots 17-32 ZINFO3: Bit mask slots 33-48 DatID: Bit mask slots 49-64 OXEB03 System error: IO mapping PK: Not user relevant ZINFO1: Error type 1: SDB parser error 2: Configured address already used 3: Mapping error ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant OXEB04 Bus: Multiple configuration of a periphery address ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output OXEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		7: Internal error
OXEADO SyncUnit configuration error ZINFO1: Status System error: Preset configuration does not match actual configuration ZINFO1: Bit mask slots 1-16 ZINFO2: Bit mask slots 1-16 ZINFO3: Bit mask slots 33-48 DatiD: Bit mask slots 49-64 OXEB03 System error: IO mapping PK: Not user relevant ZINFO1: Error type 1: SDB parser error 2: Configured address already used 3: Mapping error ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant OXEB04 Bus: Multiple configuration of a periphery address ZINFO2: Slot DatID: Input DatID: Output OXEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		8: Internal error
ZINFO1: Status		8: Internal error
OXEB02 System error: Preset configuration does not match actual configuration ZINFO1: Bit mask slots 1-16 ZINFO2: Bit mask slots 17-32 ZINFO3: Bit mask slots 33-48 DatID: Bit mask slots 49-64 OXEB03 OXEB03 System error: IO mapping PK: Not user relevant ZINFO1: Error type 1: SDB parser error 2: Configured address already used 3: Mapping error ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant OXEB04 Bus: Multiple configuration of a periphery address ZINFO2: Slot DatID: Input DatID: Input DatID: Output OXEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant OXEB06 System error: Bus structure for isochronous process image not suitable PK: Not user relevant OXEB06 System error: Bus error PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error	0xEAD0	SyncUnit configuration error
ZINFO1: Bit mask slots 1-16 ZINFO2: Bit mask slots 17-32 ZINFO3: Bit mask slots 33-48 DatiD: Bit mask slots 33-48 DatiD: Bit mask slots 49-64 0xEB03 System error: IO mapping PK: Not user relevant ZINFO1: Error type 1: SDB parser error 2: Configured address already used 3: Mapping error ZINFO2: Slot (0=cannot be determined) DatiD: Not user relevant 0xEB04 Bus: Multiple configuration of a periphery address ZINFO2: Slot DatiD: Input DatiD: Output 0xEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0=cannot be determined) DatiD: Not user relevant ZINFO2: Slot (0=cannot be determined) DatiD: Not user relevant ZINFO2: Slot (0=cannot be determined) DatiD: Not user relevant ZINFO2: Slot (0=cannot be determined) DatiD: Not user relevant ZINFO2: Slot (0=cannot be determined) DatiD: Not user relevant ZINFO2: Slot (0=cannot be determined) DatiD: Not user relevant ZINFO2: Slot (0=cannot be determined) DatiD: Not user relevant ZINFO2: Slot (0=cannot be determined) DatiD: Not user relevant ZINFO3: Bus error PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		ZINFO1: Status
ZINFO2: Bit mask slots 17-32	0xEB02	System error: Preset configuration does not match actual configuration
ZINFO3: Bit mask slots 33-48 DatID: Bit mask slots 49-64 0XEB03 System error: IO mapping PK: Not user relevant ZINFO1: Error type 1: SDB parser error 2: Configured address already used 3: Mapping error ZINFO2: Slot (0-cannot be determined) DatID: Not user relevant 0XEB04 Bus: Multiple configuration of a periphery address ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output 0XEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0-cannot be determined) DatID: Not user relevant ZINFO2: Slot (0-cannot be determined) DatID: Not user relevant ZINFO2: Slot (0-cannot be determined) DatID: Not user relevant ZINFO2: Slot (0-cannot be determined) DatID: Not user relevant 0XEB06 System error: Bus error PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		ZINFO1: Bit mask slots 1-16
DatID: Bit mask slots 49-64 0xEB03 System error: IO mapping PK: Not user relevant ZINFO1: Error type 1: SDB parser error 2: Configured address already used 3: Mapping error ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant 0xEB04 Bus: Multiple configuration of a periphery address ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output 0xEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0=cannot be determined)) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined)) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined)) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined)) DatID: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		ZINFO2: Bit mask slots 17-32
System error: IO mapping PK: Not user relevant ZINFO1: Error type 1: SDB parser error 2: Configured address already used 3: Mapping error ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant OXEB04 Bus: Multiple configuration of a periphery address ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output OXEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant XINFO1: System error: Timeout with the isochronous process image OXEB10 System error: Bus error PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		ZINFO3: Bit mask slots 33-48
PK: Not user relevant ZINFO1: Error type 1: SDB parser error 2: Configured address already used 3: Mapping error ZINFO2: Slot (0=cannot be determined) DatlD: Not user relevant Bus: Multiple configuration of a periphery address ZINFO1: Periphery address ZINFO2: Slot DatlD: Input DatlD: Output OXEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0=cannot be determined) DatlD: Not user relevant ZINFO2: Slot (0=cannot be determined) DatlD: Not user relevant ZINFO1: Timeout with the isochronous process image 0xEB10 System error: Bus error PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		DatID: Bit mask slots 49-64
ZINFO1: Error type 1: SDB parser error 2: Configured address already used 3: Mapping error ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant 0xEB04 Bus: Multiple configuration of a periphery address ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output 0xEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant 0xEB06 System error: Timeout with the isochronous process image 0xEB10 System error: Bus error PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error	0xEB03	System error: IO mapping
1: SDB parser error 2: Configured address already used 3: Mapping error ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant 0xEB04 Bus: Multiple configuration of a periphery address ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output 0xEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant OXEB06 System error: Timeout with the isochronous process image 0xEB10 System error: Bus error PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		PK: Not user relevant
2: Configured address already used 3: Mapping error ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant 0xEB04 Bus: Multiple configuration of a periphery address ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output 0xEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant OXEB06 System error: Timeout with the isochronous process image 0xEB10 System error: Bus error PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		ZINFO1: Error type
3: Mapping error ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant 0xEB04 Bus: Multiple configuration of a periphery address ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output 0xEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant 0xEB06 System error: Timeout with the isochronous process image 0xEB10 System error: Bus error PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		1: SDB parser error
ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant Bus: Multiple configuration of a periphery address ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output OxEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant OxEB06 System error: Timeout with the isochronous process image OxEB10 System error: Bus error PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		2: Configured address already used
DatID: Not user relevant 0xEB04 Bus: Multiple configuration of a periphery address ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output 0xEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant 0xEB06 System error: Timeout with the isochronous process image 0xEB10 System error: Bus error PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		3: Mapping error
DxEB04 Bus: Multiple configuration of a periphery address ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output OxEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant OxEB06 System error: Timeout with the isochronous process image OxEB10 System error: Bus error PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		ZINFO2: Slot (0=cannot be determined)
ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output OxEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant OxEB06 System error: Timeout with the isochronous process image OxEB10 System error: Bus error PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		DatID: Not user relevant
ZINFO2: Slot DatID: Input DatID: Output 0xEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant 0xEB06 System error: Timeout with the isochronous process image 0xEB10 System error: Bus error PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error	0xEB04	Bus: Multiple configuration of a periphery address
DatlD: Input DatlD: Output OxEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0=cannot be determined) DatlD: Not user relevant OxEB06 System error: Timeout with the isochronous process image OxEB10 System error: Bus error PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		ZINFO1: Periphery address
DatID: Output OxEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant OxEB06 System error: Timeout with the isochronous process image OxEB10 System error: Bus error PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		ZINFO2: Slot
OxEB05 System error: Bus structure for isochronous process image not suitable PK: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant OxEB06 System error: Timeout with the isochronous process image OxEB10 System error: Bus error PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		DatID: Input
PK: Not user relevant ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant 0xEB06 System error: Timeout with the isochronous process image 0xEB10 System error: Bus error PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		DatID: Output
ZINFO2: Slot (0=cannot be determined) DatID: Not user relevant 0xEB06	0xEB05	System error: Bus structure for isochronous process image not suitable
DatID: Not user relevant 0xEB06 System error: Timeout with the isochronous process image 0xEB10 System error: Bus error PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		PK: Not user relevant
0xEB06 System error: Timeout with the isochronous process image 0xEB10 System error: Bus error PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		ZINFO2: Slot (0=cannot be determined)
0xEB10 System error: Bus error PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error		DatID: Not user relevant
PK: Not user relevant ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error	0xEB06	System error: Timeout with the isochronous process image
ZINFO1: Error type 96: Bus enumeration error 128: General error 129: Queue execution error	0xEB10	System error: Bus error
96: Bus enumeration error 128: General error 129: Queue execution error		PK: Not user relevant
128: General error 129: Queue execution error		ZINFO1: Error type
129: Queue execution error		96: Bus enumeration error
		128: General error
130: Error interrupt		129: Queue execution error
		130: Error interrupt

Event ID	Description
	ZINFO2: Error on bus enumeration error (ZINFO1)
	DatID: Not user relevant
0xEB11	System error: Error during bus initialization
	PK: Not user relevant
	DatID: Not user relevant
0xEB15	Bus FMM message
	ZINFO1: FMM message
0xEB20	System error: Interrupt information undefined
0xEB21	System error: Accessing configuration data
	ZINFO2: Not user relevant
	ZINFO3: Not user relevant
	DatID: Not user relevant
0xEC02	EtherCAT: Configuration warning
	ZINFO1: Error code
	1: Number of slave stations is not supported
	2: Master system ID invalid
	3: Slot invalid
	4: Master configuration invalid
	5: Master type invalid
	6: Slave diagnostic address invalid
	7: Slave address invalid
	8: Slave module IO configuration invalid
	9: Logical address already in use
	10: Internal error
	11: IO mapping error
	12: Error
	13: Error in initialising the EtherCAT stack (is entered by the CP)
	14: Slave station number already occupied by virtual device
	ZINFO2: Station number
0xEC03	EtherCAT: Configuration error
	PK: Not user relevant
	ZINFO1: Error code
	1: Number of slave stations is not supported
	2: Master system ID invalid
	3: Slot invalid
	4: Master configuration invalid
	5: Master type invalid
	6: Slave diagnostic address invalid

7: Slave address invalid 8: Slave module IO configuration invalid 9: Logical address already in use 10: Internal error 11: IO mapping error 12: Error 13: Error in initialising the EtherCAT stack (is entered by the CP) 14: Slave station number already occupied by virtual device ZINFO2: Station number ZINFO3: Not user relevant DatID: Not user relevant DatID: Not user relevant DatID: Not user relevant ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output DatID: Output 0xEC05 EtherCAT: Check the set DC mode of the YASKAWA Sigma 5/7 drive OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cod start) 6: STARTUP (cod start) 7: STARTUP (cod start) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 264: Watchdog 255: Not set PK: Not user relevant	Event ID	Description
9: Logical address already in use 10: Internal error 11: IO mapping error 12: Error 13: Error in initialising the EtherCAT stack (is entered by the CP) 14: Slave station number already occupied by virtual device ZINFO2: Station number ZINFO3: Not user relevant DatID: Not user relevant DatID: Not user relevant DatID: Not user relevant ZINFO1: Periphery address PK: Not user relevant ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output DatID: Output DatID: Output CHERCAT: Check the set DC mode of the YASKAWA Sigma 5/7 drive OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (gatto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		7: Slave address invalid
10: Internal error 11: IO mapping error 12: Error 13: Error in initialising the EtherCAT stack (is entered by the CP) 14: Slave station number already occupied by virtual device ZINFO2: Station number ZINFO3: Not user relevant DatID: Not user relevant DatID: Not user relevant EtherCAT: Multiple configuration of a periphery address PK: Not user relevant ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output DatID: Output EtherCAT: Check the set DC mode of the YASKAWA Sigma 5/7 drive OXECO5 EtherCAT: Check the set DC mode of the YASKAWA Sigma 5/7 drive OXE Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 265: Not set		8: Slave module IO configuration invalid
11: IO mapping error 12: Error 13: Error initialising the EtherCAT stack (is entered by the CP) 14: Slave station number already occupied by virtual device ZINFO2: Station number ZINFO3: Not user relevant DatID: Not user relevant OXEC04 EtherCAT: Multiple configuration of a periphery address PK: Not user relevant ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Input DatID: Output OXEC05 EtherCAT: Check the set DC mode of the YASKAWA Sigma 5/7 drive OB: Operating mode O: Configuration in operating condition RUN 1: STOP (update) 2: STOP (update) 2: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (restart/warm start) 7: STARTUP (restart/warm start) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		9: Logical address already in use
12: Error 13: Error in initialising the EtherCAT stack (is entered by the CP) 14: Slave station number already occupied by virtual device ZINFO2: Station number ZINFO3: Not user relevant DatID: Not user relevant OXEC04 EtherCAT: Multiple configuration of a periphery address PK: Not user relevant ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output OXEC05 EtherCAT: Check the set DC mode of the YASKAWA Sigma 5/7 drive OB: Operating mode O: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DE-ECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		10: Internal error
13: Error in initialising the EtherCAT stack (is entered by the CP) 14: Slave station number already occupied by virtual device ZINFO2: Station number ZINFO3: Not user relevant DatID: Not user relevant DatID: Not user relevant OXEC04 EtherCAT: Multiple configuration of a periphery address PK: Not user relevant ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output DatID: Output OXEC05 EtherCAT: Check the set DC mode of the YASKAWA Sigma 5/7 drive OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (restart/warm start) 7: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		11: IO mapping error
14: Slave station number already occupied by virtual device ZINFO2: Station number ZINFO3: Not user relevant DatID: Not user relevant DatID: Not user relevant EtherCAT: Multiple configuration of a periphery address PK: Not user relevant ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output OXEC05 EtherCAT: Check the set DC mode of the YASKAWA Sigma 5/7 drive OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		12: Error
ZINFO2: Station number ZINFO3: Not user relevant DatID: Not user relevant DatID: Not user relevant EtherCAT: Multiple configuration of a periphery address PK: Not user relevant ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output DatID: Output OXEC05 EtherCAT: Check the set DC mode of the YASKAWA Sigma 5/7 drive OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		13: Error in initialising the EtherCAT stack (is entered by the CP)
ZINFO3: Not user relevant DatID: Not user relevant OXEC04 EtherCAT: Multiple configuration of a periphery address PK: Not user relevant ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output EtherCAT: Check the set DC mode of the YASKAWA Sigma 5/7 drive OXEC05 EtherCAT: Check the set DC mode of the YASKAWA Sigma 5/7 drive OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		14: Slave station number already occupied by virtual device
DatID: Not user relevant EtherCAT: Multiple configuration of a periphery address PK: Not user relevant ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output EtherCAT: Check the set DC mode of the YASKAWA Sigma 5/7 drive OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (rostart/warm start) 7: STARTUP (not restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		ZINFO2: Station number
OXEC04 EtherCAT: Multiple configuration of a periphery address PK: Not user relevant ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output OXEC05 EtherCAT: Check the set DC mode of the YASKAWA Sigma 5/7 drive OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		ZINFO3: Not user relevant
PK: Not user relevant ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output OXEC05 EtherCAT: Check the set DC mode of the YASKAWA Sigma 5/7 drive OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		DatID: Not user relevant
ZINFO1: Periphery address ZINFO2: Slot DatID: Input DatID: Output OxEC05 EtherCAT: Check the set DC mode of the YASKAWA Sigma 5/7 drive OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set	0xEC04	EtherCAT: Multiple configuration of a periphery address
ZINFO2: Slot DatID: Input DatID: Output OXEC05 EtherCAT: Check the set DC mode of the YASKAWA Sigma 5/7 drive OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		PK: Not user relevant
DatID: Input DatID: Output DatID: Output EtherCAT: Check the set DC mode of the YASKAWA Sigma 5/7 drive OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		ZINFO1: Periphery address
DatID: Output EtherCAT: Check the set DC mode of the YASKAWA Sigma 5/7 drive OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		ZINFO2: Slot
EtherCAT: Check the set DC mode of the YASKAWA Sigma 5/7 drive OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		DatID: Input
OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		DatID: Output
0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set	0xEC05	EtherCAT: Check the set DC mode of the YASKAWA Sigma 5/7 drive
1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		OB: Operating mode
2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		0: Configuration in operating condition RUN
3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		1: STOP (update)
4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		2: STOP (memory reset)
5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		3: STOP (auto initialization)
6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		4: STOP (internal)
7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		5: STARTUP (cold start)
9: RUN 10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		6: STARTUP (restart/warm start)
10: HALT 11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		7: STARTUP (hot restart)
11: COUPLING 12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		9: RUN
12: UPDATING 13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		10: HALT
13: DEFECTIVE 14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		11: COUPLING
14: Error search mode 15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		12: UPDATING
15: De-energised 253: Process image release in STOP 254: Watchdog 255: Not set		13: DEFECTIVE
253: Process image release in STOP 254: Watchdog 255: Not set		14: Error search mode
254: Watchdog 255: Not set		15: De-energised
255: Not set		253: Process image release in STOP
		254: Watchdog
PK: Not user relevant		255: Not set
		PK: Not user relevant

Event ID	Description
	ZINFO1: Station address of the EtherCAT device
	ZINFO2: Error code
	1: WARNING: For the drive the DC Beckhoff mode is recommended (DC reference clock is not in Beckhoff Mode)!
	2: NOTE: For the drive the DC Hilscher mode is recommended (DC reference clock is not in Beckhoff Mode)!
	3: The station address could not be determined for checking (station address in ZINFO1 is accordingly 0)
	4: The slave information could not be determined for checking (station address in ZINFO1 is accordingly 0)
	5: The EtherCAT status of the drive could not be determined
	6: Error when sending the SDO request (for further information, the (subsequent) event with the ID 0xED60 is to be analysed on the CP)
	7: Drive returns error in the SDO response (for further information, the (subsequent) event with the ID 0xED60 is to be analysed on the CP)
	8: SDO time out, DC mode could not be determined (for further information, the (subsequent) event with the ID 0xED60 is to be analysed on the CP)
	ZINFO3: Not user relevant
	DatID: Not user relevant
0xEC10	EtherCAT: Recovery bus with all slaves
	ZINFO1 - Position 0: New status
	0: Undefined/Unkown
	1: Init
	2: PreOp
	3: Bootstrap
	4: SafeOp
	8: Op
	ZINFO1 - Position 8: Previous status
	0: Undefined/Unkown
	1: Init
	2: PreOp
	3: Bootstrap
	4: SafeOp
	8: Op
	ZINFO2: Diagnostic address of the station
	ZINFO3: Number of stations, which are not in the same state as the master
	DatID: Station not available
	DatID: Station available
	DatID: Input address
	DatID: Output address

Event ID	Description
0xEC11	EtherCAT: Recovery bus with missing slaves
	ZINFO1 - Position 0: New status
	0: Undefined/Unkown
	1: Init
	2: PreOp
	3: Bootstrap
	4: SafeOp
	8: Op
	ZINFO1 - Position 8: Previous status
	0: Undefined/Unkown
	1: Init
	2: PreOp
	3: Bootstrap
	4: SafeOp
	8: Op
	ZINFO2: Diagnostic address of the master
	ZINFO3: Number of stations which are not in the same state as the master
	DatID: Station not available
	DatID: Station available
	DatID: Input address
	DatID: Output address
0xEC12	EtherCAT: Recovery slave
	ZINFO1 - Position 0: New status
	0: Undefined/Unkown
	1: Init
	2: PreOp
	3: Bootstrap
	4: SafeOp
	8: Op
	ZINFO1 - Position 8: Previous status
	0: Undefined/Unkown
	1: Init
	2: PreOp
	3: Bootstrap
	4: SafeOp
	8: Op
	ZINFO2: Diagnostic address of the station
	ZINFO3: AL status code

Event ID	Description
	DatID: Station not available
	DatID: Station available
	DatID: Input address
	DatID: Output address
0xEC30	EtherCAT: Topology OK
	ZINFO2: Diagnostic address of the master
0xEC40	Bus cycle time infringement resolved
	ZINFO2: Logical address of the IO system
0xEC50	EtherCAT: Distributed clocks (DC) out of sync
	OB: Operating mode
	0: Configuration in operating condition RUN
	1: STOP (update)
	2: STOP (memory reset)
	3: STOP (auto initialization)
	4: STOP (internal)
	5: STARTUP (cold start)
	6: STARTUP (restart/warm start)
	7: STARTUP (hot restart)
	9: RUN
	10: HALT
	11: COUPLING
	12: UPDATING
	13: DEFECTIVE
	14: Error search mode
	15: De-energised
	253: Process image release in STOP
	254: Watchdog
	255: Not set
	ZINFO2: Diagnostic address of the master
	ZINFO3: DC state change
	0: DC master out of sync
	1: DC slave stations out of sync
0xEC80	EtherCAT: Bus error resolved
	ZINFO1: Logical address of the IO system
	ZINFO3 - Position 0: Station number
	ZINFO3 - Position 11: IO system ID
	ZINFO3 - Bit 15: System ID DP/PN
0xED10	EtherCAT: Breakdown bus

Event ID	Description
	ZINFO1 - Position 0: New status
	0: Undefined/Unkown
	1: Init
	2: PreOp
	3: Bootstrap
	4: SafeOp
	8: Op
	ZINFO1 - Position 8: Previous status
	0: Undefined/Unkown
	1: Init
	2: PreOp
	3: Bootstrap
	4: SafeOp
	8: Op
	ZINFO2: Diagnostic address of the master
	ZINFO3: Number of stations which are not in the same state as the master
	DatID: Station available
	DatID: Station not available
	DatID: Input address
	DatID: Output address
0xED12	EtherCAT: Breakdown slave
	ZINFO1 - Position 0: New status
	0: Undefined/Unkown
	1: Init
	2: PreOp
	3: Bootstrap
	4: SafeOp
	8: Op
	ZINFO1 - Position 8: Previous status
	0: Undefined/Unkown
	1: Init
	2: PreOp
	3: Bootstrap
	4: SafeOp
	8: Op
	ZINFO2: Diagnostic address of the station
	ZINFO3: AlStatusCode
	0: No error

1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid output configuration 30: Invalid input configuration 30: Invalid input configuration 31: Invalid watchdog configuration 32: Slave station needs cold start 33: Slave station needs to be in INT state 34: Slave station needs to be in INT state 35: Slave station needs to be in INT state 36: Invalid output FMMU configuration 48: Invalid DC Sync configuration 48: Invalid DC Sync configuration 49: Invalid DC Latch configuration 49: Invalid DC Latch configuration 50: PLL error 51: Invalid DC Lice more 52: Invalid DC time out error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange Fileaccess Over EtherCAT 68: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Servo Drive Profile Over EtherCAT Datito: Station available Datito: Station available Datito: Station available Datito: Input address Datito: Output address	Event ID	Description
18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration 30: Invalid input configuration 30: Invalid input configuration 31: Invalid watchdog configuration 32: Slave station needs cold start 33: Slave station needs to be in INIT state 34: Slave station needs to be in SafeOp state 45: Invalid output FMMU configuration 46: Invalid input FMMU configuration 46: Invalid DC Sync configuration 46: Invalid DC Sync configuration 49: Invalid DC Uperror 50: PLL error 51: Invalid DC Io error 52: Invalid DC time out error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatiD: Station not available DatiD: Output address		1: Unspecified error
19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration 30: Invalid input configuration 31: Invalid watchdog configuration 31: Invalid watchdog configuration 32: Slave station needs to be in INIT state 34: Slave station needs to be in INIT state 35: Slave station needs to be in PreOp state 36: Slave station needs to be in SafeOp state 45: Invalid output FMMU configuration 46: Invalid input FMMU configuration 46: Invalid DC Sync configuration 48: Invalid DC Sync configuration 49: Invalid DC I cerror 51: Invalid DC I cerror 52: Invalid DC I cerror 55: Invalid DC I cerror 56: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Fileaccess Over EtherCAT 79: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatiD: Station not available DatiD: Station available DatiD: Output address		17: Invalid requested status change
20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration 30: Invalid input configuration 31: Invalid watchdog configuration 31: Invalid watchdog configuration 32: Slave station needs cold start 33: Slave station needs to be in INIT state 34: Slave station needs to be in PreOp state 35: Slave station needs to be in SafeOp state 45: Invalid output FMMU configuration 46: Invalid input FMMU configuration 48: Invalid DC Sync configuration 49: Invalid DC Sync configuration 49: Invalid DC Id error 51: Invalid DC Id error 52: Invalid DC Id error 53: Invalid DC time out error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Station available DatID: Input address DatID: Output address DatID: Over EtherCAT Bus state change without calling OB86 ZINFO1 - Position 0: New status		18: Unknown requested status
22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration 30: Invalid input configuration 31: Invalid watchdog configuration 31: Invalid watchdog configuration 32: Slave station needs to be in INIT state 34: Slave station needs to be in PreOp state 35: Slave station needs to be in SafeOp state 45: Invalid output FMMU configuration 46: Invalid input FMMU configuration 46: Invalid DC Sync configuration 48: Invalid DC Latch configuration 49: Invalid DC IO error 51: Invalid DC IO error 52: Invalid DC I'me out error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatlD: Station not available DattD: Input address DatlD: Output address DatlD: Output address DatlD: Output address DatlD: O: New status		19: Bootstrap not supported
23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager lypes 29: Invalid output configuration 30: Invalid input configuration 31: Invalid watchdog configuration 31: Invalid watchdog configuration 32: Slave station needs cold start 33: Slave station needs to be in INIT state 34: Slave station needs to be in PreOp state 35: Slave station needs to be in PreOp state 35: Slave station needs to be in SafeOp state 45: Invalid output FMMU configuration 46: Invalid input FMMU configuration 48: Invalid DC Sync configuration 49: Invalid DC Latch configuration 50: PLL error 51: Invalid DC IO error 52: Invalid DC IO error 55: Invalid DC Io error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Station available DatID: Station available DatID: Input address DatID: Output address		20: No valid firmware
24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration 30: Invalid input configuration 31: Invalid input configuration 31: Invalid watchdog configuration 32: Slave station needs cold start 33: Slave station needs to be in INIT state 34: Slave station needs to be in PreOp state 35: Slave station needs to be in SafeOp state 45: Invalid output FMMU configuration 46: Invalid input FMMU configuration 48: Invalid DC Sync configuration 49: Invalid DC Latch configuration 50: PLL error 51: Invalid DC Incertor 51: Invalid DC Incertor 52: Invalid DC Incertor 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Input address DatID: Output address DatID: Output address DatID: Output address DatID: Output address DatID: New status		22: Invalid mailbox configuration
25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration 30: Invalid input configuration 31: Invalid watchdog configuration 31: Invalid watchdog configuration 32: Slave station needs cold start 33: Slave station needs to be in INIT state 34: Slave station needs to be in PreOp state 35: Slave station needs to be in SafeOp state 45: Invalid output FMMU configuration 46: Invalid input FMMU configuration 48: Invalid DC Sync configuration 49: Invalid DC Latch configuration 50: PLL error 51: Invalid DC Io error 52: Invalid DC Imme out error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange Fileaccess Over EtherCAT 68: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Input address DatID: Output address DatID: Output address DatID: Output address DatID: Output address DatID: New status		23: Invalid sync manager configuration
26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration 30: Invalid input configuration 31: Invalid watchdog configuration 32: Slave station needs cold start 33: Slave station needs to be in INIT state 34: Slave station needs to be in PreOp state 35: Slave station needs to be in SafeOp state 45: Invalid output FMMU configuration 46: Invalid put FMMU configuration 48: Invalid DC Sync configuration 49: Invalid DC Invalid input FMMU configuration 50: PLL error 51: Invalid DC Io error 52: Invalid DC time out error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange CAN Over EtherCAT 68: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Station available DatID: Input address DatID: Output address DatID: Output address DatID: Output address DatID: Output address DatID: New status		24: No valid inputs available
27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration 30: Invalid input configuration 31: Invalid watchdog configuration 31: Invalid watchdog configuration 32: Slave station needs cold start 33: Slave station needs to be in INIT state 34: Slave station needs to be in PreOp state 35: Slave station needs to be in SafeOp state 45: Invalid output FMMU configuration 46: Invalid input FMMU configuration 48: Invalid DC Sync configuration 49: Invalid DC Latch configuration 50: PLL error 51: Invalid DC IO error 52: Invalid DC time out error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange CAN Over EtherCAT 68: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Station available DatID: Input address DatID: Output address DatID: Output address DatID: Output address		25: No valid outputs available
28: Invalid sync manager types 29: Invalid output configuration 30: Invalid input configuration 31: Invalid watchdog configuration 32: Slave station needs cold start 33: Slave station needs to be in INIT state 34: Slave station needs to be in PreOp state 35: Slave station needs to be in SafeOp state 45: Invalid output FMMU configuration 46: Invalid input FMMU configuration 48: Invalid DC Sync configuration 49: Invalid DC Latch configuration 50: PLL error 51: Invalid DC IO error 52: Invalid DC time out error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Station available DatID: Input address DatID: Output address DatID: Output address		26: Synchronisation error
29: Invalid output configuration 30: Invalid input configuration 31: Invalid watchdog configuration 32: Slave station needs cold start 33: Slave station needs to be in INIT state 34: Slave station needs to be in PreOp state 35: Slave station needs to be in SafeOp state 45: Invalid output FMMU configuration 46: Invalid input FMMU configuration 48: Invalid DC Sync configuration 49: Invalid DC Latch configuration 50: PLL error 51: Invalid DC IO error 52: Invalid DC time out error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Station available DatID: Input address DatID: Output address DatID: Output address DatID: Output address DatID: Output address		27: Sync manager watchdog
30: Invalid input configuration 31: Invalid watchdog configuration 32: Slave station needs cold start 33: Slave station needs to be in INIT state 34: Slave station needs to be in PreOp state 35: Slave station needs to be in SafeOp state 45: Invalid output FMMU configuration 46: Invalid input FMMU configuration 48: Invalid DC Sync configuration 49: Invalid DC Latch configuration 50: PLL error 51: Invalid DC IO error 52: Invalid DC time out error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange Fileaccess Over EtherCAT 68: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Input address DatID: Output address DatID: Output address DatID: Over Station O: New status		28: Invalid sync manager types
31: Invalid watchdog configuration 32: Slave station needs to be in INIT state 33: Slave station needs to be in INIT state 34: Slave station needs to be in PreOp state 35: Slave station needs to be in SafeOp state 45: Invalid output FMMU configuration 46: Invalid input FMMU configuration 48: Invalid DC Sync configuration 49: Invalid DC Latch configuration 50: PLL error 51: Invalid DC IO error 52: Invalid DC Io error 52: Invalid DC time out error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange Fileaccess Over EtherCAT 68: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Station available DatID: Input address DatID: Output address		29: Invalid output configuration
32: Slave station needs cold start 33: Slave station needs to be in INIT state 34: Slave station needs to be in PreOp state 35: Slave station needs to be in SafeOp state 45: Invalid output FMMU configuration 46: Invalid input FMMU configuration 48: Invalid DC Sync configuration 49: Invalid DC Latch configuration 50: PLL error 51: Invalid DC IO error 52: Invalid DC time out error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station available DatID: Station available DatID: Input address DatID: Output address		30: Invalid input configuration
33: Slave station needs to be in INIT state 34: Slave station needs to be in PreOp state 35: Slave station needs to be in SafeOp state 45: Invalid output FMMU configuration 46: Invalid input FMMU configuration 48: Invalid DC Sync configuration 49: Invalid DC Latch configuration 50: PLL error 51: Invalid DC IO error 52: Invalid DC time out error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Fileaccess Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Station available DatID: Input address DatID: Output address DatID: Output address DatID: Output address 0XED20 EtherCAT: Bus state change without calling OB86 ZINFO1 - Position 0: New status		31: Invalid watchdog configuration
34: Slave station needs to be in PreOp state 35: Slave station needs to be in SafeOp state 45: Invalid output FMMU configuration 46: Invalid input FMMU configuration 48: Invalid DC Sync configuration 49: Invalid DC Latch configuration 50: PLL error 51: Invalid DC IO error 52: Invalid DC time out error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange CAN Over EtherCAT 68: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatiD: Station not available DatiD: Station available DatiD: Input address DatiD: Output address DatiD: Output address DatiD: Output address DatiD: Over EtherCAT: Bus state change without calling OB86 ZiNFO1 - Position 0: New status		32: Slave station needs cold start
35: Slave station needs to be in SafeOp state 45: Invalid output FMMU configuration 46: Invalid input FMMU configuration 48: Invalid DC Sync configuration 49: Invalid DC Latch configuration 50: PLL error 51: Invalid DC IO error 52: Invalid DC time out error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange CAN Over EtherCAT 68: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Input address DatID: Output address DatID: Output address DatID: Output address DatID: Output address DatID: Over EtherCAT: Bus state change without calling OB86 ZINFO1 - Position 0: New status		33: Slave station needs to be in INIT state
45: Invalid output FMMU configuration 46: Invalid input FMMU configuration 48: Invalid DC Sync configuration 49: Invalid DC Latch configuration 50: PLL error 51: Invalid DC IO error 52: Invalid DC time out error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange Fileaccess Over EtherCAT 68: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Station available DatID: Input address DatID: Output address DatID: Output address DatID: Output address DatID: Over EtherCAT: Bus state change without calling OB86 ZINFO1 - Position 0: New status		34: Slave station needs to be in PreOp state
46: Invalid input FMMU configuration 48: Invalid DC Sync configuration 49: Invalid DC Latch configuration 50: PLL error 51: Invalid DC IO error 52: Invalid DC time out error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange CAN Over EtherCAT 68: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Station available DatID: Input address DatID: Output address DatID: Output address DatID: Output address DatID: Output occurrence without calling OB86 ZINFO1 - Position 0: New status		35: Slave station needs to be in SafeOp state
48: Invalid DC Sync configuration 49: Invalid DC Latch configuration 50: PLL error 51: Invalid DC IO error 52: Invalid DC time out error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange CAN Over EtherCAT 68: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Station available DatID: Input address DatID: Output address DatID: Output address DatID: Output address 0xED20 EtherCAT: Bus state change without calling OB86 ZINFO1 - Position 0: New status		45: Invalid output FMMU configuration
49: Invalid DC Latch configuration 50: PLL error 51: Invalid DC IO error 52: Invalid DC time out error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange CAN Over EtherCAT 68: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Station available DatID: Input address DatID: Output address DatID: Output address 0xED20 EtherCAT: Bus state change without calling OB86 ZINFO1 - Position 0: New status		46: Invalid input FMMU configuration
50: PLL error 51: Invalid DC IO error 52: Invalid DC time out error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange CAN Over EtherCAT 68: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Station available DatID: Input address DatID: Output address DatID: Output address 0xED20 EtherCAT: Bus state change without calling OB86 ZINFO1 - Position 0: New status		48: Invalid DC Sync configuration
51: Invalid DC IO error 52: Invalid DC time out error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange CAN Over EtherCAT 68: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Station available DatID: Input address DatID: Output address DatID: Output address 0xED20 EtherCAT: Bus state change without calling OB86 ZINFO1 - Position 0: New status		49: Invalid DC Latch configuration
52: Invalid DC time out error 66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange CAN Over EtherCAT 68: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Station available DatID: Input address DatID: Output address OxED20 EtherCAT: Bus state change without calling OB86 ZINFO1 - Position 0: New status		50: PLL error
66: Error in acyclic data exchange Ethernet Over EtherCAT 67: Error in acyclic data exchange CAN Over EtherCAT 68: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Station available DatID: Input address DatID: Output address DatID: Output address 0xED20 EtherCAT: Bus state change without calling OB86 ZINFO1 - Position 0: New status		51: Invalid DC IO error
67: Error in acyclic data exchange CAN Over EtherCAT 68: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Station available DatID: Input address DatID: Output address OxED20 EtherCAT: Bus state change without calling OB86 ZINFO1 - Position 0: New status		52: Invalid DC time out error
68: Error in acyclic data exchange Fileaccess Over EtherCAT 69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Station available DatID: Input address DatID: Output address DatID: Output address 0xED20 EtherCAT: Bus state change without calling OB86 ZINFO1 - Position 0: New status		66: Error in acyclic data exchange Ethernet Over EtherCAT
69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT 79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Station available DatID: Input address DatID: Output address DxED20 EtherCAT: Bus state change without calling OB86 ZINFO1 - Position 0: New status		67: Error in acyclic data exchange CAN Over EtherCAT
79: Error in acyclic data exchange Vendorspecific Over EtherCAT DatID: Station not available DatID: Station available DatID: Input address DatID: Output address DatID: Output address 2xED20 EtherCAT: Bus state change without calling OB86 ZINFO1 - Position 0: New status		68: Error in acyclic data exchange Fileaccess Over EtherCAT
DatID: Station not available DatID: Station available DatID: Input address DatID: Output address 0xED20 EtherCAT: Bus state change without calling OB86 ZINFO1 - Position 0: New status		69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT
DatID: Station available DatID: Input address DatID: Output address 0xED20 EtherCAT: Bus state change without calling OB86 ZINFO1 - Position 0: New status		79: Error in acyclic data exchange Vendorspecific Over EtherCAT
DatID: Input address DatID: Output address 0xED20 EtherCAT: Bus state change without calling OB86 ZINFO1 - Position 0: New status		DatID: Station not available
DatID: Output address 0xED20 EtherCAT: Bus state change without calling OB86 ZINFO1 - Position 0: New status		DatID: Station available
0xED20 EtherCAT: Bus state change without calling OB86 ZINFO1 - Position 0: New status		DatID: Input address
ZINFO1 - Position 0: New status		DatID: Output address
	0xED20	EtherCAT: Bus state change without calling OB86
0: Undefined/Unkown		ZINFO1 - Position 0: New status
		0: Undefined/Unkown

Event ID	Description
	1: Init
	2: PreOp
	3: Bootstrap
	4: SafeOp
	8: Op
	ZINFO1 - Position 8: Previous status
	0: Undefined/Unkown
	1: Init
	2: PreOp
	3: Bootstrap
	4: SafeOp
	8: Op
	ZINFO2: Diagnostic address of the master
	ZINFO3: Number of stations which are not in the same state as the master
	DatID: Station not available
	DatID: Station available
	DatID: Input address
	DatID: Output address
0xED21	EtherCAT: Incorrect bus status change
	ZINFO1 - Position 0: New status
	0: Undefined/Unkown
	1: Init
	2: PreOp
	3: Bootstrap
	4: SafeOp
	8: Op
	ZINFO1 - Position 8: Previous status
	0: Undefined/Unkown
	1: Init
	2: PreOp
	3: Bootstrap
	4: SafeOp
	8: Op
	ZINFO2: Diagnostic address of the master
	ZINFO3: Error code
	4: Cancel (master state change)
	8: Busy
	11: Invalid parameters

14: Invalid status 16: Time out DatID: Station available DatID: Station not available DatID: Output address DatID: Input address DatID: Position 0: New status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO1 - Position 8: Previous status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO1 - Position 8: Previous status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO2: Diagnostic address of the station ZINFO3: AlStatusCode 0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sym cmanager configuration 24: No valid input configuration 25: No valid output available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid output configuration	Event ID	Description
DatID: Station available DatID: Station not available DatID: Output address DatID: Input address DatID: Input address DatID: Input address DatID: Input address OXED22 EtherCAT: Slave status change that does not generate an OB86 ZINFC01 - Position 0: New status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO1 - Position 8: Previous status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO2: Diagnostic address of the station ZINFO3: AlStatusCode 0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap ot supported 20: No valid firmware 21: Invalid sync manager configuration 23: Invalid sync manager configuration 24: No valid inputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid sync manager types 29: Invalid sync manager types 29: Invalid sync manager types		14: Invalid status
DatID: Station not available DatID: Output address DatID: Input address DatID: Input address DatID: Input address DatID: Input address DatID: Output address DatID: Input address DxED22 EtherCAT: Slave status change that does not generate an OB86 ZINFO1 - Position 0: New status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO1 - Position 8: Previous status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO2: Diagnostic address of the station ZINFO3: AlStatusCode 0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap ont supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		16: Time out
DatID: Output address DatID: Input address DatID: Input address EtherCAT: Slave status change that does not generate an OB86 ZINFO1 - Position 0: New status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO1 - Position 8: Previous status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO1 - Position 8: Previous status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO2: Diagnostic address of the station ZINFO3: AlStatusCode 0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status change 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid inputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		DatID: Station available
DatID: Input address EtherCAT: Slave status change that does not generate an OB86 ZINFO1 - Position 0: New status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO1 - Position 8: Previous status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO1 - Position 8: Previous status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO2: Diagnostic address of the station ZINFO3: AlStatusCode 0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		DatID: Station not available
EtherCAT: Slave status change that does not generate an OB86 ZINFO1 - Position 0: New status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO1 - Position 8: Previous status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO1 - Position 8: Previous status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO2: Diagnostic address of the station ZINFO3: AlStatusCode 0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid sync manager configuration 24: No valid inputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid sync manager types		DatID: Output address
ZINFO1 - Position 0: New status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO1 - Position 8: Previous status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO2 - Diagnostic address of the station ZINFO3: AlStatusCode 0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		DatID: Input address
0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO1 - Position 8: Previous status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO2: Diagnostic address of the station ZINFO2: Diagnostic address of the station ZINFO3: AlStatusCode 0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration	0xED22	EtherCAT: Slave status change that does not generate an OB86
1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO1 - Position 8: Previous status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO2: Diagnostic address of the station ZINFO3: AlStatusCode 0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid sync manager types		ZINFO1 - Position 0: New status
2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO1 - Position 8: Previous status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO2: Diagnostic address of the station ZINFO3: AlStatusCode 0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid sync manager types		0: Undefined/Unkown
3: Bootstrap 4: SafeOp 8: Op ZINFO1 - Position 8: Previous status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO2: Diagnostic address of the station ZINFO3: AlStatusCode 0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		1: Init
4: SafeOp 8: Op ZINFO1 - Position 8: Previous status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO2: Diagnostic address of the station ZINFO3: AlStatusCode 0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		2: PreOp
8: Op ZINFO1 - Position 8: Previous status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO2: Diagnostic address of the station ZINFO3: AlStatusCode 0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		3: Bootstrap
ZINFO1 - Position 8: Previous status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO2: Diagnostic address of the station ZINFO3: AlStatusCode 0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		4: SafeOp
0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO2: Diagnostic address of the station ZINFO3: AlStatusCode 0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid sync manager types		8: Op
1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO2: Diagnostic address of the station ZINFO3: AlStatusCode 0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		ZINFO1 - Position 8: Previous status
2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO2: Diagnostic address of the station ZINFO3: AlStatusCode 0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		0: Undefined/Unkown
3: Bootstrap 4: SafeOp 8: Op ZINFO2: Diagnostic address of the station ZINFO3: AlStatusCode 0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		1: Init
4: SafeOp 8: Op ZINFO2: Diagnostic address of the station ZINFO3: AlStatusCode 0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		2: PreOp
8: Op ZINFO2: Diagnostic address of the station ZINFO3: AlStatusCode 0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		3: Bootstrap
ZINFO2: Diagnostic address of the station ZINFO3: AlStatusCode 0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		4: SafeOp
ZINFO3: AlStatusCode 0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		8: Op
0: No error 1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		ZINFO2: Diagnostic address of the station
1: Unspecified error 17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		ZINFO3: AlStatusCode
17: Invalid requested status change 18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		0: No error
18: Unknown requested status 19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		1: Unspecified error
19: Bootstrap not supported 20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		17: Invalid requested status change
20: No valid firmware 22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		18: Unknown requested status
22: Invalid mailbox configuration 23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		19: Bootstrap not supported
23: Invalid sync manager configuration 24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		20: No valid firmware
24: No valid inputs available 25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		22: Invalid mailbox configuration
25: No valid outputs available 26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		23: Invalid sync manager configuration
26: Synchronisation error 27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		24: No valid inputs available
27: Sync manager watchdog 28: Invalid sync manager types 29: Invalid output configuration		25: No valid outputs available
28: Invalid sync manager types 29: Invalid output configuration		26: Synchronisation error
29: Invalid output configuration		27: Sync manager watchdog
		28: Invalid sync manager types
30: Invalid input configuration		29: Invalid output configuration
oo. myana mpar oorinigaration		30: Invalid input configuration

Event ID	Description
	31: Invalid watchdog configuration
	32: Slave station needs cold start
	33: Slave station needs to be in INIT state
	34: Slave station needs to be in PreOp state
	35: Slave station needs to be in SafeOp state
	45: Invalid output FMMU configuration
	46: Invalid input FMMU configuration
	48: Invalid DC Sync configuration
	49: Invalid DC Latch configuration
	50: PLL error
	51: Invalid DC IO error
	52: Invalid DC time out error
	66: Error in acyclic data exchange Ethernet Over EtherCAT
	67: Error in acyclic data exchange CAN Over EtherCAT
	68: Error in acyclic data exchange Fileaccess Over EtherCAT
	69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT
	79: Error in acyclic data exchange Vendorspecific Over EtherCAT
	DatID: Station not available
	DatID: Station available
	DatID: Input address
	DatID: Output address
0xED23	EtherCAT: Time out while changing the master state to OP, after CPU has changed to RUN
	OB: Operating mode
	0: Configuration in operating condition RUN
	1: STOP (update)
	2: STOP (memory reset)
	3: STOP (auto initialization)
	4: STOP (internal)
	5: STARTUP (cold start)
	6: STARTUP (restart/warm start)
	7: STARTUP (hot restart)
	9: RUN
	10: HALT
	11: COUPLING
	12: UPDATING
	13: DEFECTIVE
	14: Error search mode
	15: De-energised

ZINFO2: Diagnostic address of the master 0xED31 EtherCAT: Overflow of the interrupt queue ZINFO2: Diagnostic address of the master 0xED40 Bus cycle time infringement occurred ZINFO1: Logical address of the IO system	Event ID	Description
255: Not set ZINFO1: Master status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO2: EtherCAT configuration present 0: There is no EC configuration 1: There is an EC configuration ZINFO3: DC in sync 0: Not in sync 1: In sync 0: Not in sync 1: In sync 0xED30 EtherCAT: Topology deviation ZINFO2: Diagnostic address of the master 0xED31 EtherCAT: Overflow of the interrupt queue ZINFO2: Diagnostic address of the master 0xED40 Bus cycle time infringement occurred ZINFO1: Logical address of the IO system 0xED50 EtherCAT: Distributed clocks (DC) in sync OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (rostart/warm start) 7: STARTUP (rostart/warm start) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		253: Process image release in STOP
ZINFO1: Master status 0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO2: EtherCAT configuration present 0: There is no EC configuration 1: There is an EC configuration 2: Ins ync 0: Not in sync 0: Not in sync 1: In sync 0xED30 EtherCAT: Topology deviation ZINFO2: Diagnostic address of the master 0xED31 EtherCAT: Overflow of the interrupt queue ZINFO2: Diagnostic address of the master 0xED40 Bus cycle time infringement occurred ZINFO1: Logical address of the IO system 0xED50 EtherCAT: Distributed clocks (DC) in sync 0B: Operating mode 0: Configuration in operating condition RUN 1: STOP (undate) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		254: Watchdog
0: Undefined/Unkown 1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO2: EtherCAT configuration present 0: There is no EC configuration 1: There is an EC configuration 2INFO3: DC in sync 0: Not in sync 1: In sync 1: In sync 0xED30 EtherCAT: Topology deviation ZINFO2: Diagnostic address of the master 0xED31 EtherCAT: Overflow of the interrupt queue ZINFO2: Diagnostic address of the master 0xED40 Bus cycle time infringement occurred ZINFO1: Logical address of the IO system 0xED50 EtherCAT: Distributed clocks (DC) in sync 0B: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		255: Not set
1: Init 2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO2: EtherCAT configuration present 0: There is no EC configuration 1: There is an EC configuration 2INFO3: DC in sync 0: Not in sync 1: In sync 1: In sync 0xED30 EtherCAT: Topology deviation ZINFO2: Diagnostic address of the master 0xED31 EtherCAT: Overflow of the interrupt queue ZINFO2: Diagnostic address of the master 0xED40 Bus cycle time infringement occurred ZINFO1: Logical address of the IO system 0xED50 EtherCAT: Distributed clocks (DC) in sync 0B: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		ZINFO1: Master status
2: PreOp 3: Bootstrap 4: SafeOp 8: Op ZINFO2: EtherCAT configuration present 0: There is no EC configuration 1: There is an EC configuration 2INFO3: DC in sync 0: Not in sync 1: In sync 0xED30 EtherCAT: Topology deviation ZINFO2: Diagnostic address of the master 0xED31 EtherCAT: Overflow of the interrupt queue ZINFO2: Diagnostic address of the master 0xED40 Bus cycle time infringement occurred ZINFO1: Logical address of the IO system 0xED50 EtherCAT: Overflow of the IO system 0xED50 EtherCAT: Distributed clocks (DC) in sync 0B: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (restart/warm start) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		0: Undefined/Unkown
3: Bootstrap 4: SafeOp 8: Op ZINFO2: EtherCAT configuration present 0: There is no EC configuration 1: There is an EC configuration ZINFO3: DC in sync 0: Not in sync 1: In sync 0xED30 EtherCAT: Topology deviation ZINFO2: Diagnostic address of the master 0xED31 EtherCAT: Overflow of the interrupt queue ZINFO2: Diagnostic address of the master 0xED40 Bus cycle time infringement occurred ZINFO1: Logical address of the IO system 0xED50 EtherCAT: Distributed clocks (DC) in sync 0B: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (restart/warm start) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		1: Init
4: SafeOp 8: Op ZINFO2: EtherCAT configuration present 0: There is no EC configuration 1: There is an EC configuration 2INFO3: DC in sync 0: Not in sync 1: In sync 0XED30 EtherCAT: Topology deviation ZINFO2: Diagnostic address of the master 0XED31 EtherCAT: Overflow of the interrupt queue ZINFO2: Diagnostic address of the master 0XED40 Bus cycle time infringement occurred ZINFO1: Logical address of the IO system 0XED50 EtherCAT: Distributed clocks (DC) in sync 0B: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (restart/warm start) 7: STARTUP (restart/warm start) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		2: PreOp
8: Op ZINFO2: EtherCAT configuration present 0: There is no EC configuration 1: There is an EC configuration ZINFO3: DC in sync 0: Not in sync 1: In sync OXED30 EtherCAT: Topology deviation ZINFO2: Diagnostic address of the master OXED31 EtherCAT: Overflow of the interrupt queue ZINFO2: Diagnostic address of the master OXED40 Bus cycle time infringement occurred ZINFO1: Logical address of the IO system OXED50 EtherCAT: Distributed clocks (DC) in sync OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (auto initialization) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		3: Bootstrap
ZINFO2: EtherCAT configuration present 0: There is no EC configuration 1: There is an EC configuration ZINFO3: DC in sync 0: Not in sync 1: In sync EtherCAT: Topology deviation ZINFO2: Diagnostic address of the master 0xED31 EtherCAT: Overflow of the interrupt queue ZINFO2: Diagnostic address of the master 0xED40 Bus cycle time infringement occurred ZINFO1: Logical address of the IO system 0xED50 EtherCAT: Distributed clocks (DC) in sync OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		4: SafeOp
0: There is no EC configuration 1: There is an EC configuration ZINFO3: DC in sync 0: Not in sync 1: In sync 1: In sync OXED30 EtherCAT: Topology deviation ZINFO2: Diagnostic address of the master OXED31 EtherCAT: Overflow of the interrupt queue ZINFO2: Diagnostic address of the master OXED40 Bus cycle time infringement occurred ZINFO1: Logical address of the IO system OXED50 EtherCAT: Distributed clocks (DC) in sync OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		8: Op
1: There is an EC configuration ZINFO3: DC in sync 0: Not in sync 1: In sync 0xED30 EtherCAT: Topology deviation ZINFO2: Diagnostic address of the master 0xED31 EtherCAT: Overflow of the interrupt queue ZINFO2: Diagnostic address of the master 0xED40 Bus cycle time infringement occurred ZINFO1: Logical address of the IO system 0xED50 EtherCAT: Distributed clocks (DC) in sync OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		ZINFO2: EtherCAT configuration present
ZINFO3: DC in sync 0: Not in sync 1: In sync OXED30 EtherCAT: Topology deviation ZINFO2: Diagnostic address of the master OXED31 EtherCAT: Overflow of the interrupt queue ZINFO2: Diagnostic address of the master OXED40 Bus cycle time infringement occurred ZINFO1: Logical address of the IO system OXED50 EtherCAT: Distributed clocks (DC) in sync OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		0: There is no EC configuration
0: Not in sync 1: In sync EtherCAT: Topology deviation ZINFO2: Diagnostic address of the master 0xED31 EtherCAT: Overflow of the interrupt queue ZINFO2: Diagnostic address of the master 0xED40 Bus cycle time infringement occurred ZINFO1: Logical address of the IO system 0xED50 EtherCAT: Distributed clocks (DC) in sync OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		1: There is an EC configuration
1: In sync OXED30 EtherCAT: Topology deviation ZINFO2: Diagnostic address of the master OXED31 EtherCAT: Overflow of the interrupt queue ZINFO2: Diagnostic address of the master OXED40 Bus cycle time infringement occurred ZINFO1: Logical address of the IO system OXED50 EtherCAT: Distributed clocks (DC) in sync OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (restart/warm start) 7: STARTUP (find restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		ZINFO3: DC in sync
EtherCAT: Topology deviation ZINFO2: Diagnostic address of the master 0xED31 EtherCAT: Overflow of the interrupt queue ZINFO2: Diagnostic address of the master 0xED40 Bus cycle time infringement occurred ZINFO1: Logical address of the IO system 0xED50 EtherCAT: Distributed clocks (DC) in sync OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		0: Not in sync
ZINFO2: Diagnostic address of the master 0xED31 EtherCAT: Overflow of the interrupt queue ZINFO2: Diagnostic address of the master 0xED40 Bus cycle time infringement occurred ZINFO1: Logical address of the IO system 0xED50 EtherCAT: Distributed clocks (DC) in sync OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		1: In sync
EtherCAT: Overflow of the interrupt queue ZINFO2: Diagnostic address of the master Bus cycle time infringement occurred ZINFO1: Logical address of the IO system OXED50 EtherCAT: Distributed clocks (DC) in sync OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING	0xED30	EtherCAT: Topology deviation
ZINFO2: Diagnostic address of the master 0xED40 Bus cycle time infringement occurred ZINFO1: Logical address of the IO system 0xED50 EtherCAT: Distributed clocks (DC) in sync OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		ZINFO2: Diagnostic address of the master
DxED40 Bus cycle time infringement occurred ZINFO1: Logical address of the IO system OxED50 EtherCAT: Distributed clocks (DC) in sync OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING	0xED31	EtherCAT: Overflow of the interrupt queue
ZINFO1: Logical address of the IO system EtherCAT: Distributed clocks (DC) in sync OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		ZINFO2: Diagnostic address of the master
OxED50 EtherCAT: Distributed clocks (DC) in sync OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING	0xED40	Bus cycle time infringement occurred
OB: Operating mode 0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		ZINFO1: Logical address of the IO system
0: Configuration in operating condition RUN 1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING	0xED50	EtherCAT: Distributed clocks (DC) in sync
1: STOP (update) 2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		OB: Operating mode
2: STOP (memory reset) 3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		0: Configuration in operating condition RUN
3: STOP (auto initialization) 4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		1: STOP (update)
4: STOP (internal) 5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		2: STOP (memory reset)
5: STARTUP (cold start) 6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		3: STOP (auto initialization)
6: STARTUP (restart/warm start) 7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		4: STOP (internal)
7: STARTUP (hot restart) 9: RUN 10: HALT 11: COUPLING 12: UPDATING		5: STARTUP (cold start)
9: RUN 10: HALT 11: COUPLING 12: UPDATING		6: STARTUP (restart/warm start)
10: HALT 11: COUPLING 12: UPDATING		7: STARTUP (hot restart)
11: COUPLING 12: UPDATING		9: RUN
12: UPDATING		10: HALT
		11: COUPLING
13: DEFECTIVE		12: UPDATING
		13: DEFECTIVE
14: Error search mode		14: Error search mode

Event ID	Description
	15: De-energised
	253: Process image release in STOP
	254: Watchdog
	255: Not set
	ZINFO2: Diagnostic address of the master
	ZINFO3: DC state change
	0: Master
	1: Slave
0xED60	EtherCAT: Diagnostic buffer CP: Slave status change
	OB: Operating mode
	0: Configuration in operating condition RUN
	1: STOP (update)
	2: STOP (memory reset)
	3: STOP (auto initialization)
	4: STOP (internal)
	5: STARTUP (cold start)
	6: STARTUP (restart/warm start)
	7: STARTUP (hot restart)
	9: RUN
	10: HALT
	11: COUPLING
	12: UPDATING
	13: DEFECTIVE
	14: Error search mode
	15: De-energised
	253: Process image release in STOP
	254: Watchdog
	255: Not set
	ZINFO1 - Position 0: New status
	0: Undefined/Unkown
	1: Init
	2: PreOp
	3: Bootstrap
	4: SafeOp
	8: Op
	ZINFO2: Slave address
	ZINFO3: AlStatusCode
	0: No error

Event ID	Description
	1: Unspecified error
	17: Invalid requested status change
	18: Unknown requested status
	19: Bootstrap not supported
	20: No valid firmware
	22: Invalid mailbox configuration
	23: Invalid sync manager configuration
	24: No valid inputs available
	25: No valid outputs available
	26: Synchronisation error
	27: Sync manager watchdog
	28: Invalid sync manager types
	29: Invalid output configuration
	30: Invalid input configuration
	31: Invalid watchdog configuration
	32: Slave station needs cold start
	33: Slave station needs to be in INIT state
	34: Slave station needs to be in PreOp state
	35: Slave station needs to be in SafeOp state
	45: Invalid output FMMU configuration
	46: Invalid input FMMU configuration
	48: Invalid DC Sync configuration
	49: Invalid DC Latch configuration
	50: PLL error
	51: Invalid DC IO error
	52: Invalid DC time out error
	66: Error in acyclic data exchange Ethernet Over EtherCAT
	67: Error in acyclic data exchange CAN Over EtherCAT
	68: Error in acyclic data exchange Fileaccess Over EtherCAT
	69: Error in acyclic data exchange Servo Drive Profile Over EtherCAT
	79: Error in acyclic data exchange Vendorspecific Over EtherCAT
	DatID: Cause for slave status change
	0: Regular slave status change
	1: Slave failure
	2: Recovery slave
	3: Slave is in an error state
	4: Slave has unexpectedly changed its status
0xED61	EtherCAT: Diagnostic buffer CP: CoE emergency

Event ID	Description
	OB: EtherCAT station address (high byte)
	PK: EtherCAT station address (low byte)
	ZINFO1 - Position 0: Error register
	ZINFO1 - Position 8: MEF-Byte1
	ZINFO2 - Position 0: MEF-Byte2
	ZINFO2 - Position 8: MEF-Byte3
	ZINFO3 - Position 0: MEF-Byte4
	ZINFO3 - Position 8: MEF-Byte5
	DatID: Error code
0xED62	EtherCAT: Diagnostic buffer CP: Error on SDO access
	OB: EtherCAT station address (high byte)
	PK: EtherCAT station address (low byte)
	ZINFO1: Index
	ZINFO2: SDO error code (high word)
	ZINFO3: SDO error code (low word)
	DatID: Sub index
0xED63	EtherCAT: Diagnostic buffer CP: Error in the response to an INIT command
	OB: EtherCAT station address (high byte)
	PK: EtherCAT station address (low byte)
	ZINFO1: Error type
	0: Not defined
	1: No response
	2: Validation error
	3: INIT command failed, requested station could not be reached
0xED70	EtherCAT: Diagnostic buffer CP: Twofold hot connect group recognised
	OB: Operating mode
	0: Configuration in operating condition RUN
	1: STOP (update)
	2: STOP (memory reset)
	3: STOP (auto initialization)
	4: STOP (internal)
	5: STARTUP (cold start)
	6: STARTUP (restart/warm start)
	7: STARTUP (hot restart)
	9: RUN
	10: HALT
	11: COUPLING
	12: UPDATING

Event ID	Description
	13: DEFECTIVE
	14: Error search mode
	15: De-energised
	253: Process image release in STOP
	254: Watchdog
	255: Not set
	ZINFO1: Diagnostic address of the master
	ZINFO2: EtherCAT station address
0xED80	Bus error occurred (receive time-out)
	ZINFO1: Logical address of the IO system
	ZINFO3 - Position 0: Station number
	ZINFO3 - Position 11: IO system ID
	ZINFO3 - Bit 15: System ID DP/PN
0xEE00	Additional information at UNDEF_OPCODE
	OB: Not user relevant
	ZINFO1: Not user relevant
	ZINFO2: Not user relevant
	ZINFO3: Not user relevant
	DatID: Not user relevant
0xEE01	Internal error - Please contact the hotline!
	ZINFO3: SFB number
0xEEEE	CPU was completely deleted, since after PowerON the start-up could not be finished
0xEF00	Internal error - Please contact the hotline!
	DatID: Not user relevant
0xEF01	Internal error - Please contact the hotline!
	ZINFO1: Not user relevant
	ZINFO2: Not user relevant
	ZINFO3: Not user relevant
	DatID: Not user relevant
0xEF11	Internal error - Please contact the hotline!
0xEF12	Internal error - Please contact the hotline!
0xEF13	Internal error - Please contact the hotline!
0xEFFE	Internal error - Please contact the hotline!
	PK: Not user relevant
	ZINFO3: Not user relevant
	DatID: Not user relevant
0xEFFF	Internal error - Please contact the hotline!
	PK: Not user relevant

Event ID	Description
	ZINFO3: Not user relevant
	DatID: Not user relevant
0xF9C1	Restart of the component
	OB: NCM_EVENT
	1: OVS: Component start-up request was denied
	3: Component data basis invalid
	6: IP_CONFIG: New IP address assigned by STEP7 configuration
	10: IP_CONFIG: A non-configured new IP address was assigned
	13: HW reset at P bus (for CPU memory reset)
	19: Switch actuation from STOP to RUN causes the restart of the component
	20: MGT: PG command causes the restart of the component
	21: MGT: Take-over of component data basis causes the hot restart of the component
	23: Stopping the sub-system after having loaded the already existing consistency-secured SDBs xxxx by the rack component
	25: The SIMATIC procedure has been selected for the time synchronisation of the component.
	26: Component actively established a connection
	28: The SDB xxxx loaded by the rack component is the consistency securing object (SDB type 0x3118)
	29: The component actively disconnected the system connection to the CPU
	31: Inconsistency of the component data base by loading SDB xxxx by the rack component (SDB type 0x3100)
	32: Periphery enabled by S7-CPU
	33: Periphery disabled by S7-CPU
	34: Component STOP due to switch actuation
	35: Component STOP due to invalid configuration
	36: Component STOP due to PG command
	38: SDB xxxx is not registered in the still valid consistency securing object, or it has an incorrect time stamp (SDB type 0x3107), the error is being corrected
	40: Memory reset executed
	44: Consistency of the data base achieved after loading the SDBs xxxx by the rack component (SDB type xxxx)
	45: Remanent part of the component data base is deleted by the rack component after being loaded
	70: Restore factory defaults (same as memory reset of CPU!)
	83: Network interface: automatic configuration, TP/ITP with 10 Mbit/s semi-duplex
	96: The MAC address was retrieved from the system SDB. This is the configured address.
	97: The MAC address was retrieved from the boot EPROM. This is the factory-provided address.
	100: Restart of the component
	101: Component STOP due to deletion of system SDBs

Event ID	Description
	104: PG command start was denied due to missing or inconsistent configuration
	105: Component STOP due to double IP address
	107: Start-up request by switch actuation was denied due to missing or inconsistent configuration
	PK: NCM_SERVICE
	2: Management
	3: Object management system
	6: Time synchronisation
	10: IP_CONFIG
	38: SEND/RECEIVE

Integrated blocks System MICRO

B Integrated blocks

OB 1 CYCL_EXC Program Cycle OB 10 TOD_INTO Time-of-day Interrupt OB 20 DEL_INTO Time delay Interrupt OB 21 DEL_INT1 Time delay interrupt OB 32 CYC_INT2 Cyclic interrupt OB 33 CYC_INT3 Cyclic interrupt OB 34 CYC_INT5 Cyclic interrupt OB 40 HW_INTO Hardware interrupt OB 80 CYCL_FLT Time error OB 81 PS_FLT Power supply error OB 82 I/O_FLT2 Insert / remove module OB 83 I/O_FLT2 Insert / remove module OB 85 OBNL_FLT Priority class error OB 86 RACK_FLT Slave failure / restart OB 100 COMPLETE RESTART Start-up OB 102 COLD RESTART Start-up OB 122 MOD_ERR Periphery access error SFB Name Description SFB 0 CTU Up-counter SFB 1 CTD Down-counter	ОВ	Name	Description
OB 20 DEL_INT0 Time delay interrupt OB 21 DEL_INT1 Time delay interrupt OB 32 CYC_INT2 Cyclic interrupt OB 33 CYC_INT3 Cyclic interrupt OB 34 CYC_INT5 Cyclic interrupt OB 35 CYC_INT5 Cyclic interrupt OB 40 HW_INT0 Hardware interrupt OB 80 CYCL_FLT Time error OB 81 PS_FLT Power supply error OB 82 I/O_FLT2 Diagnostics interrupt OB 83 I/O_FLT2 Insert / remove module OB 85 OBNL_FLT Priority class error OB 86 RACK_FLT Slave failure / restart OB 100 COMPLETE RESTART Start-up OB 102 COLD RESTART Start-up OB 121 PROG_ERR Programming error OB 122 MOD_ERR Periphery access error SFB 0 CTU Up-counter SFB 1 CTD Down-counter SFB 2 CTUD Up-counter	OB 1	CYCL_EXC	Program Cycle
OB 21 DEL_INT1 Time delay interrupt OB 32 CYC_INT2 Cyclic interrupt OB 33 CYC_INT3 Cyclic interrupt OB 34 CYC_INT4 Cyclic interrupt OB 35 CYC_INT5 Cyclic interrupt OB 40 HW_INT0 Hardware interrupt OB 80 CYCL_FLT Time error OB 81 PS_FLT Power supply error OB 82 I/O_FLT1 Diagnostics interrupt OB 83 I/O_FLT2 Insert / remove module OB 85 OBNL_FLT Priority class error OB 86 RACK_FLT Slave failure / restart OB 100 COMPLETE RESTART Start-up OB 102 COLD RESTART Start-up OB 102 COLD RESTART Start-up OB 121 PROG_ERR Periphery access error SFB Name Description SFB 0 CTU Up-counter SFB 1 CTD Down-counter SFB 2 CTUD Up-down counter	OB 10	TOD_INT0	Time-of-day Interrupt
OB 32 CYC_INT2 Cyclic interrupt OB 33 CYC_INT3 Cyclic interrupt OB 34 CYC_INT4 Cyclic interrupt OB 35 CYC_INT5 Cyclic interrupt OB 40 HW_INT0 Hardware interrupt OB 80 CYCL_FLT Time error OB 81 PS_FLT Power supply error OB 82 I/O_FLT2 Insert / remove module OB 83 I/O_FLT2 Insert / remove module OB 85 OBNL_FLT Priority class error OB 86 RACK_FLT Slave failure / restart OB 100 COMPLETE RESTART Start-up OB 102 COLD RESTART Start-up OB 102 COLD RESTART Start-up OB 121 PROG_ERR Periphery access error SFB Name Description SFB 0 CTU Up-counter SFB 2 CTUD Up-counter SFB 3 TP Create pulse SFB 4 TON On-delay SFB 5	OB 20	DEL_INT0	Time delay interrupt
OB 33 CYC_INT3 Cyclic interrupt OB 34 CYC_INT4 Cyclic interrupt OB 35 CYC_INT5 Cyclic interrupt OB 40 HW_INT0 Hardware interrupt OB 80 CYCL_FLT Time error OB 81 PS_FLT Power supply error OB 82 I/O_FLT1 Diagnostics interrupt OB 83 I/O_FLT2 Insert / remove module OB 85 OBNL_FLT Priority class error OB 86 RACK_FLT Slave failure / restart OB 100 COMPLETE RESTART Start-up OB 102 COLD RESTART Start-up OB 121 PROG_ERR Programming error OB 122 MOD_ERR Periphery access error SFB Name Description SFB 1 CTU Up-counter SFB 2 CTU Up-counter SFB 3 TP Create pulse SFB 4 TON On-delay SFB 5 TOF Create turn-off delay SFB 12	OB 21	DEL_INT1	Time delay interrupt
OB 34 CYC_INT4 Cyclic interrupt OB 35 CYC_INT5 Cyclic interrupt OB 40 HW_INT0 Hardware interrupt OB 80 CYCL_FLT Time error OB 81 PS_FLT Power supply error OB 82 I/O_FLT1 Diagnostics interrupt OB 83 I/O_FLT2 Insert / remove module OB 85 OBNL_FLT Priority class error OB 86 RACK_FLT Slave failure / restart OB 100 COMPLETE RESTART Start-up OB 102 COLD RESTART Start-up OB 102 COLD RESTART Start-up OB 122 MOD_ERR Periphery access error SFB SFB 0 CTU Up-counter SFB 1 CTD Down-counter SFB 2 CTUD Up-down counter SFB 3 TP Create pulse SFB 4 TON On-delay SFB 5 TOF Create turn-off delay SFB 7 TIMEMESS Time measureme	OB 32	CYC_INT2	Cyclic interrupt
OB 35 CYC_INT5 Cyclic interrupt OB 40 HW_INT0 Hardware interrupt OB 80 CYCL_FLT Time error OB 81 PS_FLT Power supply error OB 82 I/O_FLT1 Diagnostics interrupt OB 83 I/O_FLT2 Insert / remove module OB 85 OBNL_FLT Priority class error OB 86 RACK_FLT Slave failure / restart OB 100 COMPLETE RESTART Start-up OB 102 COLD RESTART Start-up OB 121 PROG_ERR Programming error OB 122 MOD_ERR Periphery access error SFB SFB 0 CTU Up-counter SFB 1 CTD Down-counter SFB 2 CTUD Up-down counter SFB 3 TP Create pulse SFB 4 TON On-delay SFB 5 TOF Create turn-off delay SFB 7 TIMEMESS Time measurement SFB 12 BSEND Sending dat	OB 33	CYC_INT3	Cyclic interrupt
OB 40 HW_INTO Hardware interrupt OB 80 CYCL_FLT Time error OB 81 PS_FLT Power supply error OB 82 I/O_FLT1 Diagnostics interrupt OB 83 I/O_FLT2 Insert / remove module OB 85 OBNL_FLT Priority class error OB 86 RACK_FLT Slave failure / restart OB 100 COMPLETE RESTART Start-up OB 102 COLD RESTART Start-up OB 121 PROG_ERR Programming error OB 122 MOD_ERR Periphery access error SFB Name Description SFB 0 CTU Up-counter SFB 1 CTD Down-counter SFB 2 CTUD Up-down counter SFB 3 TP Create pulse SFB 4 TON On-delay SFB 5 TOF Create turn-off delay SFB 7 TIMEMESS Time measurement SFB 12 BSEND Sending data in blocks SFB 13	OB 34	CYC_INT4	Cyclic interrupt
OB 80 CYCL_FLT Time error OB 81 PS_FLT Power supply error OB 82 I/O_FLT1 Diagnostics interrupt OB 83 I/O_FLT2 Insert / remove module OB 85 OBNL_FLT Priority class error OB 86 RACK_FLT Slave failure / restart OB 100 COMPLETE RESTART Start-up OB 102 COLD RESTART Start-up OB 121 PROG_ERR Programming error OB 122 MOD_ERR Periphery access error SFB Name Description SFB 0 CTU Up-counter SFB 1 CTD Down-counter SFB 2 CTUD Up-down counter SFB 3 TP Create pulse SFB 4 TON On-delay SFB 5 TOF Create turn-off delay SFB 7 TIMEMESS Time measurement SFB 12 BSEND Sending data in blocks SFB 13 BRCV Receiving data in blocks <td< td=""><td>OB 35</td><td>CYC_INT5</td><td>Cyclic interrupt</td></td<>	OB 35	CYC_INT5	Cyclic interrupt
OB 81 PS_FLT Power supply error OB 82 I/O_FLT1 Diagnostics interrupt OB 83 I/O_FLT2 Insert / remove module OB 85 OBNL_FLT Priority class error OB 86 RACK_FLT Slave failure / restart OB 100 COMPLETE RESTART Start-up OB 102 COLD RESTART Start-up OB 121 PROG_ERR Programming error OB 122 MOD_ERR Periphery access error SFB Name Description SFB 0 CTU Up-counter SFB 1 CTD Down-counter SFB 2 CTUD Up-down counter SFB 3 TP Create pulse SFB 4 TON On-delay SFB 5 TOF Create turn-off delay SFB 7 TIMEMESS Time measurement SFB 12 BSEND Sending data in blocks SFB 13 BRCV Receiving data in blocks: SFB 14 GET Remote CPU read SFB 32 <td>OB 40</td> <td>HW_INT0</td> <td>Hardware interrupt</td>	OB 40	HW_INT0	Hardware interrupt
OB 82 I/O_FLT1 Diagnostics interrupt OB 83 I/O_FLT2 Insert / remove module OB 85 OBNL_FLT Priority class error OB 86 RACK_FLT Slave failure / restart OB 100 COMPLETE RESTART Start-up OB 102 COLD RESTART Start-up OB 121 PROG_ERR Programming error OB 122 MOD_ERR Periphery access error SFB Name Description SFB 0 CTU Up-counter SFB 1 CTD Down-counter SFB 2 CTUD Up-down counter SFB 3 TP Create pulse SFB 4 TON On-delay SFB 5 TOF Create turn-off delay SFB 7 TIMEMESS Time measurement SFB 12 BSEND Sending data in blocks SFB 13 BRCV Receiving data in blocks: SFB 14 GET Remote CPU read SFB 15 PUT Remote CPU write	OB 80	CYCL_FLT	Time error
OB 83 I/O_FLT2 Insert / remove module OB 85 OBNL_FLT Priority class error OB 86 RACK_FLT Slave failure / restart OB 100 COMPLETE RESTART Start-up OB 102 COLD RESTART Start-up OB 121 PROG_ERR Programming error OB 122 MOD_ERR Periphery access error SFB Name Description SFB 0 CTU Up-counter SFB 1 CTD Down-counter SFB 2 CTUD Up-down counter SFB 3 TP Create pulse SFB 4 TON On-delay SFB 5 TOF Create turn-off delay SFB 7 TIMEMESS Time measurement SFB 12 BSEND Sending data in blocks SFB 13 BRCV Receiving data in blocks: SFB 14 GET Remote CPU read SFB 15 PUT Remote CPU write SFB 32 DRUM Realize a step-by-step switch	OB 81	PS_FLT	Power supply error
OB 85 OBNL_FLT Priority class error OB 86 RACK_FLT Slave failure / restart OB 100 COMPLETE RESTART Start-up OB 102 COLD RESTART Start-up OB 121 PROG_ERR Programming error OB 122 MOD_ERR Periphery access error SFB Name Description SFB 0 CTU Up-counter SFB 1 CTD Down-counter SFB 2 CTUD Up-down counter SFB 3 TP Create pulse SFB 4 TON On-delay SFB 5 TOF Create turn-off delay SFB 7 TIMEMESS Time measurement SFB 12 BSEND Sending data in blocks SFB 13 BRCV Receiving data in blocks: SFB 14 GET Remote CPU read SFB 15 PUT Remote CPU write SFB 32 DRUM Realize a step-by-step switch SFB 47 COUNT Control counter	OB 82	I/O_FLT1	Diagnostics interrupt
OB 86 RACK_FLT Slave failure / restart OB 100 COMPLETE RESTART Start-up OB 102 COLD RESTART Start-up OB 121 PROG_ERR Programming error OB 122 MOD_ERR Periphery access error SFB Name Description SFB 0 CTU Up-counter SFB 1 CTD Down-counter SFB 2 CTUD Up-down counter SFB 3 TP Create pulse SFB 4 TON On-delay SFB 4 TON On-delay SFB 5 TOF Create turn-off delay SFB 7 TIMEMESS Time measurement SFB 12 BSEND Sending data in blocks SFB 13 BRCV Receiving data in blocks: SFB 14 GET Remote CPU read SFB 15 PUT Remote CPU write SFB 47 COUNT Control counter	OB 83	I/O_FLT2	Insert / remove module
OB 100 COMPLETE RESTART Start-up OB 102 COLD RESTART Start-up OB 121 PROG_ERR Programming error OB 122 MOD_ERR Periphery access error SFB Name Description SFB 0 CTU Up-counter SFB 1 CTD Down-counter SFB 2 CTUD Up-down counter SFB 3 TP Create pulse SFB 4 TON On-delay SFB 5 TOF Create turn-off delay SFB 7 TIMEMESS Time measurement SFB 12 BSEND Sending data in blocks SFB 13 BRCV Receiving data in blocks: SFB 14 GET Remote CPU read SFB 15 PUT Remote CPU write SFB 32 DRUM Realize a step-by-step switch SFB 47 COUNT Control counter SFB 48 FREQUENC Frequency measurement	OB 85	OBNL_FLT	Priority class error
OB 102 COLD RESTART Start-up OB 121 PROG_ERR Programming error OB 122 MOD_ERR Periphery access error SFB Name Description SFB 0 CTU Up-counter SFB 1 CTD Down-counter SFB 2 CTUD Up-down counter SFB 3 TP Create pulse SFB 4 TON On-delay SFB 5 TOF Create turn-off delay SFB 7 TIMEMESS Time measurement SFB 12 BSEND Sending data in blocks SFB 13 BRCV Receiving data in blocks: SFB 14 GET Remote CPU read SFB 15 PUT Remote CPU write SFB 32 DRUM Realize a step-by-step switch SFB 47 COUNT Control counter SFB 48 FREQUENC Frequency measurement	OB 86	RACK_FLT	Slave failure / restart
OB 121 PROG_ERR Programming error OB 122 MOD_ERR Periphery access error SFB Name Description SFB 0 CTU Up-counter SFB 1 CTD Down-counter SFB 2 CTUD Up-down counter SFB 3 TP Create pulse SFB 4 TON On-delay SFB 5 TOF Create turn-off delay SFB 7 TIMEMESS Time measurement SFB 12 BSEND Sending data in blocks SFB 13 BRCV Receiving data in blocks: SFB 14 GET Remote CPU read SFB 15 PUT Remote CPU write SFB 32 DRUM Realize a step-by-step switch SFB 47 COUNT Control counter SFB 48 FREQUENC Frequency measurement	OB 100	COMPLETE RESTART	Start-up
SFB Name Description SFB 0 CTU Up-counter SFB 1 CTD Down-counter SFB 2 CTUD Up-down counter SFB 3 TP Create pulse SFB 4 TON On-delay SFB 5 TOF Create turn-off delay SFB 7 TIMEMESS Time measurement SFB 12 BSEND Sending data in blocks SFB 13 BRCV Receiving data in blocks: SFB 14 GET Remote CPU read SFB 15 PUT Remote CPU write SFB 32 DRUM Realize a step-by-step switch SFB 47 COUNT Control counter SFB 48 FREQUENC Frequency measurement	OB 102	COLD RESTART	Start-up
SFB Name Description SFB 0 CTU Up-counter SFB 1 CTD Down-counter SFB 2 CTUD Up-down counter SFB 3 TP Create pulse SFB 4 TON On-delay SFB 5 TOF Create turn-off delay SFB 7 TIMEMESS Time measurement SFB 12 BSEND Sending data in blocks SFB 13 BRCV Receiving data in blocks: SFB 14 GET Remote CPU read SFB 15 PUT Remote CPU write SFB 32 DRUM Realize a step-by-step switch SFB 48 FREQUENC Frequency measurement	OB 121	PROG_ERR	Programming error
SFB 0 SFB 1 CTD Down-counter SFB 2 CTUD Up-down counter SFB 3 TP Create pulse SFB 4 TON On-delay SFB 5 TOF Create turn-off delay SFB 7 TIMEMESS Time measurement SFB 12 BSEND Sending data in blocks SFB 13 BRCV Receiving data in blocks: SFB 14 GET Remote CPU read SFB 15 PUT Remote CPU write SFB 32 DRUM Realize a step-by-step switch SFB 47 COUNT Control counter SFB 48 FREQUENC Frequency measurement	OB 122	MOD_ERR	Periphery access error
SFB 1 CTD Down-counter SFB 2 CTUD Up-down counter SFB 3 TP Create pulse SFB 4 TON On-delay SFB 5 TOF Create turn-off delay SFB 7 TIMEMESS Time measurement SFB 12 BSEND Sending data in blocks SFB 13 BRCV Receiving data in blocks: SFB 14 GET Remote CPU read SFB 15 PUT Remote CPU write SFB 32 DRUM Realize a step-by-step switch SFB 47 COUNT Control counter SFB 48 FREQUENC Frequency measurement	SFB	Name	Description
SFB 2 CTUD Up-down counter SFB 3 TP Create pulse SFB 4 TON On-delay SFB 5 TOF Create turn-off delay SFB 7 TIMEMESS Time measurement SFB 12 BSEND Sending data in blocks SFB 13 BRCV Receiving data in blocks: SFB 14 GET Remote CPU read SFB 15 PUT Remote CPU write SFB 32 DRUM Realize a step-by-step switch SFB 47 COUNT Control counter SFB 48 FREQUENC Frequency measurement	SFB 0	СТИ	Up-counter
SFB 3 TP Create pulse SFB 4 TON On-delay SFB 5 TOF Create turn-off delay SFB 7 TIMEMESS Time measurement SFB 12 BSEND Sending data in blocks SFB 13 BRCV Receiving data in blocks: SFB 14 GET Remote CPU read SFB 15 PUT Remote CPU write SFB 32 DRUM Realize a step-by-step switch SFB 47 COUNT Control counter SFB 48 FREQUENC Frequency measurement	SFB 1	CTD	Down-counter
SFB 4 TON On-delay SFB 5 TOF Create turn-off delay SFB 7 TIMEMESS Time measurement SFB 12 BSEND Sending data in blocks SFB 13 BRCV Receiving data in blocks: SFB 14 GET Remote CPU read SFB 15 PUT Remote CPU write SFB 32 DRUM Realize a step-by-step switch SFB 47 COUNT Control counter SFB 48 FREQUENC Frequency measurement	SFB 2	CTUD	Up-down counter
SFB 5 TOF Create turn-off delay SFB 7 TIMEMESS Time measurement SFB 12 BSEND Sending data in blocks SFB 13 BRCV Receiving data in blocks: SFB 14 GET Remote CPU read SFB 15 PUT Remote CPU write SFB 32 DRUM Realize a step-by-step switch SFB 47 COUNT Control counter SFB 48 FREQUENC Frequency measurement	SFB 3	TP	Create pulse
SFB 7 TIMEMESS Time measurement SFB 12 BSEND Sending data in blocks SFB 13 BRCV Receiving data in blocks: SFB 14 GET Remote CPU read SFB 15 PUT Remote CPU write SFB 32 DRUM Realize a step-by-step switch SFB 47 COUNT Control counter SFB 48 FREQUENC Frequency measurement	SFB 4	TON	On-delay On-delay
SFB 12 BSEND Sending data in blocks BRCV Receiving data in blocks: SFB 14 GET Remote CPU read SFB 15 PUT Remote CPU write SFB 32 DRUM Realize a step-by-step switch SFB 47 COUNT Control counter SFB 48 FREQUENC Frequency measurement	SFB 5	TOF	Create turn-off delay
SFB 13 BRCV Receiving data in blocks: SFB 14 GET Remote CPU read SFB 15 PUT Remote CPU write SFB 32 DRUM Realize a step-by-step switch SFB 47 COUNT Control counter SFB 48 FREQUENC Frequency measurement	SFB 7	TIMEMESS	Time measurement
SFB 14 GET Remote CPU read SFB 15 PUT Remote CPU write SFB 32 DRUM Realize a step-by-step switch SFB 47 COUNT Control counter SFB 48 FREQUENC Frequency measurement	SFB 12	BSEND	Sending data in blocks
SFB 15 PUT Remote CPU write SFB 32 DRUM Realize a step-by-step switch SFB 47 COUNT Control counter SFB 48 FREQUENC Frequency measurement	SFB 13	BRCV	Receiving data in blocks:
SFB 32 DRUM Realize a step-by-step switch SFB 47 COUNT Control counter SFB 48 FREQUENC Frequency measurement	SFB 14	GET	Remote CPU read
SFB 47 COUNT Control counter SFB 48 FREQUENC Frequency measurement	SFB 15	PUT	Remote CPU write
SFB 48 FREQUENC Frequency measurement	SFB 32	DRUM	Realize a step-by-step switch
	SFB 47	COUNT	Control counter
SFB 49 PULSE Pulse width modulation	SFB 48	FREQUENC	Frequency measurement
	SFB 49	PULSE	Pulse width modulation
SFB 52 RDREC Read record set	SFB 52	RDREC	Read record set

System MICRO Integrated blocks

SFB	Name	Description
SFB 53	WRREC	Write record set
SFB 54	RALRM	Receiving an interrupt from a periphery module
SFC	Name	Description
SFC 0	SET_CLK	Set system clock
SFC 1	READ_CLK	Read system clock
SFC 2	SET_RTM	Set run-time meter
SFC 3	CTRL_RTM	Control run-time meter
SFC 4	READ_RTM	Read run-time meter
SFC 5	GADR_LGC	Logical address of a channel
SFC 6	RD_SINFO	Read start information
SFC 7	DP_PRAL	Triggering a hardware interrupt on the DP master
SFC 12	D_ACT_DP	Activating and deactivating of DP slaves
SFC 13	DPNRM_DG	Read diagnostic data of a DP salve
SFC 14	DPRD_DAT	Read consistent data
SFC 15	DPWR_DAT	Write consistent data
SFC 17	ALARM_SQ	ALARM_SQ
SFC 18	ALARM_SQ	ALARM_S
SFC 19	ALARM_SC	Acknowledgement state last alarm
SFC 20	BLKMOV	Block move
SFC 21	FILL	Fill a field
SFC 22	CREAT_DB	Create a data block
SFC 23	DEL_DB	Deleting a data block
SFC 24	TEST_DB	Test data block
SFC 28	SET_TINT	Set time-of-day interrupt
SFC 29	CAN_TINT	Cancel time-of-day interrupt
SFC 30	ACT_TINT	Activate time-of-day interrupt
SFC 31	QRY_TINT	Query time-of-day interrupt
SFC 32	SRT_DINT	Start time-delay interrupt
SFC 33	CAN_DINT	Cancel time-delay interrupt
SFC 34	QRY_DINT	Query time-delay interrupt
SFC 36	MSK_FLT	Mask synchronous errors
SFC 37	MSK_FLT	Unmask synchronous errors
SFC 38	READ_ERR	Read error register
SFC 39	DIS_IRT	Disabling interrupts
SFC 40	EN_IRT	Enabling interrupts
SFC 41	DIS_AIRT	Delaying interrupts
SFC 42	EN_AIRT	Enabling delayed interrupts

Integrated blocks System MICRO

SFC	Name	Description
SFC 43	RE_TRIGR	Re-trigger the watchdog
SFC 44	REPL_VAL	Replace value to ACCU1
SFC 46	STP	STOP the CPU
SFC 47	WAIT	Delay the application program
SFC 49	LGC_GADR	Read the slot address
SFC 51	RDSYSST	Read system status list SSL
SFC 52	WR_USMSG	Write user entry into diagnostic buffer
SFC 53	μS_TICK	Time measurement
SFC 54	RD_DPARM	Reading predefined parameters
SFC 55	WR_PARM	Write dynamic parameter
SFC 56	WR_DPARM	Write default parameter
SFC 57	PARM_MOD	Parametrize module
SFC 58	WR_REC	Write record set
SFC 59	RD_REC	Read record set
SFC 64	TIME_TCK	Read system time tick
SFC 65	X_SEND	Sending data
SFC 66	X_RCV	Receiving data
SFC 67	X_GET	Read data
SFC 68	X_PUT	Write data
SFC 69	X_ABORT	Disconnect
SFC 70	GEO_LOG	Determining the start address of a module
SFC 71	LOG_GEO	Determining the slot belonging to a logical address
SFC 81	UBLKMOV	Copy data area without gaps
SFC 101	HTL_RTM	Handling runtime meters
SFC 102	RD_DPARA	Reading predefined parameters
SFC 105	READ_SI	Reading dynamic system resources
SFC 106	DEL_SI	Releasing dynamic system resources
SFC 107	ALARM_DQ	ALARM_DQ
SFC 108	ALARM_DQ	ALARM_DQ

System MICRO SSL partial list

C SSL partial list

j

More information about this may be found in the manual "SPEED7 Operation List".

SSL-ID	SSL partial list
xy11h	Module identification
xy12h	CPU characteristics
xy13h	User memory areas
xy14h	System areas
xy15h	Block Types
xy19h	Status of all LEDs
xy1Ch	Identification of the component
xy22h	Interrupt status
xy32h	Communication status data
xy37h	Ethernet details of the module
xy3Ah	Status of the TCON Connections
xy3Eh	Web server diagnostic information
xy3Fh	Configuration of Access settings
xy74h	Status of the LEDs
xy91h	Status information CPU
xy92h	Stations status information (DPM)
xy94h	Stations status information (DPM, PROFINET IO and EtherCAT)
xy95h	Status information (DPM-, PROFINET IO system)
xy96h	Module status information (PROFIBUS DP, PROFINET IO, EtherCAT)
xyA0h	Diagnostic buffer of the CPU
xyB3h	Module diagnostic information (record set 1) via logical address
xyB4h	Diagnostic data of a DP slave
xyE0h	Information EtherCAT master/slave
xyE1h	EtherCAT bus system
xyF4h	Information about the files in the flash memory of the CPU
xyFAh	Statistics information to OBs
xyFCh	Status of the VSC features from the System MICRO CPU